

Cuisinart® Nonstick Detachable Handle Cookware



Follow us @cuisinart_au

GETTING STARTED

- **Wash Before First Use:** Do not submerge the handle. Wipe it clean with a damp cloth. Clean your cookware with warm, soapy water, rinse, and dry thoroughly.
- **Attach Handles Securely:** Ensure the detachable handle clicks **firmly** into place before lifting or moving cookware.
- **Heat Guidelines:** Use low to medium heat for most cooking. Avoid prolonged high heat to maintain nonstick performance.
- Handle should **not** be attached to cookware over a burner **for more than 10 minutes**.
- **Never** let flames exceed the exterior of the pan.
- **Don't Leave Unattended:** Overheating or boiling dry can cause damage to the cookware. If a pan boils dry, turn off the heat and let it cool naturally.
- Cookware body is oven safe up to **260°C**; silicone glass lids up to **180°C**.
- **Remove detachable handle before oven use. Handles are not oven safe.**
- Always use potholders – pans get hot.
- **Do not** use under grill.

CLEANING & CARE

- The removeable handle is not dishwasher safe. Wipe it clean with a damp cloth.
- Allow cookware to cool before washing.
- Cookware is dishwasher safe, but **hand-washing is recommended** to preserve finish. Use warm, soapy water and a nonabrasive sponge.
- Storage lids are dishwasher safe – **top rack recommended**.
- Do not use steel wool or harsh pads.
- For stubborn residue: Add 1 inch of water and 1 tablespoon of non-lemon dish soap. Simmer in water + mild detergent for 15 minutes, cool, then clean.

UTENSILS

- Silicone, nylon, or wood tools are recommended and help extend the lifespan of your cookware.
- Do not use sharp utensils like knives or forks on the nonstick surface.

COOKING TIPS

- **Induction:** Center the pan on the burner for best results.
- **Glass tops:** Lift, don't slide, to prevent scratches.
- **Gas burners:** Keep flames under the pan bottom only.

STORAGE

- Detach handles for compact storage.
- Use the included storage pan protectors when nesting to prevent scratches. **This warranty does not include or cover the following:**

WARRANTY

Cuisinart warrants that, in the unlikely event that this product develops any malfunction within 36 months of purchase of the product used for household or domestic use (or within 3 months of purchase of the product used for commercial use) due to faulty workmanship, materials or manufacture, we will either (at our discretion) repair or replace it for you.

This warranty applies for a period of 36 months for products purchased for household or domestic use (and 3 months for products purchased for commercial use) from the date of purchase of the product after which time the warranty expires and has no further force of effect.

Should you experience any operating difficulties refer to the FAQ in this booklet or contact Customer Service for advice on **1800 566 567 in Australia** or **0800 456 546 in New Zealand**.

Please retain the **Purchase Receipt** as proof of purchase in order for your warranty entitlement to be valid. This document must be presented in the event of making a claim under the terms of the Cuisinart Warranty Policy.

During the warranty period Cuisinart will repair or replace (at our discretion) any defective product. However, if the product includes a number of accessories, only the defective part or relevant accessory will be replaced. Cuisinart reserves the right to make minor adjustments to fix any defect instead of replacing the entire product or accessory. Packaging, instructions, recipe books etc. will not be replaced unless faulty. A product presented for repair may be replaced by a refurbished product of the same type rather than being repaired. Refurbished parts may be used to repair the product.

If a spare part is required under warranty it will be shipped to the customer or retailer at No Charge.

In the event of a product or accessory being replaced during the warranty period, the guarantee on the replacement product or accessory will expire 36 months for household or domestic use (or 3 months for commercial use) from the original purchase date.

- defects caused by the product not being used in accordance with instructions;
- defects caused by accidental damage;
- defects caused by misuse or negligent handling of the product;
- defects caused by the product not being maintained or cleaned according to instructions;

- defects caused by being tampered with by unauthorised persons;
- defects which are normal or fair wear and tear;
- freight or any other costs incurred in making a claim;
- consumable items or accessories that by their nature and limited lifespan require periodic renewal (such as filters, seals, blades or related accessories, such as trays, racks or utensils);
- products serviced or modified other than by Cuisinart or an authorised Cuisinart representative;
- to any claims made beyond 12 months if the filament of the light bulb breaks i.e. the light bulb has burned out;
- exposure of the product to abnormally corrosive conditions;
- any product which has its serial number or appliance plate removed or defaced;
- to any claims made beyond 3 months from the date of purchase if the product is used in commercial, industrial, educational or rental applications; or
- To any claims made beyond 36 months from the date of purchase if the product is used in household or domestic applications.
- Products purchased from any person who is not a retailer serviced by Conair's authorised distributors, overseas retailers, parallel importers or purchased second

The benefits given to you by our warranty are in addition to other rights and remedies under the Australian Consumer Law.

In Australia our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Our goods also come with guarantees that cannot be excluded under the New Zealand Guarantees Act.

To make a warranty claim or spare part, contact our customer service agents:

Cuisinart Australia

Ph: 1800 566 567

PO Box 146, Terrey Hills

NSW 2084 AUSTRALIA

Cuisinart New Zealand

Ph: 0800 456 546

YOU MUST provide your full name, address, email and phone details. A copy of your proof of purchase must be supplied.

You can contact Cuisinart Australia/New Zealand via email at aus_cuisinart@conair.com or through the "Contact Us" option on the Cuisinart website www.cuisinart.com.au

The warranty contained in this document is provided by:

Conair Australia Pty Ltd (ACN 068 492 044) (Cuisinart)

18 Rodborough Rd,

Frenchs Forest, NSW 2086

Australia