

Kenmore Sewing Machine

Model
1020
1030
1040
1045
1050

**OWNER'S
 MANUAL**

69565

TABLE OF CONTENTS

1. Knowing Your Sewing Machine

Identifying Parts	1 - 2
Connecting Machine	3
Threading - Bobbin	4 - 5
Top Thread	6

Using the Controls

Top Tension Control	7 - 8
Adjusting Bobbin Tension	9
Stitch Length Control	10
Stitch Width Control	10
Reverse Stitch Control	11
Feed Dog Control	11
Special Stitch Dial	12 - 14
Pressure Regulator	15
Sewing Light	16
Seam Guides	17

Accessories

Needles	18
Needle, Thread, Fabric Chart	19
Presser Feet	20
Buttonhole Guide Feet	21
Zigzag and Straight Stitching Needle Plate	22

2. Starting to Sew

Garment Construction Stitches

Straight Stitching	24
Zigzag Stitching	25
Stretch Stitching	26 - 28

Special Finishing Stitches

Satin Stitching, Appliqueing	29
Buttonhole Making	30 - 32
Button Sewing, Bar Tacking	33
Blind Hemming	34 - 35
Zipper Application	36
Special Edge Stitch, Mending, Darning	37


3. Checking Performance Problems

4. Caring for the Machine

Cleaning Feed Dogs and Shuttle	41
Oiling Under Arm Cover Plate	42
Oiling Underside	43
Oiling Face Cover Plate	44
Parts List	45 - 46


1. Knowing Your Sewing Machine

FRONT VIEW



- | | |
|-----------------------------|--------------------------------|
| 1. Accessory Box | 11. Thread Guide |
| 2. Hinged Extension | 12. Take-up Lever |
| 3. Needle Plate | 13. Top Thread Tension Control |
| 4. Zigzag Stitching Plate | 14. Threading Path |
| 5. Presser Foot | 15. Special Stitch Dial |
| 6. Thread Guide | 16. Stitch Width Control |
| 7. Thread Guide | 17. Reverse Stitch Control |
| 8. Thread Tension Regulator | 18. Stitch Length Control |
| 9. Thread Guide | 19. Nomenclature Plate |
| 10. Face Cover Plate | |


BACK VIEW



- 20. Light and Power Switch
- 21. Connector
- 22. Hand Wheel
- 23. Bobbin Winder Shaft
- 24. Bobbin Winder Latch
- 25. Thread Spool Pin


- 26. Bobbin Winder Tension Disc
- 27. Thread Guide
- 28. Presser Foot Lever
- 29. Thread Cutter
- 30. Needle Clamp Screw
- 31. Feed Dogs

CONNECTING MACHINE




1. Lift hinged extension at the left side of machine bed-plate.
2. For more sewing space, tip the bed plate cover up by pushing right edge as shown in Fig. 2. Turn the accessory box toward you as shown in Fig. 2.
3. Fig. 3. shows the machine ready to sew with all the extensions in place for maximum sewing space.
4. Push the plug onto three-prong connector at the back of machine column.
5. Plug machine cord into any 110-120 volt wall outlet. Turn on power by pushing light and power switch.
6. Pull up spool pin stored at top of machine.

WINDING THE BOBBIN



1. Draw thread from spool through bobbin winder tension disc as shown in Fig. 1.
2. Pull end of thread through hole in bobbin and place bobbin onto bobbin winder shaft with end of thread coming from the top of the bobbin, fitting the notch on the bobbin over locking stud on the shaft as shown in Fig. 2.
3. Push bobbin winder latch against bobbin until it clicks.
4. Release clutch by pulling hand wheel or turning clutch knob as shown in Fig. 4. Start machine, holding onto end of thread. When bobbin is slightly filled, release end of thread.
5. When bobbin is full, winding mechanism stops.
6. Push in hand wheel or turning clutch knob to return to stitching position. Remove bobbin.


THREADING THE BOBBIN CASE




1. To remove bobbin case from the shuttle, raise needle to its highest position.
2. Open bed plate cover, and remove accessory box.
3. Pull open latch of bobbin case.
4. Pull bobbin case straight out of shuttle.
5. Insert bobbin into bobbin case making sure thread is coming from bobbin as shown.
6. Pull thread through slot of case as shown.
7. Pull thread under tension spring.
8. Holding latch open, position case into shuttle, and release latch. Case should lock into place when latch is released.
9. Hold needle thread loosely in left hand and rotate hand wheel toward you one complete turn. Bring bobbin thread up by pulling upper thread.

THREADING OF TOP THREAD


Model 1050



Model 1020, 1030, 1040, 1045



TOP TENSION CONTROL




Probably the most important control on your machine is this one that regulates your top thread tension. It consists of discs between which the thread passes. The pressure on these discs is regulated by turning the dial on the front of the control. The higher the number, the tighter the tension.

There are many reasons for having to reset your tension. The best tension for one fabric may not be correct for another. The required tension depends upon the stiffness of the fabric, thickness of the fabric, numbers of layers of fabric being sewn, as well as the type of stitch you are making.

It is best to test the stitching on a scrap of the fabric you are using before starting to make a garment. To adjust for the correct stitch, see next page.


ADJUSTING TOP TENSIONS

①





A perfect straight stitch will have threads locked between the two layers of fabric with no loops on top or bottom.

② Upper thread too tight





Decrease Tension



③ Upper thread too loose



Increase Tension




ADJUSTING BOBBIN TENSIONS

Bobbin tension requires adjusting less frequently than the upper thread tension.

If the stitch is satisfactory but the seam is puckered, it may be necessary to loosen the tension on both the top and bottom threads. Be sure to balance them as indicated on Page 9.


When adjusting the tension on the bobbin case, make slight adjustments with a screwdriver.

DECREASE TENSION




Turn Counter Clockwise.

INCREASE TENSION



Turn Clockwise.

STITCH LENGTH CONTROL



The stitch length control located on the right side of the machine regulates the length of the stitch you select.

THE HIGHER THE NUMBER - THE SHORTER THE STITCH.


The stitch setting you use will be determined by the thickness of the fabric you are sewing. A longer stitch setting should be used for thicker fabric or more layers of fabric.

The middle range of the control is the 10-12 stitch per inch range which is the most commonly used.

A basting stitch is made by using the longest possible stitch setting - 6 stitches per inch.

The marking  on this control is the setting used for the shortest stitches such as in Satin Stitching.


STITCH WIDTH CONTROL



This control regulates the width of the stitch you select. **THE HIGHER THE NUMBER - THE WIDER THE STITCH.** You may vary your zigzag stitch width by adjusting this control to the setting you desire.

This control must be on Red Dot in order to do straight stitching.


REVERSE STITCH CONTROL



It is best to begin and end seams with a few stitches taken in reverse. This is called back tacking. Back tacking fastens the ends of the seams firmly and prevents raveling.

When reverse stitching is needed, turn the control clockwise and hold there during sewing. The fabric will immediately start feeding backwards and seam will be fastened.

FEED DOG CONTROL




The feed dog control is located on the machine behind accessory box. There are a few times when you want to control the feeding of the fabric yourself. When the control is pushed down, the feed dogs drop and do not move the fabric.

For most of your sewing, turn the control to the up position. (Feed dog up).

SPECIAL STITCH DIAL

There are certain types of utility stitches you will use often in your home sewing. This control enables you to just dial the stitch you need for the task at hand.


THE RED DOT SETTING



The Red Dot setting illustrated is the one used for most of your stitching - either straight or simple zigzag. When the stitch width is set on the Red Dot and the Special Stitch Dial on the Red Dot setting, you may straight stitch.


For a simple zigzag stitch, adjust the stitch width control to the desired setting, with the dial remaining on the Red Dot setting.

SPECIAL MENDING STITCH




You will find that much of your sewing is in the mending category. For this reason you have been provided with a stitch for the repair of tears. Use of the stitch setting shown is given in more detail in the next section under Mending.

BLIND STITCH SETTING




Blind hems are made by using the stitch setting shown in the illustration above. For more detailed instructions in blind hemming, see next section of the book.

SPECIAL EDGE STITCH




The setting illustrated is used for special edge finishing, combining fabrics and so on. Details on the use of this stitch are given in the next section.

ELASTIC STRETCH STITCH




The setting illustrated is used for special stretch stitch for sewing elastic such as sportswear, girdles and other garments that require stretch. See next section of this book for detailed use of the stitch.

OVERCAST STRETCH STITCH




Overcast stretch stitching is made by using the stitch setting shown in the illustration above. Detailed instructions are given in the next section of the book.

SMOCKING STRETCH STITCH




You can make smocking stretch stitching by setting the dial to the setting indicated above. See next section of this book for detailed use of the stitches.

STRETCH STITCH SETTING



Stretch stitching is easily done by setting the dial to the setting indicated above. Details on the use of this stitch are given in the next section of the book.

BUTTONHOLE SETTING




The three settings shown above are used in making a bar tacked buttonhole. Detailed instructions are given in the next section of the book.

OTHER ADJUSTMENTS OF SEWING MACHINE

In addition to the obvious controls of your machine, there are other small regulators and controls to aid you in using your sewing machine.

PRESSURE REGULATOR



Push down the outer ring of the pressure regulator. This will release the pressure on the presser foot. (See Fig. 1 above).

To increase the pressure, push down inner pin until a suitable pressure is obtained.

The pressure on the presser foot is regulated by turning the dial of this regulator which is situated in face cover plate (See Fig. 2 above). To increase the pressure, turn the dial clockwise, until a suitable pressure is obtained.

Insufficient pressure may cause poor feeding of the fabric, skipped stitches, or difficulty in guiding the fabric. If feed dogs or presser foot marks appear on the fabric, reduce the pressure.

When sewing multiple thickness or heavy fabric, reduce the pressure. Increase pressure when sewing lighter weight fabrics.

SEWING LIGHT

The light and power switch shown in Fig. 1 provides the electric current for the motor as well as for the light. In order to operate the machine, this switch must be on. To turn on the light, depress the upper side of the switch. If you are interrupted while sewing and must leave the machine unattended, just turn off the switch and the machine cannot be started accidentally.




Fig. 1

The sewing light is located inside the face cover plate as shown. To replace the bulb, turn light off, and swing the face cover plate open. Push up on the bulb slightly and turn bulb clockwise. Remove bulb from socket. Push in new bulb and turn counter-clockwise.





Fig. 2



SEAM GUIDES

Seam guides are printed on either side of the needle plate to aid you in guiding your fabric. THE GUIDE LINE EXTENDING ABOVE THE RIGHT SIDE OF THE NEEDLE PLATE IS THE "ALL IMPORTANT" 5/8" SEAM LINE.

The cornering guides are convenient when turning a square corner 5/8" from the fabric edge. See next section of this book for directions.

PRESSER FOOT LEVER

To aid you in the placement of heavy fabrics under the presser foot, the lever can raise the foot beyond the normal "up" position. This is also an aid in changing your presser feet.


NEEDLES

Use KENMORE needles. The size of the needle should conform with the size of the thread and both should be suitable to the fabric (See next page).

Never use a bent needle or one with a blunt point.


Fig. 1. shows you the exact length of your needle. Be sure you never use one in your machine that is not this exact length.

You will find among your accessories a "Q NEEDLE"™ with blue shank. This special needle is to be used when sewing certain knits and certain difficult synthetic fabrics. If you experience skipped stitches in any of your sewing, use "Q NEEDLE"™.



PLACEMENT OF NEEDLE

Raise needle bar to its highest position by turning the hand wheel toward you. Loosen the needle clamp screw. Holding the needle with the flat side away from you, slip the needle into the needle bar. When it is in as far as it will go, tighten the needle clamp screw with a screwdriver.




NEEDLE, THREAD, FABRIC CHART

THREAD SIZE	NEEDLE SIZE	FABRIC
Polyester Core/Cotton Wrap Fine Mercerized Cotton Polyester Synthetic Silk A	9 or 11	Lightweight: Batiste, Dimity, Chiffon, Silks, Synthetic Jerseys, Fine Lace, Organza, Crepe, Taffetta, Voile, Organdy
50 Mercerized Cotton Polyester Synthetic Silk A	14	Medium Weight: Cotton, Cotton Blends, Percale, Gingham, Shantung, Pique, Seersucker, Satin, Knits, Vinyl, Suitings, Linen, Wool Crepe, Leather
50 Mercerized Cotton Mercerized Heavy Duty Polyester Synthetic Silk A	14 or 16	Medium Heavy Weight: Corduroy, Denim, Wool, Sailcloth, Wool Flannel, Gabardine, Velvets, Leather
Heavy Duty Mercerized Cotton Polyester Synthetic Silk A	18	Heavy Weight: Coatings, Upholstery, Cotton Duck, Heavy Twills, Canvas
Silk Buttonhole Twist	16, 18 or "Q NEEDLE" _{TM}	Decorative Top-stitching on all
Polyester Synthetic 50 Mercerized Cotton	"Q SET" _{TM} ("Q NEEDLE" _{TM} and "Q FOOT" _{TM})	Synthetic Knits and Stretch Fabrics: Polyester Double Knits, Nylon Tricot, Jersey, Stretch Terry, Spandex, Cire Tricot

PRESSER FEET


You have been given a variety of presser feet:

- A. Zigzag Foot
- B. Straight Stitch Foot
- C. Satin Stitch Foot
- D. Zipper Foot
- E. Blindstitch Guide with shank




To change snap-on feet raise the presser bar to its highest position by lifting the presser foot lever. Press the front of presser foot upward as high as it will go and foot is released (See Fig. 1).

Place the desired foot on the needle plate aligning the needle holes and lower the presser foot lever. Press down on presser foot thumb screw until the clamping shank (C) snaps on the foot (See Fig. 2).




To change the one-piece presser feet, raise the presser bar to its highest position by lifting the presser foot lever. Loosen the presser foot thumb screw, choose the proper foot, insert from the front.

Tighten the screw using the large screw driver to make certain the foot is secure.



BUTTONHOLE GUIDE FEET



You have been provided with an assortment of guide feet to aid you in making buttonholes. By using these guides, you will accurately make identical bar tacked buttonholes every time.

The feet as illustrated above just slip onto the regular zigzag foot. They are $\frac{3}{8}$ ", $\frac{1}{2}$ ", $\frac{5}{8}$ ", $\frac{13}{16}$ " and $1\text{-}\frac{1}{16}$ " and are marked accordingly.

You will find detailed instructions as to the making of buttonholes in the next section of this book. Follow carefully and always make a practice buttonhole first.

NEEDLE PLATE INSERTS

You are provided with two needle plate inserts. The one with the wide oval hole is to be used for all zigzag stitching. The one with the round hole is for regular straight stitching or straight stretch stitch sewing.




Fig. 1

CHANGING NEEDLE PLATE INSERTS

1. Raise needle to its highest position and raise presser foot.
2. Open bed cover plate.
3. Remove accessory box from the machine, and push a spring under the plate as shown to release the needle plate insert.
4. Remove needle plate insert by placing thumb under edge of plate.
5. Replace the needle plate insert positioning as shown in Fig 2.
6. Push needle plate insert down to lock into place. Reposition the accessory box and bed cover plate.




Fig. 2




Fig. 3

2. Starting to Sew

Now that you are familiar with the controls on your machine and with the accessories provided for the machine, you are ready to start to sew with your new Kenmore sewing machine. Below are some good habits to follow each time you sit down to sew:

1. Test the needle - it should be straight, properly set and sharp on the point. It should be the correct size for the fabric and thread being used. Do not be afraid to change your needle frequently. Many of the new fabrics made of synthetic blends tend to dull the needles more easily than fabrics made of natural fibers.
2. Before placing the material on the machine, see that the ends of the threads have been drawn about 4 inches to the rear of the machine. Hold on to threads during the sewing of the first 3 or 4 stitches of the seam.
3. Test the machine stitch on a scrap of fabric you plan to use. The fabric should be double thickness. Adjust the machine for the length of stitch and tension suitable to your fabric.
4. Fabric should be placed under the presser foot with the bulk of the material to the left of the needle and the right edge of the material placed on the 5/8" seam marking on the needle plate when making a simple seam.
5. Run the machine at a slow even speed. The more pressure you put on the speed control, the faster the machine will sew.
6. Fasten each seam by back tacking at the beginning and end of the seam.
7. Always finish sewing each seam with the needle at its highest point.
8. Guide the fabric gently with your hand in front of the needle. Never pull or hold the fabric in such a way that the normal feeding is altered.
9. When turning the hand wheel manually, always turn it toward you.


GARMENT CONSTRUCTION STITCHES

STRAIGHT STITCHING

Set your machine just as shown in the illustration in order to straight stitch. It is important each dial have the following settings.

SETTINGS

Special Stitch Dial - Red Dot
Stitch Width Control - Red Dot
Stitch Length Control - Any Number
Straight Stitch Foot



You will find in garment construction that you are doing two types of sewing - temporary and permanent.


1. Temporary stitching - Usually the longest stitch possible and often done on a single layer of fabric. The various types of temporary stitching are:
 - Basting
 - Stay stitching
 - Guide line marking
2. Permanent stitching - This is the actual stitching that holds the garment together. Much of this stitching is visible on the outside of the garment and therefore must be good looking.

The best length stitch to use for medium weight fabrics is 10 - 12 stitches per inch. This is in the middle range of the Stitch Length Control.

You must remember to lengthen the stitch for heavier fabrics, multiple layers of fabric and thicker seams. Some of these seams are:


- Common two layer seams
- Curved two layer seams
- Top stitched three layer seams
- Top stitched four layer seams

When you have two seams crossing each other with considerable thickness, sew slowly and carefully so the seam will be as strong as possible in this area.




FASTENING A SEAM

Be sure both threads are drawn back under the presser foot. Lower needle into fabric about 1/2 inch from beginning of seam. Turn the reverse stitch control clockwise and stitch in reverse until needle reaches beginning of seam. Release control and complete seam. When you reach the end, turn the control clockwise and sew back over 1/2 inch of completed seam.



TURNING A SQUARE CORNER

To turn a square corner 5/8" from the fabric edge, stop stitching with the needle tip piercing the fabric, when reaching the cornering guide as shown. Raise the presser foot, turn fabric. New stitching line will align with 5/8" seam guide on side of needle plate. Lower the presser foot and begin stitching in new direction.



ZIGZAG STITCHING

SETTINGS


Special Stitch Dial - Red Dot
 Stitch Width Control - 1 to 4
 Stitch Length Control - Any Number
 Zigzag Presser Foot
 Use zigzag needle plate.

This type of stitching greatly expands the use of your machine. This is the feature that enables you to overcast seams, blind hem, applique, button-hole, monogram, and make all the pretty embroidery designs by machine. Simply use the settings indicated in the illustration for the simple zigzag. Follow directions given in the following pages for more specific uses.

STRETCH STITCHING

The stitches shown below are all for use with stretch and knit fabrics. These are special stitches built in to the machine for your quick selection.

1. Straight Stretch
2. Rick - Rack Stretch
3. Smocking Stretch
4. Elastic Stretch
5. Overcast Stretch





STRAIGHT STRETCH STITCHING


SETTINGS

Special Stitch Dial - III
Stitch Width Control - Red Dot
Stitch Length Control - 8
Straight Stitch Foot
Use straight stitching plate.

Use this stretch stitch with knitted fabric and other fabrics that stretch. Sew as you do with regular straight stitch seaming. The seam may be pressed open as with any regular seam, but will stretch if necessary.

This is also a good stitch to use on curved seams regardless of the type of fabric. Any seam that will receive a great deal of strain when worn should be sewn with the stretch stitch. Use in children's shorts and slacks as well as adult sports clothes.






RICK-RACK STRETCH STITCHING

SETTINGS

Special Stitch Dial - III
 Stitch Width Control - 1 to 4
 Stitch Length Control - 8
 Zigzag Presser Foot

Sew on stretch fabrics in any area that you might use a zig zag stitch. This stitch can be used as a decorative top stitch as well.




SMOCKING STRETCH STITCHING

SETTINGS

Step 1. Make a straight line of gathers across the fabric that you wish to smock.
 Step 2. Special Stitch Dial - X
 Stitch Width Control - 3 to 4
 Stitch Length Control - 8
 Zigzag Presser Foot

With a narrow strip of fabric directly under the line of gathering, stitch over the gathers. The design will be a series of small diamonds.



When smocking a garment, the stitching should be done before the piece is sewn into the garment.

OVERCAST STRETCH STITCHING

SETTINGS



Special Stitch Dial - 
Stitch Width Control - 3 to 4
Stitch Length Control - 8
Zigzag Presser Foot

This is the same type of stitch used by the garment industry in making sportswear. It is used for seams of $\frac{3}{8}$ " to $\frac{1}{4}$ ". The seam is formed and finished in one operation. It must be used when you are making swimwear, ski pants and other garments that require stretch.

Fig. 1 shows the raw edge finished.

Stitch so the needle pierces the fabric just short of the outside edge.

Raw or worn edges of older garments can be overcast to prevent further raveling.




ELASTIC STRETCH STITCHING

SETTINGS


Special Stitch Dial - 
Stitch Width Control - 4
Stitch Length Control - 8
Zigzag Presser Foot

This is a good stitch to use in making or repairing lingerie. The stitch is decorative as well as useful. Simply stitch the elastic into place around the waist of the garment, making sure that the elastic is evenly spaced. To do this mark the correct length piece into quarters and match these markings with center front and back of the garment as well as side seams.



SPECIAL FINISHING STITCHES

After the basic construction of your garment is finished, there are still many finishing touches to be done. To aid your completion of your garment, the Kenmore has been designed to do the following tasks that formerly had to be done by hand.



SATIN STITCHING

SETTINGS


Special Stitch Dial - Red Dot
Stitch Width Control - Any Number 1 to 4
Stitch Length Control - Red Zone
Satin Stitch Foot
Use zigzag stitching plate.

Closely spaced zigzag stitches are called satin stitches. This is an attractive stitch used for appliqueing, monogramming, buttonhole making.

Whenever you are using this stitch, it is well to remember to loosen the tension of the top thread slightly. The wider the stitch you make, the looser the tension should be.

If you are stitching on a very soft fabric, it is well to use a backing of tissue paper or interfacing for a well formed stitch. Puckering of the material will be eliminated and the bobbin thread will not be visible on the right side of the fabric.

As with all special stitches, it is best to make a sample design on your fabric before starting the design on the garment.



APPLIQUEING

SETTINGS

Same as with Satin Stitching

Select an applique design to be applied to your garment and baste it in place. Satin stitch around the raw edge of the applique completely covering the edge. You may want to do this with a contrasting color of thread or self color.



BUTTONHOLE MAKING



SETTINGS

Stitch Width Control - 4
Stitch Length Control - Red Zone
Zigzag Presser Foot
Use zigzag stitching plate.



1. Carefully mark the position and length of each buttonhole on your garment. Select the proper size buttonhole guide foot to correspond with the length of buttonhole.
2. Mount the guide foot onto the presser foot. Holding on to the top thread, rotate the handwheel toward you one complete turn. Pull the upper thread under and to the back of the buttonhole guide foot. See Figs. 1 & 2.
3. Note in Fig. 3 that each guide foot has a dot on the right edge toward the back of the foot, and on the left edge near the front of the foot. These dots are used as a point of reference for your bartacking steps in buttonholing. (See next page).
4. Slide the guide foot forward until the rear edge of the presser foot is at the rear edge of the guide.
5. Place the fabric with the marked buttonhole under the guide foot. Lower the presser foot lever and follow steps on next page.

(Check Hints for Perfect Buttonholes on Page 32.)





1. Set special stitch dial at  and bartack several times at the marked beginning of the buttonhole. Stop sewing at the left stitch. Raise needle to its highest position by turning handwheel toward you manually.
2. Set special stitch dial at . Stitch forward until the hinged portion of the presser foot aligns with the dot on the left side of the buttonhole guide foot. The toe of the presser foot will be touching the end of the guide foot. Stop sewing at the left stitch and raise needle to its highest position as in Step 1.



3. Set special stitch dial at  again and bartack several times. Raise needle at its highest position as in steps 1 & 2.
4. Set special stitch dial at  and continue sewing until the hinged portion of the presser foot aligns with the dot on the right side of the guide foot. You will have reached the bartacking done in Step 1.

HINTS FOR PERFECT BUTTONHOLES

The presser foot and buttonhole guide foot should be in this position at the start of the buttonhole sewing. The needle must be lowered at the marked line for the beginning of the buttonhole. See Fig. 1.

When the full length of the buttonhole is reached, the presser foot and guide foot will be in position shown in Fig. 2.



The presser foot and guide foot will be in position shown in Fig. 1 when buttonhole is completed.


To make firm well stitched buttonholes in heavier fabrics, repeat only steps 1 and 3 on the preceding page.

If the forward stitching does not exactly match the reverse stitching as shown in Fig. 3, slightly adjust the stitch length control during forward sewing.

Always make a practice buttonhole on a scrap of fabric you plan to use. Try the buttonhole with the button you will use.

Use an interfacing between the layers of fabric - tissue paper can be used and torn away after the stitching.






BUTTON SEWING

SETTINGS

Special Stitch Dial - Red Dot
 Feed Dogs - Down
 Zigzag Presser Foot
 Use zigzag stitching plate.

1. Align two holes of button with slot of presser foot and lower foot to hold the button securely.
2. Turn hand wheel manually until needle point is just above button.
3. Adjust stitch width control so needle will enter left hole of the button.
4. Turn hand wheel again by hand so needle enters second hole. Re-adjust stitch width if necessary. Stitch a number of times.
5. Finish sewing with an extra two inches of thread remaining. Draw these threads to reverse side of garment and tie.



BAR TACKING

SETTINGS

Special Stitch Dial - Red Dot
 Stitch Width Control - 2 to 4
 Stitch Length Control - Red Zone
 Zigzag Presser Foot
 Use zigzag stitching plate.

This stitch is similar to a very short satin stitch and is used to reinforce points of strain such as corners of pockets and straps on lingerie.

Sew 4 to 6 zigzag stitches.


BLIND HEMMING

SETTINGS

Special Stitch Dial - 4
Stitch Width Control - 2 to 3
Stitch Length Control - 12 to 10
Zigzag foot or blindstitch guide
Use zigzag stitching plate.

After you have turned up the hem width desired, turn raw edge over 1/2" and stitch this fold with a basting stitch Press.

Fig. 1 Raw edge fold



Fold hem back against right side of garment with basted raw edge extending about 1/8" to right of garment fold.

Fig. 2 Hem folded back





Fig. 3 Fabric placed in blindstitch guide.



Place the fold of the hem in the two left slots of the attachment for ease in guiding the fabric. Make certain that the zigzag stitch catches the fold of the hem by adjusting the blindstitch guide slightly from left to right.

Fig. 4 Stitching along fold with blind stitch.





Fig. 5 Finished hem on right side of garment.

Remove basting and press hem. Right side of garment will show only the blind stitches as in Fig. 5.



ZIPPER APPLICATION

SETTINGS

Special Stitch Dial - Red Dot
Stitch Width Control - Red Dot
Stitch Length Control - 12 to 10
Zipper Foot
Use straight stitching plate.

REGULAR ZIPPER

The foot is adjustable for use on the right or left side of the needle when sewing the regular type of zipper. Adjust the foot so the needle clears the side notch on the foot. See Fig. 1. Carefully follow directions given on the zipper package.




Fig. 1

INVISIBLE ZIPPER

Adjust the foot so the needle is sewing through the center hole of the foot and one groove of the foot is riding on the teeth of the zipper. See Fig. 2. Follow the zipper manufacturer's instructions.

After zipper has been inserted, finish sewing seam by shifting foot to side position sewing through side notch.




Fig. 2

CORDING

Foot can also be used to make cording for slipcovers etc. Cover a cord with a strip of bias fabric and sew as shown in Fig. 3.





Fig. 3




SPECIAL EDGE STITCH

SETTINGS

Special Stitch Dial - 
 Stitch Width Control - 1 to 4
 Stitch Length Control - Red Zone
 Zigzag Presser Foot
 Use zigzag stitching plate.

This is an attractive overcasting stitch you may want to use on fabrics that fray easily.




MENDING

SETTINGS

Special Stitch Dial - 
 Stitch Width Control - 4
 Stitch Length Control - Red Zone
 Zigzag Presser Foot
 Use straight stitching plate.

To repair a straight or three-cornered tear, position the tear under the needle in such a way that the stitching catches both sides of the tear. When mending a three-cornered tear, stitch from each end to the center. It is well to use a piece of fabric under the tear for reinforcement.



DARNING

SETTINGS

Special Stitch Dial - Red Dot
 Stitch Width Control - Red Dot
 Pressure Regulator - 0
 Feed Dogs - Up
 No Presser Foot

Remove presser foot, stretch fabric between embroidery hoops with hole centered. Draw the bobbin thread up through the fabric by holding the top thread and taking one stitch at the spot where you wish to start darning. Lowering the presser bar, start sewing at a slow to medium speed. Move the fabric back and forth with a steady rhythm to cover the darning area. When it is covered, turn the fabric and sew another layer of stitching across the first layer of stitching.

3. Checking Performance Problems WHAT TO DO

PROBLEM	PROBABLE CAUSE	CORRECTION
Irregular Stitches	Incorrect size needle. Improper threading. Loose upper thread tension. Pulling fabric. Light pressure on presser foot. Loose presser foot. Unevenly wound bobbin. Nicks or burrs on shuttle. Nicks or burrs at hole of needle plate.	Choose correct size needle for thread and fabric. Rethread machine. Tighten upper thread tension. Do not pull fabric; guide it gently. Increase pressure on presser foot. Reset presser foot. Rewind bobbin. Replace shuttle, or polish off burrs completely. Replace needle plate, or polish off burrs completely.
Breaking Needle	Pulling fabric. Incorrect size needle. Incorrect setting of needle. Loose presser foot.	Do not pull fabric; guide it gently. Choose correct size needle for thread and fabric. Reset needle. Reset presser foot.
Bunching of Thread	Upper and lower threads not drawn back under presser foot before starting seam.	When starting a seam be sure to draw both threads under and back of presser foot about 4" and hold until a few stitches are formed.
Puckering	Incorrect thread tension(s). Light pressure on presser foot. Using two different sizes or kinds of thread. Bent or blunt needle. Loose presser foot. Fabric too sheer or too soft.	Reset thread tension(s). Increase pressure on presser foot. Upper thread and bobbin thread should be same size and kind. Insert new needle. Reset presser foot. Use underlay of tissue paper.

PROBLEM	PROBABLE CAUSE	CORRECTION
Skipping Stitches	Incorrect size needle. Certain knits and synthetics. Bent or blunt needle. Incorrect setting of needle. Tight upper thread tension. Light pressure on presser foot.	Choose correct size needle for thread and fabric. Use "Q NEEDLE" TM . Insert new needle. Reset needle. Loosen upper thread tension. Increase pressure on presser foot.
Breaking Upper Thread	Starting to stitch too fast. Improper threading. Tight upper thread tension. Incorrect size needle. Sharp eye in needle. Nicks or burrs on shuttle. Nicks or burrs at hole of needle plate.	Start to stitch at a medium speed. Rethread machine. Loosen upper thread tension. Choose correct size needle for thread and fabric. Insert new needle. Replace shuttle, or polish off burrs completely. Replace needle plate, or polish off burrs completely.
Breaking Bobbin Thread	Improper bobbin case threading. Tight bobbin thread tension. Lint in bobbin case or shuttle.	Check bobbin case threading. Loosen bobbin thread tension. Clean bobbin case and shuttle.
Fabric not Moving	Feed dog down. Light pressure on presser foot. Thread knotted under fabric.	Raise feed dog. Increase pressure on presser foot. Place both threads back under presser foot before beginning to stitch.
Machine Jamming Knocking Noise	Thread caught in shuttle.	Disassemble and clean shuttle.

4. Caring for the Machine




Fig. 1

CLEANING AND OILING

Fig. 1 Cleaning the feed dogs with a brush.

To insure the best possible operation of your machine, it is necessary to keep the essential parts clean at all times. Using a small brush, remove the lint that accumulates in the shuttle area and around the feed dogs.

Fig. 2 Parts of the Shuttle Assembly

To Clean the Shuttle Area:

1. This area must be kept free of dust, lint and occasional tangled thread. Raise the needle bar to its highest point and remove the bobbin case.
2. Push levers of shuttle race aside and lift shuttle race cover and shuttle out.
3. Clean the shuttle race with small brush.
4. Put a drop of oil on the center pin of the shuttle and shuttle race. (see arrows)

To Replace Shuttle Assembly:

1. Position shuttle race as illustrated so that shuttle driver is forming half moon on the left side of the machine.
2. Hold shuttle by center pin and position shuttle so as to form a half moon on the right side. Pointed hook will be on the bottom.
3. Place shuttle race cover into place over shuttle assembly.





Fig. 2



OILING UNDER ARM COVER PLATE

Remove arm cover plate to oil points indicated in top of machine head.
To remove cover plate lift cover.




OILING UNDERSIDE

Tilt machine head back and remove bottom cover to oil points indicated on underside of machine. To remove bottom cover, remove screws (A), (B), (C), (D) and (E) as shown below.



OILING IN FACE COVER PLATE

Swing hinged face cover plate open and remove arm cover plate to oil points indicated in illustration.



SEWING MACHINE

Now that you have purchased your Sewing Machine, should a need ever exist for repair parts or service, simply contact any Sears Service Center and most Sears, Roebuck and Co. or Simpsons-Sears Limited Stores. Be sure to provide all pertinent facts when you call or visit.

The model number of your Sewing Machine will be shown on your nomenclature plate on the right side of your Sewing Machine. See Section 1, page 3 for location.

WHEN ORDERING REPAIR PARTS, ALWAYS GIVE THE FOLLOWING INFORMATION:

***MODEL NUMBER *NAME OF ITEM *PART DESCRIPTION**

If the parts you need are not stocked locally, your order will be electronically transmitted to a Sears Repair Parts Distribution Center for handling.

SEARS, ROEBUCK AND CO., Chicago, IL 60684 U.S.A.