

SINAP

SINAPACK 200 PLC SINAPACK 200 User Manual



This manual applies to the following models, and the corresponding networks supported by the models are listed in the table below:

Model	Network
SINAPACK 200	WIFI and WAN cable networks, use WAN by default

Table of Contents

1. Product Introduction	4
1.1 Brief Introduction	4
1.2 Product Outlook.....	6
1.3 Standard Accessories	7
1.4 Dimension.....	8
1.5 Working Mechanism	9
1.6 Specifications	10
1.6.1 Technical Parameters.....	10
1.6.2 Indicator Light Description.....	10
1.6.3 Serial Port Definition	11
1.6.4 RESET Button.....	12
1.7 Typical Usecases	12
2. Device Configurations	14
2.1 Configurations.....	14
2.1.1 Preparation.....	14
2.1.2 Configuring SINAPACK 200.....	14
2.2 Configuration Parameters	24
2.3 Restore to Default	25
2.4 Firmware Update	26
2.5 Remote Configurations.....	28
Appendix 1: Use SINAPACK 200 Virhub Functionality to Implement PLC Program Remote Update	31
Appendix 2: Use SINAPACK 200 Serial Functionality to Implement PLC Program Remote Update	41
Appendix 3: Configure SINAPACK 200 to Access Internet via Cable/WIFI.....	47
Appendix 4: Use VNC and SINAPACK 200 to Access and Control Devices Remotely	58
Appendix 5: Use SINAPACK 200 IP Virtual Mapping together with Virhub to Distinguish Devices with Same IP.....	67
Appendix 6: SINAPACK 200's MODBUS TCP Interface Description.....	72
Appendix 7: SINAPACK 200's Enhanced DMZ Function	74

1. Product Introduction

This chapter mainly introduces the outlook, accessories, dimension, specifications and mechanism of SINAPACK 200.

1. Brief Introduction
2. Product Outlook
3. Accessories
4. Dimension
5. Working Mechanism
6. Specifications
7. Typical Usecases

1.1 Brief Introduction

SINAPACK 200 is an industrially designed product, and is especially used with PLCs. SINAPACK 200 provides program download and data acquisition functionalities for PLCs that have RJ-45 Ethernet interface, or RS232/RS485 serial interfaces. It supports PLCs from Siemens, Mitsubishi, Omron, Panasonic, Delta, Fatek, etc. SINAPACK 200 connects with WIFI/WAN network, and with PLC programming tools or SCADA software to implement remote program download and data acquisition.

SINAPACK 200 is an enhanced version of PLC-505. Compared with PLC-505, its panel is more compact, and has stand-up shape in response to customers' request that can massively save installation space.

SINAPACK 200 has two RJ-45 Ethernet interfaces, one of which (LAN1) can be used as WAN as well, one RS232 and one RS485 serial interfaces. Ethernet interfaces and serial interfaces can be used at the same time.

SINAPACK 200 has WIFI functionality, and supports 802.11b/g/n protocol. In theory the highest speed can be 150Mbps. Mobile phones, PCs or other devices that have WIFI functionality can bind SINAPACK 200's WIFI access point and share Internet access via SINAPACK 200.

This greatly extends the number of devices that can connect with SINAPACK 200 at the same time.

SINAPACK 200 can use WAN or WIFI network: in case cable network is available, WAN (LAN1) port can be used to access cable network; and in case WIFI is available, SINAPACK 200 can be configured to access internet via WIFI. WAN and WIFI are all supported by SINAPACK 200, this greatly facilitates customer's project deployment that customers do not have to choose different devices from different suppliers because of different network access at the spot. This can not only save procurement cost, but also reduce maintenance effort for the projects.

SINAPACK 200 is easy to use, and is plug-n-play without any configuration. Together with eTung's eYun platform and Virhub/Vircom software, it can be easy to integrate with PLC programming software, and there is no extra integration effort. SINAPACK 200 is stable and easy-to-use, thus greatly facilitates project deployment.

1.2 Product Outlook



Figure 1-1: SINAPACK 200 whole view




Figure 1-2: SINAPACK 200 panel view

1.3 Standard Accessories



Figure 1-3: WIFI dual-frequency antenna




Figure 1-4: Cross cable

NOTE: The accessories may be different because of different models and customer requirements, the figures above are just for reference.

1.4 Dimension




Figure 1-5: SINAPACK 200 dimension

1.5 Working Mechanism




Figure 1-6: SINAPACK 200 working mechanism

SINAPACK 200 has RJ45 Ethernet interface and RS232/RS485 serial interface, so it can connect with PLCs that have Ethernet interface or serial interface, and Ethernet and serial interfaces can be used at the same time.

1. Usage of Ethernet interface

SINAPACK 200 connects with PLC via Ethernet cross cable, and after power on, it connects into Internet via Cable/WIFI network, then establishes connection with mServer. At the same time Virhub software is run at the host computer and connects to mServer as well. Then with Virhub functionality PLC and the host computer are in the same virtual LAN, and user software at the host computer can then access PLC, to download or update program.

2. Usage of serial interface

SINAPACK 200 connects PLC with RS232 (or RS485) serial port. After power on it connects into Internet via Cable/WIFI network, then establishes connection with mServer. At the same time Vircom is run at the host computer and connects to mServer as well, then user software at the host computer can use the virtual serial port from Vircom to implement bi-directional communication with PLC, thus perform remote control and program update.

1.6 Specifications

1.6.1 Technical Parameters

◆ Basic Parameters

- ✧ Power Supply: +12 ~ +48V wide range of voltage input
- ✧ Power Connector: terminal
- ✧ Max Current: 350mA@+12V DC
- ✧ Standby Current: 250mA@+12V DC
- ✧ Network & Frequency:
WIFI IEEE 802.11n/g/b: 2.4G
WAN
- ✧ Data Interface: RS232/RS485, two RJ45 Ethernet interfaces
- ✧ Working current: 250 mA@+12V DC
- ✧ Standby current: 200 mA@+12V DC
- ✧ Temperature: -30°C ~ +80°C
- ✧ Humidity: 95%@+40°C
- ✧ Dimension: 105*50*135mm (excluding antenna and handle)
- ✧ Weight: 600g

◆ Basic Functions

- ✧ Support NAT
- ✧ Support DHCP server
- ✧ Support DNS Proxy
- ✧ Support port forwarding
- ✧ Support DMZ host(IP address mapping)
- ✧ Support configuring static route table
- ✧ Support real-time speed display of wireless network
- ✧ Support configuring with serial port, telnet and web interface
- ✧ Support serial port DTU function, Ethernet and serial interfaces can be used at the same time
- ✧ Support agent client

1.6.2 Indicator Light Description

LED Indicato	Color	Status	Description
--------------	-------	--------	-------------

Light	Color	Status	Description
Signal lights	Orange	Always light	There are three signal lights. All lights one means the signal is strongest.
PWR	Red	Always light	Device is working
		Extinguished	Device is not working
WIFI	Green	Always light	WIFI is enabled
		Extinguished	WIFI is not enabled
NET	Green	Always light	Connected to Internet
		Extinguished	No connection to Internet
SVR1	Green	Always light	DTU has connected to data center
		Extinguished	DTU does not connect to data center
SVR2	Green	Always light	Connection to mServer is established.
		Extinguished	Connection to mServer is not established.
232	Green	Flashing	Receive data from RS232 interface
		Extinguished	No data received from RS232 interface
485	Green	Flashing	Receive data from RS485 interface
		Extinguished	No data received from RS485 interface
ERR	Red	Extinguished	Reserved

Table 1-1 SINAPACK 200 indicator light description

1.6.3 Serial Port Definition

Type	RS-232		
Pin	2	3	5
Definition	RXD	TXD	GND

Table 1-2: SINAPACK 200 RS232 serial port (Standard RS-232 DB9 male port) pin definition

Type	RS-485		
Pin	A	B	G
Definition	A	B	GND

Table 1-3: SINAPACK 200 RS485 serial port pin definition

1.6.4 RESET Button

To reset SINAPACK 200 to default, login its configuration web page, and choose "System tools" -> "Restore set"; Or: press the RESET button continuously, the signal lights will flash one by one, until all lights are on, that means the reset is finished.



Figure 1-7: SINAPACK 200 reset button

1.7 Typical Usecases




Figure 1-8: Implement PLC remote monitoring and program update via

SINAPACK 200's serial functionality




Figure 1-9: Implement PLC remote monitoring and program update via SINAPACK 200's virhub functionality




Figure 1-10: Implement remote control of touchscreen desktop via SINAPACK 200's agent client functionality and VNC software

2. Device Configurations

This chapter introduces how to use SINAPACK 200 and related parameters.

1. Configurations
 2. Parameters
 3. Restore to default
 4. Firmware Update
 5. Remote Configurations
-


2.1 Configurations

2.1.1 Preparation

- ✧ One cross Ethernet cable used to connect SINAPACK 200 with PC or customer device;
- ✧ One power supply.

2.1.2 Configuring SINAPACK 200

- ✧ Connect SINAPACK 200's LAN(LAN2) with PC via a cross Ethernet cable;
- ✧ Boot PC, and set IP address as "Automatically obtain IP address";






Figure 2-1: Set IP address as "Automatically obtain IP address"

- ✧ Open IE browser, input address "http://192.168.10.1" and press Enter;
- ✧ Input "root" as username and "1234" as password, then press Enter to login web configuration interface and configure the device.

Figure 2-2: Login router configuration interface

- ✧ It is clear to see each configuration item in the router configuration interface. To change some parameter, click it, modify and then save it, then reboot the router.

Below shows SINAPACK 200's current status, including: product ID, version, running time, current time, CPU usage, memory usage, status, model and model manufacturer, WAN/LAN connection status, current status, network, network speed, and signal, etc.

The screenshot displays the 'PLC Connector' web interface. On the left is a yellow sidebar with a menu: Status (selected), Network Settings, LAN, NAT Rule, DTU Function, Virhub, MQTT, Agent Client, System Tools, and Reboot System. The main content area is titled 'Status' and shows the following information:

- Product ID: 240305005119954
- Version: 501-M1-2.1.9-05/10/23
- Running: 0 days 0 hours 31 minutes 1 seconds
- Now: 2023/05/18 15:28:43
- CPU Usage: 17%
- RAM Usage: 49%
- Module Model: L610-CN-62-00
- Module Revision: 16000.1000.00.06.71.15
- Module Status: Module detected, SIM card detected
- Module IMEI: 864908057872169
- SIM IMSI: 460060204253723
- SIM ICCID: 89860621240012562585
- Ethernet Status: 
- WAN Connected to network, IP:192.168.0.101
- Connection Status: Connected to DC.
- Virhub connected.
- Received(Bytes): 1,959,446
- Sent(Bytes): 1,874,029
- Receive Rate(Byte/s): 1,043
- Send Rate(Byte/s): 831
- Packet Loss Rate(%): 0
- Ping Round-trip(ms): 28.6

At the bottom of the interface, a footer note states: [For more information please visit: Etung Technology]

Figure 2-3: Current Status

To use virhub functionality, click “Virhub”, virhub functionality is enabled by default; server is set to auto-selected by default that means SINAPACK 200 will automatically choose the server that is near it and has lowest network delay.

VIRTUAL HUB

This Page: Enable or disable virhub function.

VIRTUAL HUB 

Server Select:

DC IP (Or Dnsname):

DC Port:

Transfer Protocol:

Remote Access IP:

Remote Access Mask:

Disable Broadcast Packet:

Heartbeat Interval:

Data Auto:

Usb device sharing:

Interface:

Max Conn Failure:

Note :

Server can also be set manually, as shown in the figure below, Server is set to "Self-defined", and then input server domain/IP and port accordingly.

VIRTUAL HUB

This Page: Enable or disable virhub function.

VIRTUAL HUB 

Server Select:

DC IP (Or Dnsname):

DC Port: (1~65535)

Transfer Protocol:

Remote Access IP:

Remote Access Mask:

Disable Broadcast Packet:

Heartbeat Interval:

Data Auto:

Usb device sharing:

Interface:

Max Conn Failure:

Note :

Figure 2-4: Configure virhub functionality

To use DTU functionality, click "DTU Function" -> "Basic Cfg". DTU function is enabled by default; server is set to auto-selected by default that means SINAPACK 200 will automatically choose the server that is near it and has lowest network delay.

Basic Cfg

This product will be finded and connected data center according to the configure.

DTU Function: ON ▼

Server Select: Auto-selected ▼

DC IP (Or Dnsname): beijing.lianwangbao.com

DC Port: 8080 (1~65535)

Transfer Protocol: TCP ▼

Connect mServer: YES ▼

Register custom defined: ETUNG:240305005060152

Heartbeat custom defined: ETUNGx00

Packet header custom defined:

User Serial Configuration:

Uart Choice: RS232 ▼

Baud Rate: 115200 ▼

Data Bit: 7bit ▼

Parity: Even ▼

Stop Bit: 1bit ▼

Note :

Save Revert

Server can also be set manually, as shown in the figure below, Server is set to "Self-defined", and then input server domain/IP and port accordingly.

Basic Cfg

This product will be finded and connected data center according to the configure.

DTU Function: ON 

Server Select: Self-defined

DC IP (Or Dnsname): eyun.etungtech.com

DC Port: 8080 (1~65535)

Transfer Protocol: TCP

Connect mServer: YES

Register custom defined: ETUNG:240305005060152

Heartbeat custom defined: ETUNGx00

Packet header custom defined:

User Serial Configuration:

Uart Choice: RS232

Baud Rate: 115200

Data Bit: 7bit

Parity: Even

Stop Bit: 1bit

Note :

Save Revert

Figure 2-5: Configure DTU functionality

SINAPACK 200 has one RS232 and one RS485 serial port, choose either serial port to use in "UART Choice":

Basic Cfg

This product will be finded and connected data center according to the configure.

DTU Function: 

Server Select:

DC IP (Or Dnsname):

DC Port: (1~65535)

Transfer Protocol:

Connect mServer:

Register custom defined:

Heartbeat custom defined:

Packet header custom defined:

User Serial Configuration:



Baud Rate:

Data Bit:

Parity:

Stop Bit:

Note :

Figure 2-6: Choose serial port

In case that SINAPACK 200 is used together with VNC software to perform remote access, agent client functionality is used. To configure agent client functionality, click "Agent Client", set mServer (plc.SINAPACK 200.com) DN and port (8080), the default values are eTung mServer DN and port, normally keep the default values, unless users build its own mServer. Then configure device information, set device IP (for example, 192.168.10.20) and port (for example, 5900), and tick "Enable", then click Save and reboot SINAPACK 200.

Agent Client:

This Page: Configure agent client function.

mServer DN or IP:

mServer Port: (1~65535)

Configure device information

Channel ID	Device IP	Device Port	Enable
240305504004928	192.168.10.20	5900	☒
240305514004928			☐
240305524004928			☐
240305534004928			☐
240305544004928			☐

Note :

Figure 2-7: Configure agent client functionality

It is possible to configure multiple lines in agent client configuration, each line corresponds to a channel, and at most 5 channels are supported. Each channel has a 15-byte channel ID. The channel ID is derived from SINAPACK 200's IMEI. For example, SINAPACK 200's IMEI is 240305001234567, then the agent clients' channel ID is 2403055X1234567, and X can be 0~4, to represent one of the five channels. For example, set two channels as shown in the figure below:

Agent Client:

This Page: Configure agent client function.

mServer DN or IP:

mServer Port: (1~65535)

Configure device information

Channel ID	Device IP	Device Port	Enable
240305504004928	192.168.10.20	5900	☒
240305514004928	192.168.10.20	5900	☒
240305524004928			☐
240305534004928			☐
240305544004928			☐

Note :

Figure 2-8: Configure multiple channels in agent client functionality

2.2 Configuration Parameters

Each configuration menu has multiple parameters, and some of them have sub-menus. Details are described below.

Configuration Menu Item		Description
Current status		Show device information, connection and data transfer status.
Network Settings	Network Select	Configure to use cable network (WAN) or WIFI, set ICMP host, and whether to allow external access.
	WAN	Configure WAN interface, WAN is enabled by default.
	WIFI client	Configure WIFI parameters. Once WIFI is enabled, WAN will be disabled.
LAN		Set inner IP and DHCP
WIFI Hotspot		Configure WIFI hotspot parameters. WIFI hotspot and WIFI client cannot be used at the same time, to enable WIFI hotspot function, please disable WIFI client if it is enabled: set network to WAN in network settings.
Forwarding rules	NAT	Whether the device connected with router can access internet via NAT.
	Port forwarding	Use pre-defined port to forward data from internet to some inner IP's dedicated port.
	DMZ host	Forward data from internet directly to some inner IP.
Routing		Forward data to a pre-defined inner IP
DTU Function	Simple Cfg	Set data center address and serial port parameters, by default server is set to auto-selected, and there is no need to change.
	Advanced Cfg	Set advanced parameters, for example, frame size for data transmission, and timeout for data received from serial port.
	Link Management	Set heart beat parameters, normally with default values
Virhub		Set server address for Virhub function, "Auto-selected" by default that means it will automatically choose the server that is near it and has lowest network delay.

MQTT		Set MQTT version. There are two versions: Standard and General, and General by default.
Agent Client		Configure agent client. Configure mServer domain and port, the master device's IP and port. Allow at most 5 agent clients.
System tools	System settings	Set router's communication parameters, normally with default values
	Show system log	Show router's connection and communication logs
	Show DTU log	Show router's data transfer logs with DTU function
	Restore to default	Restore to initial default settings with one key
	Update firmware	Update router's firmware
	Change password	Change password logging router(1234 by default)
Reboot		Reboot router

Table 2-1: Details of configuration parameters

2.3 Restore to Default

According to the description of "Configuring SINAPACK 200", after entering SINAPACK 200 configuration interface, select "System Tools" and then "Restore Set".




Figure 2-9: Restore to default

Or: press the RESET button continuously to reset it to default.

2.4 Firmware Update

- ✧ Ask eTung for firmware to update. The firmware (*.img) can be uploaded from local disk, or downloaded from a server from Internet.
- ✧ According to the description of "Configuring SINAPACK 200", connect SINAPACK 200 with PC via a cross Ethernet cable, open browser, input `http://192.168.10.1` as URL, input username and password (by default username is root and password is 1234), and login router configuration webpage.
 - ✧ Select "System tools" and then "Upgrade Firmware";
 - ✧ If the firmware is on the local disk, click "Browse", select the file (.img) to update, and click "Open", then click "Upload/Download":




Figure 2-10: Upgrade firmware

- ✧ If the firmware can be downloaded from a server, input download URL (please ask eTung technical support for the URL), and click "Upload/Download":

Upgrade Firmware

Upload the firmware or Download it from Internet and reboot automatically after update.

Upload Firmware:

Download By URL: Must be connected to Internet.

Note : It need about 1 minute to upload the firmware, please not leave this page.

Figure 2-11: Input URL and download firmware

- ✧ Wait for a moment, until "Update" is shown, choose "Delete the configuration" (delete all configurations), or "Only keep the network configuration" (delete all configurations except network configuration), then click "Update". It will prompt the file system has been updated, the original settings is clear, and the system is rebooting. Wait a moment and then refresh the webpage to see the configuration page again.

Upgrade Firmware

Please choose wether to delete the configuration:

☐ Keep the configuration
 ☐ Delete the configuration
 ☒ Only keep the network configuration

Upload File Path: plc502-2.1.5.img
 Upload File Size: 9691216Bytes
 Old Version: 502-2.1.4-02/17/23
 New Version: 502-2.1.5-02/17/23

Make sure and then press Update button.

Upload Success.

Figure 2-12: Choose delete the configuration or keep network configuration

2.5 Remote Configurations

Remote AT commands can be used on SINAPACK 200 to modify configuration parameters remotely. Details are described below:

NOTE: this can be used only when enabling DTU function or virhub function, and SINAPACK 200 is shown online in mServer.

Choose the router in mServer's console, right-click it and choose "Remote Control", in the popped-up dialog, input AT commands in "CMD List" on the left side.

For example, input the following command to change the data center's address and port:

```
AT+MSERVER=3g.etungtech.com,8080
```

Click "Send" afterwards, and if successful, a "OK" will show in "CMD Response" on the right side. Then SINAPACK 200 will be offline from the original mServer, and connect to the new data center and port.




Figure 2-12: Transfer Terminal remotely

Below are remote AT commands that are supported on SINAPACK 200 Ethernet channels.

- 1) AT+MSERVER=addr, port
Change data center address and port, with reply OK or ERROR.
addr: data center address, either IP address or domain
port: data center port
- 2) AT+CSQ
Query signal strength and network mode, with the following reply:
OK:sig_quality,net_mode
sig_quality: 0-31, bigger value means better signal quality
net_mode:
- 3) AT+REBOOT
Reboot the router, with reply OK.
- 4) AT+HBI?
Query heart beat interval (unit: second), with reply OK.
- 5) AT+HBI=interval
Set heart beat interval (unit: second), with reply OK.
- 6) AT+SMSPING=PHONE_NUM
Ask the router to send an SMS to PHONE_NUM, and the content is the router's IMEI number, with reply OK.
- 7) AT+SMSZHUANFA=txt,info_src,dest
Ask the router to send an SMS to info_src first with content "txt" (only in English characters and digits), and then forward the reply to dest. dest can be omitted, and if then the reply will be forwarded to the mobile that sends this AT command. If the reply SMS has more than one message, the router will forward the messages one by one.
For example: AT+SMSZHUANFA=CXLL,10086,13801234567, means to send an SMS to 10086 to query traffic and then forward the reply to 13801234567.
- 8) AT+RDEBUG&ENABLED=0/1
Enable/Disable remote debugging, with reply OK.
- 9) AT+SIMID
Query SIM IMSI and CCID.
- 10) AT+CELLID
Query base station's location code and cell code.
- 11) AT+OPER
Query operator information.

12) AT+NETMODE

Query current network in use, with reply:

+NETMODE: WAN/WIFI/MOBILE\r
OK

13) AT+IFSTATUS

Query data interfaces' status, with reply:

+IFSTATUS: SERIAL(0/1,0/1), LAN(0/1,0/1)\r
OK

Bracket SERIAL(0/1,0/1) shows RS232 and RS485 data interfaces' status: 1 means data are received from the serial interface, otherwise 0. Bracket LAN(0/1,0/1) shows LANs' status: 1 means cable line is plugged, otherwise 0.


Appendix 1: Use SINAPACK 200

Virhub Functionality to Implement

PLC Program Remote Update

1. Apply eYun account

Access website <http://wangkoutong.lianwangbao.com>, press "Register", and input registration information. Pay attention that the password should not be too simple. Input a correct email address, then after submit the system will automatically send a web link to the mailbox, just click the link to enable the account.



The screenshot shows the 'e-Cloud Etung M2M Management System' login and registration interface. At the top, there is a banner with the 'e-Cloud' logo and a navigation bar with 'Homepage' and 'Add to' links. Below the banner is a 'CUSTOMER LOGIN' section with input fields for 'Name', 'Password', and 'Verification'. The 'Verification' field shows a CAPTCHA '2020' with a 'Change' link. There are 'Sign in' and 'Register' buttons. To the right of the login section, there is a 'Download:' link with three options: 'vircom v4.2', 'virhub v1.7', and 'dtucfg v2.3'.

Figure Appendix 1-1: Apply eYun account


Registration Page


Basic Information

Name:

Account Password:

Enter the password again

*Unique identification number representative of a client or project must consistent with the user name in terminal device.Please enter a user name consisting of a ~ z, numbers, underscores

*The length of password must between 6 and 15.

*Please input the password again to confirm.


Contact Information

Email:

Telephone:

Contact Person:

Company

*Please enter email account(open account requires authentication)

*Please enter a valid contact

*contact_name

*Please enter company name

Figure Appendix 1-2: Input registration information

2. Configure SINAPACK 200

- ✧ Connect SINAPACK 200 with PC via Ethernet cross cable, and the IP address in PC is set to obtain automatically;
- ✧ Open browser and input URL: 192.168.10.1;
- ✧ Input username: root, and password: 1234 to login;
- ✧ Choose "Virhub" in the menu list, enable virhub, server is set to auto-selected by default that means SINAPACK 200 will automatically choose the server that is near it and has lowest network delay.
- ✧ Choose "Reboot System" in the menu list, and reboot SINAPACK 200.

VIRTUAL HUB

This Page: Enable or disable virhub function.

VIRTUAL HUB

Server Select:

DC IP (Or Dnsname):

DC Port: (1~65535)

Transfer Protocol:

Remote Access IP: 192.168.168.1

Remote Access Mask: 255.255.255.0

Disable Broadcast Packet:

Heartbeat Interval: 30

Data Auto:

Usb device sharing:

Interface:

Max Conn Failure: 10000

Note :

Figure Appendix 1-3: Configure SINAPACK 200's virhub functionality

3. Configure Virhub software

Open and run Virhub installation package from eTung's CD, or downloaded from eTung's website: www.etungtech.com: Downloads->Software. Run Virhub and click "Settings", server is set to "Auto Select" by default, input the username and password applied before.

The image shows a 'Parameters Settings' dialog box with a blue title bar and a close button (X) in the top right corner. The dialog is divided into several sections. The top section contains a 'Server:' dropdown menu set to 'Auto Select', an 'mServer Address:' text field with 'wangkoutong.lianwangbao.com', and an 'mServer Port:' text field with '9001' and a red 'register' link. Below this is a checked checkbox for 'Authentication'. The middle section, highlighted with a red border, contains an 'Account:' text field with 'etung' and a 'Password:' text field with '*****'. To the right of these fields is a blue 'Logout' button. The bottom section, titled 'Virtual Network IP:', contains three rows of IP and mask settings. The first row shows IP1 as '192 . 168 . 10 . 200' and Mask1 as '255 . 255 . 255 . 0'. The second row shows IP2 as '192 . 168 . 168 . 200' and Mask2 as '255 . 255 . 255 . 0'. The third row shows empty fields for IP3 and Mask3. Below the IP settings are three checkboxes: 'Packets transfer' (unchecked), 'Auto add network' (checked), and 'Auto run on reboot' (unchecked). At the bottom of the dialog are two blue buttons: 'OK' and 'Cancel'.

Parameters Settings

Server: Auto Select

mServer Address: wangkoutong.lianwangbao.com

mServer Port: 9001 [register](#)

☒ Authentication

Account: etung

Password: ***** [Logout](#)

Virtual Network IP:

IP1: 192 . 168 . 10 . 200 Mask1: 255 . 255 . 255 . 0

IP2: 192 . 168 . 168 . 200 Mask2: 255 . 255 . 255 . 0

IP3: Mask3:

☐ Packets transfer

☒ Auto add network

☐ Auto run on reboot

[OK](#) [Cancel](#)

Figure Appendix 1-4: Login Virhub

- 1) Configure virtual network adapter's IP address: in the "Settings" dialog, we can set virtual net adapter's IP address in "Virtual Network IP". Set IP1 to be in the same IP range as PLC's IP that connects to SINAPACK 200, for example, PLC's IP is 192.168.10.20, and then set IP1 to 192.168.10.200. The virtual net adapter is used to build a virtual LAN with PLC. In Virhub IP1, IP2 and IP3 can be set on the virtual net adapter. If all PLCs are in the same IP range, then just set IP1.

Parameters Settings

Server: Auto Select

mServer Address: wangkoutong.lianwangbao.com

mServer Port: 9001 [register](#)

☒ Authentication

Account: etung

Password: ***** [Logout](#)

Virtual Network IP:

IP1: 192 . 168 . 10 . 200 Mask1: 255 . 255 . 255 . 0

IP2: 192 . 168 . 168 . 200 Mask2: 255 . 255 . 255 . 0

IP3: Mask3:

☐ Packets transfer

☒ Auto add network

☐ Auto run on reboot

[OK](#) [Cancel](#)

Figure Appendix 1-5: Configure virtual network adapter's IP address

Press "OK" after configuration, in the system info area, there will be a prompt "Setting virtual network ip address successfully", then the software has set the IP address to the virtual net adapter




Figure Appendix 1-6: Succeed to set IP address of Virtual network adapter

- 2) Add device: in Virhub software add SINAPACK 200 to the user account: press "Add Terminal", and input the IMEI number of SINAPACK 200.




Figure Appendix 1-7: Add device




Figure Appendix 1-8: Succeed to add device

If add device fails, please first make sure if the SVR2 led light is on, that means SINAPACK 200 has connected to eYun platform. If SINAPACK 200 does not connect to eYun platform, add device will fail.

- 3) Then Virhub configuration is complete, check if the communication between host pc and PLC is OK. Open a cmd window, input command: ping 192.168.*.* (PLC's IP address), If there are responses, that means the communication is OK, then use PLC programming software to update program. And if there is no response for a long time, please contact eTung technical support.
- 4) Detect IP address of devices via Virhub
 In order that PC running Virhub can communicate with devices at the far end that connect to SINAPACK 200, the devices' IP must be known beforehand. Virhub's "Detect IP" functionality can automatically detect the devices' IP.
 In Virhub's interface, right-click the terminal and choose "Detect IP", offer the device IP's subnet area, and then click "Detect IP"; and after a while, the IPs detected will be shown in the list, as shown in the figure below:

The 'Detect IP' dialog box contains the following elements:

- Network:** 192 . 168 . 10 . 0
- Mask:** 255 . 255 . 255 . 0
- Buttons:** Detect, Close
- Table:**

Number	IP Address
01	192.168.10.120

Figure Appendix 1-9: Detect device's IP address

Attention:

- 1) The terminal must be online to use this functionality;
- 2) Virhub version must be V9.0 or higher.

4. Access SINAPACK 200 remotely via Virhub

SINAPACK 200 can be accessed remotely via Virhub. Normally, SINAPACK 200 accesses Internet via Cable/WIFI network, and gets an inner IP address, and it cannot be accessed from the internet via this inner IP. eTung's Virhub solution can solve the problem. First, enable Virhub function on SINAPACK 200, and set a remote access IP; the remote access IP is dedicated to access SINAPACK 200 remotely when Virhub is enabled on it. Then run Virhub software on the far-end PC, and configure an IP address on the Virtual Network adapter; this IP must be in the same range as the remote access IP on SINAPACK 200. This way, we can access the router remotely on the far-end PC via the remote access IP, to perform configuration, system monitoring, etc. Below are the details about the configuration procedure.

1) Configure the router's remote access IP

According to "2.1 Configuring SINAPACK 200", go to the router's Virhub configuration, enable Virhub and configure username, then there are two parameters: "Remote Access IP" and "Remote Access Mask", with default values: 192.168.168.1 and 255.255.255.0.

VIRTUAL HUB

This Page: Enable or disable virhub function.

VIRTUAL HUB

Server Select:

DC IP (Or Dnsname):

DC Port: (1~65535)

Transfer Protocol:

Remote Access IP:

Remote Access Mask:

Disable Broadcast Packet:

Heartbeat Interval:

Data Auto:

Usb device sharing:

Interface:

Max Conn Failure:

Note :

Figure Appendix 1-10: Configure SINAPACK 200r's remote access IP

Normally set the two parameters with default values, and they can also be changed on demand. Press "Save" after configuration, and then reboot the router. These two parameters can also be changed/checked via remote AT commands, please refer "2.5 Remote Configurations".

- 2) Configure the Virtual Network adapter's IP address to access SINAPACK 200 remotely
Run Virhub software, click button "Configure", and on the popped up "Settings" dialog, set the Virtual Network adapter's IP address in "Virtual Network IP" part. IP2 is the IP address set on the Virtual Network adapter to access SINAPACK 200 remotely via Virhub, and this IP must be in the same range as the "Remote Access IP" (192.168.168.1 by default) set on SINAPACK 200 in step 1), for example, 192.168.168.*.

Parameters Settings

Server: Auto Select

mServer Address: wangkoutong.lianwangbao.com

mServer Port: 9001 [register](#)

☒ Authentication

Account: etung

Password: ***** [Logout](#)

Virtual Network IP:

IP1: 192 . 168 . 10 . 100 Mask1: 255 . 255 . 255 . 0

IP2: 192 . 168 . 168 . 200 Mask2: 255 . 255 . 255 . 0

IP3: Mask3:

☐ Packets transfer

☒ Auto add network

☐ Auto run on reboot

[OK](#) [Cancel](#)

Figure Appendix 1-11: Configure the Virtual Network adapter's IP address to access SINAPACK 200 remotely

Click "OK" after configuration is complete, the software will then set the IP address on the Virtual Network adapter.

- 3) Access SINAPACK 200 remotely
Open browser, and input SINAPACK 200's remote access IP (192.168.168.1 by default), and then SINAPACK 200's web configuration page shows.

Figure Appendix 1-12: Access SINAPACK 200's Web configuration page remotely

Then we can login the web page to change SINAPACK 200's parameters remotely, just as SINAPACK 200 is directly connected locally.

Attention: When host pc accesses SINAPACK 200's webpage remotely via virhub, it reaches SINAPACK 200 with its remote access IP address, 192.168.168.1 by default. If the default remote access IP address is used, in order to make it work, make sure that only one device is mapped at one time in

virhub, as shown in the figure below, in column "Added", there should be only one device that is marked as YES, i.e. the device that need to be accessed is added to the virtual network, and disconnect all the other devices from the virtual network (click the device, and then click "Exit Network").




Figure Appendix 1-13: Map device in virhub

Appendix 2: Use SINAPACK 200


Serial Functionality to Implement

PLC Program Remote Update

SINAPACK 200 has two user serial ports, so it can connect with PLCs that have serial ports, and perform remote program download and transparent data transmission. eYun platform and Vircom functionality make it easier to implement remote access of PLCs that have serial port. Below we will illustrate the implementation in detail.

1. Apply SINAPACK 200 eYun account

Access website <http://chuankoutong.lianwangbao.com>, press "Register", and input registration information. Pay attention that the password should not be too simple. Input a correct email address, then after submit the system will automatically send a web link to the mailbox, just click the link to enable the account.



The screenshot shows the 'e-Cloud Etung M2M Management System' login and registration interface. At the top, there is a banner with the 'e-Cloud' logo and a background image of a man and a woman. Below the banner, the 'CUSTOMER LOGIN' section contains three input fields: 'Name', 'Password', and 'Verification'. The 'Verification' field shows a CAPTCHA code '2020' and a 'Change' link. To the right of the 'Password' field is a 'Forget?' link. Below the input fields are two buttons: 'Sign in' and 'Register'. To the right of the buttons, there is a 'Download:' section with three links: 'vircom v4.2', 'virhub v1.7', and 'dtucfg v2.3'.

Figure Appendix 2-1: Apply eYun account

Registration Page

Basic Information

Name:

Account Password:

Enter the password again

*Unique identification number representative of a client or project must consistent with the user name in terminal device.Please enter a user name consisting of a ~ z, numbers, underscores

*The length of password must between 6 and 15.

*Please input the password again to confirm.

Contact Information

Email:

Telephone:

Contact Person:

Company

*Please enter email account(open account requires authentication)

*Please enter a valid contact

*contact_name

*Please enter company name

Figure Appendix 2-2: Input registration information

2. Configure SINAPACK 200

- ✧ Connect SINAPACK 200 with PC via Ethernet cross cable,
- ✧ the IP address in PC is set to obtain automatically;
- ✧ Open browser and input URL: 192.168.10.1;
- ✧ Input username: root, and password: 1234 to login;
- ✧ Choose "DTU Function";
- ✧ DTU function is enabled by default, server is set to auto-selected by default that means SINAPACK 200 will automatically choose the server that is near it and has lowest network delay.
- ✧ Choose serial type (RS232 or RS485) based on PLC serial port type, and set serial port parameters (baud rate, data bits, stop bits and parity);
- ✧ Click "Save" and choose "Reboot System" in the menu list, and reboot SINAPACK 200.

Basic Cfg

This product will be found and connected data center according to the configure.

DTU Function: ON

Server Select: Auto-selected

DC IP (Or Dnsname): beijing.lianwangbao.com

DC Port: 8080 (1~65535)

Transfer Protocol: TCP

Connect mServer: YES

Register custom defined: ETUNG:240305005060152

Heartbeat custom defined: ETUNGlx00

Packet header custom defined:

User Serial Configuration:

Vart Choice: RS232

Baud Rate: 9600

Data Bit: 8bit

Parity: None

Stop Bit: 1bit

Note :

Save Revert

Figure Appendix 2-3: Configure SINAPACK 200's serial functionality

3. Configure Vircom software

Find Vircom installation package from eTung website: www.etungtech.com: Downloads->Software, then download and install Vircom.

- ✧ Run Vircom software, and click "Settings", server is set to auto-selected by default and there is no need to change; input username and password that is applied on eYun platform.
- ✧ Add terminal in Vircom by clicking "Add Terminal", input the IMEI on SINAPACK 200;
- ✧ Choose the device, and then click "Add Com" to map a virtual COM for SINAPACK 200;
- ✧ Run PLC programming software to open the virtual COM and send/receive data.




Figure Appendix 2-7: Configure Vircom




Figure Appendix 2-8: Add terminal




Figure Appendix 2-7: Succeed to add terminal




Figure Appendix 2-9: Map a virtual COM




Figure Appendix 2-10: Succeed to map virtual COM

Appendix 3: Configure SINAPACK 200 to Access Internet via Cable/WIFI

1. Configure SINAPACK 200 to access Internet via cable network

According to the description of ch. 2.1 Configurations, login SINAPACK 200's webpage, choose "Network Settings" -> "Network Select", configure to use WAN to access Internet.

For SINAPACK 200, the default network settings are to use WAN:




Figure Appendix 3-1: Use WAN to access Internet

Set "Network Select" as WAN, and then click "Save";

Choose "Network Settings" -> "WAN" to configure WAN parameters;

There are three kinds of types: DHCP, PPPoE and STATIC. Choose PPPoE if cable MODEM is used to access internet, and choose DHCP or STATIC if a dedicated line or LAN is used to access internet. Use STATIC if the IP address is static or assigned manually, otherwise use DHCP.

PLC Connector [中文 | English] Warning: Setting effect after reboot!

WAN

Set up the WAN interface.

WAN MAC: 10:9C:94:96:A1:93

Type: DHCP

PPPOE Account:

PPPOE Password:

Static IP:

Mask:

Gateway:

DNS1:

DNS2:

Note:

Save Revert

Figure Appendix 3-3: Set type

When choosing PPPoE, PPPoE username and password should be set additionally:

WAN

Set up the WAN interface.

Type: PPPOE

PPPOE Account: username

PPPOE Password:

Static IP:

Mask:

Gateway:

DNS1:


DNS2:

Note:

Save Revert

Figure Appendix 3-4: Configure PPPoE username and password

When choosing STATIC, configure static IP, net mask, gateway and DNS accordingly:



WAN

Set up the WAN interface.

Type:

PPPOE Account:

PPPOE Password:

Static IP:

Mask:

Gateway:


DNS1:

DNS2:

Note:

Figure Appendix 3-5: Configure static IP

When choosing DHCP, no additional parameters need to configure:



WAN

Set up the WAN interface.

Type:

PPPOE Account:

PPPOE Password:

Static IP:

Mask:

Gateway:

DNS1:

DNS2:

Note:

Figure Appendix 3-6: Configure DHCP

Click "Save", and plug in Ethernet cable on LAN1 (WAN) of SINAPACK 200 and connect to the cable network, then reboot SINAPACK 200. After reboot, login SINAPACK 200's web configuration page, it can be seen that SINAPACK 200 has connected to the internet with WAN.




Figure Appendix 3-7: SINAPACK 200 accesses Internet via WAN

2. Configure SINAPACK 200 to access Internet via WIFI

SINAPACK 200 can access Internet via WIFI. According to the description of ch. 2.1 Configurations, login SINAPACK 200's webpage, choose "Network Settings" -> "Network Select", set network as WIFI, then click "Save".




Figure Appendix 3-8: Set network as WIFI

Choose "Network Settings" -> "WIFI Client", to configure WIFI parameters. SINAPACK 200 supports configuring at most 3 WIFI APs. By default AP3 has SSID: ABC and pin: 12345678.




Figure Appendix 3-9: Configure WIFI parameters – 1

Click "Refresh" to search the WIFI APs around:

AP: WIFI AP list
 Note: If wifi is disabled, the first time clicking "Refresh", it need some time to output the result.

	SSID	Frequency	Signal (0-100)	Security
☐	etungtech	2412	92	[WPA2]
☐	XJ_Wi-Fi5	2462	88	[WPA2]
☐	IP-COMyhzt	2427	92	[WPA2]
☐	XJ	2462	80	[WPA2]
☐	HIK-server	2417	84	[WPA2]
☐		2417	84	[WPA2]
☐	TP-LINK_1018A_Wi-Fi5	2437	88	[WPA2]
☐	TP-LINK_1018A	2437	84	[WPA2]
☐	HONGRONG	2412	64	[WPA2]
☐	213xhw	2437	64	[WPA2]
☐	TP-LINK_1018A	5220	52	[WPA2]
☐	TP-LINK_1018A_Wi-Fi5	5220	50	[WPA2]
☐	XJ_Wi-Fi5	5220	62	[WPA2]
☐	XJ	5220	60	[WPA2]
☐	IP-COM_yhzt5G	5200	50	[WPA2]
☐	DIRECT-EUMS-LPQZQSIEDUHEmsPX	2412	66	[WPA2]
☐	etung	2437	64	[WPA2]
☐	IP-COM_AP4	2442	50	[WPA2]
☐	HONGRONG_5G	5745	38	[WPA2]
☐	IP-COM_1EDC38	2417	48	[WPA2]
☐	HUAWEI-B315-DOB7	2437	46	[WPA2]
☐		2437	44	[WPA2]
☐	IP-COM_AP1	2422	40	[WPA2]
☐	HP-Print-11-LaserJet Pro MFP	2437	48	[WPA2]
☐		2417	36	[WPA2]
☐	DIRECT-91-HP Smart Tank 750	5220	36	[WPA2]
☐	nova 8 Pro	2437	24	[WPA2]

Figure Appendix 3-10: Search WIFI APs

Choose WIFI AP in the list, select security type, and input pin, then click "Save", and reboot SINAPACK 200.

WIFI Client

This Page: Set WIFI client parameters

WIFI MAC: 30:7B:C9:18:C4:DE

AP1 SSID:

AP1 Security:

AP1 PSK pin:

AP2 SSID:

AP2 Security:

AP2 PSK pin:

AP3 SSID:

AP3 Security:

AP3 PSK pin:

Type:

Static IP:

Mask:

Gateway:

DNS1:

DNS2:

WIFI Bridge:

AP: WIFI AP list

Note: If wifi is disabled, the first time clicking "Refresh", it need some time to output the result.

	SSID	Frequency	Signal (0-100)	Security
☐	TP-LINK_1018A	2437	82	[WPA2]
☒	etungtech	2412	100	[WPA2]

Figure Appendix 3-11: Configure WIFI parameters – 2

By default connection type is DHCP, i.e. get IP address dynamically. It is also supported to assign static IP address manually, and set subnet netmask, default gateway and DNS, as shown in the figure below:

WIFI Client

This Page: Set WIFI client parameters

WIFI MAC:

30:7B:C9:18:C4:DE

AP1 SSID:

etungtech

AP1 Security:

WPA2-PSK AES ▾

AP1 PSK pin:

12345678

AP2 SSID:

AP2 Security:

OPEN ▾

AP2 PSK pin:

AP3 SSID:

ABC

AP3 Security:

WPA2-PSK AES ▾

AP3 PSK pin:

12345678

Type:

STATIC ▾

Static IP:

192.168.0.230

Mask:

255.255.255.0

Gateway:

192.168.0.254

DNS1:

192.168.0.254

DNS2:

WIFI Bridge:

OFF ▾

Save

Revert

Figure Appendix 3-12: Configure WIFI parameters – 3

After configuration and reboot, login SINAPACK 200's web configuration page, it can be seen that SINAPACK 200 has connected to the internet with WIFI.




Figure Appendix 3-13: SINAPACK 200 accesses Internet via WIFI

NOTE: Some SINAPACK 200 types do not have WIFI module, and then cannot access Internet via WIFI.

SINAPACK 200 supports WIFI Bridge, and by default it is disabled. Network devices that connect to SINAPACK 200's Ethernet interfaces, have IP addresses that are different from the IP addresses that WIFI AP specifies. So the devices that connects to SINAPACK 200's Ethernet interfaces cannot PING devices that connect to the WIFI AP. WIFI Bridge functionality can solve this problem. After enabling WIFI Bridge, network devices that connect to SINAPACK 200's Ethernet interface can get(or set) IP addresses from WIFI AP, and then they are in the same LAN with those devices connecting to the same WIFI AP, and they can PING each other freely.

WIFI Client

This Page: Set WIFI client parameters

WIFI MAC: 30:7B:C9:18:C4:DE

AP1 SSID: etungtech ✓

AP1 Security: WPA2-PSK AES ▾

AP1 PSK pin: 12345678

AP2 SSID:

AP2 Security: OPEN ▾

AP2 PSK pin:

AP3 SSID: ABC

AP3 Security: WPA2-PSK AES ▾

AP3 PSK pin: 12345678

Type: STATIC ▾

Static IP: 192.168.0.230

Mask: 255.255.255.0

Gateway: 192.168.0.254

DNS1: 192.168.0.254

DNS2:

WIFI Bridge: ON ▾

Note:

1. To enable WIFI Bridge, please disable WAN, and choose WIFI.

Network Select

Select the interface to connect.

Network: WIFI ▾

ICMP Host:

Backup ICMP Host:

Max Try:

External access:

Note 1: ICMP Host should be s

WIFI
MOBILE(2G/3G/4G)
WAN
WIFI
WAN&MOBILE
WAN&WIFI
WIFI&MOBILE
WAN&WIFI&MOBILE

Save Revert

2. In case devices need to get IP automatically from WIFI AP, please disable SINAPACK 200's DHCP function. Otherwise, SINAPACK 200 will specify IP to the devices, and they cannot get IP from WIFI AP.

LAN

Set up the router IP of LAN and set the DHCP function.

Gateway IP:

Mask:

DHCP Start:

IP Number:

DNS IP:

DHCP Lease: Lease: (1~200000)

DHCP Service: ▼

Note : Gateway IP and DHCP Settings must be in the same network.

Appendix 4: Use VNC and SINAPACK 200 to Access and Control Devices Remotely

VNC is the abbreviation of Virtual Network Console. It is a kind of excellent remote control software, and it includes two parts: client software (vncviewer) and server software (vncserver). Vncserver runs on the remote master device, and vncviewer runs on the local pc (or mobile phone), and vncviewer connects to device that runs vncserver and displays the desktop remotely. The basic mechanism of VNC is just like those remote control software that run on windows: first vncviewer establishes connection with vncserver, and then vncserver displays it's desktop to vncviewer, and allows the remote control of its desktop, thus implements remote control of device.

VNC supports multiple OSs, including Windows, Linux, MAC OS, and Android; and it is platform independent, i.e. we can use Windows PC running VNC to control device that runs Linux or MAC OS, or use Android mobile to control touchscreen that runs Linux.

Customers' devices, for example, touchscreens, is located on the remote places. It requires that PC or mobile phone can remote control the touchscreen, with vncserver running the touchscreen, and vncviewer running on the PC (or mobile). PC and mobile can access Internet, but cannot access the touchscreen, because there is no network access in the place of touchscreen, or: although the touchscreen can access Internet, it does not have public network IP, and PC (or mobile) still cannot access the touchscreen remotely. SINAPACK 200 and together with SINAPACK 200 cloud server, offer an effective and convenient solution to control the far-end touchscreen remotely via PC or mobile. Below are details of the solution.




Figure Appendix 4-1: Use SINAPACK 200 an VNC to remote control touchscreen

1. Install and run vncserver on the touchscreen, and run vncviewer on PC or mobile, and PC (or mobile) can access Internet;
2. Configure touchscreen IP address: set the IP address to be in the same IP range as SINAPACK 200's LAN IP, for example 192.168.10.20. Check SINAPACK 200's LAN IP range in its web configuration page, by default 192.168.10.* , as shown in the figure below:

LAN

Set up the router IP of LAN and set the DHCP function.

Gateway IP:

Mask:

DHCP Start IP:

DHCP End IP:

DNS IP:

DHCP Lease: Lease: (1~200000)

DHCP Service:

Note : Gateway IP and DHCP Settings must be in the same network.

Figure Appendix 4-2: Configure SINAPACK 200 LAN IP – 1

Modify SINAPACK 200 LAN IP as required, click Save and reboot SINAPACK

200.

LAN

Set up the router IP of LAN and set the DHCP function.

Gateway IP: 192.168.2.1

Mask: 255.255.255.0

DHCP Start IP: 192.168.2.20

DHCP End IP: 192.168.2.254

DNS IP:

DHCP Lease: 86400 Lease: (1~200000)

DHCP Service: ON

Note : Gateway IP and DHCP Settings must be in the same network.

Save Revert

Figure Appendix 4-3: Configure SINAPACK 200 LAN IP – 2

3. Configure agent client on SINAPACK 200

Login SINAPACK 200 web configuration page, choose "Agent Client", mServer DN or IP is plc.lianwangbao.com and mServer port is 8080 by default, that is eTung mServer, normally use the default settings, until customer builds its own mServer. Then configure device information, including touchscreen's IP (for example, 192.168.10.20) and vncserver's listening port (for example, 5900), and tick "Enable", press Save and reboot SINAPACK 200.

Agent Client:

This Page: Configure agent client function.

mServer DN or IP: plc.lianwangbao.com

mServer Port: 8080 (1~65535)

Configure device information

Channel ID	Device IP	Device Port	Enable
240305504004928	192.168.10.20	5900	☒
240305514004928			☐
240305524004928			☐
240305534004928			☐
240305544004928			☐

Note :

Save Revert

Figure Appendix 4-4: Configure agent client

SINAPACK 200 supports multiple vncviewers' remote access from different PCs (or mobiles). This can be done by supporting multiple channels on agent client functionality. Configure multiple lines in agent client configuration, and enable

all of them. For example, configure two channels as shown in the figure below, each channel has touchscreen's IP as device IP, and vncserver's listening port as device port. This allows two PCs (or mobile phones) to remote control the touchscreen at the same time, thus implements device remote control in different locations. SINAPACK 200 support at most 5 channels, and each channel has a 15-byte channel ID. The channel ID is derived from SINAPACK 200's IMEI. For example, SINAPACK 200's IMEI is 240305001234567, then the agent clients' channel ID is 2403055X1234567, and X can be 0~4, to represent one of the five channels.

Agent Client:

This Page: Configure agent client function.

mServer DN or IP:

mServer Port: (1~65535)

Configure device information

Channel ID	Device IP	Device Port	Enable
240305504004928	192.168.10.20	5900	☒
240305514004928	192.168.10.20	5900	☒
240305524004928			☐
240305534004928			☐
240305544004928			☐

Note :

Figure Appendix 4-5: Configure multi-channel agent client

4. Connect SINAPACK 200 and touchscreen with RJ45 net cable, plug SIM card in SINAPACK 200, tighten the antenna, and power on SINAPACK 200.
5. Assign TCP port for terminals on SINAPACK 200 server
Open browser on PC, visit SINAPACK 200 server's web page: plc.SINAPACK 200.com. First register a user and enable it, and then login with username and password;




Figure Appendix 4-6: Login SINAPACK 200 server

Click "Terminal Control" -> "Add Terminal",





Figure Appendix 4-7: Add terminal


Input the channel ID corresponding to the agent client, for example:
240305501234567:



A dialog box titled "Add Terminal" with a text input field labeled "Terminal Number:" containing the value "240305501234567". Below the input field are "OK" and "Cancel" buttons.

Attention: terminal can be added only when it is online. If it fails to add terminal, make sure SINAPACK 200 has connected online in SINAPACK 200 server, or ask eTung technical support for help.

After terminal is added, assign TCP port for the terminal: Click the terminal in terminal list, then click "Terminal Control" -> "Add TCP port". System prompts: "Add TCP port command has been submitted successfully!" Then in the terminal list it can be seen the terminal has been assigned a TCP port, as shown in the figure below:



The screenshot shows the "Etung M2M Management System" interface. At the top, there's a header with a logo, the date "2018-3-9", and time "14:28:03". Below the header are three buttons: "List", "Tasks", and "Relationship". The main area displays a "Terminal Control" menu on the left with options like "Query Signal", "Remote Reboot", "Remote Update", "DTU transfer", "change user name", "Add Terminal", "Add TCP port", and "Delete TCP port". The "Add TCP port" option is highlighted with a red box. To the right of the menu is a table showing terminal information.

Terminal Name	User	Device Status	TCP port	Signal Inte...	Month Flow	Firmw
DTU4004928_51	wmy	Offline			2176 KB	PLC5I
DTU4004928_50	wmy	Offline			460 KB	PLC5I
DTU4004928_40	wmy	Offline			1 KB	PLC5I
DTU4004928_20	wmy	Offline			636 B	PLC5I
DTU4030163	wmy	Offline			0 B	MD30
240305003079986	DTU3079986	wmy			0 B	PLC-5
240305003074233	DTU3074233-----	wmy			0 B	PLC-5

Figure Appendix 4-8: Add TCP port

Etung M2M Management System

2018-3-9 14:30:22

List Tasks Relationship

Terminal Control On/Offline History Flow History Delete Export Terminals : 7 Online : 0

Terminal Number	Terminal Name	User	Device Status	TCP port	Signal Inte...	Month Flow	Firmwa
240305514004928	DTU4004928_51	wmy	Offline	30024		2176 KB	PLC505
240305504004928	DTU4004928_50	wmy	Offline			460 KB	PLC505
240305404004928	DTU4004928_40	wmy	Offline			1 KB	PLC505
240305204004928	DTU4004928_20	wmy	Offline			636 B	PLC505
240305004030163	DTU4030163	wmy	Offline			0 B	MD309I
240305003079986	DTU3079986	wmy	Offline			0 B	PLC-50
240305003074233	DTU3074233-----	wmy	Offline			0 B	PLC-50

If multiple channels are configured in SINAPACK 200's agent client, then add terminal for each independent channel and assign TCP port for the terminal accordingly. As shown in the figure below, two terminals and corresponding TCP ports are added:

Etung M2M Management System

2018-3-9 14:35:23

List Tasks Relationship

Terminal Control On/Offline History Flow History Delete Export Terminals : 7 Online : 0

Terminal Number	Terminal Name	User	Device Status	TCP port	Signal Inte...	Month Flow	Firmwa
240305514004928	DTU4004928_51	wmy	Offline	30024		2176 KB	
240305504004928	DTU4004928_50	wmy	Offline	30025		460 KB	
240305404004928	DTU4004928_40	wmy	Offline			1 KB	
240305204004928	DTU4004928_20	wmy	Offline			636 B	
240305004030163	DTU4030163	wmy	Offline			0 B	
240305003079986	DTU3079986	wmy	Offline			0 B	
240305003074233	DTU3074233-----	wmy	Offline			0 B	

Figure Appendix 4-9: Add TCP port for each terminal

- Use vncviewer on PC or mobile to remote control touchscreen
Run vncviewer in PC or mobile, input server information as LianWangBao server's domain plus the TCP port assigned in step 5, as shown in the figure below:




Figure Appendix 4-10: Use vncviewer to access LianWangBao server's TCP port

Click "OK", then there will be a warning dialog, and then prompts the password dialog. Input the password to verify, then the remote touchscreen's desktop will be shown on PC (or mobile).




Figure Appendix 4-11: Input password


Attention:

- 1) If multiple PCs (or mobile phones) access touchscreen at the same time, make sure each PC use an independent channel, i.e. in vncviewer's server information use different TCP port for different channels, otherwise the connections will be lost and PCs cannot work correctly.
- 2) The solution above is just one of device remote access solutions. In fact, to support PCs' remote access on touchscreen, Virhub + VNC is another effective solution. Please refer to Appendix 1 for details on how to use Virhub.

Appendix 5: Use SINAPACK 200 IP Virtual Mapping together with Virhub to Distinguish Devices with Same IP

Some projects have devices, i.e. PLCs, with a fixed IP address by default. SINAPACK 200 is used to implement devices' remote access. However, the devices are configured with the same default IP, and the monitoring center cannot distinguish them with IP. Virhub together with SINAPACK 200 IP virtual mapping can solve this problem.

SINAPACK 200 IP Virtual Mapping
to Distinguish Devices with Same IP



1. Use Ethernet cable to connect device with SINAPACK 200;
2. Configure SINAPACK 200 Ethernet IP to be in the same IP range as device Ethernet IP, for example: 192.168.2.*;

eTung **PLC Connector** [中文 | English] Warning: Setting effect after reboot!

- Status
- Network
- Settings
- LAN**
- WIFI Hotspot
- NAT Rule
- Router
- DDNS
- VPN
- DTU Function
- Virhub
- Agent Client
- System Tools
- Reboot System

LAN

Set up the router IP of LAN and set the DHCP function.

Gateway IP: 192.168.2.1

Mask: 255.255.255.0

DHCP Start IP: 192.168.2.20

DHCP End IP: 192.168.2.254

DNS IP:

DHCP Lease: 86400 Lease: (1~200000)

DHCP Service: ON

Note : Gateway IP and DHCP Settings must be in the same network.

Save Revert

3. Configure IP virtual mapping, map the device's IP to some IP (Access IP) in a different IP range, for example: 192.168.8.1, and make sure different devices are assigned to different IPs;

eTung **PLC Connector** [中文 | English] Warning: Setting effect after reboot!

- Status
- Network
- Settings
- LAN
- WIFI Hotspot
- NAT Rule
- Router
- DDNS
- VPN
- DTU Function
- Virhub
- Agent Client
- System Tools
- Reboot System

DMZ Host

This Page: DMZ IP mapping

ID	Host IP	Access IP	Netmask	Access Source	Enable
1				External	☐
2	192.168.2.100	192.168.8.1	255.255.255.0	Virtual	☒
3				Virtual	☐
4				Virtual	☐
5				Virtual	☐
6				Virtual	☐
7				Virtual	☐
8				Virtual	☐
9				Virtual	☐
10				Virtual	☐

Note :

Save Revert

4. Enable Virhub in SINAPACK 200;

VIRTUAL HUB

This Page: Enable or disable virhub function.

VIRTUAL HUB 

Server Select:

DC IP (Or Dnsname):

DC Port:

Transfer Protocol:

Account:

Remote Access IP:

Remote Access Mask:

Disable Broadcast Packet:

Heartbeat Interval:

Data Auto:

Usb device sharing:

Interface:

Max Conn Failure:

Note :

5. Run Virhub software on host PC, and set virtual network adapter IP as in the same IP range as the access IPs mapped to devices;

Parameters Settings

Server: Auto Select

mServer Address: wangkoutong.lianwangbao.com

mServer Port: 9001 [register](#)

☒ Authentication

Account: etung

Password: ***** [Logout](#)

Virtual Network IP:

IP1: 192 . 168 . 8 . 200 Mask1: 255 . 255 . 255 . 0

IP2: 192 . 168 . 168 . 200 Mask2: 255 . 255 . 255 . 0

IP3: Mask3:


☐ Packets transfer

☒ Auto add network

☐ Auto run on reboot

[OK](#) [Cancel](#)

6. Use the access IPs to communicate with devices.



Appendix 6: SINAPACK 200's

MODBUS TCP Interface Description

SINAPACK 200 has built-in MODBUS TCP protocol, and as MODBUS TCP slave, MODBUS TCP client can get system time, SINAPACK 200 current status, signal strength, SINAPACK 200 serial ID, etc. Below is the brief description of SINAPACK 200's MODBUS TCP interface.

- ✓ MODBUS device address: 0x01
- ✓ MODBUS TCP port: 502
- ✓ Max connections: 32
- ✓ Protocol addresses base 0
- ✓ 16-bit high first
- ✓ 32-bit low first

Function	Description	Variable Address Offset	Variable Datatype	Variable Description
03	Read Holding Register	1~6	Int16	System time: Year, Month, Day, Hour, Minute, and Second.
		7	Int16	Signal strength
		8	Int16	Current network: 0: No connection 1: Cable 2: WIFI
		9~12		Reserved
		13	Int16	SINAPACK 200 current status 0: Running 1: Breakdown
		14	Int16	CPU usage, with value 0~100
		15	Int16	Memory usage, with value 0~100
		16	Int16	Positioning status, 0: Invalid, 1: Valid
		17~18	Float32	Running time, unit: hour
		19~20		Reserved

		21~35	Int16	SINAPACK 200 serial ID, 15 digits, encoding with BCD
		36		Reserved


Appendix 7: SINAPACK 200's

Enhanced DMZ Function


In case SINAPACK 200 chooses WAN or WIFI network, if some PC in the same WAN/WIFI network needs to connect to devices under SINAPACK 200, the enhanced DMZ function can be enabled.

By default, only one host can be specified for DMZ host. The enhanced DMZ allows multiple hosts.

As shown in the figure below, SINAPACK 200 connects to network via WAN/WIFI, and gets IP address 192.168.0.*. PLC 1 and PLC 2 connects to SINAPACK 200, with IP address 192.168.2.100 and 192.168.2.200. One PC in the same WAN network has IP 192.168.0.196, and the PC needs to connect to PLC 1 and PLC 2.




To implement this, configure two rules in DMZ, as shown in the figure below:



After configuration, save and reboot SINAPACK 200.

Then, PC in the WAN network can access PLC 1 via IP: 192.168.0.190, and PLC 2 with IP: 192.168.0.191.

For example, to download/upload PLC program:



Similarly, in case SINAPACK 200 connects to WIFI network, the DMZ rules are configured below:

eTung PLC Connector [中文 | English] Warning: Setting effect after reboot

- Status
- Network Settings
- LAN
- NAT Rule
 - NATNET
 - Port Mapping
 - DMZ Host
- DTU Function
- Virhub
- MQTT
- Agent Client
- System Tools
- Reboot System

DMZ Host

This Page: DMZ IP mapping

ID	Host IP	Access IP	Netmask	Access Source	Enable
1				External	☐
2	192.168.2.100	192.168.0.190	255.255.255.0	WIFI	☒
3	192.168.2.200	192.168.0.191	255.255.255.0	WIFI	☒
4				Virtual	☐
5				Virtual	☐
6				Virtual	☐
7				Virtual	☐
8				Virtual	☐
9				Virtual	☐
10				Virtual	☐

Note :
Note1:

Save Revert

[For more information please visit: Etung Technology]

Attention:

In case WAN is specified in the rules, please enable WAN network; and in case WIFI is specified in the rules, please enable WIFI network. Go to Network Settings --> Network Select, and choose WAN or WIFI to enable the corresponding network.

FCC Statement:

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

After connecting to WIFI, the device can be used.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.