



LONGER



Quick Start Guide



LONGER LASER ENGRAVER **LASER B1 20W/30W**

Thank you for choosing our products.
Please read this manual carefully before use.

Please reference more details on digital manual in TF card about the operation of
Laser Engraver and installation of LaserGRBL or LightBurn.

Please join our Facebook Group:
LONGER Laser Engraver Official Group
Email: Support@longer3d.com

If you have any question, please feel free to contact us as above.

*Copyright © Shenzhen Longer 3D Technology Co.,Ltd. All Rights Reserved

Dear customer,

Thank you for choosing LONGER products **LASER B1**.

Maybe you are familiar with the engraving machine or have bought a similar engraving machine before, we still highly recommend that you read this manual carefully. The installation techniques and precautions in this manual can help you avoid any unnecessary damage or frustration.

Contents

A.	Safety Precautions.....	1
B.	Product Information.....	8
	(1) Specifications	8
	(2) Components Introduction	10
	(3) Packing List.....	11
	(4) Machine assembly.....	12
C.	Machine Operation	17
	(1) Power On.....	17
	(2) LaserGRBL Software Operation	18
	(3) LightBurn Software Operation	21
	(4) Firmware Upgrading.....	30
	(5) APP Operation	32
	(6) Air valve instructions.....	41
D.	FAQ.....	46
	Question 1: Are there recommended engraving and cutting parameters?	46
	Question 2: The engraved pattern appears vibration, or is not closed?	46
	Question 3: How about the warranty policy?	46
	Question 4: How to maintain LASER B1 laser module?.....	49
	Question 5: How to solve alarm 2 error or hard limit?	51
	Question 6: How to solve the upload error of the APP?	51

A. Safety Precautions

(1) The **LASER B1** engraves and cuts materials by the means of a high-energy diode laser beam.

The hazards associated with a high-energy diode laser beam include the possibility of fires, generation of hazardous and/or irritating toxic fumes, but more importantly damage to eyes and skin.

(2) Laser engravers are divided into several internationally valid classes based on their performance and the risk of injury. The **LASER B1** falls into the Class IV (Class 4 IEC standard focus on the American FDA classification).

Laser class	Class Definition
Class I	Class I laser radiation is not considered hazardous.
Class IIa	Class IIa laser radiation is not considered hazardous if viewed for any period of time less than or equal to 1×10^3 seconds but is considered a chronic viewing hazard for any period of time greater than 1×10^3 seconds.
Class II	Class II laser radiation is considered a chronic viewing hazard.
Class IIIa	Class IIIa laser radiation is, depending upon the irradiance, either an acute in-trabeam viewing hazard or chronic viewing hazard. If viewed directly with optical instruments, Class IIIa laser radiation is classified as an acute viewing hazard.

Class IIIb	Direct Class IIIb laser radiation is considered an acute hazard to the skin and eyes.
Class IV	Class IV laser radiation is considered an acute hazard to the skin and eyes from both direct and scattered radiation.

The high energy laser beam can cause severe eye damage, including blindness and serious skin burns.

Improper use of the controls and modification of the safety features may cause serious eye injury and burns.

Please wear Personal Protective Equipment (PPE, Safety Glasses are designed to filter specific ranges of laser wavelength. The **LASER B1** Safety Glasses provided are specific for LONGER Laser Module;) when using the machine.

- DO NOT look directly into the laser beam.
- DO NOT aim the laser beam at reflective surfaces.
- DO NOT operate the laser without PPE protection for all persons nearby in the proximity of the **LASER B1**.
- DO NOT allow unsupervised access to the **LASER B1** to children.
- DO NOT allow access near the **LASER B1** to pets.
- DO NOT modify or disable any safety features of the laser system.
- DO NOT touch the high energy laser beam.

(3) We strongly recommend placing the machine in a well-ventilated room, and at the same time, the door of the room has a sealing effect, and the windows have curtains, to effectively avoid looking directly at the laser beam and some smoke and steam, Particles, and other highly toxic substances. At the same time, you can pay attention to the LONGER products (cover) in the follow-up.

(4) The high-energy diode laser beam can produce extremely high temperatures and significant amounts of heat as the substrate material is burned away while engraving and cutting. Some materials are prone to catch fire during cutting operations creating flame, fumes, and smoke.

(5) Although the **LASER B1** has a built-in flame sensor, this technology should NOT be considered 100% accurate and should be seen only as a warning system.

During the working process of **LASER B1**, if a flame is found, the machine will stop the laser and make a sound to indicate abnormal conditions. Please pay attention to the working status of the machine.

during operation to ensure that any flare ups/ flame is properly contained and extinguished.

It is strongly recommended that a Fire Extinguisher should be

located within proximity to the **LASER B1**. Extinguishers should be halogen or multi-purpose dry chemical. Alternatively, or in conjunction with the Fire Extinguisher it is recommended a “Fire Extinguisher Ball” is positioned beside the **LASER B1**.

- DO NOT use materials that are highly flammable, explosive or produce toxic by-products.
- DO NOT remove material from the cutting bed before it has cooled.
- DO NOT leave the **LASER B1** operating unattended.
- ALWAYS clean up clutter, debris, and flammable materials in the laser **LASER B1** bed after use.
- ALWAYS keep a properly maintained fire extinguisher nearby.
- DO NOT allow the USB cable to contact with the laser Beam.
- DO NOT allow the 24V power cable to contact with the laser Beam.

(6) During the engraving process of the **LASER B1** laser engraving machine, different materials may produce different pungent odors. Always use **LASER B1** laser engravers in open and well-ventilated areas.

(7) Environmental requirements

Temperature requirement: 10° C~30° C, humidity requirement: 20%~50%, this **LASER B1** laser engravers can work normally

within this range; beyond this range, this laser engravers will be unable to achieve the best engraving results.

(8) Below a list of some of the most known hazardous materials that the user SHOULD NOT attempt to engrave or cut on. If a material is not in this list, do not consider it to be safe to use. Obtain the Safety Data Sheet (SDS) from the material's manufacturer when handling unknown materials.

Material	Reason to avoid engraving / cutting it
PVC (Poly Vinyl Chloride)	PVC will emit Chlorine gas when laser cut, or laser engraved. This toxic gas can ruin the optics and motion control system of the laser engraver, in fact, engraving or cutting PVC is a sure way of voiding the warranty of your laser engraver
Lexan / Thick Poly-carbonate	Lexan not only cuts poorly but it also catches on fire very easily. The window of the laser engraving machine is usually made from polycarbonate because it does a very good job of attracting infrared radiation., which is the frequency of light the engraver uses when cutting and engraving materials. This makes the laser cutter quite ineffective in cutting polycarbonate materials
ABS	ABS melts upon exposure to a laser beam as opposed to vaporizing which would be the ideal reaction needed for laser engraving. Instead of leaving a crisp image, ABS will melt and leave a gooey deposit on the surface.
HDPE	HDPE melts and catches on fire easily upon exposure to a laser beam.

Polystyrene Foam	Only very thin pieces can be laser cut but for the most part, polystyrene catches on fire and melts when exposed to a laser beam
Fiberglass	Fiberglass is made from two materials: glass and epoxy resin. The best method of marking glass is etching while epoxy resin can emit toxic fumes upon laser engraving. These two reasons make fiberglass a bad choice for a laser engraving material
Polypropylene	polypropylene melts and catches on fire easily and then the melted material continues to burn thereby forming pebble-like drips that harden on the surface
Coated Carbon Fiber	Coated carbon fiber emits noxious fumes. Additionally, carbon fiber can be cut albeit with some fraying but this is not the case when it is coated.

(9) The **LASER B1** has built in technology and algorithms to keep its users and the surrounding environment safe. This said it is important to understand the **LASER B1** is not a toy and should be operated with care and respect.

(10) Important information regarding your **LASER B1**

LASER B1 use 24V DC power system:

- Never Use a different voltage Power Adapter.

Make sure to use DC 24V 5A and 7.5A adapters for 20W and 30W respectively.

- When using an alternative Power Adapter, the Voltage should always be 24V, Make sure to use DC 24V 5A

and 7.5A adapters for 20W and 30W respectively.

Higher amperage output Power Adapter can be used without risk of damage to your LASER B1. On inserting the power barrel into your motherboard, it is possible that a small spark is visible. This is NOT hazardous to your machine and is caused by the 24V power inrush. If you prefer to avoid this, connect the power barrel to your motherboard first, then connect your power adapter to the mains electricity plug.

- Once the **LASER B1** detects 24V present you will see the motherboard emit a light red glow on the LED of the Motherboard. This means the motherboard is powered.
- If when plugging your Power Adapter barrel to your Motherboard and the Power adapter to mains power a green LED does not turn on, please verify your power adapter is receiving Mains Power.


B. Product Information

(1) Specifications


Laser B1 20W	
Working Area	450x440mm(17.72x17.32inch)
Power Adapter Input Voltage (AC)	AC110 - 240V 50/60Hz
Power Adapter Output Voltage (DC)	DC 24V 5A
Power Max Consumption	120W
Packaging Size	742x557x124 mm (29.2x21.9 x4.9 in)
Packaging Weight	9.6kg
Machine Size Assembled	727x668x239 mm (28.6x26.3x9.4 in)
Operating Temperature	-20 – 50℃
Laser Module Model	Laser B1 20W
Laser Technology	Four Diode Laser with FAC
Wavelength	450 - 460 nm
Max Power Input	DC 24V 3.2 A
Optical Power Output	20-22W
Focus Type	50mm Fixed Focus
Dot Size at Optimal Focus	0.08 x 0.15mm
Laser Class	FDA Class IV, or Class 4 IEC standard
Applicable Material	Engraving: Plywood, Basswood, Hardwood, Pinewood, Acrylic, Kraft paper, Stainless steel, Aluminum alloy, Ceramics, etc. Cutting: Basswood, Acrylic, Bamboo, Kraft paper, etc.
Laser B1 30W	
Working Area	450x440mm(17.72x17.32inch)

Power Adapter Input Voltage (AC)	AC110 - 240V 50/60Hz
Power Adapter Output Voltage (DC)	DC 24V 7.5 A
Power Max Consumption	180W
Packaging Size	742x557x124 mm (29.2x21.9x4.9 in)
Packaging Weight	9.7kg
Machine Size Assembled	727x668x244 mm (28.6x26.3x 9.7 in)
Operating Temperature	-20 – 50℃
Laser Module Model	Laser B1 30W
Laser Technology	Six Diode Laser with FAC
Wavelength	450 - 460 nm
Max Power Input	DC24V 4.5 A
Optical Power Output	33-36W
Focus Type	50mm Fixed Focus
Dot Size at Optimal Focus	0.08 x 0.15mm
Laser Class	FDA Class IV, or Class 4 IEC standard
Applicable Material	Engraving: Plywood, Basswood, Hardwood, Pinewood, Acrylic, Kraft paper, Stainless steel, Aluminum alloy, Ceramics, etc. Cutting: Basswood, Acrylic, Bamboo, Kraft paper, etc.
Software	
Software	LaserGRBL (free), LightBurn (paid)
Operating System	LaserGRBL: Windows Lightburn: Windows, MacOS, Linux
Input Image Format	jpg,bmp,png,dxf,svgai,tiff,etc
Connection type	USB cable, Micro SD Card, Wi-Fi

(2) Components Introduction



(3) Packing List



(4) Machine assembly

The machine step-by-step assembly process is described in the document “LASER B1 Quick Start Guide”. Please follow the guide to assemble machine.

- During the machine assembly, if there is any unclear place, please refer to the video “LASER B1 Quick Start Guide”.
- Each unit of the engraving machine has been inspected and tested. Therefore, in some cases, very small traces may be left on the profile and the metal shell. These will not affect the quality. It is normal that it does not affect normal engraving. Thank you very much for your understanding.
- Be cautious during assembly as some parts may have sharp edges.
- If you have any questions after receiving the product, please contact our customer service first.

INSTALLATION STEPS

1

Prepare:

Left frame, right frame, X-axis frame

Place the left frame, right frame, and X-axis frame as shown, and mount the X-axis frame to the left frame and right frame ▼




2

Prepare:

M5*12 Screws x 4, M5*16 Screws x 4, Front frame, Rear frame

First, pre-lock the M5*12 screws. Then, pre-lock the M5*16 screws. Finally tighten the M5*12 and M5*16 screws ▼




3

Prepare:

Timing belt × 2

Install the belt with the gears facing in and the smooth side facing out ▼




4

Prepare:

Laser module, M3*20 handle screw

First install the laser module on the X-axis frame, then tighten the M3*20 handle screw to fix the laser module ▼





5

Prepare:

Limit Switch × 2, M2*10 Screws × 4


Install X-axis limit switch and Y-axis limit switch ▼



6

Install connection cables


There are 6 cables to be installed, including 2 limit switch cables, 2 motor cables, 1 laser module cable, and 1 adapter board terminal cable ▼



7 Prepare:

Air pump, Silicone Tube, Cable tie, Key

First, install the air pump, silicone tube and connecting cable, then move the laser module to the upper right corner, and fix the silicone tube and connecting cable together with two Velcro tapes on the X axis; then use a cable tie to secure the remaining silicone Tube and cable fastened together again ▼




Tip: After the motor cables are connected, please manually move the X or Y axes slowly and **DO NOT** manually move the axes quickly, otherwise it will cause damage to the motherboard

8

Adjust laser focus

Pull out the focusing block, loosen the M3*20 handle screw, move the laser module down, tighten the M3*20 handle screw when the bottom of the focusing block touches the plywood, and close the focusing block ▼



MORE INFORMATION ▼



Support Email : support@longer3d.com



Facebook ID: longer3dprinter



Facebook Group: Longer Laser Engraver Official Group



Youtube channel: Longer 3D

C. Machine Operation

(1) Power On


- a) Find the adapter and power cable and connect them. Please
Make sure to use DC 24V 5A and 7.5A adapters for 20W and 30W respectively.
- b) Connect the power cord to the power supply and connect the other end of the adapter to the power port of the motherboard.
- c) Connect the computer and the engraving machine through a USB computer (or insert a Micro SD card).
- d) Turn ON your **LASER B1** by press the power switch (To Turn OFF your **LASER B1** by press the power switch once again.)

(2) LaserGRBL Software Operation

LaserGRBL is an easy-to-use and fully free software for laser engraver only running on Windows.

Download


- a) Find LaserGRBL software in attached SD card(path: /software), Or download from the link:
<https://lasergrbl.com/download/>
- b) Double-click the software installation package to start the software instalation, and keep clicking Next>until the installation is complete.




- c) After installing laserGRBL, power up the **LASER B1**, press the power switch button, and connect the laser engraver and computer via USB cable.

Usage


a) Open LaserGRBL, select correct port(depend on your PC), baud rate: 115200. Then click connect button.



b) If you cannot find correct port, please install CH340 driver manually by click Menu >> Tools >> install CH340 Driver to install the driver, and restart the computer after installation to connect.



c) Open file and set parameters




d) Start to engrave


- i. Place a board under the laser, then calibrate the laser.
- ii. Move the laser head to the place you want.
- iii. Click “**Run frame**” button to check the work frame.



- iv. Click  button to start engraving.



- v. Or you can save gcode file to SD card by click “File” >> “Quick Save” for offline working.



More help information about LaserGRBL, please refer to the link:

<https://lasergrbl.com/usage/0>

(3) LightBurn Software Operation


LightBurn is professional software for engraver, a charging software running on Windows, MacOS, and Linux. It provides a trial period.

You could pay for it afterward if you like it.


Setup

- a) Find Lightburn software in SD card(path: /software) came with the package. Or just download from the link:


<https://lightburnsoftware.com/download/>




- b) After installing Lightburn, power up the **LASER B1**, press the Power Switch button, and connect the laser engraver and computer via USB cable.
- c) For the first time launching LightBurn, it will prompt a “New Device Wizard” for help you setup machine.
Click “Create Manually”



d) Select GRBL form the list, then click “Next” button



e) Select Serial/USB and press “Next” button.




f) Fill your Device Name, X, Y axis, then click “Enter” button

Name: **LASER B1**

X = 450

Y = 440

g) Select “Front Left” as your Origin X,Y and activate “Auto ‘Home’”, then click “Next” button.




The automatic home function is turned on by default, if you do not want the engraver to automatically home when power on, it is recommended to turn off this function.


h) Select **LASER B1** and press Make Default. Your **LASER B1** is ready to be used in LightBurn software.

Usage


a) Main interface



b) Select correct port (depends on your PC), then the **LASER B1** is connected to the computer.




- c) Click Menu “File” >> “Import image from disk.” Or just use draw tool on left column to design your own pattern.




- d) Set the name, speed, maximum power, mode, and other parameters in the cutting/layer; (engraving function and cutting function are only different in speed, power. Normally, the cutting speed parameter is slower).
- e) After placing the board under the laser, click **Frame** to check the laser path whether is completely inside of the board.

f) Click “Start” to start to work.





g) Or you can save gcode file to SD card by click “Save GCode” button in Laser panel for offline working



More help information about LightBurn, please refer to the link: <https://lightburnsoftware.com/pages/tutorials>

h) Function description

Cut Setting Editor



Cuts/Layers

The **Cuts / Layers** dialog box is used to manage cutting layers. It features a table with columns: #, Layer, Mode, Spd/Pwr, Output, and Show. The first row shows layer C00 with mode Line, speed 300.0 / 100.0, and both Output and Show checkboxes checked. A context menu for the 'Line' mode shows options: Line, Fill, Fill+Line, and Offset Fill. To the right of the table are buttons for moving layers up/down, deleting a layer, copying settings to cache, and applying cached settings. Below the table are input fields for Layer Color, Pass Count (1), Interval (mm) (0.100), Speed (mm/m) (300), Power Max (%) (100.00), and Power Min (%) (20.00).

Annotations:

- Layer name:** Points to the 'Layer' column header.
- Layer number:** Points to the '#' column header.
- Cutting mode:** Points to the 'Mode' column header.
- Speed/Power:** Points to the 'Spd/Pwr' column header.
- Whether to output:** Points to the 'Output' column header.
- Whether to show:** Points to the 'Show' column header.
- Double click here to set more parameters:** Points to the 'Show' checkbox.
- Move selected cut layer up:** Points to the up arrow button.
- Move selected cut layer down:** Points to the down arrow button.
- Delete selected layer and all content:** Points to the trash icon button.
- Copy the selected cut setting into the cache:** Points to the right arrow button.
- Apply the cached cut setting to the selected cut layer:** Points to the left arrow button.
- Layer color:** Points to the 'Layer Color' input field.
- Pass count:** Points to the 'Pass Count' input field.
- Interval:** Points to the 'Interval (mm)' input field.
- Speed:** Points to the 'Speed (mm/m)' input field.
- Power Max:** Points to the 'Power Max (%)' input field.
- Power Min:** Points to the 'Power Min (%)' input field.


Move

The **Move** dialog box is used to control the movement of the machine. It includes a 'Get Position' button and fields for X, Y, Z, and U coordinates. Below these are 'Move to Position' fields with X and Y values set to 0.00, and a 'Go' button. A 'Saved Positions' dropdown and 'Manage' button are also present. A grid of directional buttons (up, down, left, right, and combinations) is used for XY axis movement control. To the right are input fields for Distance (10.00 mm), Speed (6000 mm/m), and Z-Speed (600 mm/m). At the bottom are buttons for 'Set Origin', 'Clear Origin', and 'Set Finish Position', along with a checkbox for 'Move From Machine Zero'.

Annotations:

- Get current position:** Points to the 'Get Position' button.
- Move to position (input X and Y position values on the right):** Points to the 'Move to Position' X and Y input fields.
- XY axis movement control:** Points to the directional button grid.
- Distance:** Points to the 'Distance' input field.
- Step distance:** Points to the 'Distance' input field.
- XY axis speed:** Points to the 'Speed' input field.
- Z-axis speed:** Points to the 'Z-Speed' input field.
- Set Origin:** Points to the 'Set Origin' button.
- Clear Origin:** Points to the 'Clear Origin' button.
- Set Finish Position:** Points to the 'Set Finish Position' button.
- Move from machine zero:** Points to the 'Move From Machine Zero' checkbox.


Console and Laser



(4) Firmware Upgrading

The Firmware of **LASER B1** is continuously updated for fixing bugs and add new features. The firmware upgrade operations are different for different systems. The detailed tutorial about firmware upgrading is contained in the firmware package.

Install the MKSLaserTool_setup V1.1.2.exe file, click [MKS ESP32 Download Tool](#), select the [right port](#) and .bin update firmware, and click [Start](#), it will prompt firmware successfully flashed after the update is completed.




Copy the [dlc_cfg.txt](#) file from the configuration folder to the root directory of the SD card, insert the SD card into the main board of the engraver, restart the engraver, and the configuration file update will be completed automatically.


(5) APP Operation

LASER B1 can be controlled or engraved through MKSLaser APP when the engraver and APP are connected to the same WIFI.


Open the MKSLaserTool file. Click on the WiFi configuration tool.



Select the correct port. Click connect.



Click Connect and enter the WiFi account and password. Click Connect WiFi. Wait for the word 'ok' to appear in the log below, and click Get IP.



a) How to download the MKSLaser APP

Please search for "MKSLaser" in Google play or app store or visit the address below to download Android system


<https://play.google.com/store/apps/details?id=makerbase.com.mks>

laser


Please search for "MKSLaser" in the app store or visit the address below to download

<https://apps.apple.com/us/app/mkslaser/id1542756280?uo=4&at=11l6hc&app=itunes&ct=fnd> for Apple system

b) Home page about the APP





c) Connect APP to WIFI



When the LASER B1 engraver is connected to wifi, we will get an IP address, click the connect button in the upper left corner of the APP, enter the IP address, and click CONNECT.


d) Enter text or take a photo to engrave






Click [Creation](#), choose free drawing or input text, click [Next](#), adjust the brightness and contrast, click [Next](#), set the size, engraving speed, laser power (such as input 1000 for 100% power, and so on), click [Frame](#) to confirm the engraving range, click [Engrave](#) for working.

For picture, it can click [Creation](#), choose camera or album to take or select a photo, click [Next](#), adjust the brightness and contrast, click [Next](#), set the size, engraving speed, laser power (such as input 1000 for 100% power, and so on), click [Frame](#) to confirm the engraving range, click [Engrave](#) for working. After engraving, click [Confirm](#) to enter the [Graving View](#) to check the engraving progress, adjust parameters, pause or cancel the engraving process.




e) Control the engraver from APP



f) Engrave from SD files

Click [Graving](#) on the home UI, the APP will read the engraving file in the SD card, select the engraving file, click [Frame](#) to determine the engraving range, and click [Confirm](#) to start engraving.

In the [Graving View](#) UI, it can check the engraving progress, adjust speed and laser power, pause or cancel the engraving process.



Note: To use APP for engraving, it needs to insert the SD card into the motherboard firstly to ensure that the data can be received normally; otherwise it will prompt upload error.


g) Control the engraving machine through the web page

 Connect	 Connect
IP Address	IP Address
192.168.43.64	192.168.43.164
CONNECT	DISCONNECT
SEARCH LASER	

When the LASER B1 engraver is connected to wifi, we will get an IP address, click the connect button in the upper left corner of the APP, enter the IP address, and click CONNECT.



Enter the IP address in the browser of mobile phone or computer, then the control interface will pop up.



Click SD File tag, it will change to SD file page. Upload “.gcode/.nc” files generated by “LaserGRBL” or “LightBurn” software.

(6) Air valve instructions

Please note that when the air pump starts, please do not

completely close the air valve switch, otherwise it will damage the equipment.

a) Installation and use of air valve



1. The silicone tube pointed by the first arrow connects the air pump to the air valve.
2. The silicone tube pointed by arrow No.2 connects the air assist nozzle to the air valve.

b) The air valve in the picture is closed




c) Turn the valve switch clockwise 90° to open the valve (as shown below)




Lightburn Software sets air assist method

- a) In the Cut / Layers control bar on the right, turn on the Air Assist indicated by the blue arrow (green means on, red means off, as shown below).




- b) Click Edit to enter device Settings and select M8 (as shown in the picture below).



LaserGRBL Software sets air assist method

- a) Before cutting, enter "M8" in the left control column to turn on the air pump, and after cutting, enter "M9" in the left control column to turn off the air pump.



D.FAQ

Question 1: Are there recommended engraving and cutting parameters?

Please refer to the table “LONGER Laser Engraver Material Profiles” which describes the common materials engraving and cutting parameters for **LASER B1**.

If there is no information you need. Please wait for our updates in the future.

Question 2: The engraved pattern appears vibration, or is not closed?

- Adjust the eccentric nut to make the parts move smoothly without shaking.
- Re-tension the timing belt.
- Adjust the synchronous wheel to prevent the synchronous belt from rubbing against the side of the synchronous wheel during movement.

Question 3: How about the warranty policy?

For LONGER official stores and LONGER designated distributors, **LASER B1** has a One-year International Limited Manufacturer warranty from the date of purchase of **LASER B1**.

Please note the following warranty terms. One-year International Limited Manufacturer Warranty means that LONGER will provide the following free warranty services:

- Diagnostics and Evaluation.
- Technical Support.
- Replacement Parts under Warranty terms.

How to handle a warranty case:

Any warranty case must be submitted to our official support channels (Email: support@longer3d.com). In case the product was bought from a reseller, contact us first so that we can help you diagnose the problem, then turn to your reseller for spare parts if needed.

Documentation needed for a warranty case:

1. Machine purchase order number and channel, nameplate number on the machine.
2. A brief description of the problem along with the clear evidence of its presence (e.g., photos or videos).
3. On the initial contact for customer support further tests and diagnostic steps might be required to identify the cause of the problem.
4. Some parts of the **LASER B1** inevitably “get used up” over time. For these parts, specific conditions apply, unless failure has

occurred due to a defect in materials or workmanship.

Part	Warranty Limitation
Motherboard	One-year International Limited Manufacturer Warranty
Motor	One-year International Limited Manufacturer Warranty
LONGER Laser Module	One-year International Limited Manufacturer Warranty
Touch Screen	One-year International Limited Manufacturer Warranty
Power Adapter	One-year International Limited Manufacturer Warranty
Air Pump	One-year International Limited Manufacturer Warranty
Chrome-Plated Rod	Warranty does not apply on normal wear and tear
2020 Profile	Warranty does not apply on normal wear and tear
Coupling	Warranty does not apply on normal wear and tear
Eccentric Nut	Warranty does not apply on normal wear and tear
Bearing	Warranty does not apply on normal wear and tear
L-Shaped Right-Angle Foot Slot	Warranty does not apply on normal wear and tear
Goggles	Warranty does not apply on normal wear and tear
Brush	Warranty does not apply on normal wear and tear
Board\ Acrylic Board\ Stainless Steel Plate	Warranty does not apply on normal wear and tear
Linear Bearing Wheels	Warranty does not apply on normal wear and tear
GT2 Timing Belts	Warranty does not apply on normal wear and tear
Powder-Coated Aluminum Extrusion	Warranty does not apply on normal wear and tear
Cables & Drag Chain	Warranty does not apply on normal wear and tear
Cosmetic Appearance & Logos	Warranty does not apply on normal wear and tear

Note:

- The warranty does not cover normal, expected wear and tear caused by using the **LASER B1** for its intended purpose.

- In case we have provided a free replacement part, the warranty does not reset. The original warranty period still applies.

This warranty is voided by:

- Any damages caused by improper assembly of the product.
- Any damage caused by improper use, maintenance, or operation of the engraver.
- Any damage caused by long-term lack of maintenance.
- Using the **LASER B1** in improper conditions (temperature, dustiness...).
- Upgrades, modifications, or add-ons that are not officially supported.

Our Technical Support Team is always available to help you out under any circumstances, even if the issue is not covered under warranty.

Question 4: How to maintain LASER B1 laser module?

LASER B1's lasers are carefully designed to resist stains, but after long-term use, there may still be dust and grease on the laser hood, air guide, and even the lens. This will affect the appearance and performance. It is recommended to clean the laser regularly to keep


it in good performance. You need to perform the following steps to clean the laser.

Preparation: hex wrench, non-woven fabric, alcohol/isopropanol solution.

Start:

1. Remove the laser hood and air guide
2. Dip a little alcohol/isopropyl alcohol solution with a non-woven fabric
3. Carefully wipe the laser lens with a non-woven fabric
4. Reinstall the laser hood and air guide

Warning: Excess solution may immerse inside the laser and cause damage to the laser.



LASER B1 laser module


Question 5: How to solve alarm 2 error or hard limit?

ALARM:2

G-code motion target exceeds machine travel. Machine position safely retained. Alarm may be unlocked. (Right-click the 'Devices' button to reset the connection)

On or near line 2:

It adds two limit switch in LASER B1 laser engraver, the firmware has hard limit and soft limit features to locate the laser module position precisely. The position of the laser module is assumed to be the home position by default when powered on. So the engraver will trigger the alarm 2 or hard limit error if the laser head is moved in the X or Y negative direction at this time. Then it needs to home the engraver as shown in the picture below.



Question 6: How to solve the upload error of the APP?

To use APP for engraving, it needs to insert the SD card into the motherboard firstly to ensure that the data can be received normally; otherwise it will prompt upload error.

Thank you for purchasing LONGER products! Under normal usage and service, the products and its parts have a warranty period up to one year. Our professional after-sale service would respond within 24 hours and help you to solve the issues.