



Need help with your appliance?  
Contact our customer service team or visit our website  
for information and tips on getting the most from your appliance.

Australia	New Zealand
Phone 1300 881 861	Phone 0800 786 232
Mail Units 5 & 6, 13 Lord Street, Botany, NSW 2019, Australia	Mail Level 6, Building 5, Central Park, 660-670 Great South Road, Greenlane, Auckland, New Zealand
Visit <a href="http://www.sunbeam.com.au">www.sunbeam.com.au</a>	Visit <a href="http://www.sunbeam.co.nz">www.sunbeam.co.nz</a>

Sunbeam Corporation Limited | ABN 45 000 006 771  
Sunbeam Corporation is a division of GUD Holdings Limited.  
Sunbeam is a registered trademark. Made in China to Sunbeam's specification.  
Due to minor changes in design or otherwise, the product you buy may differ slightly from the one  
shown here. Approved by the appropriate electrical regulatory authorities.  
©Copyright Sunbeam 2015.

## Care and Cleaning

Always turn the power OFF and remove the plug from the power outlet after use and before cleaning your toaster.

### To clean the exterior

Wipe exterior with a slightly dampened cloth and polish with a soft dry cloth.

**Do not use metal scourers or abrasives as this may scratch the exterior surface.**

### Removable Crumb Tray

To remove the crumbs, simply pull off the top of the toaster, empty the tray and place it back under the toaster.

**Important:** Clean the crumb tray regularly. Do not allow crumbs to accumulate, as they may cause a potential fire hazard.

### To clean the toaster interior

Clean inside the toaster regularly. To do this, unplug the appliance, turn it upside down over the sink and gently shake all the crumbs

## 12 Month Replacement Guarantee

Upon receipt of your claim, Sunbeam will seek to resolve your difficulties or, if the product is defective, advise you on how to obtain a replacement or refund.

To assist us in managing warranty claims, we recommend you register your product as soon as practicable after purchase by creating a MySunbeam account on our website and uploading a copy of your original receipt.

In order to make a claim under our warranty, you must have the original proof of purchase documentation for the product and present it when requested (if not already uploaded to our website).

Should your product develop any defect within 12 months of purchase because of faulty materials or workmanship, we will replace or repair it, at our discretion, free of charge. A product presented for repair may be replaced by a refurbished product of the same type rather than being repaired. Refurbished parts may be used to repair the product.

Our replacement or repair warranty only applies where a defect arises as a result of faulty material or workmanship during the warranty period. Your warranty does not cover misuse or negligent handling (including damage caused by failing to use the product in accordance with this instruction booklet), accidental damage, or normal wear and tear.

Your warranty does not:

- cover freight or any other costs incurred in making a claim, consumable items, accessories that by their nature and limited lifespan require periodic renewal (such as filters and seals) or any consequential loss or damage; or
- cover damage caused by:
  - power surges, power dips, voltage supply problems, or use of the product on incorrect voltage;
  - servicing or modification of the product other than by Sunbeam or an authorised Sunbeam service centre;
  - use of the product with other accessories, attachments, product supplies, parts or devices that do not conform to Sunbeam specifications; or
  - exposure of the product to abnormally corrosive conditions; or
- extend beyond 3 months if the product is used in commercial, industrial, educational or rental applications.

The benefits given to you by our warranty are in addition to other rights and remedies under law in relation to the product.

In Australia our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Our goods also come with guarantees that cannot be excluded under the New Zealand Consumer Guarantees Act.


If your warranty claim is not accepted, we will inform you and if requested to do so by you, repair the product provided you pay the usual charges for such repair. You will also be responsible for all freight and other costs.

Should your product require repair or service after the warranty period, contact your nearest Sunbeam service centre. For a complete list of Sunbeam's service centres, visit our website or call our customer service line for advice on 1300 881 861 in Australia, or 0800 786 232 in New Zealand.

Should you experience any difficulties with your product during the warranty period, please contact our customer service line for advice on 1300 881 861 in Australia, or 0800 786 232 in New Zealand.

Australia | [www.sunbeam.com.au](http://www.sunbeam.com.au)  
1300 881 861  
Units 5 & 6,  
13 Lord Street,  
Botany NSW 2019  
Australia

New Zealand | [www.sunbeam.co.nz](http://www.sunbeam.co.nz)  
0800 786 232  
Level 6, Building 5, Central Park,  
660-670 Great South Road,  
Greenlane, Auckland  
New Zealand



## 2 Slice Toaster User Guide

Sunbeam's safety precautions	2
Features of your toaster	3
Using your toaster	4
Toaster functions	4
Toasting tips	5
Troubleshooting guide	5
Care and cleaning	6

## Sunbeam's Safety Precautions

Important Instructions - retain for future use

### SAFETY PRECAUTIONS FOR YOUR SUNBEAM TOASTER.

- Do not place any objects such as toast, bread or similar on top of your toaster when in use.
- Operate the toaster on a flat level surface.
- The bread may burn, therefore do not use the toaster near or below combustible material, such as curtains.
- Do not leave your toaster unattended when in use.
- Clean crumb tray regularly.
- Do not allow crumbs to accumulate in the crumb tray.
- Do not toast stale bread, rice crackers or similar on a high setting as they may catch fire.
- **WARNING:** Never attempt to extract jammed toast, crumpets or muffins with a knife or any other metal object, as contact with a live element may cause electrocution.

Sunbeam is very safety conscious when designing and manufacturing consumer products, but it is essential that the product user also exercise care when using an electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance:


- Read carefully and save all the instructions provided with an appliance.
- Always turn the power off at the power outlet before you insert or remove a plug. Remove by grasping the plug - do not pull on the cord.
- Turn the power off and remove the plug when the appliance is not in use and before cleaning.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by a qualified technician or service person.
- Always use your appliance from a power outlet of the voltage (A.C. only) marked on the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge,

unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- Children should be supervised to ensure that they do not play with the appliance.
- The temperature of accessible surfaces may be high when the appliance is operating.
- Never leave an appliance unattended while in use.
- The heating element surface is subject to residual heat after use.
- Do not use an appliance for any purpose other than its intended use as this may result in potential injury.
- Do not place an appliance on or near a hot gas flame, electric element or on a heated oven.
- Do not place on top of any other appliance.
- Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surface.
- Do not operate any electrical appliance with a damaged cord or after the appliance has been damaged in any manner. If damage is suspected, return the appliance to the nearest Sunbeam Appointed Service Centre for examination, repair or adjustment.
- For additional protection, Sunbeam recommend the use of a residual current device (RCD) with a tripping current not exceeding 30mA in the electrical circuit supplying power to your appliances.
- Do not immerse the appliance in water or any other liquid unless recommended.
- Appliances are not intended to be operated by means of an external timer or separate remote control system.
- This appliance is intended to be used in household and similar applications such as: staff kitchen areas in shops, offices and other working environments; farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments.

If you have any concerns regarding the performance and use of your appliance, please visit [www.sunbeam.com.au](http://www.sunbeam.com.au) or contact the Sunbeam Consumer Service Line. Ensure the above safety precautions are understood.

## Features of your Marc Newson Toaster



### 1. Toast/ Cancel Button

One button control to start and lower your toast. The Toast/Cancel button starts or immediately stops any of the toasting cycles. As a consequence of this, the toast will pop up.

### Defrost Button

The defrost setting ensures bread can be toasted straight from the freezer.

### Reheat

The reheat button toasts for 30 seconds.

### 2. Browning Control

Select your desired browning level.

### 3. Removable Crumb tray

Full length crumb tray for easy crumb removal.

### 4. Cord Storage

The cord can be wrapped around the cord storage facility for convenient storage.

### 5. Self centering slots

Allows bread to always be held in centre of slot to ensure even toasting.

## Using your Marc Newson Toaster

**Before first use, remove any packaging material or promotional labels attached to your toaster.**

1. Insert the power plug into a 220/240 volt power outlet then turn the power on.
2. Place bread into toasting slot. Ensure items for toasting are not too long or too thick to fit in the toasting slots.
3. Select the toast setting by adjusting the BROWNING CONTROL on the front of the toaster. The toast settings range from 'Left' (lightest) to 'Right' (darkest).

To start the toasting process, press the TOAST/CANCEL button. The TOAST/CANCEL button will illuminate and the carriage will automatically lower into the toasting position and start the toasting cycle.

4. Once the toasting cycle has completed and the carriage has risen and locked into the raised position, the toast ready alert will sound. Remove the toast.

**NOTE:** Push the TOAST/CANCEL button during operation to cancel the toasting process or any other function.

## Toaster Functions

### Toast/ Cancel button

The Toast/Cancel button starts or immediately stops any of the toasting cycles. As a consequence of Cancel, the toast will move to the raised position.

### Defrost Feature

The defrost feature can be used to toast your frozen bread. The colour of your toast will brown according to the toasting setting you have chosen. This feature is activated by pressing the frozen button at any time during the toasting cycle.

### Reheat

The reheat button toasts for 30 seconds or raises the toast if the cycle time has exceeded 30 seconds.

## Toasting Tips

- If your bread jams in the toaster, switch power off, remove the plug from the power outlet and ease the bread out of the toaster.
- Ensure muffins or bagels are cut into even halves and fit freely into the bread slot. Do not force them into the toaster.

**WARNING:** Never attempt to extract jammed toast, muffins, bagels or crumpets with a knife or any other metal object, as contact with the live element may cause electrocution.

## Troubleshooting Guide

Problem	Possible Cause	Solution
Unit is not heating or stops heating	Electrical outlet is not working or toaster is unplugged	Check to make sure the outlet is working. Unplug unit and re-insert plug. Test toaster by selecting a setting and depressing the toast control level with nothing in the toaster
Uneven toast	Toasting single slice or toasting brown bread	Simply reset the selector to the desirable setting
Second toasting is too dark	Setting on toast is too dark.	If doing repeated toasting in the toaster, you may want to select a setting lower than the previous setting
Toast is too light or too dark	You may have changed the setting	Simply reset the selector to the desirable setting for the function you wish to use
You smell burnt food or smoke is coming out when toaster is being used	Remnants of food in crumb tray.	Refer to the directions in CARE AND CLEANING section of this booklet. Make sure the crumb tray is empty and wiped clean. Check to make sure no large crumbs are caught in the slot.  Refer to the directions in CARE AND CLEANING section of this booklet. Make sure the crumb tray is empty and wiped clean. Check to make sure no large crumbs are caught in the slot.  Turn unplugged unit upside down over the sink and shake to remove crumbs.