




# High Efficiency Dryer

(Condensing)

Model - CD 4040 W/T/MB



## OWNER'S MANUAL

|                                                                                    |                                        |                                                                                                                      |
|------------------------------------------------------------------------------------|----------------------------------------|----------------------------------------------------------------------------------------------------------------------|
|  | <b>DO NOT RETURN TO STORE!</b>         |  <b>1-800-776-3538</b>            |
|                                                                                    | <b>HAVE QUESTIONS OR NEED SERVICE?</b> |  <b>Service@ApplianceDesk.com</b> |

Read the instructions carefully and keep for future reference. Information maybe updated from time to time so please refer to the website for the latest version of the manual.

## WARRANTY INFORMATION

**Your appliance is protected by this warranty under normal, personal, family or household use for 2 Year Parts & Labor and limited commercial use (90 days) in USA and Canada.**

### WARRANTY

Conserv Appliances undertakes to the consumer/owner to repair or, at our option, to replace any part of this product which proves to be defective in workmanship or material under normal personal, family or household use in USA and Canada, for a period of two years parts & labor from the date of original purchase. For commercial use, the product is warranted for a period of 90 days.

During this period, we will provide all labor and parts necessary to correct such defect, free of charge, if the appliance has been installed and operated in accordance with the written instructions provided with the appliance. Ready access to the appliance, for service, is the responsibility of the consumer/owner. If unit installed in closet or cabinet, it should be removed for access by service technician. If this cannot be done, then there will be extra charge.

We may require return of products or parts to our warranty department for which the shipping charges are to be incurred by the consumer. If a return or replacement is required, allow 3-4 weeks to process. If unit is located more than 25 miles there will be a trip charge. If unit is in remote area more than 75 miles, customer will need to take the product to the technician's workshop. Replacement unit will be delivered with curb side delivery only. If Unit is installed in a 5th wheel RV, in a location behind the axle it won't be covered under warranty.

All repairs or replacements are warranted only for the remainder of the original warranty period. Charges may incur if warranty coverage is not applicable. Service would be provided from Monday to Friday between normal business hours.

### GENERAL

Since it is the responsibility of the consumer/owner to establish the warranty period by verifying the original purchase date, Conserv Appliances recommends that a receipt, delivery slip or some other appropriate payment record be kept for that purpose. This warranty gives you specific legal rights, and you may also have other rights which vary from State to State.

You can register your Warranty by either of the following methods:

1. Scan QR Code
  - Open Smart Phone
  - Open Camera
  - Click the Link
2. Register online at [ApplianceDesk.com/Warranty](https://ApplianceDesk.com/Warranty)



**Note: QR Code is also used to obtain Product Information, Manuals and Updates**

### WARRANTY SERVICE

This warranty is given by:

**Conserv Appliances**  
5006 Steffani Lane,  
Houston, TX 77041

#### QUESTIONS / SERVICE

Phone/Text: 1-800-776-3538  
Email: [Service@ApplianceDesk.com](mailto:Service@ApplianceDesk.com)  
Web: [www.ApplianceDesk.com](http://www.ApplianceDesk.com)

## Exclusions

---

In no event shall Conserv Appliances be liable for incidental or consequential damages or for damages resulting from external causes such as abuse, operation misuse, neglect, alterations, normal wear and tear, incorrect voltage or acts of God. This warranty does not cover service calls which involve defective workmanship, damage due to other products while combined use with this product or materials covered by this warranty. Accordingly, diagnosis and repair costs for a service call which involves defective workmanship or materials will be the responsibility of the consumer-owner.

Most work is covered. The defining factor is has the appliance malfunctioned (Conserv Appliances is responsible) or has the customer omitted or done something to cause malfunction (customer is responsible).

---

### THE FOLLOWING WORK ARE NOT COVERED UNDER WARRANTY:

---

#### Installation

1. Non-removal of shipping bolts, causing vibration, resulting in internal damage.
2. Non-adjustment of feet to level machine, causing vibration, resulting in internal damage.
3. Not conforming to minimum space requirements for built-in installation, causing excess heat and resulting in damage to internal components.
4. Installation in a corrosive environment.

#### Maintenance

1. Non-cleaning of lint filters and condenser.
2. Non-cleaning of vent fan & exhaust hose for lint, causing the unit to not dry properly.
3. Improper maintenance (such as, but not limited to, scale build-up, freeze damage, or vent blockage).

#### Damage

1. Breakage of cosmetic parts e.g., door handle, knob.

#### Other

1. Accident, abuse or misuse.
2. Using solvents to clean the machine causing damage.
3. Misapplication of this product e.g., use in a non household/commercial environment.
4. Any other cause not due to defects in materials or workmanship.
5. Problems or damage due to fires, flooding, electrical surges, freezing or any acts of God.
6. Force majeure.

## Warranty Limitations

1. If a unit is located more than 25 miles away, there will be a trip charge.
2. If a unit is in a remote area more than 75 miles away, the machine should be taken to the technician's workshop.
3. All repairs or replacements are warranted only for the remainder of the original warranty period.
4. If a return or replacement is required, allow 3-4 weeks to process.
5. Replacement units will be delivered with curbside delivery only.
6. We may require the return of products or parts to our warranty department for which the shipping charges are to be pre-paid by the consumer / owner.
7. Charges may be incurred if warranty coverage is not applicable.
8. Service would be provided from Monday to Friday between normal business hours.

## GENERAL

---

Since it is the responsibility of the consumer / owner to establish the warranty period by verifying the original purchase date, Consolidated Brands recommends that a receipt, delivery slip or some other appropriate payment record be kept for that purpose. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

All rights reserved. Manual subject to change without notice.

## California Proposition 65

**WARNING:** This product contains chemical known to the State of California to cause cancer and birth defects or other reproductive harm.



# Table of Contents

|                                            |           |
|--------------------------------------------|-----------|
| <b>Safety</b>                              | <b>1</b>  |
| <b>Installation</b>                        | <b>4</b>  |
| <b>Electrical Connection</b>               | <b>5</b>  |
| <b>Connection to Water Outlet</b>          | <b>8</b>  |
| <b>Connecting the Water Discharge Hose</b> | <b>8</b>  |
| <b>Operations</b>                          | <b>9</b>  |
| <b>Control Panel</b>                       | <b>9</b>  |
| <b>Program Dial</b>                        | <b>10</b> |
| <b>Dry Programs Table</b>                  | <b>11</b> |
| <b>Display Panel</b>                       | <b>12</b> |
| <b>Maintenance</b>                         | <b>14</b> |
| <b>Troubleshooting</b>                     | <b>16</b> |
| <b>Technical Specifications</b>            | <b>17</b> |
| <b>Error Codes</b>                         | <b>18</b> |

# SAFETY

## Your safety and the safety of others are very important.

Please read and follow the important safety warnings in this manual and on your appliance.



Danger indicates a hazardous situation that, if not avoided, will result in death or serious injury.



Warning indicates a hazardous situation that, if not avoided, could result in death or serious injury.



Caution indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

To reduce the risk of fire, electric shock, or injury to persons when using your appliance, always follow basic precautions.

### **WARNING Risk of Fire**

- Do not wash items that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances, as they give off vapors that could ignite or explode.
- Do not add gasoline, dry-cleaning solvents, or other flammable or explosive substances to the wash water. These substances give off vapors that could ignite or explode.
- Do not store flammable liquids near the appliance.
- The sulfur content of paint removers may cause corrosion. Never use paint removing materials in the appliance.
- Never use products that contain solvents in the appliance.
- Please ensure that items loaded into your appliance do not have plastic, metallic, or sharp objects such as pins, keys, or coins.
- Do not tamper with controls.
- Do not repair or replace any part of the appliance or attempt any servicing unless specifically recommended in the manual or in published user-repair instructions that you understand and have the skills to carry out.
- To reduce the risk of electric shock, disconnect this appliance from the power supply before attempting any maintenance. Turning the controls to the OFF position does not disconnect this appliance from the power supply.

## **WARNING** Risk of Burns

Do not touch the drain hose or any discharged water while your appliance is running. The high temperatures pose a burn risk.

### **Risk of Injury or Death from Electrical Current**

- Do not connect your appliance to the mains electricity supply using an extension cord.
- Do not insert a damaged plug into a socket.
- Never remove the plug from the socket by pulling the cord. Always hold the plug.
- Never touch the power cord/plug with wet hands as this could cause a short circuit or electric shock.
- Do not touch your appliance if your hands or feet are wet.
- A damaged power cord/plug can cause fire or give you an electric shock. A damaged cord or plug must be replaced by a qualified technician.
- Connect to a dedicated circuit.

### **Risk of Falling and Injury**

- Do not climb on your appliance.
- Do not reach into the appliance if the drum is rotating.
- Ensure hoses and cables are secured and do not present a tripping hazard.
- Do not turn your appliance upside down or on its side.
- Do not lift your appliance using the door.
- The appliance must be carried by at least 2 people.

## Child Safety

- The appliance is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children of less than 3 years should be kept away unless continuously supervised.
- Do not leave children unattended near the appliance. Children might lock themselves in the appliance resulting in risk of death.
- Children should not play with the appliance.
- Cleaning and maintenance should not be done by children.
- Do not allow children to touch the glass door during operation. The surface becomes extremely hot and may cause damage to skin.
- Poisoning and irritation may occur if detergent and cleaning materials are consumed or come into contact with the skin and eyes. Keep cleaning materials out of the reach of children.
- Keep packaging material away from children. The packaging of the appliance could be hazardous to children. Do not allow children to play with the packaging or small parts from the appliance.
- Keep the packaging materials in a place where children cannot reach them or dispose of them appropriately.
- Before the appliance is removed from service or discarded, remove the door to prevent child entrapment.

## Safe disposal

Dispose off this appliance in accordance with local regulations.

## Installation

Please check the packaging of the washer and the outer surface of the washer once the packaging has been removed. Do not operate the washer if it appears damaged or if the packaging has been opened.

Your dryer must only be installed by an authorized service agent.

- The operating temperature of the dryer is 41°F to 95°F.
- Do not install or store this dryer where it will be exposed to the weather or outdoors.
- Install your dryer in a location that can be fully ventilated and preferably has constant air circulation.
- Do not install the dryer on a carpet or surfaces that would prevent the ventilation of its base.
- Ensure that the door of your dryer is not restricted and can be opened fully.
- To ensure silent and vibration-free operation of the dryer place the dryer on a flat, smooth and firm surface. Ensure the back of the dryer is against a wall.

## Leveling

- Level your dryer using the adjustable feet. Never insert cardboard, wood or other similar materials under the washer to level it.
- To increase the height of the dryer, turn the feet clockwise. To decrease the height of the washer, turn the feet counterclockwise.
- Once the dryer is level, tighten the locking nuts by turning them clockwise.

## Under Counter Installation

- Leave at least 1 inch (3 cm) of space between the side and rear walls of the product and the underside of the counter top when installing your dryer under a counter.
- Assembly / disassembly under the counter must be done by an authorized technician.

## Stacking kit

If you are going to place the dryer above the washer, you must obtain a stacking kit that is specific for this model of dryer from Customer Service.

Do not place the washer above the dryer.

## Electrical Connection

**⚠ ATTENTION:** There is risk of fire and electric shock.

- Your Dryer is set to 208-240V and 60Hz.
- The mains cable of the dryer is equipped with a special plug. This plug must be connected to a grounded socket protected by a fuse of 30 Amperes as indicated on the type plate. The fuse current rating of the power line where the outlet is connected must also be 30 Amperes. Consult a qualified electrician if you do not have such an outlet or fuse.
- Our company cannot be held responsible for damages resulting from usage without grounding.



4-Prong Plug

## Power Supply

The Dryer must be connected to an individual circuit identical to the specified on the rating plate of the loading port protected by fuses or circuit breaker conforming to local codes.

**ⓘ IMPORTANT:** Operating your dryer at low voltage values will shorten the service life and decrease the performance of your machine.

## Electric Installation


- The clothes dryer installation must be performed by a qualified installer.
- Install the appliance according to the manufacturer's instructions and local codes.
- To reduce the risk of severe injury or death, follow all installation instructions.
- Do not use adaptors or extension cords since they could result in overheating and burn out.

## 4- Wire Power Supply Cord Connection


**▲WARNING** Before making the connection, disconnect the power.  
Use UL listed 240V / 30A power supply cord.

Your dryer was equipped with strain relief. Use this strain relief in connection.


1. Remove the screw and terminal box cover.




2. Remove the clamp of the strain relief which has already attached on your machine. Then pass the clamp through the supply cord and put the supply cord through the main body of the strain relief. Be sure that wire insulation of the cord inside the strain relief.



3. Remove the terminal block screws which are indicated by A and grounding screw which is indicated by B. Neutral ground conductor (central terminal) is provided in the dryer as a closed loop.



4. Connect the ground conductor (green wire) under the terminal B. Then connect the neutral wire (white wire) to center of the terminal. Neutral ground conductor of the dryer should remain on the center terminal. Be sure that neutral ground conductor of dryer and neutral wire of supply cord connected to center terminal together. Tighten all screws.
5. Connect remaining wires under the outer terminals of the block and tighten all screws. After every connection is completed, tighten strain relief clamp in order to secure the supply cord. Finally, cover up the box cover.




## Connection to Water Outlet (with optional drain hose)

Water accumulates in the water tank during the drying process. You must empty the accumulated water after each drying process. Instead of periodically emptying the water tank, as an option, you can also use a drain hose to directly drain the water outside.

### Connecting the Water Discharge Hose

1. Pull and take out the end of the hose at the back of the dryer. Do not use any tools to take out the hose.
2. Fit one end of the water discharge hose, which is provided with the product, to the slot from which you have removed the hose.
3. Fix the other end of the water discharge hose directly to the water outlet or sink.



**⚠ ATTENTION:** The hose must be connected in a manner that it cannot be displaced. If the hose comes out during water discharge, there might be flooding.

**👉 IMPORTANT:** The water discharge hose must be installed at a height of 31 inch (80 cm) maximum.

**👉 IMPORTANT:** Ensure that the water discharge hose is not bent, twisted or obstructed in any way.


## Operations

**WARNING** - To reduce the risk of fire, electric shock, or injury, read **IMPORTANT SAFETY INSTRUCTIONS** before operating the dryer.

**Ensure the Dryer is plugged in correctly.**

**Ensure that children and pets have not climbed into the appliance and keep them away from the appliance when it is in use.**


### Control Panel



- Please ensure that items loaded into your dryer do not have objects such as lighters, keys, coins, etc.
- Dry the same type of materials together in a load.
- Shake out and load each item of laundry separately (it will enhance drying).
- Close zips, fasten any hooks and place small or delicate items in a net bag.
- Reverse items such as printed t-shirts and items that have embroidery, sequins, etc.
- Do not overload the dryer. You should be able to comfortably place your hand above the loaded laundry, ensuring there is enough space for the clothes to tumble, allowing air flow to dry the clothes properly.
- Check that no items of laundry are trapped between the rubber seal and the door.
- Gently push the door until it clicks shut. Ensure the door is fully closed, otherwise the program will not start.

**Do not open the door while the dryer is in operation. If you have to open it, press the Start/Pause key and then open it. Close the door quickly and restart the program by pressing the Start/Pause key again.**

## Program Dial



- The Program Dial should be in the Off position (no lights will appear around the dial).
- To select the desired program, turn the Program Dial either clockwise or counterclockwise until the light next to the selected program illuminates and you hear a beep.
- Ensure the display panel is illuminated with the default features.
- If the above does not happen, then turn the Program Dial to the Off position, and select the program again.
- **The dry program is successfully selected when the light on the dial next to the program is illuminated and the Display Panel is also illuminated with the default features.**
- Refer to the Dry Programs Table as a guide to select programs.
- For all programs there are default factory settings. Depending on the specific program, some features can be changed and options added.

## Dry Programs Table

| Program      | Load Descriptions                   | Spin Speed | Temp.* (Default) | Time (Mins) |
|--------------|-------------------------------------|------------|------------------|-------------|
| NORMAL       | Mixed clothes (shirts, pants, etc.) | 1000       | High             | 158         |
| Outdoor      | Jackets                             | 800        | Med              | 43          |
| Towels       | Thick towels, cottons               | 1000       | High             | 71          |
| Mix          | Mixed fabrics                       | 1000       | Med              | 81          |
| Warm Refresh | Woolens, refresh all types          | -          | Low              | -           |
| Air Fluff    | All types (refresh with no hot air) | -          |                  | -           |
| Time Drying  | All types (10-150 mins)             | -          | Low              | -           |
| Sanitize     | All types                           | 1000       | High             | 59          |
| Baby Care    | Delicate baby clothes               | 1000       | Med              | 68          |
| Delicates    | Silks, light fabrics                | 600        | Low              | 41          |
| Perm Press   | Cotton blends                       | 800        | Med              | 61          |
| Sheets       | Bedsheets, linen                    | 800        | Low              | 127         |
| Sportswear   | T-shirts, leggings                  | 800        | Med              | 53          |
| Express 29'  | Light fabrics                       | 1200       | High             | 29          |
| Shirts 12'   | Light fabrics, shirts (damp dry)    | 1200       | Med              | 12          |

\*Temperature can be changed depending on the dry program.

### Normal Program


The Normal program uses a sensor dry function which monitors the moisture in the clothes and adjusts the dry time. When you start this program, the time on the Display Panel will show 158 minutes. However, depending on the load and the drying process, the time can be decreased significantly, and the dryer will run only long enough to dry the clothes and then stop.

Normal cycle was used to rate the dryer for energy efficiency. The normal cycle defaults to regular drying level and high temperature setting.

This product meets the ENERGY STAR® guidelines for energy efficiency.

Cycles with the low heat setting save the most energy. Use the low heat setting for auto dry cycles without any level adjust to save on energy and prevent over drying your clothing.

## Display Panel



## Display Panel and Features

Once the dry program has been selected, there are additional features and options that can be changed or added to the program. It is not necessary to select additional functions and options. You can simply select the dry program on the Program Dial and then press the Start key and the dry cycle will begin with the pre-programmed default settings.

**Note:** Each dry program has a different set of features and options. Depending on the dry program selected, not all features and options are available.

### Delay ⌚

Press this key to delay the start of the dry program. The time icon  and the delay time (1h) will appear on the Display Panel. Each time you press the Delay key, the time will increase in one-hour increments from 1 to 23 hours. Press the Start key to activate the program.

To cancel the delay, press the Delay key until it passes 23h or turn the Program Dial to Off and select the dry program again.

### Drying Level

To change the drying level from the default, press the Drying Level key to select from 3 levels and the selection will illuminate on the Display Panel: Extra, Regular, or Damp.

## Level Adjust

To get clothes even more dry, press the Level Adjust key to select +1, +2 or +3 and the selection will illuminate on the Display Panel.

### Time Drying

This key can only be used when the Time Drying program has been selected. Press the Time Drying key to select the number of minutes to dry clothes: 10, 30, 60, 90, 120 or 150.

## Temp

The default maximum temperature for the dry program selected will be illuminated on the Display Panel. To change the level of hot air, press the Temp. key to select from High, Medium, and Low. (Not all may be displayed.)

|                                                                                                      |                                                                                                                                                                                                                                                           |
|------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Options</b>                                                                                       | Press the Options key to select Delicate drying  . The Delicate option lets the dry program run at low temperature and for a longer period of time.                       |
| <b>Anti wrinkle</b>                                                                                  | This is a default function that rotates the drum after the dry program ends, thereby eliminating wrinkles. Depending on the Dry Program, the anti wrinkle feature will operate for either 60 or 120 minutes. The icon illuminates on the Display Panel.   |
| <b>Child Lock </b>  | Press the Options and Anti wrinkle keys simultaneously for at least 3 seconds until “CL” flashes on the Display Panel for 2 seconds and child lock is activated. Follow the same procedure to deactivate child lock and CL will disappear from the panel. |
| <b>Cancel beep </b> | At the end of each dry program the dryer will sound a beep to let you know the program has ended. Should you want to silence the beep, it can be cancelled by pressing the Anti wrinkle key for 2 seconds.                                                |
| <b>Start/Pause</b>                                                                                   | Press this key to start the dry program. When the cycle has already begun, press it again to pause the program. When the cycle ends, a beep will sound and End will show on the Display Panel.<br>(After some time the Display Panel will go blank.)      |

**Alert Indicators:** Alert icons illuminate on the Display Panel that remind you to perform specific maintenance activities:

- Empty the water tank 
- Clean lint filter 
- Clean condenser 

**Drying Status:** These icons indicate the drying status.






Drying
Damp Dry
Regular dry
End

**Energy Consumption Display**



The energy consumption display shows the energy consumption of the selected program. The bigger the display, the more the energy consumption. The energy consumption level increases or decreases depending on the fabric type, duration of the selected program, the drying level and the spinning speed.




## Maintenance

**ⓘ IMPORTANT:** Do not use industrial chemicals to clean your dryer.

### Cleaning the Lint Filter


**ⓘ IMPORTANT:** DO NOT FORGET TO CLEAN THE LINT FILTER AFTER EACH USE.




To clean the lint filter:

1. Open the door.
2. Pull up the lint filter to remove it.
3. Use your hands or a soft cloth to clean the lint.
4. Close and replace the lint filter.

Periodically remove and wash the filter with warm water and thoroughly dry it before reinstalling it.



### Emptying the Water Tank




1. Pull out the drawer cover and carefully take out the tank.
2. Empty the water from the tank in the sink.
3. If there is lint accumulated on the discharge cap in the tank, clean it with water.
4. Replace the water tank.

**ⓘ IMPORTANT:** Never remove the water tank when the program is running. The water condensed in the water tank is not suitable for human consumption.

**ⓘ IMPORTANT:** DO NOT FORGET TO EMPTY THE WATER TANK AFTER EACH USE.

## Cleaning the Condenser


**👉 IMPORTANT:** Clean the condenser once a month.



Wait for the dryer to cool down before cleaning the condenser.

1. Open the plinth and release the 2 cover locks of the condenser.
2. Hold the condenser by the plastic part and pull it out.
3. Clean it with a showerhead and wait for the water to drain off.
4. Fully insert the condenser into its seat and lock the 2 locks.
5. Close the plinth cover.

## Cleaning the Moisture Sensor and Door



Inside the dryer, there are moisture sensors that detect whether the laundry is dry.

To clean the sensors:

1. Open the door.
2. If the dryer is still hot due to the drying process, wait for it to cool down.
3. Using a soft cloth soaked in vinegar, wipe the metal surfaces of the sensor and dry them.

**👉 IMPORTANT:** CLEAN THE METAL SURFACES OF THE SENSORS EVERY QUARTER.

Do not use metal tools to clean the metal surfaces of the sensor and the door.

Clean the door including the inner surfaces and the gasket with a soft, damp cloth.

**⚠ WARNING:** Due to the risk of fire and explosion, do not use solution agents, cleaning agents or similar products when cleaning the sensors.

## Troubleshooting

In most cases, when your Dryer fails to work, the problems arising can be easily solved without having to call for a technician. Before calling for assistance, always check these points.

| PROBLEM                                                                                                      | POSSIBLE CAUSE                                                                                                                                                                | SOLUTION                                                                                                                               |
|--------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| The drying process takes a long time.                                                                        | The surface of the lint filter might be clogged.                                                                                                                              | Wash the filter with lukewarm water.                                                                                                   |
|                                                                                                              | The condenser might be clogged.                                                                                                                                               | Clean the condenser.                                                                                                                   |
|                                                                                                              | The ventilation grills in front of the machine might be closed.                                                                                                               | Open the doors/windows to prevent the room temperature from rising too much.                                                           |
|                                                                                                              | There might be a layer of limescale on the humidity sensor.                                                                                                                   | Clean the moisture sensor.                                                                                                             |
|                                                                                                              | The dryer might be overloaded with laundry.                                                                                                                                   | Do not overload the dryer.                                                                                                             |
|                                                                                                              | The laundry might be insufficiently spun.                                                                                                                                     | Select a higher spin speed on your washing machine.                                                                                    |
| Laundry comes out damp at the end of the drying process.                                                     |  The laundry that comes out hot at the end of the drying process generally feels more humid. |                                                                                                                                        |
|                                                                                                              | The program used might not be suitable for the type of laundry.                                                                                                               | Check the care labels on the laundry items, select a suitable program for the type of laundry and additionally, use the time programs. |
|                                                                                                              | The surface of the lint filter might be clogged.                                                                                                                              | Wash the filter with lukewarm water.                                                                                                   |
|                                                                                                              | The condenser might be clogged.                                                                                                                                               | Clean the condenser.                                                                                                                   |
|                                                                                                              | The dryer might be overloaded with laundry.                                                                                                                                   | Do not overload the dryer.                                                                                                             |
|                                                                                                              | The laundry might be insufficiently spun.                                                                                                                                     | Select a higher spin speed on your dryer.                                                                                              |
| The dryer cannot be opened or the program cannot be started. The dryer does not get activated when adjusted. | The dryer might not be plugged in.                                                                                                                                            | Make sure that the plug is fitted in the socket.                                                                                       |
|                                                                                                              | The door might be open.                                                                                                                                                       | Make sure that the door is properly closed.                                                                                            |
|                                                                                                              | You might not have set a program or pressed the Start/Pause key.                                                                                                              | Make sure that the program has been set and the dryer is not in the Standby (Pause) mode.                                              |
|                                                                                                              | Child lock might be active.                                                                                                                                                   | Deactivate the child lock.                                                                                                             |
| The program has been interrupted for no reason.                                                              | The door might not be closed properly.                                                                                                                                        | Make sure that the door is properly closed.                                                                                            |
|                                                                                                              | There might have been a power failure.                                                                                                                                        | Press the Start/Pause key to start the program.                                                                                        |
|                                                                                                              | The water tank might be full.                                                                                                                                                 | Empty the water tank.                                                                                                                  |
| Clothes have shrunk, felted or deteriorated.                                                                 | The program used might not be suitable for the type of laundry.                                                                                                               | Check the care labels on the laundry items, select a suitable program for the type of laundry.                                         |

| PROBLEM                                                                                | POSSIBLE CAUSE                                                                                                   | SOLUTION                                                                                  |
|----------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|
| Water leaking from the door.                                                           | There might be lint accumulated on the inner surfaces of the door and on the surfaces of the gasket of the door. | Clean the inner surfaces of the door and the surfaces of the gasket of the door.          |
| The door opens on its own.                                                             | The loading door might not be closed properly.                                                                   | Push the loading door until you hear the closing sound.                                   |
| The water tank warning symbol is on/flashing.                                          | The water tank might be full.                                                                                    | Empty the water tank.                                                                     |
|                                                                                        | The water discharge hose might be bent.                                                                          | If the product is connected directly to the water outlet, check the water discharge hose. |
| The condenser cleaning warning symbol is on.                                           | The condenser might be unclean.                                                                                  | Clean the condenser.                                                                      |
| The filter cleaning warning symbol is on.                                              | The lint filter might be unclean.                                                                                | Clean the filter.                                                                         |
|                                                                                        | The filter seat might be clogged by lint.                                                                        | Clean the filter seat.                                                                    |
|                                                                                        | There might be a layer that causes obstruction on the surface of the lint filter.                                | Wash the filter with lukewarm water.                                                      |
| The program can not be started and the filter warning led is blinking                  | The filter seat might be clogged by lint.                                                                        | Clean the filter seat.                                                                    |
|                                                                                        | There might be a layer that causes obstruction on the surface of the lint filter.                                | Wash the filter with lukewarm water.                                                      |
|                                                                                        | The condenser may not be placed.                                                                                 | Replace the condenser.                                                                    |
| The program can not be started and both condenser and filter warning leds are blinking | The condenser and filter may not be placed.                                                                      | Replace the filter and condenser.                                                         |
|                                                                                        | The filter and condenser warning leds are blinking even though the filter and condenser are placed.              | Call technical service.                                                                   |

## Technical Specifications

|                                       |                    |
|---------------------------------------|--------------------|
| <b>Brand</b>                          | Conserv            |
| <b>Model Name</b>                     | CD 4040            |
| <b>Product Dimension (HxWxD) inch</b> | 33.3 x 23.5 x 24   |
| <b>Door Open Depth</b>                | 43 inch (1090 mm)  |
| <b>*Capacity (max.)</b>               | 19.84 lbs (9 kg)*  |
| <b>Net Weight (with glass door)</b>   | 75.61lbs(34.3 kg)  |
| <b>Voltage / Power</b>                | 208-240 V / 2700 W |

\*Dry laundry weight before washing.

 **IMPORTANT:** To improve the quality of the dryer, technical specifications are subject to change without prior notice.

 **IMPORTANT:** The values declared have been obtained in a laboratory environment according to the relevant standards. These values may change depending on the environmental conditions and use of the dryer.

## Error Codes

The Dryer is equipped with a built-in fault detection system.

The Error Code flashes on the Display Panel.

The most common error codes are listed below.

| Error Codes                                                                              | Possible Cause                                                                                                                                          | Solution                                                                                                                                        |
|------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| E00                                                                                      | T2 and T3 Touch UI card does not receive communication from main board.                                                                                 | Fix the connection. If connection is good, and error persists, change UI card. If error continues, change main board.                           |
| E03<br> | Aqua switch connector is disconnected.<br><br>Faulty cable harness                                                                                      | Empty the water tank.<br>Connect the aqua switch or if problem continues, change aqua switch.<br><br>Change cable harness.                      |
| E04                                                                                      | Heater is not connected correctly.<br>Measured resistance values through the heater connector are not correct.<br>Disconnect between e-card and heater. | Fix heater connections.<br>Change heater.<br><br>Change main board or cable/wiring harness.                                                     |
| E05                                                                                      | Heater NTC connector may be disconnected.                                                                                                               | Connect Heater NTC.<br>Check cable/wiring harness.<br>Check NTC resistance values and change heater or main board.                              |
| E06                                                                                      | Door NTC connector is disconnected.<br><br>Door NTC short circuit.                                                                                      | Connect Door NTC.<br>Check cable/wiring harness.<br><br>Check door NTC resistance values and change door NTC or main board.                     |
| E08                                                                                      | Voltage fluctuation.                                                                                                                                    | There may be voltage fluctuation in mains. Wait until voltage is appropriate for working range.<br><br>If the voltage is ok, change main board. |

An authorized service technician should make the repairs for these errors.

A separate service manual provides detailed instructions on how to correct the problems. Please contact customer service.

