


KETELESE Portable Glass Speaker



Novel Engineering glass speaker

Why we Choose glass?



It is from a large amount of research data and patent authorization

Novel Engineering glass:

Natural and authentic sound has always been our attempt and pursuit to bring people a comfortable hearing, using thin and tough glass (amorphous SiO_2) as a sound radiation film for various traditional and novel speaker driver designs. In this way, the performance of the speaker can be greatly improved, and we hope that this new product can also bring you a different feeling



Tech Support Service

Please contact us immediately if you need any tech support service and have any after-sale problems. We will give feedback to you within 24 hours.



ktls004@shineconn.net
www.ketelese.com

After-sales service and support

Warranty Period

15 months from the date of purchase of the product.


Free service

During the product warranty period, if the product quality problem causes the failure, get in touch with the dealer according to the manual to enjoy free maintenance.

The following conditions are not warranted

1. The product repair label has been damaged;
2. Damage caused by self-disassembly;
3. Failure caused by falling and man-made mechanical damage;
4. Failure or damage caused by force majeure such as natural disasters.
5. Damage caused by incorrect usage method, violation of operations including but not limited to the product manual.


Please read this manual carefully before using the product and keep it properly.



- ① Power Switch
- ② Pause/Play
- ③ VOL-
- ④ VOL+
- ⑤ Lighting
- ⑥ Next
- ⑦ Previous
- ⑧ Mode
- ⑨ CD In&Out bin/EQ Button
- ⑩ Flashlight

Bright side of CD orient to the front of speaker





⑪ Drive Beast

⑫ TF Card

⑬ AUX

⑭ USB A

⑮ TYPE-C

Operations

- 1. Plug in DC Power Supply to charge** 
The red light flashes for every 1 second when plug in power supply and start charging. When it is fully charged, red light stays on. It supports charging during using.
- 2. Power ON/OFF**  
Press and hold the “Power” button for 3 seconds to power on or power off. Will hear sound playing “Power on” or “Power off”.
- 3. Play/Pause Button**   
Please note that short press the play/pause button is play/pause function with sound playing “Play” or “Pause” under the mode of below: Bluetooth connection/CD mode/TF mode/USB mode insertion status detection.
Under TWS mode: press and hold play/pause button for 3 seconds to activate TWS search function or disconnect TWS.
Under FM mode: When the desired station is found, short press the play/pause button to manually store the function.
- 4. Volume +/- Button**  

Short press to adjust the volume for each level, long press to quickly adjust.

5. Lighting Button

Adjust the brightness of the lighting: short press the button to switch between weak, medium, strong and off. Press and hold the button for 3 seconds to quickly turn off the lights.

6. Next/Previous Buttons

Please note that the next/previous functions available only under below modes: Bluetooth connection/CD mode/TF mode/USB mode insertion status detection.

Next music: short press next button.

Previous music: short press previous button.

FM mode search: Enter FM mode, press and hold next/previous button for 3 seconds to automatically search stations backward/forward, short press to manually fine tuning.

7. Mode Switching Button

Short press the mode switching button to switch between BT/USB/TF/CD/AUX/FM mode.

Bluetooth disconnection: Long press the mode switching button for 3 seconds to disconnect/reset Bluetooth and will have sound playing "Bluetooth disconnected".

8. CD in/out button **CD**

Short press this button to let CD in or out.

Press and hold this button for 3 seconds to select indoor or outdoor mode.

9. Flashlight Button

Adjust the brightness of the flashlight: short press the button to switch between weak, medium, strong, burst and off. Press and hold the button for 3 seconds to quickly turn off the flashlight.

10. Drive the Beast Button

Short press this button to turn on or off the animal repellent effect. If on, will have loud and noisy sound with flashing light to drive the beast.

Scenarios

Scenario 1. Music Mode

1. Short press the mode switch button to switch to Bluetooth mode. Will have sound playing "Bluetooth mode" and display BE and  flashing.
2. Turn on your phone's Bluetooth and search for the device. Click on "DK21" to pair. Will have sound playing "Bluetooth connected". The  on the screen will keep on after successfully pair the Bluetooth.
3. Open the music player app on the phone and start to play the music.

Scenario 2. CD Mode

1. Short press the mode switch button to switch to CD mode.
2. Put CD in, wait few seconds to read the CD and then start to play music automatically. The screen will display the CD songs sequence number at first, then disappear and show playing duration of song.

Special Note: In CD mode, put CD with mirror side forward to speaker, will wait 10~15seconds to decode the CD then start playing.

Scenario 3. Card insertion / AUX Mode

1. Automatically enter the corresponding mode after inserting a USB card, TF card.

2. After entering the corresponding mode, will sound a mode prompt and then start playing the songs. The screen will display the corresponding mode logo and play/pause status.

Scenario 4. FM Mode

1. Short press the mode switch button to switch to FM mode.
2. After entering FM mode, keep press mode button for 3 seconds to automatically search and save stations.
3. Under FM mode, press Previous/Next to switch and play between saved stations.
4. Under FM mode, keep press Previous/Next to automatically search stations and stop and play when find station with signal.
5. Under FM mode, press Play/Pause button to play/pause the FM.

Special note: To use FM mode, pull out the rod antenna before using this mode.

Scenario 5. TWS Mode

1. Turn on both speakers, switch both speakers to Bluetooth mode, and then press and hold the mode switch button for 3 seconds to disconnect the speakers from the phone's Bluetooth.
2. Press and hold the play/stop button on one of the speakers, and the host TWS will start searching for another auxiliary machine to pair. After TWS pairing succeeds, it will has sound playing "TWS connected".

3. Connect the host speaker with phone via Bluetooth, search for "DK21". Click on the name to pair. After successfully pairing the Bluetooth and open APP to play music, two speakers will play it simultaneously.

Special note: The speaker TWS function currently only supports the connection of two speakers, and does not currently support pairing and connection of three or more speakers.

Product Specification

Bluetooth name: DK21

IC Solution: BP1048+HT328C

Bluetooth Rev. No: V5.3

Transmission Frequency: 2.402GHz~2.480GHz

Bluetooth Profile: A2DP, AVRCP

Audio Decoding: SBC

Transmission Power: CLASS 2

Wireless Range: $\geq 10\text{m}$

Supported audio interfaces: USB Card, TF Card, CD, FM, AUX 3.5mm audio

Battery capacity: 7.4V/7800mAh

Charging interface: Type-C

Charging voltage: 5V/3A, 9V/2A, 15V/1.8A, 20V/1.5A

IP rating: IPX6

Size Specification: 342*142*221mm

Weight: About: 3.3kg

Audio output specification

Speaker outer Diameter: 3 inches*2+1.25 inches*2

Speaker Impedance: $4\Omega \pm 15\%$

Speaker Power: 15W+5W

Sensitivity: 80dB $\pm$ 3 dB(3 inches), 87.5dB $\pm$ 3 dB(1.25 inches)

Frequency Range: 50~20KHz

THD: 5% 1KHz

Safety and General Information

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment