

SEARS Owner's Manual



MICROWAVE OVEN


Model Nos.

565. 68380

565. 68381

565. 68480

565. 68481



CAUTION:

Before using this appliance, read this manual and follow all safety rules and Operating Instructions.

(Spanish Owner's Manual can be found on page 33 - 46.)

(El manual del propietario en español se encuentra en las páginas 33 - 46)

SAVE THESE INSTRUCTIONS

Sears, Roebuck and Co., Hoffman Estates, IL 60179, U.S.A.

SAFETY

ASSEMBLY

OPERATION

COOKING GUIDE

MAINTENANCE

ESPAÑOL

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) **Do not** attempt to operate this oven with the door open since open-door operation can result in harmful exposure to microwave energy. It is important not to defeat or tamper with the safety interlocks.
- (b) **Do not** place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- (c) **Do not** operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the:
 - (1) DOOR (bent)
 - (2) HINGES AND LATCHES (broken or loosened)
 - (3) DOOR SEALS AND SEALING SURFACES
- (d) **The oven** should not be adjusted or repaired by anyone except properly qualified service personnel.

SPECIFICATIONS		
Model:	565. 68380/565. 68381	565.68480/ 565. 68481
Power Source:	AC 120 V, 60 Hz	AC 120 V, 60 Hz
Power Consumption:	1480W, 12.9 Amps	1480W, 12.9 Amps
Maximum Output:	1000W*	1000W*
Oven Capacity:	1.3 cu. ft	1.8 cu. ft.
Turntable Diameter:	12-5/8" (320 mm)	12-5/8" (320 mm)
Dimensions:(w x h x d)	21-5/8" x 12-1/2" x 17-5/8" (550 x 317 x 447 mm)	23-7/16" x 14-1/4" x 17-5/8" (595 x 362 x 448 mm)
Weight: Approx.	38.5 lbs. (17.5 kg)	42 lbs. (19 kg)

*According to IEC-705 test procedure
Specifications subject to change without notice.

FOR YOUR ASSISTANCE...

To make a request for service, information or replacement of parts, Sears will require the complete **Model number** and **Serial number** of your oven.
Copy your Model and Serial numbers.

Model No. _____
(Located on the inner left side of control panel)
Serial No. _____
(Located on the inner left side of control panel)



TABLE OF CONTENTS

SAFETY

Proper and safe use of your oven	4
Important Safety Instructions	5
Electrical Grounding Instructions	6
Utensils	6

ASSEMBLY

Names of Oven Parts and Accessories	8
Turntable	8
Installation	9

OPERATION

Basic Features

Control Panel and Features	10
Setting Clock	11
Hold Warm	12
Kitchen Timer	12
Manual Cooking	13
Multistage Cooking	14

Special Features

Auto Sensor Cooking	14
Automatic Defrost by Weight	15
Quick-On Cooking	17
Other Convenient Functions	18

COOKING GUIDE

Cooking Techniques	19
Sensor Cooking	20
Sensor Cooking Recipes	22
Appetizers and Rice	24
Soup and Sandwiches	25
Meats, Poultry and Fish	26
Eggs	28
Baked Goods and Desserts	29

MAINTENANCE

Cleaning	30
Sears Service	30
Troubleshooting	31

ESPAÑOL (Spanish Instructions)

GARANTIA	33
SEGURIDAD	34
ENSAMBLE	36
OPERACION	38

(Consulte la página 33 para encontrar el índice detallado).

WARRANTY

KENMORE MICROWAVE OVEN

FULL ONE YEAR WARRANTY

For one year from the date of purchase, if this Kenmore Microwave Oven fails due to a defect in material or workmanship, Sears will repair it, free of charge.

KENMORE MAGNETRON

FULL FIVE YEAR WARRANTY

For five years from the date of purchase, if the magnetron in this Kenmore Microwave Oven fails due to a defect in material or workmanship, Sears will repair it, free of charge.

The above warranty coverage applies only to microwave ovens which are used for private household purposes.

Warranty service is available by simply **CONTACTING THE NEAREST SEARS STORE OR SERVICE CENTER** in the United States.

This Warranty applies only while this product is in use in the United States.

The Warranty give you specific legal rights, and you may also have other rights which vary from state to state.

**SEARS, ROEBUCK AND CO.,
D/817 WA,
HOFFMAN ESTATES, IL. 60179**

For Service Call:
1 - 800 - 4 - REPAIR
1 - 800 - 473 - 7247

SAFETY

PROPER AND SAFE USE OF YOUR OVEN

- The oven must be level.
- **The turntable and turntable roller rest** must be in the oven during cooking. See page 8.
- **Place** the cookware gently on the turntable and handle it carefully to avoid possible breakage.
- **Incorrect use** of browning dish may cause the turntable to break. See page 7.
- **Use** only the specified bag size when using Sensor Popcorn.
- **The oven** has several built-in safety switches to ensure that the power remains off when the door is open. Do not tamper with these switches.
- **Do not** operate the microwave oven when empty. Operating the oven with no food or food that is extremely low in moisture can cause fire, charring or sparking.
- **Do not** cook bacon directly on the turntable. Excessive local heating of the turntable may cause it to break.
- **Do not** heat baby bottles or baby food in the microwave oven. Uneven heating may occur and could cause physical injury.
- **Do not** heat narrow-necked containers, such as syrup bottles.
- **Do not** attempt to deep-fry in your microwave oven.
- **Do not** do home canning in this microwave oven as it is impossible to be sure all contents of the jar have reached boiling temperature.
- **Do not** use this microwave oven for commercial purposes. This microwave oven is made for household use only.
- When heating liquids, e.g. beverages in your oven, overheating the liquid beyond boiling point can occur without evidence of bubbling. This could result in a sudden boil-over of the hot liquid. To prevent this possibility, the following steps should be taken:
 - a) Avoid using straight-sided containers with narrow necks.
 - b) Do not overheat.
 - c) Stir the liquid before placing the container in the oven and again halfway through the heating time.
 - d) After heating, allow to stand in the oven for a short time, stirring again before carefully removing the container.
- Demo mode is designed for retail store display.

IMPORTANT SAFETY INSTRUCTIONS

SAFETY

When using electrical appliances, basic safety precautions should be followed, including the following:



WARNING – To reduce the risk of burns, electric shock, fire, injury to persons or exposure to excessive microwave energy:

- **Read** all instructions before use.
- **Read and follow** the specific “PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY” on page 2.
- As with most cooking appliances, close supervision is necessary to reduce the risk of a fire in the oven cavity.
- **If a fire should start:**
 - Keep the oven door closed
 - Turn the oven off, and
 - Disconnect the power cord or shut off power at the fuse or circuit breaker panel.
- **Keep in mind the following rules at all times:**
 - a) **Do not** overcook foods. Carefully attend the appliance if paper, plastic, or other combustible materials are placed inside the oven to facilitate cooking.
 - b) **Do not** use the cavity for storage purposes. Do not store combustible items such as bread, cookies, paper products, etc. inside the oven. If lightning strikes the power line, the oven may turn on by itself.
 - c) **Do not** use wire twist-ties in the oven. Be sure to inspect purchased items for wire twist-ties and remove before placing them in the oven.
- **This oven** must be grounded. Connect only to properly grounded outlet. See page 6.
- **Some products** such as whole eggs, water with oil or fat, sealed containers and closed glass jars may explode and therefore should not be heated in this oven.
- **Install or locate** this oven only in accordance with the provided installation instructions.
- Use this appliance only for its intended use as described in the manual. Do not use corrosive chemicals or vapors in this appliance. This type of oven is specifically designed to heat, cook or dry food. It is not designed for industrial or laboratory use.
- As with any appliance, close supervision is necessary when used by children.
- **Do not** operate this oven if it has a damaged cord or plug, if it is not working properly or if it has been damaged or dropped.
- **This appliance** should be serviced only by qualified service technicians. Contact the nearest authorized service facility for examination, repair or adjustment.
- **Do not** cover or block any vents on the oven.
- **Do not** store or use this appliance outdoors.
- **Do not** use this oven near water, near a kitchen sink, in a wet basement or near a swimming pool, and the like.
- **Do not** immerse cord or plug in water.
- **Keep** cord away from heated surfaces.
- **Do not** let cord hang over edge of table or counter.
- **When cleaning** surfaces of door and oven that comes together on closing the door, use only mild, nonabrasive soaps or detergents applied with a sponge or soft cloth. See page 30.

SAVE THESE INSTRUCTIONS

ELECTRICAL GROUNDING INSTRUCTIONS

DANGER

Electric Shock Hazard

- Touching some of the internal components can cause serious personal injury or death. Do not disassemble this appliance.

WARNING


Electric Shock Hazard

- Improper use of the grounding plug can result in electric shock. Do not plug into an outlet until appliance is properly installed and grounded.

This appliance must be grounded. If there is an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord that has a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

Consult a qualified electrician if the grounding instructions are not completely understood as to whether the appliance is properly grounded.

Properly polarized and grounded outlet



A short power supply cord is provided to reduce the risk of becoming entangled in or tripping over a longer cord.

Three-pronged (grounding)

Longer cord sets or extension cords may be used with following precautions:

- The marked electrical rating of the cord set or extension cord should be equal to or higher than the electrical rating of the appliance.
- The extension cord must be a grounding type 3-wire cord.
- A longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over accidentally.

The electrical power cord must be kept dry and must not be pinched or crushed in any way.

UTENSILS

CAUTION

Personal Injury Hazard

- Tightly-closed utensils could explode. Closed containers are opened and plastic pouches pierced before cooking.

See following page for further instructions "Materials you can use in microwave oven or to be avoided in microwave oven."

Utensil Test:

1. Fill a microwave-safe container with 1 cup of cold water (250 mL) along with the utensil in question.
2. Cook on **P-100** power for 1 minute.
3. Carefully feel the utensil.

If the empty utensil is warm,
Do not use them for Microwave Cooking.
Do not exceed 1 minute testing time.

CAUTION:

1. Do not use plastic containers for testing.
2. Some containers and dishware may be warm (or hot) in only one area. Do not use a container that becomes warm anywhere.

Materials you can use in microwave oven

Utensils	Remarks
Aluminum foil	Shielding only. Small smooth pieces can be used to cover thin parts of meat or poultry to prevent overcooking. Arcing can occur if foil is too close to oven walls. The foil should be at least 1 inch (2.5 cm) away from oven walls.
Browning dish	Follow manufacturer's instructions. The bottom of browning dish must be at least $\frac{3}{16}$ inch (5 mm) above the turntable. Incorrect usage may cause the turntable to break.
Dinnerware	Microwave-safe only. Follow manufacturer's instructions. Do not use cracked or chipped dishes.
Glass jars	Always remove lid. Use only to heat food until just warm. Most glass jars are not heat resistant and may break.
Glassware	Heat-resistant oven glassware only. Make sure there is no metallic trim. Do not use cracked or chipped dishes.
Oven cooking bags	Follow manufacturer's instructions. Do not close with metal tie. Make slits to allow steam to escape.
Paper plates and cups	Use for short-term cooking/warming only. Do not leave oven unattended while cooking.
Paper towels	Use to cover food for reheating and absorbing fat. Use with supervision for a short-term cooking only.
Parchment paper	Use as a cover to prevent spattering or a wrap for steaming.
Plastic	Microwave-safe only. Follow the manufacturer's instructions. Should be labeled "Microwave Safe." Some plastic containers soften as the food inside gets hot.
Plastic wrap	Microwave-safe only. Use to cover food during cooking to retain moisture. Do not allow plastic wrap to touch food.
Thermometers	Microwave-safe only (meat and candy thermometers).
Wax paper	Use as a cover to prevent spattering and to retain moisture.

Materials to be avoided in microwave oven

Utensils	Remarks
Aluminum tray	May cause arcing. Transfer food into microwave-safe dish.
Food carton with metal handle	May cause arcing. Transfer food into microwave-safe dish.
Metal or metal-trimmed utensils	Metal shields the food from microwave energy. Metal trim may cause arcing.
Metal twist ties	May cause arcing and could cause a fire in the oven.
Paper bags	May cause a fire in the oven.
Plastic foam cups	Plastic foam may melt or contaminate the liquid inside when exposed to high temperature.
Wood	Wood will dry out when used in the microwave oven and may split or crack.

ASSEMBLY

NAMES OF OVEN PARTS AND ACCESSORIES



Remove the oven and all materials from the carton.

Your oven comes with the following accessories:

Turntable/ Turntable roller rest/ Owner's Manual

Super EvenWave System

The microwave reach the embossments on the interior walls and then bounce in every direction. As a result, microwave energy will be reflected from many angles to cook and defrost more evenly and results in improved performance.



Door release button

Press the button to open door.

When you open the door during cooking process, the cooking stops but the program will not be canceled. Touch START to resume cooking.

Safety interlock system

Shuts off oven power if door is opened during operation.

TURNTABLE

CAUTION: The inside of the oven and turntable get very hot, so do not touch them immediately after use.


Auto Return Turntable

When a cook cycle is completed, the turntable will continue to turn until it reaches the same position as it was at the start. If however, you open the door it will stop immediately even if it has not reached the original position.



Turntable Installation


- Place the roller rest on the cavity bottom.
- The turntable hub should be securely locked in the receptacle. **Never place the turntable upside down.**
- The turntable rotation should never be restricted.
- Place the turntable on top of the roller rest as shown in the diagram.
- Both turntable and roller rest must always be used during cooking.
- All food and containers of food are always placed on this turntable for cooking.
- This turntable rotates clockwise or counterclockwise; this is normal.



ASSEMBLY

INSTALLATION

Remove all packing material and accessories.
Examine the oven for any damage such as dents or broken door.
Do not install if oven is damaged.




1. Select a level surface that provides enough open space for the intake and/or outlet vents.
A minimum clearance of 3 inches (7.5 cm) is required between the oven and any adjacent wall. One side must be open.
 - Leave a minimum clearance of 3 inches (7.5 cm) above the oven.
 - Do not remove the legs from the bottom of the oven.
 - Blocking the intake and/or outlet openings can damage the oven.
 - Do not install oven over a range, cooktop or other heat-producing appliance.
2. Plug your oven into a standard 120-volt / 60-Hz household outlet.
Be sure the electrical circuit is at least 15 amperes and that your microwave oven is the only appliance on the circuit.

NOTE: This unit is not designed for 50 Hz or any circuit other than a 120-volt/60-Hz AC circuit. This oven is designed for countertop installation only. Insertion into a cabinet or wall will damage the product and void the warranty.

OPERATION

CONTROL PANEL AND FEATURES



(1) Display Window

(2) Indicators

1/ 2/ 3 : Cooking stage indicators

SENSOR/ DEF :

Cooking mode indicators

START/ LOCK : A indicator prompts you to enter start or shows the oven is locked.

(3) Sensor menu keypads (page 14)

(4) **MORE/LESS** : Adds or reduces cooking time for Sensor menu keypad.

Auto menu keypads

(5) **AUTO DEFROST** (page 15)

(6) **QUICK ON** (page 17)

(7) **POWER LEVEL** (page 13)

(8) **TIME** (page 13)

(9) **HOLD WARM** (page 12)

(10) **KITCHEN TIMER** (page 12)

(11) **NUMBER**

(12) **CLOCK** (page 11)


(13) **START**

(14) **STOP/CLEAR**

Clears all previous setting if pressed before cooking starts. During cooking: touch once to stop oven; twice to stop and clear all entries.

Beep Sound

A beep tone sounds when a keypad on the control panel is touched to indicate a setting has been entered.



BEFORE OPERATION

Interactive Display

This oven is preprogrammed with the Interactive Display ON.

The Interactive Display will prompt you with step-by-step instructions to complete any cooking program.

When you become familiar with your oven, the Interactive Display can be turned off. See other convenient functions on page 18 for how to turn on and off.

Before using your oven, follow below procedure and set clock.

1) Plug in the oven.







TO SET TIME PRESS CLOCK KEYPAD appears in the display window.

2) Set clock.

SETTING CLOCK

To set the correct time of day, follow the steps as below.

Example: To set 3:15 :

Step	Procedure	Keypad	Display
1	Touch CLOCK .		
2	Touch 3, 1, 5 to enter time of day.		
3	Touch CLOCK . The clock starts counting.		





- Note:
- If the clock (or display) shows any abnormality, unplug the oven from the AC outlet. Plug it in again and then reset the clock.
 - When your oven is plugged in for the first time or when power resumes after a power interruption, the Interactive display will guide you to the next step or reset to **0:00**.
 - This is a 12 hour clock.
 - You can use the oven without setting clock.

OPERATION

HOLD WARM

This is an appropriate feature to keep food warm such as stew, casserole, etc. up to 100 minutes after a cooking program is completed or until the door is opened or **STOP/CLEAR** is pressed. Touch **HOLD WARM** and then touch **START**.

Example: To keep a casserole warm:







Step	Procedure	Keypad	Display
1	Touch HOLD WARM . Clock display reappears.		
2	Touch START .		

- Note:**
- You can use this feature without setting cooking program, but this will not warm cold food.
 - Do not use this feature after a defrost program as spoilage may occur.

KITCHEN TIMER

You can use the Kitchen Timer function independently, even while a cooking program is going on in the oven.

Example: To set timer for 5 minutes 30 seconds:












Step	Procedure	Keypad	Display
1	Touch KITCHEN TIMER .		
2	Touch 5, 3 and 0 to set 5 minutes 30 seconds. (up to 99 minutes 99 seconds)		
3	Touch START . The timer starts counting and beeps sound for 7 seconds at the end.		

- Note:**
- To check remaining timer time during cooking, touch **KITCHEN TIMER**. The remaining time appears in the display for 5 seconds.
 - To clear a timer setting, touch **STOP/CLEAR** while the display shows remaining timer time.
 - The indicator **K** flashes when the display shows a cooking time.
 - The indicator **K** lights when the display shows a timer time.
 - To stop beeps of Kitchen Timer, touch **KITCHEN TIMER**.
 - Kitchen Timer will not beep if the oven beeps at the same time to indicate another oven operation (the end of a cooking, for example).
 - If you do not enter a timer time for 10 seconds after step 1, the setting is cleared with a beep.
 - If a cooking completes while you are setting the Kitchen Timer, all settings are cleared. Restart from step 1.
 - If no key is touched for 5 seconds after the last key entry at step 2 above, the timer automatically starts.

MANUAL COOKING

This basic microwave cooking method allows you to cook food for a desired time. In addition to the **P-100** (maximum) power level, you can select different microwave power from 9 levels, **P-10** to **P-90** (10-90% of P-100 power level).

Example: To cook at power level P-80 for 40 seconds:

Step	Procedure	Keypad	Display
1	Touch TIME .		
2	Enter 40 seconds by touching 4 and 0.	 	
3	Touch POWER LEVEL .		
4	Touch 8 to select power level P-80.		
5	Touch START .		

OPERATION

- Note:**
- Cooking time can be set up to 99 minutes 99 seconds.
 - When you cook on **P-100** power, skip steps 3 and 4.
 - Foods with high moisture content should be cooked on **P-100** power.
 - To check the power level during cooking, touch **POWER LEVEL**.
 - The display will show P-10 - P-100 to indicate the 10-100% power level.

Manual Defrosting (Without using Auto Defrost feature) :

Use power level **P-30**. To speed up the defrosting of dense foods over 1 pound (450 g), you may start on **P-100 for 2 minutes**, then reduce to the level P-30.

Delay Start Cooking:

Use power level **P- 0** (no power) for the first stage of multistage cooking. You can delay cooking start time by up to 99 minutes 99 seconds.

POWER LEVEL SETTING GUIDE

P-10	• Softening cream cheese, butter. • Keeping casseroles warm.	P-60	• Cooking scrambled eggs. • Baking cakes.
P-20	• Softening chocolate. • clarifying butter. • Heating breads, rolls, pancakes, tacos, tortillas, French toast.	P-70	• Cooking cheese dishes.
P-30	• Completing the cooking cycle of casseroles, stews, sauces. • Manual defrosting.	P-80	• Reheating precooked or prepared food quickly. • Cooking fish.
P-40	• Cooking less tender cuts of meat in liquid or slow-cooking dishes. • Completing the cooking cycle of less tender roasts.	P-90	• Reheating rice and pasta.
P-50	• Cooking custards and pasta. • Cooking rump roast, ham, veal, lamb.	P-100	• Cooking poultry, vegetables, and most casseroles. Boiling water. • Preheating a browning dish.







MULTISTAGE COOKING

- You can program up to 3 stages of cooking in sequence. Stage indicators will be shown in the display window. Each stage can be programmed with a different power and time setting. To program 2-stage or 3-stage cooking, repeat the Manual Cooking steps 1 to 4 on page 13 and touch **START**. The oven automatically proceeds to the end of cooking.

AUTO SENSOR COOKING

Auto Sensor Cooking provides simple touch operation for a variety of foods. At the start of a microwave function, the sensor records the amount of steam generated from the food and determines the correct cooking time and power level.

Example: To reheat 1 serving of beef stew:

Step	Procedure	Keypad	Display
1	Touch REHEAT .		
2	Touch MORE/LESS once to adjust longer cooking time, if desired. (Optional)		
3	Touch START . After sensor measures steam, cooking time appears in the display.		

Sensor Cooking Courses:

REHEAT	to reheat precooked room or refrigerator temperature food
FROZEN REHEAT	to defrost and heat precooked frozen food
VEGETABLE	for cooking fresh and frozen vegetables
STEW/SOUP	for cooking one-container dishes of stew or soup
CASSEROLE	for cooking one-container dishes of casserole
POTATO	for cooking all types of raw potatoes, whole, quartered or sliced
POPCORN	for cooking variety types of microwave popcorn bags
PIZZA SLICE	to reheat room or refrigerator temperature cooked pizza

MORE/LESS DONENESS ADJUSTMENT

By using this pad, you can adjust cooking time for a longer or shorter time. Touch **MORE/LESS** keypad before touching **START**.

- Touch keypad once: **MORE** cooking (longer cooking time: 5 - 15 % depending on the Sensor Cooking course selected)
- Touch keypad twice: **LESS** cooking (shorter cooking time: 5 - 15 % depending on the Sensor Cooking course selected)

Error messages

- Error message **ERROR 1:**

Cause: The door is opened before the time countdown appears in the display.

Solution: Press **STOP/CLEAR** and use Manual Cooking.

- Error message **ERROR 2:**

Cause: Auto Sensor Cooking was used within 5 minutes after plugged in the oven.







Solution: Press **STOP/CLEAR** and wait for 5 minutes before using Auto Sensor Cooking.

- See page 20 - 23 for Sensor Cooking guide and sample recipes.

AUTOMATIC DEFROST BY WEIGHT

This feature allows you to defrost meat, poultry and seafood automatically.

Example: To defrost 1.2 lb of chicken pieces:

Step	Procedure	Keypad	Display																				
1	Touch AUTO DEFROST .		 START DEF																				
2	Enter the weight of food. Weight must be programmed in pounds and tenth of a pound. Conversion Chart Convert oz into tenths of a lb. e.g. 1 lb. 4 oz., program, 1.2 lbs. <table border="1" data-bbox="203 787 560 1144"> <thead> <tr> <th>Ounces</th> <th>Tenths of a Pound</th> </tr> </thead> <tbody> <tr><td>1 - 2</td><td>0.1</td></tr> <tr><td>3 - 4</td><td>0.2</td></tr> <tr><td>5</td><td>0.3</td></tr> <tr><td>6 - 7</td><td>0.4</td></tr> <tr><td>8</td><td>0.5</td></tr> <tr><td>9 - 10</td><td>0.6</td></tr> <tr><td>11 - 12</td><td>0.7</td></tr> <tr><td>13</td><td>0.8</td></tr> <tr><td>14 - 15</td><td>0.9</td></tr> </tbody> </table>	Ounces	Tenths of a Pound	1 - 2	0.1	3 - 4	0.2	5	0.3	6 - 7	0.4	8	0.5	9 - 10	0.6	11 - 12	0.7	13	0.8	14 - 15	0.9		 START DEF
Ounces	Tenths of a Pound																						
1 - 2	0.1																						
3 - 4	0.2																						
5	0.3																						
6 - 7	0.4																						
8	0.5																						
9 - 10	0.6																						
11 - 12	0.7																						
13	0.8																						
14 - 15	0.9																						
3	Touch START . Total defrost time appears in the display.		 DEF 1																				

OPERATION

Defrosting Techniques:

- Remove food from wrapper to prevent holding steam and juice and place in a microwave-safe baking dish or a roasting rack to catch drippings.
- Cover thin parts with aluminum foil to prevent overdefrosting.
- Because some food should be still icy in center, it is necessary to have standing time after defrosting food in the oven to complete defrosting. Leave your food for a while out of oven. The denser the food such as roasts, the longer standing time is required.

Note:

- Weight can be entered up to 5.9 lbs.
- The oven selects 1lb if a weight is not entered.
- **Beep tone sounds 5 seconds during the defrosting cycle to signal that food should be rearranged to improve defrosting performance.** Open the door and rearrange the food. The oven continues the defrosting cycle to the end if you do not open the door.
- Food can be defrosted in a styrofoam package.
- Using the Auto Defrost by Weight feature for the first stage of Manual Cooking, you can defrost first and can program up to 3 stages of cooking.





DEFROSTING CHART

Item	During Defrosting	Standing time
Beef		
Ground beef	Turn over. Remove defrosted portion.	5 - 10 min.
Liver	Drain liquid. Separate pieces.	10 - 15 min.
Roasts	Turn over. Cover ends with foil.	20 - 40 min.
Sirloin steak	Turn over.	5 - 10 min.
Rib or T-bone	Turn over.	10 - 20 min.
Flank steak	Turn over.	5 - 10 min.
Stewing meat	Break apart.	5 - 10 min.
Pork		
Ground pork	Turn over. Remove defrosted portion.	5 - 10 min.
Bacon	Defrost in original wrapper. Turn over.	3 - 5 min.
Chops	Separate and turn over.	5 - 10 min.
Ribs	Turn over.	10 - 20 min.
Roasts	Turn over. Cover ends with foil.	20 - 40 min.
Lamb		
Ground lamb	Turn over. Remove defrosted portion.	5 - 10 min.
Chops	Separate. Turn over.	5 - 10 min.
Ribs	Turn over.	10 - 20 min.
Roasts	Turn over. Cover end with foil.	20 - 40 min.
Poultry		
Chicken, whole	Turn over. Cover ends with foil. Rinse under cold water after defrosting.	15 - 30 min.
Pieces	Separate. Turn over.	10 - 15 min.
Cornish hens	Turn over. Cover ends with foil. Rinse under cold water after defrosting.	15 - 30 min.
Fish and Seafood		
Crabmeat, Shrimp	Break apart.	5 - 10 min.
Fish fillets	Turn over. Rearrange. Rinse under cold water to separate after defrosting.	5 - 10 min.
Fish whole	Turn over. Cover head and tail with foil.	5 - 10 min.
Steaks	Turn over.	5 - 10 min.
Scallops	Break apart. Remove defrosted seafood.	5 - 10 min.

QUICK-ON COOKING (P-100 POWER)

A time-saving feature, this simplified control lets you quickly set and start microwave cooking without the need to touch **START**.

Example: To set Quick-On cooking for 2 minutes:

Step	Procedure	Keypad	Display						
1	Touch QUICK ON .								
2	Touch 2 . The display shows time counting down.								
	<table border="1"> <thead> <tr> <th>Touch</th> <th>Cooking time</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>30 seconds</td> </tr> <tr> <td>1 - 9</td> <td>1 - 9 minutes</td> </tr> </tbody> </table>	Touch	Cooking time	0	30 seconds	1 - 9	1 - 9 minutes		
Touch	Cooking time								
0	30 seconds								
1 - 9	1 - 9 minutes								

Note: This feature only cook at highest power level (P-100).

QUICK-ON REHEATING AND COOKING CHART

Reheating	Amount	Time	Special Notes
Meat			
Chili, stews	2 cups (500 g)	3 - 4 min.	Place in microwave-safe dish. Cover. Stir halfway through cooking time.
Hamburgers, meat loaf slices,	1 serving 2 servings	½ - 1 min. 1 - 2 min.	Place on microwave-safe plate. Cover with paper towel. Turn over once.
Poultry			
Chicken pieces	2 4	1 - 2 min. 2 - 3 min.	Heat on microwave-safe plate. Cover with wax paper. If fried, cover with paper towel.
Chicken, turkey, sliced	3 - 5 oz (85 - 140 g)	1 - 2 min.	Heat on microwave-safe plate. Cover with wax paper.
Seafood			
Shrimp, crab, or scallops in sauce, frozen	6½ oz (185 g)	3 - 5 min.	Pierce pouch and place on microwave-safe plate. Flex pouch to mix halfway through cooking time.
Cooked rice, pasta			
	1 cup (250 mL) 2 cups (500 mL)	1 - 2 min. 2 - 3 min.	Heat in microwave-safe casserole, covered with plastic wrap.
Canned vegetable			
	8 oz (230 g) 15 oz (425 g)	1 - 2 min. 2 - 3 min.	Use microwave-safe casserole, covered. Stir once.
Cooking	Amount	Time	Special Notes
Mashed potatoes, instant	4 servings	3 - 5 min.	Follow package directions. Reduce liquid by 1 tbsp (15 mL).
Pudding and pie filling mix	3¼ oz (90 g)	4 - 6 min.	Follow package directions. Stir once.
Cereals			
Cream of wheat (regular)	¼ cup (50 mL)	1 - 2 min.	Add ¾ cup (175 mL) of water. Cook uncovered. Stir once. Let stand 1 minute.

OPERATION

OTHER CONVENIENT FUNCTIONS











CHILD LOCK OUT : This is a safety feature which prevents use by children. The feature locks the electronic operation of the oven until canceled.

DEMO MODE : To demonstrate the oven functions without generating any power.

WORD SPEED (HIGH, MEDIUM, LOW) : You can change the speed of the Interactive Display to your preference. The Interactive Display automatically sets to medium speed if no selection is made.

INTERACTIVE DISPLAY : The oven is preset with the Interactive Display on. This can be turned off when you become familiar with your oven.

Example: To set Child Lock :

Step	Procedure	Keypad	Display								
1	Touch CLOCK .										
2	Touch 9 four times.	 x 4 times									
3	Touch START .										
4	Enter CHILD LOCK/DEMO MODE by touching 1 .										
	<table border="1"> <thead> <tr> <th>Press</th> <th>Courses</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Child Lock/ Demo Mode</td> </tr> <tr> <td>2</td> <td>Word Speed</td> </tr> <tr> <td>3</td> <td>Interactive Display</td> </tr> </tbody> </table>			Press	Courses	1	Child Lock/ Demo Mode	2	Word Speed	3	Interactive Display
	Press			Courses							
	1			Child Lock/ Demo Mode							
2	Word Speed										
3	Interactive Display										
1	Child Lock/ Demo Mode										
2	Word Speed										
3	Interactive Display										
5	Enter CHILD LOCK ON by touching 1 . CHILD LOCK ON appears in the display.										
	<table border="1"> <thead> <tr> <th>Press</th> <th>Courses</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Child Lock ON</td> </tr> <tr> <td>2</td> <td>Demo Mode ON</td> </tr> <tr> <td>3</td> <td>Child Lock/ Demo Mode OFF</td> </tr> </tbody> </table>			Press	Courses	1	Child Lock ON	2	Demo Mode ON	3	Child Lock/ Demo Mode OFF
	Press			Courses							
	1			Child Lock ON							
2	Demo Mode ON										
3	Child Lock/ Demo Mode OFF										
1	Child Lock ON										
2	Demo Mode ON										
3	Child Lock/ Demo Mode OFF										

Note: • If any key is touched except **STOP/CLEAR, CLOCK, ERROR** appears and clock reappears in the display.

COOKING GUIDE

COOKING TECHNIQUES

Advantages of microwave cooking are speed and efficiency. For warming, heating, and defrosting, nothing compares. There are a few tips that will make microwaving easier and more enjoyable.

Microwave Cooking Principles

Because microwave cooking requires only one-quarter to one-third the time of conventional cooking, the same cooking principles become even more important.

Quantity

The more food being cooked, the longer you will have to cook it. As a general rule, when doubling a recipe, increase the cooking time by about 50 percent. When cutting a recipe in half, reduce the time by about 40 percent.

Density

Dense foods, such as potatoes, roasts and carrots, absorb microwave energy less quickly than porous foods such as ground beef or mashed potatoes. Therefore, denser foods take longer to cook.

Shape and Size

Small pieces cook faster than large ones. For even cooking, it is important to have all the pieces the same size. Evenly shaped pieces, round or doughnut shaped, microwave best. When cooking items of varying thickness, arrange the thick portion near the outer edge of the dish.

Moisture, Sugar and Fat

Food high in moisture, sugar or fat cook faster than foods that are low in these substances. Add a minimum of liquid to moist foods. An excess amount of water slows cooking.

Starting Temperature

Frozen or refrigerated foods take longer to microwave than food at room temperature.

Delicate Ingredients

Some foods require special attention when cooked in the microwave oven. Delicate foods such as eggs, cheese, mayonnaise, etc. cook so quickly, they should be watched carefully.

Microwave Cooking Techniques

Arranging: Arrange foods in a circular pattern, when possible.

Piercing: Pierce the membrane of foods such as eggs, oysters, snails, sausages, livers, clams and whole vegetables, so they do not burst.

Covering: Covering speeds heating and prevents spattering.

Stirring: To help food cook more quickly and evenly.

Turning Over: To help larger foods such as roasts or whole chickens cook more evenly.

Reheating: Place food that is denser/larger/ thicker to the outer edge and the smaller/thinner or more porous food to the center.

Shielding: To prevent overcooking, thin or bony areas can be protected with small strips of aluminum foil.

Standing Time: Foods continue cooking even after removal from the oven. Standing time is necessary to allow foods to complete cooking.

Converting Recipes

Microwave recipes will likely call for less liquid and cooking time

Safety Food Temperatures

For your safety, following temperature is recommended to avoid potential food poisoning problems.

160°F (71°C): Meat, Fish, Eggs

165°F (74°C): Reheating foods

170°F (77°C): Poultry (White Meat)

180°F (82°C): Poultry (Dark Meat)

SENSOR COOKING

General Cooking Tips:

- Room temperature should be below 95°F (35°C).
- Keep the inside of oven, the turntable and the outside of cooking containers dry. Wipe off all spillovers. Excessive humidity in the oven may result in an incorrect cooking time.
- When cooking starts, do not open the door while the selected course number appears. During this period, the oven sensor is measuring steam to determine the cooking time.

Sensor Reheating Tips:

- Auto Sensor Reheat is best used for 1 - 2 servings.
- Always cover foods loosely but completely with wax paper, plastic wrap or casserole lids. Loose-fitting covers may cause the oven to miscalculate time. Never use tightly sealed plastic containers such as those with plastic snap closing lids.

- Do not heat food for less than 4 oz (115 g) or more than 20 oz (560 g). Always use Time cooking for these amounts.
- Very dense foods (e.g. frozen lasagna) should be allowed to stand covered after reheating.
- Do not heat uncooked food.
- The following types of foods are not recommended :
Boil-in-the-bag entrees or vegetables, raw or uncooked food, frozen cheesecake, dried foods, bread or pastry, beverages.
- Do not reheat in foil containers.
- When reheating delicate sauces/dips that contain sour cream, or eggs, or cream cheese, reheat manually using power level P-30.
- Use **MORE/LESS** keypad for fine adjustments in cooking. After using this feature, you will know which setting yields the best results for your individual taste.

Reheating Guide

Item/Amount	Press keypad	Special Notes
Casserole/ Entree Lasagna Macaroni cheese 4 oz - 20 oz (115 g - 560 g)	REHEAT FROZEN REHEAT	Cover with plastic wrap or casserole lid. Stir after reheating. Foods that cannot be stirred (ex. lasagna) should be allowed to stand covered for a few minutes after reheating.
Plate of food Pasta in sauce Meat loaf dinner Turkey dinner 4 oz - 20 oz (115 g - 560 g)		Arrange less dense foods in the center of plate. Cover with wax paper or plastic wrap. Allow to stand, covered for a few minutes after reheating.
Fried chicken 2 - 4 pieces		Cover with wax paper.
Pizza Slice 1 - 6 1 slice, (12 inch, 1/8 cut or 16 inch, 1/2 cut)	PIZZA SLICE	Pizza should not be frozen. Place precooked pizza on a paper towel or paper plate. No cover. Place pizza points toward the center. CAUTION: Be careful when eating pizza heated in the microwave. The pizza surface and sauce can be very hot.

SENSOR COOKING (CONT.)

Cooking Guide

Item/Amount	Press keypad	Special Notes
Artichokes, Beans, Broccoli, Brussels sprouts, Cabbage, Carrots, Corn, Cauliflower, Eggplant, Mushrooms, Onion, Okra, Peas, Spinach, Squash, Zucchini, or a mixture of these. 4 oz - 2 lbs (115 g - 900 g)	VEGETABLE	Wash. Prepare and cut into slices, cubes, wedges, or julienne strips. The best container for cooking vegetables is a ½ to 2 quart (½ to 2 litre) microwave-safe casserole. Add 1 - 4 tbs. (15 - 60 mL) water and cover with plastic wrap or casserole lid. Stir large quantities of vegetables after cooking time appears in the display window. Let stand 3 - 5 minutes before serving.
White potatoes Baking potatoes Sweet potatoes Whole: 6 - 8 oz each. (170 - 230 g) 1 - 6	POTATO	Wash, scrub and pierce several places with fork. Place on paper towels. Arrange potatoes in circle and avoid placing potatoes in the center of the turntable. Turn potatoes over after cooking time appears in the display window. Allow 5 - 10 minutes standing time.
Quartered or sliced ½ - 1 lb (225 g - 450 g)		The best container for cooking quartered or sliced potatoes is a ½ to 1½ quart (½ to 1½ litre) microwave-safe casserole dish. Peel and quarter or slice. Add ¼ cup (50 mL) water. Cover with plastic wrap or casserole lid.
Red potatoes, boiling New potatoes, small ½ - 1 lb (225g - 450g)		Wash and pierce with a fork. Add ¼ cup (50 mL) water. Cover with plastic wrap or lid.
Popcorn 1.5 oz - 3.5 oz	POPCORN	Follow package directions. 1) Bag should be at room temperature. 2) Do not use this feature, if popcorn bag size is other than 1.5 oz - 3.5 oz. CAUTION: 1) After popping, open bag carefully. Popcorn and steam are extremely hot. 2) Do not reheat unpopped kernels or reuse bag. Overcooking can result in an oven fire. 3) Never use a brown paper bag for popping corn.

COOKING GUIDE

SENSOR COOKING RECIPES

Asparagus with Orange-Balsamic Vinaigrette Makes 4 servings Cooking Time : About 7 - 10 minutes

Ingredients

1 lb (450 g) asparagus, washed and trimmed
2 tbsp. (30 mL) water
2 tsp. (10 mL) finely grated orange peel
¼ cup (50 mL) orange juice
2 tbsp. (30 mL) olive oil or vegetable oil
1 tbsp. (15 mL) balsamic or red wine vinegar
½ tsp. (2 mL) Dijon mustard
Salt and pepper to taste

Method

Trim asparagus so that stems will lie flat in microwave-safe dish.
Add water. Cover with dish lid or plastic wrap.
Cook on **VEGETABLE**. When done, drain, cover and set aside.
Meanwhile, combine orange peel, orange juice, oil, vinegar and mustard in a non-metallic dish.
Pour over asparagus and toss lightly to coat asparagus.
Cover, and cook on P-100, 1 to 1½ minutes or until heated through.

Hearty Beef Vegetable Stew

Makes 4 - 6 servings
Cooking Time : About 60 - 70 minutes

Ingredients

2¼ cups (510 mL) water
2 beef bouillon cubes
1 lb (450 g) round steak, cut into ½ inch (1.25 cm) cubes
3 tbsp. (45 mL) cornstarch
2 large potatoes, peeled and cubed
¾ cup (175 mL) thinly sliced carrots
½ cup (125 mL) thinly sliced celery
1 medium onion, diced
½ tsp. (2 mL) salt
¼ tsp. (1 mL) freshly ground pepper
¼ tsp. (1 mL) thyme
1 bay leaf, crushed

Method

Place all ingredients in 3 quart (3 litre) microwave-safe casserole, and stir.
Cover with casserole lid.
Cook on **STEW/SOUP**.
Stir once after cooking time appears in the display window.

Onion-Beef Soup

Makes 6 servings
Cooking Time : About 50 - 60 minutes

Ingredients

3 medium onions, thinly sliced
¼ cup (50 mL) butter or margarine
4 cups (920 mL) beef broth
¼ cup (50 mL) white wine
1 tsp. (5 mL) Worcestershire sauce
1 tsp. (5 mL) salt
1 tsp. (5 mL) soy sauce
½ tsp. (2 mL) paprika
Grated Parmesan cheese

Method

Combine onions and butter in 3 quart (3 litre) microwave-safe casserole.
Cover with casserole lid.
Cook on P-100, 4 to 6 minutes.
Add remaining ingredients, except cheese. Blend well. Cover.
Cook on **STEW/SOUP**.
Stir once after cooking time appears in the display window.
Serve in bowls with cheese sprinkled on top.

SENSOR COOKING RECIPES (CONT.)

Bacon Vegetable Soup

Makes 4 - 6 servings

Cooking Time : About 65 - 75 minutes

Ingredients

4 oz (115 g) slices bacon, diced
1 medium tomato, peeled and chopped
1 carrot, sliced
1 stalk celery, sliced
1 medium red potato, cubed
1 small zucchini, sliced
1 medium onion, chopped
2 bay leaves
1 tsp. (5 mL) basil
1 tsp. (5 mL) Italian herb seasoning,
season as desired
3 cups (690 mL) beef broth

Method

Combine all ingredients in 3 quart (3 litre) microwave-safe casserole. Cover with casserole lid. Cook on **STEW/SOUP**. Stir once after cooking time appears in the display window.

Ham and Potato Scallop

Makes 4 servings

Cooking Time : About 20 - 30 minutes

Ingredients

1 cup (250 mL) white sauce, seasoned as desired
3 medium potatoes, peeled and thinly sliced (about 1 lb - 450 g)
5 oz (140 g) diced cooked ham
1 tsp. (5 mL) instant minced onion
¼ cup (1 oz - 30 g) shredded cheddar cheese

Method

Place potatoes in 1½ quart (1½ litre) microwave-safe casserole. Add ham and onion. Pour white sauce over ham and potatoes mixture, stir to combine. Cover with casserole lid. Cook on **CASSEROLE**. Stir once after cooking time appears in the display window. After cooking, sprinkle with cheese. Cover and let stand 10 minutes or until cheese is melted.

Casserole Italiano

Makes 6 -8 servings

Cooking Time : About 30 - 40 minutes

Ingredients

½ lb (225 g) lean ground beef
¾ cup (175 mL) spaghetti sauce
½ can (4 oz -115 g) tomato sauce
¾ cup (175 mL) water
½ can (8 oz - 230 g) green beans, drained
3 cups (4 oz - 115 g) uncooked medium-width egg noodles
1 tbsp. (15 mL) onion flakes
1 clove garlic, minced
1 tbsp. (15 mL) sugar
1 tsp. (5 mL) Italian herb seasoning
¼ tsp. (1 mL) salt
pepper to taste
1 cup (4 oz - 115 g) shredded mozzarella cheese

Method

Crumble beef into 2 quart (2 litre) microwave-safe casserole. Cook on P-100, 2 to 4 minutes. Stir to break up beef. Drain. Add remaining ingredients except cheese to beef. Blend well. Cover with casserole lid. Cook on **CASSEROLE**. Stir once after cooking time appears in the display window. After cooking, sprinkle with cheese. Stir and let stand before serving.

MANUAL COOKING - APPETIZERS AND RICE

CONVERTING RECIPES

Most hot appetizers adapt well to microwave cooking, the exception being those wrapped in pastry. Pastry requires the hot environment of the conventional oven to become crisp.

- Toppings for canapés can be made ahead and then placed on bread or crackers just before heating. This guarantees crispness.

- Cover appetizers or dips only when called for by a recipe. Use casserole lids, wax paper, plastic wrap, or paper towel.
- Appetizers and dips that contain cheese, mayonnaise and other delicate ingredients are usually heated on power level P-10. A higher setting might cause separation or drying.

Reheating Guide - Convenience Appetizers

Item	Power	Cooking Time	Special Notes
Meat spread 4 oz (115 g)	P-80	1 - 1½ min.	Transfer to small microwave-safe bowl.
Cocktail franks 4 servings	P-70	½ - 1½ min.	Place on paper towel. Cover with wax paper.
Dips, cream ½ cup (125 mL)	P-10	2 - 3 min.	Cover with wax paper.
Egg rolls 12 (6 oz - 170 g)	P-70	1 - 2 min.	Place on paper towel or paper plate.
Mini Tacos 4 - 6 (6 oz - 170 g)	P-50	1 - 2 min.	Place on paper towel or paper plate.

Cooking Guide – Hot Drinks

Item	Power	Cooking Time	Special Notes
Water 8 oz (230 mL) cup, 1 8 oz (230 mL) cup, 2	P-100 P-100	1½ - 2½ min. 3 - 4 min.	For instant coffee, soup, tea, etc.
Milk 8 oz (230 mL) cup, 1 8 oz (230 mL) cup, 2	P-70 P-70	2 - 3 min. 4 - 5 min.	For hot chocolate, etc.

Cooking Guide - Rice

1 cup (250 mL) rice (Use 3-quart (3 L) microwave-safe casserole. Heat water 4 to 7 min. to boil. Add rice, salt and butter or margarine. Cover tightly. Let stand 5 minutes after cooking.)

Item	Water	Power	Cooking Time
Long grain,	2 cups (500 mL)	P-30	20 - 25 min.
Short grain,	1½ cups (400 mL)	P-30	22 - 27 min.

MANUAL COOKING - SOUPS AND SANDWICHES

A large variety of sandwich combinations can be made in your microwave oven. Because sandwiches heat quickly, be careful not to overcook them — the bread can become tough and chewy. Heat breads until warm, not hot, and cheese until it just begins to melt. Let the following tips guide you when adapting or creating your own sandwiches.

CONVERTING SANDWICH RECIPES

- Heat sandwiches on white paper towels or paper plates. To prevent splattering, as well as to absorb steam and prevent sogginess, you can wrap each sandwich in a paper towel. Remove wrapping immediately after warming. It takes less than 1 minute to heat most sandwiches. Heat on power level P-80.

- Thinly sliced meat heats better than thickly sliced meat. The slower-cooking thick slices often cause the bread to overcook before the meat is hot.

CONVERTING SOUP RECIPES

- When cooking canned soups, remove from can. Use microwave-safe dish. Add milk or water as directed on can. Cover dish.
- Stir cream-style soup halfway through cooking time. Let stand, covered, 3 minutes before serving.

Cooking Guide – Canned Soups

Item	Amount	Power	Cooking Time
Broth	10¼ oz (290 mL)	P-80	4 - 6 min.
Cream-style	10¼ oz (290 mL)	P-80	5 - 7 min.
Tomato	10¾ oz (300 mL)	P-80	5 - 7 min.
Bean, pea, or mushroom	10¾ oz (300 mL)	P-70	6 - 8 min.
Undiluted chunk-style vegetable	10¾ oz (300 mL)	P-80	2 - 4 min.
	19 oz (540 mL)	P-80	5 - 7 min.

COOKING GUIDE

Cooking Guide - Quick Soups

Item	Amount	Power	Cooking Time
Cup of Instant soup 1¼ oz (35 g) envelope	1	P-100	1 - 2 min.
	2	P-100	2 - 3 min.
	4	P-100	4 - 5 min.

Food	Power	Cooking Time	Stand Time	Special Notes
Beef Meat loaf 1½ lb (680 g)	P-50	15 - 20 min.	5 min.	Arrange in loaf dish. Cover with wax paper.
Pork Chops, loin ½ inch (1 cm) thick, 7 oz (200 g) each	1 P-100 2 P-100 4 P-100	3 - 5 min. 6 - 8 min. 9 - 11 min.	2 min. 3 min. 3 min.	Place in a shallow dish. Cover loosely with wax paper. Turn over halfway through cooking.
Pork roast, 1 lb (450 g)	P-50	12 - 15 min.	10 - 15 min.	Cover with wax paper. Shield halfway through cooking and turn roast over if necessary. *Approx. temp. after stand 170°F to 175°F (77°C to 79°C)
Ham, slice 1 inch (2.5 cm) thick, 1 lb (450 g)	P-100	7 - 9 min.	5 min.	Cover with wax paper. Turn over halfway through cooking.
Sausage links, Wieners, fresh 1 - 2 oz (30 - 55 g) each	2 P-100 4 P-100	½ - 2 min. 1 - 3 min.	1 min. 1 min.	Score or pierce before cooking. Cover with wax paper. Turn over once.
Bacon, slices	2 P-100 4 P-100	1½ - 2 min. 2½ - 4 min.	1 min. 1 min.	Cook on bacon rack or line bottom of dish. Place bacon on paper towel. Cover loosely with another paper towel. Do not turn over bacon.
Lamb Chops, shoulder ½ inch (1 cm) thick	1 P-100 2 P-100	2 - 4 min. 4 - 6 min.	2 min. 5 min.	Cover loosely with wax paper.
Poultry Chickens, whole, up to 4 lb (1.8 kg) 1 lb (450 g) Cornish hens 1 lb (450 g)	P-100 P-100	6 - 9 min. 5 - 8 min.	10 min. 10 min.	Place breast-side down on a roasting rack in a dish. Cover with plastic wrap or wax paper. Turn over halfway through cooking. Stand tented with foil. When cooked, internal temperature should be 180°F (82°C) and juices should run clear.

COOKING GUIDE

*Check with conventional meat thermometer.

Food	Power	Cooking Time	Stand Time	Special Notes
Poultry Chicken pieces, up to 2 lb (900 g) 1 lb (450 g)	P-100	5 - 8 min.	5 min.	Arrange skin-side up in a baking dish halfway through cooking, meatier portions toward edge of dish. Cover with plastic wrap or lid.
Fish and Seafood Fish fillets, ¾ lb (340 g) Fish steaks 2, 6 oz (170 g) each Scallops 1 lb (450 g) Shrimp, medium size, shelled and cleaned, 1 lb (450 g) Whole fish, stuffed or unstuffed, 1½ to 1¾ lb (680 - 800 g)	P-100 P-50 P-70 P-70 P-100	4 - 6 min. 6 - 9 min. 4 - 7 min. 4 - 7 min. 7 - 10 min.	3 min. 5 min. 3 min. 3 min. 5 min.	Arrange in a single layer in dish. Cover with wax paper. Rearrange or stir shrimp or scallops halfway through cooking.

MANUAL COOKING - EGGS

SCRAMBLED EGGS

Break eggs into a microwave-safe glass measure.

Add 1 tablespoon milk and 1 teaspoon butter for each egg. Beat with a fork.

Cook at **Power Level P-60** according to time in the chart. Stir at least once during cooking time.

Stir after cooking, and let stand 1 minute.

Eggs	Cooking Time
1	¾ - 1½ min.
2	1½ - 2½ min.
3	2¼ - 4 min.
4	3¼ - 5 min.

POACHED EGGS

Use 6-ounce (170 mL)

microwave-safe custard cup with ¼ cup (50 mL) water for 1 to 3 eggs.

Use 1-quart (1 L) microwave-safe dish with 1 cup (250 mL) water for 4 eggs.

Heat at **P-100 POWER** to bring water to a boil with ⅛ teaspoon salt and up to

¼ teaspoon vinegar.

Break egg carefully into hot water.

Pierce egg several times lightly with toothpick.

Cover with wax paper.

Cook at **Power Level P-50** according to time in the chart. Let stand, covered, 1 minute before serving.

Eggs	Cooking Time
1	¾ - 1½ min.
2	1½ - 3 min.
3	2 - 3½ min.
4	3 - 5 min.

MANUAL COOKING - BAKED GOODS AND DESSERTS

Converting Recipes

When adapting quick bread recipes, you will find it necessary to reduce the amount of leavening (baking powder or soda) by about one-quarter the normal amount. A bitter aftertaste is apparent if too much leavening is used in biscuits or muffins. Since food rises higher in the microwave oven, you will not see a loss in volume from the reduction of soda or baking powder.

If a recipe contains buttermilk or sour cream, do not change the amount of soda, since it serves to counteract the sour taste and does not act only as a leavening agent.

When using a mix where leavening cannot be reduced, allow the dough to stand about 10 minutes before cooking in order for some of the gas to be lost.

Breads and rolls should be reheated only until they are warm to the touch. Overheating or overcooking makes bread tough and rubbery.

Cooking/Reheating Guide

Item	Power	Cooking Time	Special Notes
Hamburger buns, hot dog rolls, frozen: 1 lb (450 g) Room temp.: 2 4	P-30 P-80 P-80	2 - 3 min. 10 - 15 sec. 15 - 20 sec.	Place on paper plate or wrap in paper towel.
French bread, Frozen: 1 lb (450 g) Room temp.: 1 lb (450 g)	P-80 P-80	1 - 2 min. 20 - 30 sec.	Place on paper plate or towel.
Doughnuts, sweet rolls, muffins 4 oz (115 g) each 2 4	P-80 P-80	25 - 35 sec. 50 - 60 sec.	Place on paper plate or towel. If frozen, defrost foods for 30 to 40 seconds per serving at power level P-30 before reheating.
Whole coffee cake, Frozen: 10 - 13 oz (280 - 370 g) Room temp.: 10 - 13 oz (280 - 370 g)	P-80 P-80	1 - 2 min. ½ - 1 min.	Place on paper plate or towel. Let stand 5 - 10 minutes before serving.
Butter cake 2¼ cups (550 mL) batter 1st stage 2nd stage	P-50 P-100	5 - 7 min. 1 - 2 min.	Place on inverted pie plate.
Brownies 2 cups (500 mL) batter	P-50	8 - 11 min.	Cover with wax paper. Place on inverted pie plate.
Muffins, ¼ cup (50 mL) batter each 2 6	P-70 P-70	1 - 1½ min. 3 - 4 min.	

MAINTENANCE

CLEANING

Wipe the oven inside and outside with a soft cloth and a mild detergent solution. Then rinse and wipe dry. Never use cleaning powders or rough pads. Excessive oil splatters on the inside top will be difficult to remove if left for many days. Wipe splatters with a wet paper towel, especially after cooking chicken or bacon.

REMOVABLE PARTS

Wash in warm (not hot) water with a mild detergent and a soft cloth. Rinse them well and dry with a soft cloth. Never use cleaning powders, steel wool or rough pads.

- The turntable may be cleaned at the sink. Be careful not to chip or scratch the edges as this may cause the turntable to break during use.

- The turntable roller rest should be cleaned regularly.

SPECIAL CARE

For best performance and safety, the inner door panel and the oven front frame should be free of food or grease buildup. Wipe them often with a mild detergent. Then rinse and wipe dry. Never use cleaning powders or rough pads.

After cleaning the control panel, touch STOP/CLEAR to clear any entries that might have been entered accidentally while cleaning the panel.



CAUTION

Product Damage Hazard

Uncleaned cavity cover (located in the right side wall of the oven cavity) will cause fire, burn or sparking. Clean your oven with wet towel.

SEARS SERVICE

"WE SERVICE WHAT WE SELL"

"We Service What We Sell" is our assurance to you that you can depend on Sears for service because Sears Service is nationwide.

Your Sears Kenmore Microwave Oven has added value when you consider that Sears has a service unit near you, staffed by Sears Trained Technicians—professional technicians specifically trained on Sears Kenmore Microwave Ovens, having the parts, tools and equipment to insure that we meet our pledge to you—"We Service What We Sell!"

TO FURTHER ADD TO THE VALUE OF YOUR MICROWAVE OVEN, BUY A SEARS MAINTENANCE AGREEMENT.

Sears Kenmore Microwave Ovens are designed, manufactured, and tested for years of dependable operation. Yet, any modern appliance may require service from time to time. A Sears Maintenance Agreement is more than an extension of the Warranty.

It provides complete protection from unexpected repair bills and undue

inconvenience. It assures you of maximum efficiency from your Microwave Oven.

Here's a comparative warranty and Maintenance Agreement chart showing you the benefits of a Sears Microwave Oven Maintenance Agreement.

Years of Ownership Coverage	1 st Yr.	2 nd Yr. thru 5 th Yr.
Replacement of defective parts other than magnetron	W	MA
Replacement of magnetron	W	W
Annual preventive maintenance check at your request	MA	MA

W - WARRANTY

MA - MAINTENANCE AGREEMENT

Contact your Sears salesperson or local Sears Service Center today and purchase a Sears Maintenance Agreement.

TROUBLESHOOTING

Check your problem by using the chart below and try the solutions for each problem. If the microwave oven still does not work properly, contact the nearest authorized service center.

TROUBLE	CAUSE	REMEDY
When the oven is plugged into a wall outlet for the first time, it does not work properly.	<ul style="list-style-type: none"> The microcomputer used in the oven control may temporarily become scrambled and fail to function as programmed. 	<ul style="list-style-type: none"> Unplug the oven from the wall outlet and then plug it back in.
Light reflection around the outer case.	<ul style="list-style-type: none"> This light is from the oven light located outside the oven cavity. 	-
Noise coming from the turntable when the oven is turned on.	<ul style="list-style-type: none"> Noise occurs when the turntable roller rest and cavity bottom are dirty. 	<ul style="list-style-type: none"> Clean the turntable roller rest and cavity bottom.
How are the boil-overs avoided.	<ul style="list-style-type: none"> Small utensil is used. 	<ul style="list-style-type: none"> Use a larger utensil than usual for cooking.
Noise coming from the oven when reducing power.	<ul style="list-style-type: none"> When cooking with a power other than P-100, the oven cycle to obtain the lower power level. The clicking noise can be heard when the oven cycles. This is normal. 	-
Oven will not start.	<ul style="list-style-type: none"> Electrical cord for oven is not plugged in. Door is open. Wrong operation is set. 	<ul style="list-style-type: none"> Plug into the outlet. Close the door and try again. Check instructions, (pages 11-18)
Arcing or sparking.	<ul style="list-style-type: none"> Materials to be avoided in microwave oven are used. The oven is operated when empty. Food refuse remains in the cavity or inside the cavity is uncleaned. 	<ul style="list-style-type: none"> Use microwave-safe cookware only. (page 6) Do not operate with oven empty. Clean cavity with wet towel.
Unevenly cooked foods.	<ul style="list-style-type: none"> Materials to be avoided in microwave oven are used. Food is not defrosted completely. Cooking time/ Cooking power level is not suitable. Food is not turned or stirred. 	<ul style="list-style-type: none"> Use microwave-safe cookware only. (page 6) Completely defrost food. Use correct time/ cooking power level. Turn or stir food.
Steam coming out of the air exhaust vent.	<ul style="list-style-type: none"> Steam is produced during cooking. The microwave oven has been made to vent this steam. 	-

MAINTENANCE

TROUBLE	CAUSE	REMEDY
Overcooked foods.	<ul style="list-style-type: none"> • Cooking time/ Cooking power level is not suitable. 	<ul style="list-style-type: none"> • Use correct time/ cooking power level.
Undercooked foods.	<ul style="list-style-type: none"> • Materials to be avoided in microwave oven are used. • Food is not defrosted completely. • Oven ventilation ports are restricted. • Cooking time/ Cooking power level is not suitable. 	<ul style="list-style-type: none"> • Use microwave-safe cookware only. (page 6) • Completely defrost food. • Check to see that oven ventilation ports are not restricted. • Use correct time/ cooking power level.
Improper defrosting.	<ul style="list-style-type: none"> • Materials to be avoided in microwave oven are used. • Cooking time/ Cooking power level is not suitable. • Food is not turned or stirred. 	<ul style="list-style-type: none"> • Use microwave-safe cookware only. (page 6) • Use correct time/ cooking power level. • Turn or stir food.
Oven light will not glow.	<ul style="list-style-type: none"> • The light bulb has burned out. • START has not been touched. 	<ul style="list-style-type: none"> • Contact your nearest Sears Service Center. See Back cover for phone numbers. • Touch START.
Eggs sometimes pop.	<ul style="list-style-type: none"> • The egg yolk may pop because of steam build-up inside the membrane. 	<ul style="list-style-type: none"> • Pierce the membrane with a toothpick before cooking it.
ERROR message (ERROR 1 or ERROR 2) appears in the display window.	<ul style="list-style-type: none"> • ERROR 1 light if door is opened before time countdown appears in the display. • ERROR 2 light if the oven has not been plugged into a power supply cord for more than 5 minutes when you start a Sensor Cooking. 	<ul style="list-style-type: none"> • Touch STOP/CLEAR and restart using Manual Cooking on page 13. • Touch STOP/CLEAR and wait for 5 minutes to restart from step 1 of Auto Sensor Cooking on page 14.
Why couldn't I get good results even though I cooked food using Auto Sensor Cooking.	<ul style="list-style-type: none"> • The food was not covered properly. • STOP/CLEAR was pressed or the door was opened while the sensor was programming the right cooking time and power level. • The food being cooked was not suitable for Auto Sensor Cooking. • There may have been too much or not enough food to ensure proper results from Auto Sensor Cooking. 	<ul style="list-style-type: none"> • See page 20 - 21 for instructions on how to prepare food. • Do not open the door or press STOP/CLEAR while display shows SENSOR COOKING. • Use Manual Cooking. (see page 13) • When cooking more than 2 lbs (900 g) or less than 4 oz (115 g) of food, use Manual Cooking on page 13.

SEARS Owner's Manual



MICROWAVE OVEN

Model Nos.

565. 68380/ 565. 68381/ 565. 68480/565. 68481

For in-house major brand repair service
Call 24 hours a day, 7 days a week

1-800-4-REPAIR
(1-800-473-7247)

Para pedir servicio de reparación a
domicilio - 1 - 800 - 676 - 5811



For the location of a Sears Parts and
Repair Center in your area
Call 24 hours a day, 7 days a week

1-800-488-1222



For information on purchasing a Sears
Maintenance Agreement or to inquire
about an existing Agreement
Call 9 am - 5 pm, Monday-Saturday

1-800-827-6655



When requesting service, always provide the
following information:

- Product Type • Serial Number
- Model Number • Problem Description



Sears, Roebuck and Co., Hoffman Estates, IL. 60179, U.S.A.