

Elite Gourmet ®

12 CUP STAINLESS STEEL PERCOLATOR

MODEL: EC812

INSTRUCTION MANUAL

Before operating your new appliance, please read all instructions carefully and keep for future reference.



Questions? Elite's customer service team is ready to help.
For more Elite products, visit us at shopelitegourmet.com.

TABLE OF CONTENTS

IMPORTANT SAFEGUARDS	2
SHORT CORD PURPOSE	3
POLARIZED PLUG	3
PARTS IDENTIFICATION	4
BEFORE FIRST USE	5
HOW TO USE	5
CLEANING AND MAINTENANCE	6
WARRANTY POLICY	7
RETURN INSTRUCTIONS	8

IMPORTANT SAFEGUARDS

The Elite Brand takes consumer safety very seriously. Products are designed and manufactured with our valued consumers' safety in mind. Additionally, we ask that you exercise a level of caution when using any electrical appliance by following all instructions and important safeguards.

READ ALL INSTRUCTIONS BEFORE USE AND SAVE FOR FUTURE REFERENCE.

WARNING: When using electrical appliances, basic safety precautions should always be followed as below:

1. Read all instructions and retain the instruction manual in a safe place.
2. Do not touch hot surfaces always use the handles and knobs.
3. Do not immerse cord, plug, or base unit in water or other liquids.
4. Close supervision is recommended when the appliance is used near children.
5. Unplug when not in use or before cleaning.
6. Always allow the percolator to cool before cleaning.
7. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged.
8. The use of accessories or attachments is not recommended.
9. Do not use outdoors or in wet/damp environments
10. Do not let power cord hang over edge of table, counter, or touch hot surfaces.
11. Do not place on or near a hot gas or electric burner, or in a heated oven.
12. Always fill the percolator first, then set the appliance onto the swivel base and plug in. To disconnect, turn any control to off, then remove plug from wall outlet.
13. Do not operate when the water is below the minimum level.
14. The appliance is not intended to be operated by means of an external timer or separate remote-control system.
15. The housing may get hot when the appliance is operating.
16. If the tank of appliance is overfilled, boiling water may be ejected.
17. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
18. Children should be supervised to ensure that they do not play with the appliance.
19. If the SUPPLY CORD is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.
20. The appliances are not intended to be operated by means of an external timer or separate remote-control system.
21. This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
22. To prevent damage or serious injury discontinue use of the Percolator and contact customer support if Brew Progress Knob is loose and/or will not screw onto the lid tightly.
23. The appliance is only to be used with the stand provided.
24. To against electric shock, never make spillage on the connector of stand.
25. Do not use appliance for other than intended use.

SHORT CORD PURPOSE

Note: A short power cord is provided to reduce the risk of personal injury resulting from becoming entangled in or tripping over a long cord.

Longer power-supply cords or extension cords may be used if care is exercised in their use.

If an extension cord is used: (1) the marked electrical rating of the extension cord should be at least as great as the electrical rating of the product; (2) the extension cord should be arranged so that it will not drape over the counter top or tabletop where it can unintentionally be pulled on or tripped over by children or pets.

POLARIZED PLUG

If this appliance is equipped with a *polarized plug* (one blade is wider than the other), please follow the below instructions:

To reduce the risk of electrical shock, this plug is intended to fit into a polarized outlet only one way. If you are unable to fit the plug into the electrical outlet, try reversing the plug.

If the plug still does not fit, contact a qualified electrician. Never use the plug with an extension cord unless the plug can be fully inserted into the extension cord. Do not alter the plug of the product or any extension cord being used with this product. Do not attempt to defeat the safety purpose of the polarized plug.

**SAVE THESE INSTRUCTIONS.
THIS PRODUCT IS FOR
HOUSEHOLD USE ONLY.**

PARTS IDENTIFICATION



- | | |
|---------------------------------------|----------------------|
| A. Spout | F. Base |
| B. Brew Progress Knob | G. Coffee Basket Lid |
| C. Lid | H. Coffee Basket |
| D. Cool Touch Handle | I. Pump Tube |
| E. On/Off Button with Indicator Light | J. Spring |

STOP!

Under NO circumstances should this percolator or any of its parts or components be placed ON or NEAR a stovetop, range, or open flame.

Doing so will cause serious damage to the percolator and/or injury to person.

This is NOT a stovetop percolator

BEFORE FIRST USE

1. Before using your percolator for the first time, thoroughly wash all parts of the percolator.
2. Always ensure that the Brew Progress Knob is in position on the lid. Ensure that it is not loose or unstable.
3. To remove the Brew Progress Knob on the lid, simply twist counter-clockwise to unscrew. To reattach the knob back to the lid, simply twist clockwise to lock it back into place. Do NOT snap or push the knob back into position. Make sure the black washer ring is always in position.
4. If the Brew Progress Knob feels loose or unstable in any way, please contact Customer Support to obtain a replacement.
5. Discontinue use of the Coffee Percolator if it has a loose or unstable Progress Knob to reduce the risk of damage or personal injury.

HOW TO USE

1. Remove coffee basket lid, coffee basket, stainless steel lid, and pump tube with spring. Using the measurement markings found on the inside of the unit, fill the Percolator with the desired amount of water. For best results, please use cold water.
2. Place Coffee Basket over pump tube and spring. Add desired amount of coffee grounds using the markings found inside the Coffee Basket.
3. Place Coffee Basket and Pump Tube assembly into the Percolator so that the bowl shaped end of the Pump Tube fits directly into the well found on the bottom of the inside of the Percolator. Place Coffee Basket Lid over the Coffee Basket and push the Stainless Steel Lid on top of the Percolator.
4. Plug the Swivel Base into an outlet and connect the Percolator to the Swivel Base. Press the on/off button to brew coffee, the red indicator light will light up. When coffee is finished brewing, the blue indicator light will illuminate and automatically keep warm for 30 minutes until the percolator automatically cuts off the power.

No. of Cups of Coffee	Mild (tbsp)	Medium (tbsp)	Strong (tbsp)
12	6	8	10
10	5	7	9
8	4	6	8
6	3	4	6
4	2	3	4

Questions? We're here to help!
Visit: shopelitegourmet.com for support on this product.



NOTE:

- It is best to use coarse ground coffee as finer grounds will sift through the holes in the Coffee Basket. The following chart can be referenced as a guide for brewing coffee at various strengths.

- Please note that once the percolator is removed from the base, it will reset and shut off. Press the power button again to maintain the Keep Warm function.



CAUTION:

Never fill the percolator above the maximum level since hot foaming coffee or other liquids might overflow during heating.

CLEANING & MAINTENANCE

1. Always remove the Percolator from the Swivel Base then unplug Swivel Base from the wall outlet before attempting to clean the Percolator.
2. Allow Percolator to cool before cleaning.
3. Remove the Percolator body from the swivel base. Make sure the unit is sitting evenly on a flat surface. Grasp the lid with the Brew Progress knob and gently pull straight up.
4. Gently, pull the Coffee Basket, Coffee Basket Lid, and Pump Tube straight up and out of the body. Take the Coffee Basket Lid off the Coffee Basket and dispose of used coffee grounds.
5. The Stainless Steel Lid, Coffee Basket, Coffee Basket Lid, and Pump Tube (with spring) can all be placed into the upper rack of a dishwasher or washed in warm soapy water and rinse thoroughly.
6. Simply wipe the Percolator body and base with a clean, damp cloth and dry before storing.
7. Storage: The power supply cord is attached to the swivel base. For clutter free storage, wrap the power cord into a coil underneath the swivel base.

Brew Progress Knob

1. To remove the Brew Progress Knob on the lid, simply twist counter-clockwise to unscrew.
2. Rinse under warm water to clean and dry thoroughly. To reattach the knob back to the lid, simply twist clockwise to lock it back into place. Do NOT snap or push the knob back into position. Make sure the black washer ring is always in position.
3. If the Brew Progress Knob feels loose or unstable in any way, please contact Customer Support to obtain a replacement.
4. Discontinue use of the Coffee Percolator if it has a loose or unstable Progress Knob to reduce the risk of damage or personal injury.

Removal Of Mineral Deposits And Lime Scale:

Lime Scale forms over time when water is heated. Though scale is natural and harmless, it may produce a powdery substance or mineral-like chunks that can get into your hot beverages and affect the taste.

Mineral deposits in tap water may cause the percolator interior to discolor. To remove this build-up, use Liquid De-scaler, a simple to use, non-toxic cleaner.

Alternatively:

1. Fill the percolator with 3 cups of white vinegar and the remainder with water and be allowed to stand overnight. DO NOT BOIL!
 2. Empty the solution from the percolator, any stains remaining inside the spout can be removed by rubbing with a damp cloth. Fill the percolator with clean water, bring to boil and then discard the water. Repeat and the percolator will then be ready to use.
- 6 Questions? We're here to help!
Visit: shopelitegourmet.com for support on this product.



NOTE:

The washer at the bottom of the pump tube must be able to move freely to ensure error free operation. In the event that coffee grounds become trapped near the washer, loosen the trapped coffee grounds with a toothpick, and then run under water to clean.



CAUTION:

- Never immerse the swivel base, its cables or the plug into water or wash in a dishwasher.
- Do not use scouring agents or harsh cleaners on any part of the percolator.

LIMITED WARRANTY* ONE (1) YEAR
WARRANTY IS ONLY VALID WITH A DATED PROOF OF PURCHASE

PLEASE DO NOT RETURN TO STORE OF PURCHASE.

If you have any problems with this unit, contact Customer Service for support.

1. Your small kitchen appliance is warranted to the original purchaser to be free from any manufacturing defects under normal use and conditions for one (1) year, cord excluded. This Warranty applies only to the original purchaser of this product.
2. Retail stores/merchants selling this product do not have the right to alter, modify, or in any way revise the terms and conditions of the warranty.
3. If you use your appliance for household use and according to instructions, it should give you years of satisfactory service.
4. At its sole discretion, Maxi-Matic USA will either repair or replace the product found to be defective during the warranty period.
5. The repaired or replacement product will be in warranty for the remaining balance of the one-year warranty period and an additional one-month period.
6. Consumer's remorse is not an acceptable reason to return a product to our Service Center.
7. This limited warranty covers appliances purchased and used within the 50 U.S. states plus the District of Columbia and does NOT cover normal wear of parts or:
 - Damages caused by unreasonable use, neglect, normal wear and tear, commercial use, improper assembly or installation of product.
 - Damages caused in shipping.
 - Damages caused by replacement or resetting of house fuses or circuit breakers.
 - Defects other than manufacturing defects.
 - Breakage caused by misuse, abuse, accident, alteration, lack of proper care and maintenance, or incorrect current or voltage.
 - Lost or missing parts of the product. Parts will need to be purchased separately.
 - Damages of parts that are not electrical; i.e. cracked or broken plastic/glass, scratched/dented inner pots.
 - Damage from service or repair by unauthorized personnel.
 - Extended warranties purchased via a separate company or reseller.
 - Acts of nature such as fire, floods, hurricanes, tornadoes, etc.
8. **This warranty does not apply to re-manufactured merchandise.**

Maxi-Matic, USA shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Apart from the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in time to the duration of the warranty.

*One Year Limited Warranty valid only in the 50 U.S. states plus the District of Columbia, excluding Puerto Rico and the Virgin Islands.

This warranty is effective only if the product is purchased and operated in the USA; product usage which is in violation of the written instructions provided with the unit will void this warranty. For international warranty, please contact the local distributor.

This warranty gives you special legal rights and you may also have other rights to which you are entitled which may vary by state, province, and/or jurisdiction.

**Any instruction or policy included in this manual may be subject to change at any time.

MAXI-MATIC, USA

18401 E. Arenth Ave. City of Industry, CA 91748

Visit: shopelitegourmet.com for Live Chat Support and Contact Us Form

RETURN INSTRUCTIONS

RETURNS:

- A. Any return of defective merchandise to the manufacturer must be processed accordingly by first contacting customer service to obtain an RA # (Return Authorization Number). We will not accept any returns of merchandise without an applicable RA #.
- B. **IMPORTANT RETURN INSTRUCTIONS.** Your Warranty depends on your following these instructions if you are returning the unit to Maxi-Matic, USA:
1. Carefully pack the item in its original carton or other suitable box with sufficient cushioning to avoid damage in shipping.
 2. Before packing your unit for return, be sure to enclose:
 - a) Your name, full address with zip code, daytime telephone number, and RA#,
 - b) A dated sales receipt or PROOF OF PURCHASE,
 - c) The model number of the unit and the problem you are having (Enclose in an envelope and tape directly to the unit before the box is sealed,) and
 - d) Any parts or accessories related to the problem.
 3. Maxi-Matic, USA recommends that you ship the package via UPS ground service for tracking purposes. **We cannot assume responsibility for lost or damaged products returned to us during incoming shipment.** For your protection, always carefully package the product for shipment and insure it with the carrier. C.O.D shipments cannot be accepted.
 4. **All return shipping charges must be prepaid by you.**
 5. Once your return has been received by our warehouse, Maxi-Matic, USA will repair or replace the product if it is defective in material or workmanship, subject to the conditions in paragraph B.
 6. **Maxi-Matic will pay the shipping charges to ship the repaired or replacement product back to you.**

Elite Gourmet

Elite Customer Service Center

Mail: Maxi-Matic, USA
18401 E. Arenth Ave
City of Industry, CA
91748-1227

Website: shopelitegourmet.com
Visit our website for Live Chat Support
& Contact Us Form
Register your product online



We take pride in the fact that Elite Gourmet products are continuously improving. To keep you well informed of these changes and to reduce paper consumption, we've included this QR code for you to scan and easily download the most recent updates to your product to your mobile device.

It's simple, just access your camera, point at the QR code & your mobile device will do the rest.



[elitebymaximatic](https://www.facebook.com/elitebymaximatic)



[@elite_by_maximatic](https://www.instagram.com/elite_by_maximatic)

Elite is a registered trademark of Maxi-Matic, USA.
Copyright Elite by Maxi-Matic.

Actual product may vary from the images/illustrations in this manual due to continual product improvement.

MODEL: EC812