




OPERATION AND MAINTENANCE MANUAL



English

Ed. 09/2022 - ver. 002

Pizza Ovens NUOVO

FOREWORD

- This manual has been designed to provide the **customer** with all the information and safety standards necessary for the use of the oven, as well as the operating and maintenance instructions which will guarantee the correct operation of the appliance and its optimum performance over time.
- This manual must be given to the users of the oven and to those responsible for its maintenance.

CONTENTS

CHAP. 1 - INFORMATION ON THE OVEN	page 4
1.1 - GENERAL SAFETY PRECAUTIONS	
1.2 - DESCRIPTION OF THE OVEN	
1.2.1 - General description	
1.2.2 - Construction features	
1.2.3 - Oven parts	
CHAP. 2 - TECHNICAL INFORMATION	page 5
2.1 - OVERALL DIMENSIONS, WEIGHT, FEATURES...	
CHAP. 3 – OVEN DELIVERY	page 6
3.1 - SHIPPING OF THE OVEN	
3.2 - INSPECTION PACKAGING UPON DELIVERY	
3.3 - PACKAGING PROCESS	
CHAP. 4 - INSTALLATION	page 7
4.1 - OVEN SET-UP	
4.2 - ELECTRICAL CONNECTION	
4.2.1 - ELECTRICAL CONNECTION OF THE OVEN	
4.3 - OPERATIONAL CHECK	
CHAP. 5 - OPERATING THE OVEN	page 8
5.1 - CONTROLS	
5.2 - LOADING AND COOKING THE PRODUCT	
CHAP. 6 - ROUTINE CLEANING	page 9
6.1 - GENERAL	
6.2 - OVEN CLEANING PROCEDURE	
CHAP. 7 - MAINTENANCE	page 9
7.1 - GENERAL	
7.2 - POWER SUPPLY CABLE	
7.3 - TROUBLESHOOTING	
CHAP. 8 - DISMANTLING	page 10
8.1 - PUTTING THE OVEN OUT OF SERVICE	
8.2 - WEEE Waste Electrical and Electronic Equipment	
CHAP. 9 - ELECTRICAL DIAGRAM	page 11
9.1 - OVEN - 1ph or 3ph 208V / 220V.	

CHAP. 1 - INFORMATION ON THE OVEN

1.1 - GENERAL PRECAUTIONS

- The oven may only be operated by specialists who are fully aware of the safety standards described in this manual.
- In case of a personnel turnover, training is to be provided in advance.
- Before any cleaning or maintenance operation, disconnect the unit from the power supply.
- Residual risks must be carefully assessed when cleaning and maintaining the oven.
- Remain focused during cleaning and maintenance operations.
- Regularly check the condition of the power cord; a worn or damaged cord represents a serious electrical hazard.
- If the oven shows any signs or indications of malfunction, we recommend that you do not use the appliance and do not carry out repairs directly but contact the "After Sales Service".
- Do not use the oven for frozen food or non-food products.
- The manufacturer is not liable for damage to objects or persons in the event of an incident:
 - ⇒ if unauthorized persons have repaired or modified the oven.
 - ⇒ if any parts have been replaced by non-original parts.
 - ⇒ if the instructions in this manual have not been **carefully** followed.
 - ⇒ if the oven surface has been treated with unsuitable products.

1.2 - DESCRIPTION OF THE OVEN

1.2.1 - general description

The oven has been designed and manufactured by our company with the specific aim of guaranteeing:

- maximum safety during use, cleaning and maintenance;
- maximum hygiene, thanks to the careful selection of materials in contact with food;
- robust and stable components;
- sturdiness and stability of all components;
- excellent visibility and handling.

This oven has been designed for baking pizzas, focaccias, piadinas, etc. It must not be used for cooking other foods (meat, vegetables, etc.).

1.2.2 - Construction Features

This appliance is built entirely from the following materials:


- Internal and external structure in stainless steel, aluminized steel, and pre-painted steel.
- Baking surface in refractory stone.

1.2.3 - Oven parts

FIG. n°1 - Main view of the oven


REFERENCES:

- 1. External structure
- 2. Door handle
- 3. Door
- 4. Controls
- 5. Smoke extraction chimney



CHAP. 2 - TECHNICAL INFORMATION

2.1 - OVERALL DIMENSIONS, WEIGHT, FEATURES...



TAB. n°1 - OVERALL DIMENSIONS AND TECHNICAL SPECIFICATIONS

Model		NUOVO
Power	watts	6.400
Power supply		208V / 220V 60 Hz 1Ph or 3Ph
Temperature	°C °F	50 - 450°C 120 - 840°F
Inside dimensions	mm in	(W) 500 x (L) 520 (H)115 (x2) (W)21.6" x (L)19.6" x (H) 4.5"
A x B x D	mm in	(W) 780 x (L) 720 x (H) 600 (W) 30.7" x (L) 28.3" x (H) 20.8"
C	mm in	810 31.8"
Net weight	kg lbs	70 kg 154.3 lbs
Shipping weight	kg lbs	83 kg 183lbs

WARNING: Oven electrical specifications are indicated on the rating plate affixed to the side of the oven; before connecting to power supply, please read chap. 4.2.

CHAP. 3 – OVEN DELIVERY

3.1 - SHIPPING OF THE OVEN (see FIG. n°3)

The oven is carefully packed and shipped from our warehouse.

The package includes:

- a) a sturdy cardboard box on a pallet;
- b) the oven;
- c) this manual.




FIG. n°3 - Package description

3.2 - INSPECTION PACKAGING UPON RECEIPT

Upon receipt of the appliance if the external packaging shows no signs of damage, open and check that there are no missing parts. If upon receipt of the appliance, the packaging shows signs of damage or seems to have been dropped or hit, inform the carrier of the damage and within three days of the date of delivery provided in the transport document, send a report detailing the damage to the appliance.

3.3 - PACKAGING PROCESS

The packaging components (cardboard, pallet, plastic straps and polyurethane foam) are solid urban waste and therefore they can be easily disposed of.

If the oven is to be installed in countries with specific regulations, the packaging must be disposed of in accordance with these regulations.

CHAP. 4 - INSTALLATION

4.1 - OVEN SET-UP

Once the oven has been removed from its packaging, remove the protective adhesive film from the outer casing. This film must always be removed before using the oven (check that no plastic film remains on the appliance, and do not use abrasive substances to remove the plastic film). Check that the work surface on which the unit is to be placed is sufficiently large (see technical specifications), flat, sturdy, dry, stable and resistant to high temperatures.

Place the oven at least 10 cm away from walls, which must be able to withstand high temperatures, and in a suitable room equipped to evacuate the heat generated by the oven.

4.2 - ELECTRICAL CONNECTION

4.2.1 - Electrical connection of the oven

The appliance is supplied without power cable or plug: these must be installed by qualified personnel. The cable must be of the type indicated, and the plug must be suitable for the power consumption and the connection of the oven to the mains.

The appliance must be connected to a power supply with a minimum 10AWG cable (supplied by the installer). To carry out this operation, remove the oven's right-side panel (FIG. n°4),

connect the cable to the terminal board and secure it using the relative cable gland located on the back of the appliance itself (FIG. n°5).

Connect the oven to 208/220 Volt 60 Hz 1 or 3 phase, by interposing a differential thermomagnetic switch 35A, $\Delta I = 0.03A$.




FIG. n°4




FIG. n°5

4.3 - OPERATIONAL CHECK


Before testing the appliance, make sure the plug is securely plugged into the power socket, then test the unit by following each step of the procedure below:

1. Start the oven by turning the thermostat knob to switch on the heating elements.
2. With the oven running, set the temperature to 200°C.
3. Once the set temperature has been reached, operate the oven empty under the supervision of an operator for at least 2 hours, occasionally opening the front doors. In addition to checking that the oven is working properly, this operation allows any residue from processing and moisture from the firing stones to evaporate.
4. Switch off the oven's heating elements by turning the knob back to its initial position.

CHAP. 5 - OPERATING THE OVEN

5.1 - CONTROLS

The controls are located on the right front of the oven, as shown in the figure below.



1. Resistance intervention indicator
2. Upper heating element temperature control thermostat
3. Lower heating element temperature control thermostat

The two chambers can be switched on separately or simultaneously.

5.2 - LOADING AND COOKING THE PRODUCT (refer to Fig.n°6)

To cook proceed as follows:

1. Start the oven by setting the thermostat to the desired temperature (Ref. 2 - 3).
2. Once the oven has reached the desired cooking temperature place the food to be cooked inside the oven. Always use the handle to open the oven door.
3. When the work cycle is complete, turn the knob back to its initial position (Ref. 2 - 3).
4. **WARNING!** During cooking, the outer surface of the oven reaches very high temperatures. Avoid getting too close.
5. **WARNING!** Wait until the oven has cooled down completely before coming into direct contact with it, and always use the door handle to open the door.
6. During cooking, you can remove cooking residuals from the worktop with a fireproof brush.

CHAP. 6 - ROUTINE CLEANING

6.1 - GENERAL

- The oven should be cleaned at least once a day, or more frequently if necessary.
- All parts of the oven in direct or indirect contact with the food to be cooked must be scrupulously cleaned.
- The oven must not be cleaned with hydro-cleaners or water jets (to avoid infiltrations that could damage the oven interior); no utensils or brushes should be used to clean the oven exterior surface.

Before starting cleaning operations, it is necessary to:

1. Set the switch to its initial 0° position (Fig. 6 - Ref. 2 - 3).
2. Disconnect the oven plug from the mains supply.

6.2 - OVEN CLEANING PROCEDURE

N.B. Do not clean the appliance until it has cooled down completely. To avoid burns, we recommend using anti-scald gloves when cleaning.

To clean the unit, proceed as follows:

1. Open the oven door using the handle.
2. Brush the refractory stone floor.
3. **WARNING! DO NOT** pour cold water or any other substance onto the refractory cooking stone to clean it. **ONLY** use a oven brush to remove any food waste.
4. Use a damp cloth and neutral detergent to clean the glass and the door.
5. After cleaning the inner cooking chamber and outer casing make sure that all parts of the oven are completely dry.

CHAP. 7 - MAINTENANCE

7.1 - GENERAL

Before carrying any maintenance operation, it is necessary to:

1. Set the switch to its initial 0° position (Fig. 6 - Ref. 2 - 3).
2. Disconnect the mains plug from the power supply.

7.2 - POWER SUPPLY CABLE

Periodically check power cable for wear. If the power cable shows signs of wear or deterioration, call the "SERVICE CENTER" for replacement.

7.3 - TROUBLESHOOTING

In the event of a breakdown or malfunction, contact your "LOCAL SERVICE CENTER".

CHAP. 8 - DISMANTLING

8.1 - PUTTING THE OVEN OUT OF SERVICE

If, for any reason, you decide to put the oven out of service, make sure no one else can use it: unplug it and disconnect the electrical connections.




8.2 - WEEE Waste Electrical and Electronic Equipment

The crossed-out wheeled-bin symbol on the equipment or its packaging indicates that, at end-of-life, the product must be collected separately from other waste. Selective sorting of end-of-life equipment is organized and managed by the producer. Users wishing to dispose of their equipment must therefore contact the producer and follow the instructions adopted by the latter to enable selective sorting of the enclosed equipment at end-of-life.

Appropriate selective sorting for recycling, treatment and environmentally-friendly disposal of end-of-life equipment helps to avoid possible negative effects on the environment and health, and promotes the reuse and/or recycling of the materials of which the equipment is composed. Incorrect disposal of the product by the holder will result in the application of the administrative penalties provided for by the applicable regulations.

CHAP. 9 - ELECTRICAL DIAGRAM

9.1 - OVEN - 1ph or 3ph 208V / 220V.



English

FIG. n°7



Eurodib Inc.
Address: 120 de la Barre
Boucherville
QC J4B 2X7
CANADA

Tél: 1-888-956-6866
www.eurodib.com
customerservice@eurodib.com

Eurodib Corp.
Mailing address:
334 Cornelia St. #272
Plattsburgh, NY, 12901
USA

Office:
401 Penbrooke Dr., Suite 3R
Penfield, NY, 14526
USA

**SERVICE CENTRE
AUTHORISED DEALER**