



morphy richards®

**3 Year
Guarantee***

*Upon registering your product
at morphyrichards.co.uk

SEAR & STEW Stainless Steel 6.5L Slow Cooker



Model No.

461014 461026
461023 461027
461024

User Manual

Please read and keep these
instructions for future use



Health And Safety

The use of any electrical appliance requires the following common sense safety rules. Please read these instructions carefully before using the product.

- This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Keep the appliance and its cord out of the reach of children aged less than 8 years. Children shall not play with the appliance.
- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- **WARNING:** Misuse of appliance could cause potential injury.
- Do not immerse main unit in water.
- This appliance is intended for household use only. It is not suitable for use in staff kitchen areas in shops, offices and other working environments.
- This appliance is not intended to be operated on an extension cable or by means of an external timer or a separate remote-control system.
- If the supply cable is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Location

- Always locate your appliance away from the edge of the worktop.
- Ensure that the appliance is used on a firm, flat, heat resistant surface.
- Do not use the appliance outdoors or near water.

Mains cable

- The mains cable should reach from the socket to the appliance without straining the connections.
- Do not let the mains cable hang over the edge of the worktop or open space where a child could reach it.
- Do not let the cable run across a cooker or hot area which might damage the cable.

Other safety considerations

- Do not switch on the Slow Cooker if the Cooking Pot is empty.
- Allow the Glass Lid and Cooking Pot to cool before immersing in water.
- Never cook directly on the Base Unit. Use the Cooking Pot.
- Do not switch on the Base Unit without the Cooking Pot in place.
- Switch off the Base Unit before removing the Cooking Pot.
- Do not use the Cooking Pot or Glass Lid if cracked or chipped.
- Do not switch on the appliance when it is upside down or laid on its side.
- The Glass Lid and Cooking Pot are fragile.

Handle them with care.

- The use of attachments or tools not recommended by Morphy Richards may cause fire, electric shock or injury.
- Do not place on or near a hot gas or electric burner or in a heated oven.
- The heating element surface is subject to residual heat after use.
- Unplug from the socket when not in use, before putting on or taking off attachments, and before cleaning.

Personal safety

- **WARNING: Do not touch the top of the appliance or other hot parts during or after use, use handles or knobs. Misuse of this appliance could cause potential injury.**
- To protect against the risk of electrical shock do not put base in water or in any other liquid.
- Do not touch hot surfaces. Use oven gloves or a cloth when removing lid or handling hot containers.
- Extreme caution must be used when moving an appliance containing hot food, water, or other hot liquids.

Electrical requirements

Check that the voltage on the rating plate of your appliance corresponds with your house electricity supply which must be A.C. (Alternating Current).

Should the fuse in the mains plug require changing, a 3 amp BS1362 fuse must be fitted.

WARNING: This appliance must be earthed.



Introduction

Thank you for purchasing your new Morphy Richards Slow Cooker.

Your Sear & Stew Slow Cooker will allow you to create an extensive selection of meals with the added benefit of being able to sear the meat in the same pan. Searing meat in the cooking pan means that the juices from the meat combine with the rest of the ingredients creating richer fuller flavours in your dishes.

Contents

Health And safety	2
Before First Use	3
Features	4
Using Your Slow Cooker	5
Handling The Cooking Pot	6
Handling The Glass Lid	6
Foods For Slow Cooking	6
Slow Cooking Tips	6
Care And Cleaning	7
Caring For The Lid And Cooking Pot	7
Troubleshooting	7
Notes	8
Recipes / Cooking Guide	9
Recipes - Soup	10
Recipes - Poultry	10
Recipes - Meat	11
Recipes - Dessert	15
Contact Us	15
Guarantee	16

Before First Use


Wash the Lid (2) and Cooking Pot (3) in hot, soapy water. Rinse and dry.

Note

The Cooking Pot is not suitable for use on an induction hob.



Product Overview




Features


- (1) Lid Handle
- (2) Glass Lid
- (3) Cooking Pot
- (4) Base Unit
- (5) Base Handles
- (6) Indicator Light
- (7) Control Knob




Using Your Slow Cooker




Add oil to Cooking Pot (3). Refer to the recipe for the correct amount of oil to use.




Pre-heat the oil in the Cooking Pot (3) on the hob over a medium-high heat. The Cooking Pot (3) is compatible with most hobs, except induction.




When the oil is hot, add the meat in to the Cooking Pot (3). **WARNING:** The Cooking Pot (3) will be hot. Handle with oven gloves.




When the meat has seared, place the Cooking Pot (3) into the Base Unit (4). **WARNING:** The Cooking Pot (3) will be hot. Handle with oven gloves.




Add the rest of the ingredients to the Cooking Pot (3).



Place the Glass Lid (2) on the Cooking Pot (3).



Select Low, Medium or High cooking setting on the Control Knob (7) to start slow cooking. The Indicator Light (6) will illuminate



When cooking has finished (refer to the cooking guide on page 9), turn the Control Knob (7) to Off. The Indicator Light (6) will switch off.



Handling The Cooking Pot

- **WARNING:** The Cooking Pot (3) will become very hot when in use.
- To prevent the Cooking Pot from slipping when using to sear, saute or fry the ingredients on your hob, use an oven glove to support the Cooking Pot when stirring the food.
- Be careful when using the Cooking Pot on a gas hob, select the correct size gas ring to fit the base area of the Cooking Pot. **DO NOT use on a wok burner or oversized gas hob.**
- Do not use metal utensils to stir food in the Cooking Pot as this will scratch and remove the non stick coating. Use either wood or silicone plastic utensils.
- **WARNING:** The Lid handle (1), the Base Unit (4) and the Cooking Pot (3), as well as the outside of the Base Unit, all become hot during cooking. Always use oven gloves when handling ANY part of the Slow Cooker during cooking.

Handling The Glass Lid

- When removing the Glass Lid (2), tilt so that opening faces away from you to avoid being burned by steam.

Foods For Slow Cooking

- Most foods are suited to slow cooking methods, however there are a few guidelines that need to be followed.
- Ensure all frozen ingredients are thoroughly defrosted prior to cooking.
- Cut root vegetables into small, even pieces, as they take longer to cook than meat. They can be gently sauteed for 2-3 minutes before slow cooking. Ensure that root vegetables are always placed at the bottom of the Cooking Pot (3) and all ingredients are immersed in the cooking liquid.
- Trim all excess fat from meat before cooking, as the slow cooking method does not allow fat to evaporate.
- If adapting an existing recipe from conventional cooking, you may need to reduce the amount of liquid used. Liquid will not evaporate from your Slow Cooker to the same extent as conventional cooking.
- Never leave uncooked food at room temperature in your Slow Cooker.

- Uncooked kidney beans must be soaked overnight and boiled for at least 10 minutes to remove toxins before use in a Slow Cooker.
- Insert a meat thermometer into joints of roasts, hams or whole chickens to ensure they are cooked to the desired temperature.
- Do not use your Slow Cooker to reheat food.

Slow Cooking Tips

- The Slow Cooker must be at least half full for best results.
- Slow cooking retains moisture. If you wish to reduce liquid, remove the lid after cooking and turn the control to High. Reduce the moisture by simmering for 30 to 45 minutes.
- If cooking soups, leave 5 cm gap from the rim of the Cooking Pot (3) and the food surface to allow for simmering.
- Removing the Glass Lid (2) will allow heat to escape, reducing the efficiency of your Slow Cooker and increasing the cooking time. If you remove the lid to stir or add ingredients, you will need to allow 10-15 minutes extra cooking time for each time you remove the Glass Lid.
- Many things can affect how quickly a recipe will cook, including water and fat content, initial temperature of the food and the size of the food. Check food is properly cooked before serving.
- Many recipes will take several hours to cook. If you don't have time to prepare food in the morning, prepare it the night before, storing the food in a covered container in the fridge. Transfer the food to the Cooking Pot and add boiling liquid/stock. In most of the recipes in this book, the meat ingredients are browned first to improve their appearance and flavour.
- If you are short on preparation time and would prefer to skip the searing stage, simply add your meat and other ingredients into your Slow Cooker and cover with boiling liquid/stock. You will need to increase the recipe cooking time as follows: High setting +1hr, Medium setting +1-2 hrs, Low Setting +2-3hrs.
- Most meat and vegetable recipes require 8-10 hours on Low, 5-7 hours on Medium and 4-6 hours on High.
- Some ingredients are not suitable for slow cooking. Pasta, seafood, milk and cream should be added towards the end of the cooking time.
- Pieces of food cut into small pieces will cook quicker. A degree of 'trial and error' will be required to fully optimise the potential of your Slow Cooker.



- All food should be covered with a liquid, gravy or sauce. In a separate pan or jug, prepare your liquid, gravy or sauce and completely cover the food in the Cooking Pot (3).
- When cooking joints of meat, ham, poultry etc, the size and shape of the joint is important. Try to keep the joint in the lower 2/3 of the pot. If necessary, cut into two pieces. Joint weight should be kept within the maximum limit of 2kg.
- For ham and brisket fill with hot water to just cover the joint. For beef, pork or poultry cover to 1/3 depth.

Care And Cleaning

- Turn off and unplug you Slow Cooker from the mains. Allow to cool completely before cleaning.
- Do not use metal utensils or abrasive cleaners when cleaning.
- Remove the Glass Lid (2) and Cooking Pot (3) and clean in hot soapy water.
- Wipe the sides of the main unit with a damp cloth.
- The Glass Lid and Cooking Pot are dishwasher safe.

DO NOT IMMERSE THE MAIN UNIT IN WATER

Caring For The Glass Lid And Cooking Pot

- Please handle the Glass Lid (2) and Cooking Pot (3) carefully to ensure long life.
- Avoid sudden, extreme temperature changes to the Glass Lid. For example, do not place a hot lid into cold water or onto a wet surface.
- Avoid hitting the Glass Lid against any hard surfaces.
- Do not use the Glass Lid if chipped, cracked or severely scratched.
- Do not use abrasive cleansers or metal scouring pads.
- Never heat the Cooking Pot when empty, when searing or browning add the meat as soon as the oil is hot.
- Never place the Glass Lid or Cooking Pot under a grill, in the oven, in a microwave or toaster oven.
- Never place lid directly on a burner or hob.
- Do not use metal utensils when searing or to stir food in the Cooking Pot as this will scratch and remove the non stick coating. Use either wooden or silicone plastic utensils.

Troubleshooting


Problem	Reason	Solution
• Food is undercooked.	• Loss of power	• Test the mains outlet with a lamp known to be working.
	• Food cooked on wrong setting for cooking time	• Check the Control Knob position and the recipe details.
	• Glass Lid not placed correctly on the Cooking Pot	• Check the Glass Lid is correctly placed and nothing is obstructing it.
• Food is overcooked.	• Cooking Pot was under half full	• Your Slow Cooker has been designed to thoroughly cook food in a filled Cooking Pot. If the Cooking Pot is only half-filled, check to see if the food is cooked 1 to 2 hours earlier than recipe time.
	• Food cooked too long	• Check the Control Knob position and the recipe details.
	• Cooking Pot placed in Base Unit while still very hot.	• Cooking time may be shortened. Check food is cooked 30 minutes to 1 hour earlier than the stated recipe time.



Notes



Recipes



We have developed 12 recipes for you to use in your Sear and Stew Slow Cooker. From soups for starters, curries for mains and pears in red wine for dessert, there are choices for all tastes.

The cooking times given in the following recipes are for the Medium setting. Should you want to increase or decrease the cooking time, please refer to the cooking guide below. Please note that these cooking times are for guidance only and may vary depending on food type and personal tastes.

For example if the recipe says cook for 4-6 hours on Medium and you require the cooking time to be shorter, cook on High, which will reduce the cooking time to 3-4 hours. To increase the cooking time, choose Low which will increase the cooking time to 8-10 hours.

The recipes are based on the maximum working volume of your slow cooker (5 litres / 10.5 pints). This allows a 2cm space between the top of the pot and the food.

Cooking Guide

Cook on Low

- 8-10 hours

Cook on Medium

- 4-6 hours

Cook on High

- 3-4 hours



Recipes - Soup

Vegetable soup

Ingredients:

- 60g butter
- 1.8kg mixed vegetables, e.g. potatoes, onions, carrots, parsnips, celery, leeks, tomatoes
- 2L vegetable stock
- mixed herbs to taste
- salt and pepper
- 60g plain flour

Method:

- 1 Peel, wash and cube or slice all the vegetables.
- 2 Melt butter in the Cooking Pot and gently fry the vegetables on the hob for 2-3 minutes.
- 3 Add the hot stock. Stir well and bring to the boil. Season to taste and add mixed herbs.
- 4 Transfer the Cooking Pot into the Base Unit.
- 5 Cover with the Glass Lid and cook for approximately 4-6 hours on the Medium setting.
- 6 Cool and liquidise the soup.
- 7 Reheat on the hob, thickening the soup with the flour.

Recipes - Poultry

Chicken in white wine sauce

Ingredients:

- 10 chicken breasts
- 40g butter
- 2 large onions, finely chopped
- 400g mushrooms, sliced
- 5tbsp dry white wine
- 750ml chicken stock
- 2tsp mixed herbs
- 3tbsp cornflour
- 3 egg yolks
- 150ml double cream
- salt and pepper

Method:

- 1 Place the chicken breasts and butter in the Cooking Pot and gently fry on the hob until sealed on all sides.
- 2 Add the onion and fry until softened but not browned. Add the mushrooms and cook for a minute on low heat.
- 3 Blend the cornflour with a splash of wine. Pour the remaining wine into the pot with the blended cornflour, mixed herbs and seasoning. Bring to the boil, stirring continuously until thickened.
- 4 Transfer the Cooking Pot into the Base Unit, cover with the Glass Lid.
- 5 Cover with the Glass Lid and cook for approximately 4-6 hours on the Medium setting.
- 6 Just before serving, beat together the egg yolks and cream. Beat in a few tablespoons of the cooking liquid, mix well together. Pour this mixture into the Cooking Pot and stir until the sauce thickens.



Recipes - Meat

Beef Stew

Ingredients:

- 1kg beef, cubed
- 700g potatoes, cubed
- 700g carrots, sliced
- 3 large leeks, sliced
- 2 large onions, chopped
- 2 garlic clove, crushed
- 1.5L beef stock
- 3tbsp cornflour
- 3tsp mixed herbs
- salt and pepper

Method:

- 1 In the Cooking Pot, fry the onions and garlic on the hob until softened, then add the meat and continue to fry until the meat is seared.
- 2 Add the potatoes, carrots and leeks.
- 3 Blend the stock with the mixed herbs. Add to the Cooking Pot and season to taste.
- 4 Transfer the Cooking Pot into the Base Unit.
- 5 Cover with the Glass Lid and cook for approximately 4-6 hours on the Medium setting.
- 6 Before serving, thicken the sauce with the cornflour. Mix the cornflour with a little cold water until a smooth paste is achieved. Mix this into a cup of the hot liquid taken from the Cooking Pot, when fully mixed into the liquid add this back into the rest of the ingredients and stir well until the cornflour is evenly distributed. This can be done 30 minutes from the end of the cooking time.

New England beef

Ingredients:

- 1.5kg topside beef
- 1 bouquet garni
- 2tsp thyme
- 2tsp black peppercorns
- 10 shallots
- 550g carrots, sliced
- 300g swede, diced
- Water (enough to cover the joint)

Method:

- 1 Put the beef into the Cooking Pot and sear on the hob on all sides.
- 2 Add all the remaining ingredients. Cover the beef with cold water (1.2L should be sufficient to submerge the joint.) Place the lid on and bring to a simmer on the hob.
- 3 Season well and then transfer the Cooking Pot into the Base Unit, cover with the Glass Lid.
- 4 Cook for approximately 4-6 hours on the Medium setting.
- 5 Take the beef out of the Cooking Pot with a slotted spoon and allow to cool for 10 minutes. The cooking liquid can be used as a base to make gravy.
- 6 Cut the beef into slices and spoon a little of the cooking liquid over. Serve with vegetables and garnish with fresh parsley.

IMPORTANT: When buying a joint of meat, ensure it will fit into the Cooking Pot, so when it is covered with liquid it will be 2.5cm below the rim. The joint must not stick out above the rim and there should be enough room to cover the meat with water. The shape of the meat is just as important as the weight.



Recipes - Meat

Thai beef curry

Ingredients:

- 60g butter
- 1kg stewing beef, cubed
- 2 onions, chopped
- 4 garlic cloves, crushed
- 6tbsp peanut butter
- 800g coconut milk
- 700g potatoes, quartered
- 4tbsp curry powder
- 4tbsp thai fish sauce
- 4tbsp soft brown sugar
- 1L beef stock

Method:

- 1 In the Cooking Pot, melt the butter and gently brown the beef on the hob.
- 2 Add the onions and garlic and fry until soft.
- 3 Add the remaining ingredients and mix well.
- 4 Transfer the Cooking Pot into the Base Unit, cover with the Glass Lid.
- 5 Cook for approximately 4-6 hours on the Medium setting.

Note: a slight 'crust' of brown meat may appear on the top. It soon disappears if stirred into the sauce.

Beef curry

Ingredients:

- 5tbsp vegetable oil
- 3 medium cooking apples, peeled, cored and sliced
- 3 large onions chopped
- 1.5kg stewing steak, cubed
- 5tsp curry powder
- 1L beef stock
- 5tbsp mango chutney
- 150g sultanas
- 600g tinned tomatoes, chopped
- 3tbsp lemon juice
- 5tbsp cornflour
- salt and pepper

Method:

- 1 Add the oil, apple and onion to the Cooking Pot and fry on the hob until soft.
- 2 Add the steak to the pan and fry until lightly seared.
- 3 Stir in the stock and bring to a simmer.
- 4 Add the remaining ingredients and bring back to a simmer.
- 5 Transfer the Cooking Pot into the Base Unit, cover with the Glass Lid.
- 6 Cook for approximately 4-6 hours on the Medium setting.
- 7 At the end of the cooking time, thicken with the cornflour. Mix the cornflour with a little cold water until a smooth paste is achieved. Mix this into a cup of the hot liquid taken from the Cooking Pot, when fully mixed into the liquid add this back into the rest of the ingredients and stir well until the cornflour is evenly distributed. This can be done 30 minutes from the end of the cooking time.



Bolognese sauce

Ingredients:

- 1.5kg minced beef
- 3 onions, chopped
- 6 sticks of celery, thinly sliced
- 3 garlic cloves, crushed
- 7tbsp tomato puree
- 3tbsp flour
- 3x400g cans chopped tomatoes
- 600ml beef stock
- 300g mushrooms, sliced
- 2tsp mixed herbs
- salt and pepper

Method:

- 1 In the Cooking Pot, gently brown the mince on the hob without adding any fat or oil.
- 2 When the fat has started to run from the meat, add the onion, celery and garlic.
- 3 Fry for a couple of minutes and then add the tomato puree.
- 4 Blend some of the tomato juice with the flour to make a smooth pouring cream, add to the meat with remaining tomatoes and juice and bring to the boil, stirring continuously until thickened.
- 5 Add the remaining ingredients and mix well.
- 6 Transfer the Cooking Pot into the Base Unit, cover with the Glass Lid.
- 7 Cook for approximately 4-6 hours on the Medium setting.

Note: a slight 'crust' of brown meat may appear on the top. It soon disappears if stirred into the sauce.

BBQ beef ribs

Ingredients:

- 1.5kg ribs
- 300ml BBQ sauce

Method:

- 1 Marinade the ribs in the sauce for a few hours, preferably overnight.
- 2 Place in the Cooking Pot and cover with the Glass Lid.
- 3 Cook for approximately 4-6 hours on the Medium setting.



Recipes - Meat

Boiled ham

Ingredients:

- 1.8kg (max) gammon joint

Method:

- 1 Put the gammon in the Cooking Pot, cover with cold water (1.5L should be sufficient to submerge the joint) and bring to the boil.
- 2 Drain and rinse the joint.
- 3 Place the gammon joint back into the Cooking Pot and fill the Cooking Pot with boiling water to roughly cover the joint.
- 4 Transfer the Cooking Pot to the Base Unit, cover with the Glass Lid.
- 5 Cook for approximately 4-6 hours on the Medium setting.

IMPORTANT: When buying a joint of meat, ensure it will fit into the Cooking Pot. The joint must not stick out above the rim. The shape of the meat is just as important as the weight.

Sausage pot

Ingredients:

- 1tbsp oil
- 1.5kg sausages
- 3 large onion, finely chopped
- 5 carrots, thinly sliced
- 3 leeks, sliced
- 1.5L beef stock
- 6tbsp chutney
- 5tbsp worcestershire sauce
- salt and pepper

Method:

- 1 In the Cooking Pot, quickly sear the sausages on the hob on all sides in the oil.
- 2 Add the onions, carrots and leeks and gently saute until softened, but not browned.
- 3 Stir in the flour and cook on a low heat until the oil is absorbed.
- 4 Slowly add the stock and bring to the boil, stirring continuously until thickened.
- 5 Stir in the chutney, worcestershire sauce and seasoning.
- 6 Add the remaining ingredients and bring to a simmer.
- 7 Transfer the Cooking Pot into the Base Unit, cover with the Glass Lid.
- 8 Cook for approximately 4-6 hours on the Medium setting.

If the sausages contain a lot of fat, any excess can be removed from the surface of the finished dish with kitchen paper.



Recipes - Dessert

Rice pudding

Ingredients:

- 60g butter
- 250g pudding rice
- 250g sugar
- 2L milk
- 1tsp nutmeg

Method:

- 1 Butter the sides of the Cooking Pot
- 2 Add all the ingredients and stir well.
- 3 Transfer the Cooking Pot into the Base Unit, cover with the Glass Lid.
- 4 Cook for approximately 8-10 hours on the Low setting.

Sponge Pudding

Ingredients:

- 125g butter
- 4tbsp golden syrup
- 100g caster sugar
- 2 eggs
- 200g self raising flour
- 2tbsp Milk
- 2tbsp Lemon juice

Method:

- 1 Butter the inside of a 1.25L pudding basin and line the bottom with greaseproof paper. of the Cooking Pot
- 2 Pour the syrup into the bottom of the basin.
- 3 In a mixing bowl, cream the butter and sugar until smooth and creamy.
- 4 Gradually mix in the eggs and flour and stir in the milk and lemon juice.
- 5 Spoon the mixture on top of the syrup and cover with pleated baking paper. Tie with string to secure and make a handle.
- 6 Place into the Cooking Pot and fill with boiling water halfway up the sides of the basin.
- 7 Cover with the Glass Lid. Cook for approximately 4-6 hours on the Medium setting.

Contact us

Helpline

If you are having a problem with your appliance, please contact our Helpline, as we are more likely to be able to help than the store you purchased the item from.

Please have the product name, model number and serial number to hand when you contact us to help us deal with your enquiry quicker.

Website: www.morphyrichards.com

E-mail: hello@morphyrichards.co.uk

Registering Your 3 Year Guarantee

Your standard two year guarantee is extended for an additional 12 months when you register the product within 28 days of purchase with Morphy Richards. If you do not register the product with Morphy Richards within 28 days, your product is guaranteed for 2 years. To validate your 3 year guarantee register with us online at www.morphyrichards.co.uk

N.B. Each qualifying product needs to be registered with Morphy Richards individually.

Please note that the 3 year guarantee is only available in the UK and Ireland. Please refer to the two year guarantee for more information.

Your 2 Year Guarantee

It is important to retain the retailer's receipt as proof of purchase. Staple your receipt to this back cover for future reference.

Please quote the following information if the product develops a fault. These numbers can be found on the base of the product.

Model no.

Serial no.

All Morphy Richards products are individually tested before leaving the factory. In the unlikely event of any appliance proving to be faulty within 28 days of purchase, it should be returned to the place of purchase for it to be replaced.

If the fault develops after 28 days and within 24 months of original purchase, you should contact the Helpline quoting Model number and Serial number on the product, or write to Morphy Richards at the address shown.

You may be asked to return a copy of proof of purchase.

Subject to the exclusions set out below (see Exclusions), the faulty appliance will then be repaired or replaced as appropriate and dispatched usually within 7 working days of receipt.

If, for any reason, this item is replaced or repaired during the 2 year guarantee period, the guarantee on the new item will be calculated from original purchase date. Therefore it is vital to retain your original till receipt or invoice to indicate the date of initial purchase.

To qualify for the 2 year guarantee, the appliance must have been used according to the instructions supplied. For example, crumb trays should have been emptied regularly.

Exclusions

Morphy Richards shall not be liable to replace or repair the goods under the terms of the guarantee where:

- 1 The fault has been caused or is attributable to accidental use, misuse, negligent use or used contrary to the manufacturer's recommendations or where the fault has been caused by power surges or damage caused in transit.
 - 2 The appliance has been used on a voltage supply other than that stamped on the products.
 - 3 Repairs have been attempted by persons other than our service staff (or authorised dealer).
 - 4 The appliance has been used for hire purposes or non domestic use.
 - 5 The appliance is second hand or refurbished.
 - 6 Morphy Richards reserves the right not to carry out any type of servicing under the guarantee at its discretion
 - 7 Plastic filters for all Morphy Richards kettles and coffee makers are not covered by the guarantee.
 - 8 Batteries and damage from leakage are not covered by the guarantee.
- This guarantee does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This guarantee is offered as an additional benefit and does not affect your statutory rights as a consumer. Morphy Richards products are intended for household use only. See usage limitations within the location safety instructions.

Disclaimer

Morphy Richards has a policy of continuous improvement in product quality and design. The company, therefore reserves the right to change the specification of its models at any time.



For electrical products sold within the European Community. At the end of the electrical products useful life, it should not be disposed of with household waste.

Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country

**IF YOU ARE HAVING A PROBLEM
WITH ONE OF OUR PRODUCTS,
CONTACT OUR HELPLINE:**

www.morphyrichards.co.uk

hello@morphyrichards.co.uk

morphy richards

9 Cabot Lane
Poole
Dorset
BH17 7BY
UK

