


SMART DROPPER

operating instruction



Before using the product, please read the manual carefully and follow the relevant precautions to ensure the best performance of the equipment and avoid dangerous or illegal situations.

▲ WARNING


- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as **2 hours**.
- **KEEP new and used batteries OUT OF REACH of CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



A – Warning and Safety Information

1. Electrically controlled seatpost products must be installed by qualified bicycle maintenance technicians in accordance with the official installation specifications for electric seatposts. Improper installation may cause malfunctions, lead to loss of bicycle control, and result in serious personal injury or even death.
2. Modifying or altering an electronically controlled seatpost product may cause it to malfunction, potentially resulting in serious injury or even death. Do not modify or alter any part of the electronically controlled seatpost product.
3. Improper maintenance or the installation of non-ECU seat tube replacement parts on an ECU seat tube product may cause the product to malfunction, resulting in serious personal injury or even death. Do not use high-power cleaners to clean the ECU seat tube product. The included dial contains a button battery. The only compatible battery type is the CR2032 (nominal battery voltage: 3 V).
4. Keep new and used batteries out of reach of children. Do not swallow batteries, as they pose a risk of chemical burns. If a button battery is accidentally swallowed, it can cause severe internal burns within just two hours and may lead to serious personal injury or even death. If you believe that a battery has been swallowed or has entered any part of your body, seek medical attention immediately. Please call your local Poison Control Center for information on appropriate treatment. If the battery compartment is not securely closed, stop using this product and keep it out of reach of children; failure to do so may result in serious personal injury or even death.
5. Please remove and immediately recycle or dispose of used batteries in accordance with local regulations; store used batteries out of reach of children. Batteries should not be disposed of together with household waste, nor should they be incinerated. Even used batteries can cause serious injury or even death. Non-rechargeable batteries should not be recharged. Do not forcibly discharge, recharge, disassemble, heat (above the rated temperature specified by the manufacturer), or incinerate these batteries; otherwise, air release, leakage, or explosion may cause chemical burns, resulting in personal injury.
6. Ensure that the positive and negative terminals (+ and –) of the battery are correctly oriented after installation. Do not mix new and old batteries, nor mix batteries of different brands or types (e.g., alkaline batteries, carbon-zinc batteries, or rechargeable batteries). In accordance with local regulations, remove any batteries that have not been used for an extended period from the device and recycle or dispose of them immediately. Always securely fasten the battery compartment. If the battery compartment is not securely closed, stop using this product, remove the battery, and keep it out of reach of children.
7. Ensure that operating the electric control seat post does not interfere with the normal operation of the brake or the gear shift lever. If such interference occurs, it may cause the bicycle to lose control, resulting in serious injury or even death.
8. Before using the SEEKRuN seatpost during riding, practice using it in a safe and controlled environment to fully understand its functions. Sudden and unexpected movement of the saddle may cause you to lose control of the bicycle, leading to serious injury or death.
9. Press the remote button when you want to adjust the saddle height. When lowering the saddle, press down on it with your body; when raising the saddle back to a higher position, guide it with your body. Release the remote button once the seatpost reaches your desired position. Always release the remote button first before removing body pressure from the saddle. Before using the SEEKRuN seatpost in technically demanding riding scenarios, practice within your ability to acquire professional skills in operating the SEEKRuN seatpost.
10. Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.
11. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

1. Please refer to your bicycle user manual. Electrically controlled stem products must be installed by a certified professional bicycle technician in accordance with the official installation specifications for electric stems. Improper installation of electric stem products may cause malfunctions, lead to loss of bicycle control, and result in serious personal injury or even death.
2. Install the seat post into the frame with the correct orientation (for carbon fiber frames, apply a slip-prevention compound as needed). Ensure the seat post extends beyond the minimum insertion depth mark on your seat post.
3. The electrically controlled seat tube has a directional orientation. When oriented correctly (with the battery facing backward), use the push-button function to check whether the seat tube can move freely to all positions.
4. Set the base pipe to the desired height, then tighten the base pipe fastening bolt to 44 in-lb (5 N·m) (as shown in the figure). After insertion, ensure that the "Minimum Insertion Depth Mark" on the base pipe extends beyond the base pipe fastening bolt (as shown in the figure). Again, verify that the base pipe can be moved freely to all positions.



5. The maximum torque value for the electrically controlled seat post tightening bolt is 44 in-lb (5 Nm). The actual required torque depends on the rider's weight and the bicycle frame.


As well as the type or brand of the seat tube clamp. The correct torque will properly support the rider without interfering with the seat tube's functionality. If the torque is too high, the seat tube may not fully retract from any position or may not move up or down smoothly. If the torque is too low, the seat tube may not adequately support the rider's weight or may fail to remain stationary on the seat tube. Improper torque applied at the seat tube clamp connection can cause the bicycle to lose control, resulting in serious injury or even death.

6. Regardless of the original configuration of the bicycle frame tube, to achieve optimal structural support, you should insert the electrically controlled seat tube at least into the lowest insertion mark on the seat tube and into the minimum insertion point specified by the bicycle frame manufacturer. Failure to adhere to these two requirements poses a risk of damaging the frame or the seat tube, which could result in serious personal injury or even death.


Note: All images in this manual are schematic diagrams; they may differ slightly from the actual product – please refer to the actual product for accurate information.

PRODUCT INTRODUCTION

BLUETOOTH REMOTE




WIRELESS DROPPER SEATPOST




Note: All images in this manual are schematic diagrams; they may differ slightly from the actual product – please refer to the actual product for accurate information.

Component List



Seat Tube & Bluetooth Button Battery Installation


Electric control seat tube battery installation



Note: All images in this manual are schematic diagrams; they may differ slightly from the actual product – please refer to the actual product for accurate information.

Note: The keypad is powered by a CR2050 button cell battery; the keypad is powered by an already

Electric control seat tube battery installation



1. Use a CR2032 battery or other suitable tool to rotate the compartment cover counterclockwise to remove it;
2. Insert the CR2032 battery into the battery compartment with the positive terminal (marked “+”) facing outward;
3. As shown in the figure, the red circle corresponds to the locking position. Use the appropriate tool to press and rotate the hatch cover counterclockwise to the red circle corresponding to the locking position.

installed CR2050 button cell battery. The side marked with the “+” symbol indicates the positive terminal of the battery.

function Introduction


1. Bluetooth pairing: Hold the seat control button for 6 seconds until the red indicator light starts flashing; then hold the controller button for 6 seconds until the red indicator light starts flashing. Both devices will enter pairing mode. Once pairing is successful, the hand indicator light will stop flashing – this indicates that pairing has been completed. Alternatively, you can hold both the seat control button and the controller button simultaneously for an extended period, and the red light will flash to initiate pairing; once the flashing stops, pairing is successful. (The device is pre-paired; no re-pairing is required when replacing the battery.)
2. After 15 minutes of inactivity, the controller will automatically enter sleep mode; simply press the button briefly to power it on and resume normal operation;
3. The seat pipe enters a sleep mode automatically after 90 minutes of inactivity;
4. Resume seat pipe sleep mode: Press and hold the controller's button six times to wake it up; the device will then function normally.
5. Turn off the device, install the battery, and it will be ready for use.

Button Functions:

Bluetooth pairing		Long press for 6 seconds (Red light flashing)	Bluetooth pairing mode
Controller Button		Hold down (No more than 6 seconds, it will enter Bluetooth pairing)	Turn on Journey Adjustment (Blue Light)
		Release	Close the travel adjustment / lock the seat post
Seat post button		Hold down (No more than 6 seconds, it will enter Bluetooth pairing)	Turn on/Close the travel adjustment


Note: All images in this manual are schematic diagrams; they may differ slightly from the actual product – please refer to the actual product for accurate information.

Controller Indicator Light Instructions:

	Battery level > 10%	Short press the control button	Green light flashes once
	Battery level ≤ 20%	Short press the control button	Red light flashes once

Note: To ensure optimal device performance, it is recommended to consider replacing the battery as soon as the battery level falls below 10% (the indicator light will flash red).

Seat Pipe Indicator Light Instructions:

	Battery level > 20%	Short press the seat control button	Green light flashes once
	Battery level ≤ 20%	Short press the seat control button	Red light flashes once

Note: To ensure optimal device performance, it is recommended to charge the device as soon as the battery level drops below 20% (when the red indicator light starts flashing).

- Note: 1. It is recommended that users adjust the seatpost height again based on their actual riding experience after installation; however, please ensure that the seatpost is inserted to its minimum depth.**
- 2. Apply the seat tube clamp to the recommended locking force (≤5 N•m). Excessive tightening may cause excessive deformation of the lifting seat tube, potentially leading to issues such as uneven lifting motion; therefore, do not over-tighten the clamp.**
- 3. When the seat post will not be used for an extended period, raise it to its maximum height and remove the battery.**

FCCW ARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.




Note: All images in this manual are schematic diagrams; there may be slight discrepancies between these images and the actual product. Please refer to the actual product for accurate information.

Saddle fixed



The clip is compatible with the following bow mounting track specifications: 7 mm circular track / 7x9 mm elliptical track

The controller is loaded onto the truck.



Note: Both the tension adjustment screw and the saddle clamp screw require a 5 mm T-Head Hex Socket Wrench; simply follow the above procedure for the specific installation steps.

During initial installation, the mounting position may not be ideal for operation; however, after using the device for a while, users can adjust the mounting position according to their preferences.

Seat-mounted battery charging


When the seat tube battery status indicator light flashes red, it indicates that the seat tube battery's charge level is too low and needs to be charged.

During charging, the ambient temperature should be maintained at 50°C; it is recommended to use a power adapter with a rated output voltage of 5 V and a rated output current of no less than 1 A.

During charging, the ambient temperature should be maintained between 0°C and 45°C; additionally, avoid using this product in humid environments.

Note: All images in this manual are schematic diagrams; they may differ slightly from the actual product – please refer to the actual product for accurate information.

Seat tube battery charging



Charging Base Indicator Light Instructions

	Red indicator light stays on continuously		Battery charging in progress
	Indication light remains constantly green.		charge complete
	The indicator light flashes alternately in red and green.		Charging故障

matters need attention

1. This product has an IP65 protection rating. Note: This rating applies only to the saddle head (when the battery is properly installed) and the push-button controller; it does not cover the tube body.
2. Operating temperature range: Discharging – –10°C to 50°C; Charging – 0°C to 45°C;
3. Do not immerse the battery in water or any other liquid;
4. The battery charging port should be kept dry. If the port is damp, please ensure it is thoroughly dried before charging;
5. It is prohibited to disassemble, impact, or compress the battery of the base unit without authorization, or to place it near a fire source or in any environment with high temperatures;
6. If the battery exhibits any abnormal symptoms, such as significant swelling or bulging, stop using it immediately;
7. Do not store the battery in high-temperature environments or near heat-generating devices (e.g., direct sunlight, microwave ovens, ovens, etc.).
8. Do not store batteries in areas where infants or young children can reach them, to prevent injury resulting from swallowing, chewing, or accidental handling;
9. Do not connect metal conductors to the battery terminals or touch the battery's ends;
10. Please dispose of batteries in accordance with local regulations; do not dispose of batteries as general household waste.
11. For long-term storage, the battery should be charged every three months using the charging base for 0.5–1 hour to maintain the battery pack at a charge level of 40%–60%.

Related certifications: CE, FCC

Related certifications: CE, FCC

Note: All images in this manual are schematic diagrams; they may differ slightly from the actual product – please refer to the actual product for accurate information.

Product Warranty Information

I. Warranty Scope and Duration

Applicable regions: Chinese mainland, European Union, United States

Effective date: From the date of purchase

The authorized distributor provides the following limited warranty for this product:

component	Warranty Period
Seat Pipe	12 months
cell	12 months
controller	12 months

Note: This warranty is valid only for the original purchaser and is non-transferable. Should you require any after-sales service in accordance with this warranty, please contact the retailer who sold you the electronic seat post product or an authorized service center.

The product must be returned, and the original purchase receipt must be provided. All warranty claim requests for electronically controlled seat tubes shall be evaluated by the authorized service centers for such seat tubes. If Where the authorized dealer has agreed to the warranty and after-sales service terms, the authorized dealer may independently decide whether to repair, replace, or refund the product. Within the limits permitted by local law, any claim arising under this warranty must be filed within the warranty period and within one year from the date on which such claim arises. put forward.

II. Non-Warranty Regulations

1. Unauthorized repair, misuse, impact, negligence, abuse, introduction of foreign substances, accident, modification, incorrect use of components not supplied with this product, or tearing or altering labels or anti-counterfeiting markings;
2. The warranty period has expired;
3. Damage caused by force majeure;
4. Cases where the product does not exhibit any performance-related faults as listed in the Product Fault List;
5. When performance failures listed in the "Product Failure List" arise in the product or its accessories due to human error.

Note: All images in this manual are schematic diagrams; they may differ slightly from the actual product – please refer to the actual product for accurate information.

III. Product Malfunction

component	hitch
Seat Pipe	Material defects, fracture, deformation The seat tube cannot be adjusted for upward or downward travel. Electrical system not operating
Battery/Charging Base	runner block
controller	Not working

Note: To ensure the safe transportation of your products, it is recommended that you retain the packaging box for at least 30 days from the date of receipt.

maintenance period	Maintenance Content
After each ride	Wipe away dust or sand from the telescopic section of the seat tube using a damp cloth.
Annual; every 500 hours of riding; or every 10,000 rides	Replace lubricant
Every two years / After 1,000 hours of riding / After 20,000 rides	We recommend sending the product to an authorized after-sales service center for comprehensive disassembly and maintenance, including the replacement of all wear parts.
Reminder: For those participating in downhill hiking (DH), park cycling, or extreme free riding, or when riding in extremely wet/muddy or dry conditions... For riders operating their bikes in dusty environments, it is recommended to perform maintenance earlier than the above-mentioned schedule, as needed. If you hear, see, or notice any abnormality, please stop riding immediately and contact an authorized service center for proper repair.	