


Creader Professional 919 Advanced
(SparkAce Version)
Professional Diagnostic Tool

User Manual

LAUNCH



Scan the QR code to download the user manual for your easy reference.



WARNING

**Read this material before using this product.
Failure to do so can result in serious injury.**

制作要求：

纸张要求：封面157g双铜纸（需要过胶），彩色印刷。
内页80g书写纸，黑白印刷

纸张大小：宽：128mm x 高: 182mm

装订方式：骑马钉

Trademarks

LAUNCH is a registered trademark of LAUNCH TECH CO., LTD. in China and other countries. All other marks are trademarks or registered trademarks of their respective holders.

Copyright Information

Copyright © LAUNCH TECH CO., LTD. (also called LAUNCH for short). All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying and recording or otherwise, without the prior written permission.

Disclaimer of Warranties and Limitation of Liabilities

- All information, illustrations, and specifications in this manual are based on the latest information available at the time of publication.
- The right is reserved to make changes at any time without notice. We shall not be liable for any direct, special, incidental, indirect damages or any economic consequential damages (including the loss of profits) due to the use of the document.
- To take full advantage of the unit, you should be familiar with the engine.
- LAUNCH shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original LAUNCH Products or LAUNCH Approved Products by LAUNCH.

Safety Precautions and Warnings

To prevent personal injury or damage to vehicles and/or the tool, read this user's manual first carefully and observe the following safety precautions at a minimum whenever working on a vehicle:

- There are no user serviceable parts. Have the device serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the device is maintained. Disassembling the device will void the warranty right.
- Caution: This tool contains an internal Lithium Polymer battery. The battery can burst or explode, releasing hazardous chemicals. To reduce the risk of fire or burns, do not disassemble, crush, pierce or dispose of the battery in fire or water.

LAUNCH

- This product is not a toy. Keep children away from the device and do not allow them to play with it.
- Do not expose the device to rain or wet conditions.
- Do not place the device on any unstable surface.
- Never leave the device unattended during charging process. The device must be placed on a non-flammable surface during charging.
- Handle the device with care. If the device is dropped, check for breakage and any other conditions that may affect its operation.
- Do not operate the tool in explosive atmospheres, such as in the presence of flammable liquids, gases, or heavy dust.
- Keep the tool dry, clean, and free of oil, water or grease. Use a mild detergent on a clean cloth to clean the enclosure of the device when necessary.
- People with pacemakers should consult their physician(s) before use. Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure.
- Always perform automotive testing in a safe environment.
- Do not attempt to operate or observe the tool while driving a vehicle. Operating or observing the tool will cause driver distraction and could cause a fatal accident.
- Wear safety eye protection that meets ANSI standards.
- Keep clothing, hair, hands, tools, test equipment, and other objects. away from all moving or hot engine parts.
- Operate the vehicle in a well-ventilated work area. Exhaust gases are poisonous.
- Chock the drive wheels and never leave the vehicle unattended while running tests.
- Use extreme caution when working around the ignition coil, distributor cap, ignition wires and spark plugs. These components create hazardous voltages when the engine is running.
- Put the transmission in P (for A/T) or N (for M/T) and make sure the parking brake is engaged.
- Keep a fire extinguisher suitable for gasoline/chemical/electrical fires nearby.
- Don't connect or disconnect any test equipment while the ignition is on or

the engine is running.

Compliance Information

FCC ID: XUJOC349P702919

IC: 29886-OCP349P702

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s) and part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference;
- (2) This device must accept any interference received, including interference that may cause undesired operation.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada et à la partie 15 des règles de la FCC applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) L'appareil ne doit pas produire d'interférences nuisibles;
- (2) L'appareil doit accepter tout brouillage radioélectrique reçu, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This device complies with Canadian CAN ICES-003(B)/NMB-003(B).

Cet appareil est conforme à la norme canadienne CAN ICES-003(B)/NMB-003(B).

The device for operation in the band 5150-5250MHz is only for indoor use.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information

This product meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

RF Exposure Information and Statement

The SAR limit is 1.6 W/kg averaged over one gram of tissue. This device has also been tested against this SAR limit. This device was tested for typical body-worn operations 0mm from the body. To maintain compliance with RF exposure requirements, use accessories that maintain a 0mm separation distance between the user's body.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 0mm must be maintained between the user's body, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.

Cet appareil a été testé pour des opérations typiques portées sur le corps, pour satisfaire aux exigences relatives à l'exposition RF, une distance minimale de séparation de 0mm doit être maintenue entre le corps de l'utilisateur, y compris l'antenne. Les clips de ceinture, les étuis et les accessoires similaires de tiers utilisés par cet appareil ne doivent pas contenir de composants métalliques. Les accessoires portés sur le corps qui ne répondent pas à ces exigences ne peuvent pas être conformes aux

exigences relatives à l'exposition RF et doivent être évités. Utilisez uniquement l'antenne fournie ou une antenne approuvée.

This device is in compliance with the essential requirements and other relevant provisions of Radio Equipment Directive 2014/53/EU. The RF frequencies can be used in Europe without restriction.

Table of Contents

1 Overview	1
1.1 Vehicle Coverage	1
1.2 On-Board Diagnostics (OBD) II	1
1.3 OBD II Definitions	2
1.4 Diagnostic Trouble Codes (DTCs)	4
1.5 Location of the Data Link Connector (DLC)	5
2 Product Descriptions	7
2.1 Components & Controls	7
2.2 Technical Specifications	8
2.3 Packing List	9
3 Initial Use	10
3.1 Charging the Tool	10
3.2 Getting Started	10
3.3 Main Menu	11
4 Vehicle Diagnostics	12
4.1 Connection	12
4.2 System Diagnostics	13
4.2.1 Smart Diagnostics (Auto-Detect)	13
4.2.2 Manual Diagnostics	14
4.3 OBDII Diagnostics	20
4.4 I/M	22
4.5 History	22
5 Service Function	23
6 Toolbox	24
6.1 Battery Voltage	24
6.2 Diagnostic Software Clear	24
6.3 Firmware Fix	24
6.4 DTC Library	24
6.5 Diagnostic Record	24

6.6	DLC	25
6.7	Feedback	25
6.8	FAQ	25
6.9	Image	25
6.10	User Manual	25
7	Software Update	26
8	Mall	27
9	Mine	28
9.1	My Report	28
9.2	My Order	28
9.3	Settings	28
9.3.1	Units of Measurement	28
9.3.2	Screen capture	28
9.3.3	Automatic detection on connect	28
9.3.4	Display/Brightness	28
9.3.5	Sound	28
9.3.6	Network	28
9.3.7	Time Zone	29
9.3.8	Language	29
9.3.9	Workshop Information	29
9.3.10	Expiration Date	29
9.3.11	Recovery	29
9.3.12	Clear Cache	29
9.4	About	29
10	Other Modules	30
10.1	TPMS	30
10.2	Camera	30
10.3	Remote Assistance	30
10.4	BST	30
	Warranty	31


1 Overview

1.1 Vehicle Coverage


This diagnostic tool is specially designed to work with all OBD II compliant vehicles, including Controller Area Network (CAN).

A small number of 1994 and 1995 model year gasoline vehicles are OBD II compliant. To verify if a 1994 or 1995 vehicle is OBD II compliant, check the following:

1. **Vehicle Emissions Control Information (VECI) Label.** It is located under the hood or by the radiator of most vehicles. If the vehicle is OBD II compliant, the label will designate **OBD II Certified**.



2. Government regulations mandate that all OBD II compliant vehicles must have a "common" 16-pin Data Link Connector (DLC).



*Note: Some 1994 and 1995 vehicles have 16-pin connectors but are not OBD II compliant. Only those vehicles with a Vehicle Emissions Control Label stating **OBD II Certified** are OBD II compliant.

1.2 On-Board Diagnostics (OBD) II

The OBD II system is designed to monitor emission control systems and key engine components by performing either continuous or periodic tests of

specific components and vehicle conditions, which will offer three pieces of such valuable information:

- Whether the Malfunction Indicator Light (MIL) is commanded “on” or “off”;
- Which, if any, Diagnostic Trouble Codes (DTCs) are stored;
- Readiness Monitor status.

1.3 OBD II Definitions

The following terms and their definitions are related to OBD II systems. Read and reference this list as needed to aid in the understanding of OBD II systems.

EOBD - European On-Board Diagnostics. Essentially the same as OBD II, with the same Data Link Connector and Communication Protocols.

Communication Protocols - Allows different systems and sensors in a vehicle to communicate. There are currently five protocols:

- CAN Bus
- J1850 VPW
- ISO 9141-2
- J1850 PWM
- ISO 14230 KWP

PCM -- Powertrain Control Module. The PCM is the OBD II accepted term for the vehicle’s “on-board computer.” In addition to controlling the engine management and emissions systems, the PCM also participates in controlling the powertrain (transmission) operation. Most PCMs also have the ability to communicate with other computers on the vehicle (ABS, ride control, body, etc.).

DLC -- Data Link Connector. The 16-cavity connector on the vehicle that allows communication between the computer system and the diagnostic tool.

MIL -- Malfunction Indicator Light. The vehicle’s “Check Engine” warning light that activates when a DTC is stored.

DTC -- Diagnostic Trouble Code. A code stored in the computer system’s memory, which helps to identify the fault condition that is causing the MIL to activate.

Freeze Frame Data -- Operating conditions that are stored when a DTC is stored.

PID -- Parameter Identification Data. Data returned by the vehicle's control modules to the diagnostic tool.

Monitors -- Monitors are "diagnostic routines" programmed into the PCM. The PCM utilizes these programs to run diagnostic tests, and to monitor operation of the vehicle's emissions-related components or systems to ensure they are operating correctly and within the vehicle's manufacturer specifications.

Enabling Criteria -- Also termed Enabling Conditions. They are the vehicle-specific events or conditions that must occur within the engine before the various monitors will set, or run. Some monitors require the vehicle to follow a prescribed "drive cycle" routine as part of the enabling criteria. Drive cycles vary among vehicles and for each monitor in any particular vehicle. Refer to the vehicle's factory service manual for specific enabling procedures.

Trip - A Trip for a particular Monitor requires that the vehicle is being driven in such a way that all the required "Enabling Criteria" for the Monitor to run and complete its diagnostic testing are met. The "Trip Drive Cycle" for a particular Monitor begins when the ignition key is turned "On." It is successfully completed when all the "Enabling Criteria" for the Monitor to run and complete its diagnostic testing are met by the time the ignition key is turned "Off."

Drive Cycle -- A specific mode of vehicle operation that provides conditions required to set all the readiness monitors applicable to the vehicle to the "ready" condition. The purpose of completing an OBD II drive cycle is to force the vehicle to run its onboard diagnostics. Some form of a drive cycle needs to be performed after DTCs have been erased from the PCM's memory or after the battery has been disconnected. Running through a vehicle's complete drive cycle will "set" the readiness monitors so that future faults can be detected. Drive cycles vary depending on the vehicle and the monitor that needs to be reset. For vehicle specific drive cycle, consult the service manual.

*Note: Do not confuse a "Trip" Drive Cycle with an OBD II Drive Cycle. A "Trip" Drive Cycle provides the "Enabling Criteria" for one specific Monitor to run and complete its diagnostic testing. An OBD II Drive Cycle must meet the "Enabling Criteria" for all Monitors on a particular vehicle to run and complete their diagnostic testing.

Warm-up Cycle - Vehicle operation after an engine off period where

engine temperature rises at least 40°F (22°C) from its temperature before starting, and reaches at least 160°F (70°C). The PCM uses warm-up cycles as a counter to automatically erase a specific code and related data from its memory. When no faults related to the original problem are detected within a specified number of warm-up cycles, the code is erased automatically.

Fuel Trim (FT) - Feedback adjustments to the base fuel schedule. Short-term fuel trim refers to dynamic or instantaneous adjustments. Long-term fuel trim refers to much more gradual adjustments to the fuel calibration schedule than short-term trim adjustments. These long-term adjustments compensate for vehicle differences and gradual changes that occur over time.

1.4 Diagnostic Trouble Codes (DTCs)

OBD II Diagnostic Trouble Codes are codes that are stored by the on-board computer diagnostic system in response to a problem found in the vehicle. These codes identify a particular problem area and are intended to provide you with a guide as to where a fault might be occurring within a vehicle. DO NOT replace parts based only on DTCs without first consulting the vehicle's service manual for proper testing procedures for that particular system, circuit or component.

OBD II Diagnostic Trouble Codes consist of a five-digit alphanumeric code.


- The 1st character is a **letter** (B, C, P or U). It identifies the **main system** where the fault occurred (Body, Chassis, Powertrain, or Network).
- The 2nd character is a **numeric digit** (0 thru 3). It identifies the **type** of code (Generic or Manufacturer-Specific).

*Note: Generic DTCs are codes that are used by all vehicle manufacturers. The standards for generic DTCs, as well as their definitions, are set by the Society of Automotive Engineers (SAE).

Manufacturer-Specific DTCs are codes that are controlled by the vehicle manufacturers. The Federal Government does not require vehicle manufacturers to go beyond the standardized generic DTCs in order to comply with the new OBD II emissions standards. However, manufacturers are free to expand beyond the standardized codes to make their systems easier to diagnose.

- The 3rd character is a letter or a **numeric digit** (0 thru 9, A thru F). It identifies the specific system or sub-system where the problem is located.
- The 4th and 5th characters are **letters** or **numeric digits** (0 thru 9, A thru

F). They identify the section of the system that is malfunctioning.




P0201 - Injector circuit malfunction, Cylinder 1

1.5 Location of the Data Link Connector (DLC)

The DLC is typically a 16-pin connector where the diagnostic tool interfaces with the vehicle's on-board computer. It is usually located 12 inches from the center of the instrument panel, under or around the driver's side for most vehicles. For some vehicles with special designs, the DLC location may vary.

LAUNCH

Refer to the following figure for DLC locations.



A- Opel, Volkswagen, Audi

B- Honda

C- Volkswagen

D- Opel, Volkswagen, Citroen


E- Changan

F- Hyundai, Daewoo, Kia, Honda, Toyota, Nissan, Mitsubishi, Renault, Opel, BMW, Mercedes-Benz, Mazda, Volkswagen, Audi, GM, Chrysler, Peugeot, Regal, Beijing Jeep, Citroen and other most popular models

If the DLC cannot be found, refer to the vehicle's service manual for the location.

2 Product Descriptions

2.1 Components & Controls



1. Type-C Charging Port

Connect the charging cable to charge the tool.

2. DB-15 Diagnostic Connector

Connect the tool to the vehicle's DLC by using the diagnostic cable.

3. Power Button

Turn on or off the tool.

4. LCD Screen

Indicate test results.

5. LED Charging Indicator

Red means Charging and Green means Fully Charged.

6. Back Button

Return to the previous screen.

7. Selection Buttons



Move up and down for selection.




Move left or right for selection; Or turn pages up and down when more than one page is displayed.

8. OK Button

Confirm a selection (or an action) from a menu list.

9. HOME Button

Navigate to the Main Menu screen.



10. Adjustable Stand

Unfold the stand and adjust it to your preferred viewing angle.

11. Camera Flash

12. Rear Camera

2.2 Technical Specifications

- Screen: 7" touch screen
- RAM: 4GB
- Storage: 64GB
- OBDII input voltage range: 9~18V
- Charging via:
 - DC 5V 2A charging cable & power adapter, or

- Diagnostic cable through connection to vehicle's DLC
- Dimensions: 251 mm x 148.4 mm x 36 mm
- Operating temperature: 0°C to 50°C (32°F to 122°F)
- Storage temperature: -20°C to 70°C (-4°F to 158°F)

*Note: The operating temperature refers to the temperature at which the scan tool works normally in non-charging status.

2.3 Packing List

The following packing list is for reference only. For details, consult the seller or check the packing list supplied with this tool.

1. Diagnostic tool x 1
2. OBD II diagnostic cable x 1
3. Charging cable x 1
4. Quick start guide x 1
5. GPSR safety warning x 1

3 Initial Use

3.1 Charging the Tool

There are two charging methods available:

Via Charging Cable: Plug one end of the included charging cable into the USB Type-C port of the tool, and the other end to the external power supply device.

Via Diagnostic Cable: Insert one end of the diagnostic cable into the DB-15 connector of the tool, and the other end to the vehicle's DLC.

Once the charging LED illuminates solid green, it indicates that the battery is fully charged.

3.2 Getting Started

If it is the first time you have used this tool, you need to make some system settings.

1. Press the power button to turn on the device.
2. The screen displays a welcome page. Tap **Start** to go to next step.
3. Choose the desired system language, and tap **Next step**.
4. Choose the desired time zone, and tap **Next step** to enter the WLAN setup screen.
5. Slide the switch to ON, the system starts searching for all available wireless LANs. Choose the desired WLAN access point / network,
 - If the selected network is open, you can connect it directly.
 - If the selected network is encrypted, you have to enter the right security key (network password).
6. After the network connection is done, tap **Next step** to configure workshop information. Input the required information, and tap **Next step** to go to next step.

*Note: Once the workshop information has been configured, it will automatically be added to the report every time you generate a report successfully.

7. Carefully read all terms and conditions of the user agreement, check the box before the **Agree to all the above terms**, and tap **OK** to finish the sign-up process and navigate to Main Menu.

3.3 Main Menu


The Main Menu screen includes the following function modules:

Local Diagnose	Configure the device as a professional diagnostic tool.
Service Function	It offers coding, reset, relearn and other service functions to help restore vehicles to normal operation after repair or component replacement.
Other Modules	It includes some add-on modules, which can extend the functionalities of the diagnostic tool.
Software Update	Update vehicle diagnostic software and APK. *Note: This function requires a stable network connection.
Mall	Subscribe to extra vehicle diagnostic software or reset software that is not included within the tool.
Know Your Customer	Assist repair shops in business analysis, customer management, diagnosis statistics and service ranking.
Mine	Access saved diagnostic reports, view order information, and configure system settings.
Toolbox	Some practical add-on modules are available, including battery voltage, diagnostic software clear, firmware fix, DTC library, diagnostic record, DLC lookup, feedback, image, user manual, etc.
More	It includes Online support and LAUNCH Academy.

4 Vehicle Diagnostics

4.1 Connection

- 1). Turn the ignition off.



- 2). Locate the vehicle's 16-pin Data Link Connector (DLC). Refer to Chapter 1.5.
- 3). Plug one end of the diagnostic cable into the vehicle's DLC port, and the other end to the DB-15 diagnostic connector of the tool, and then tighten the captive screws.



***Notes:**

- A plastic DLC cover may be found for some vehicles and you need to remove it before plugging the diagnostic cable.
- The cable connector is keyed and will only fit one way. If you have problems connecting the cable connector to the DLC, rotate the connector

180° and try again.

- 4). Turn the ignition on. The engine can be off or running.

Caution: Don't connect or disconnect any test equipment with the ignition on or engine running.

- 5). Press the power button for several seconds to turn the tool on and enter the Main Menu.

4.2 System Diagnostics

This function is specially designed to diagnose electronic control systems of single vehicle model.

4.2.1 Smart Diagnostics (Auto-Detect)

This function allows you to quickly access the electronic control systems of the vehicle via decoding the VIN, without manual step-by-step menu selection.

Tap **Mine -> Settings** to set the **Automatic detection on connect** to ON. After connection, turn the ignition on and the system enters auto-detect mode.

Alternatively, you can also tap **Local Diagnose -> AutoDetect** to start the smart diagnosis manually if the **Automatic detection on connect** is OFF.

*Notes:

- A highly stable and solid network connection is recommended for successful VIN access.
 - If automatic detection fails to identify the vehicle, try connecting to the network again. Note that not all vehicles support the auto-detect function due to the vehicle manufacturer settings.
- A. Once the system successfully obtains the VIN (Vehicle Identification Number) information of the currently identified vehicle, confirm the VIN information and tap **OK** to start diagnosing all available systems. After the diagnosis is completed, a diagnostic report will be automatically generated.
 - B. If the tool failed to access the VIN information, the following screen will appear:



Input the VIN and tap **OK**, the system will decode the VIN information automatically, and then proceed to the smart diagnostics procedure if the VIN is obtained. Otherwise, you can perform manual diagnostics. Refer to Chapter 4.2.2 for details.

*Notes:

- The most recognizable location for this number is in the top left corner on the vehicle's dashboard. Other locations include the driver's door or post, and the firewall under the hood.
- In general, the VIN is a 17-character string of uppercase letters and numbers without intervening spaces or the letters Q, I, and O; these are omitted to avoid confusion with the numerals 0 and 1.


4.2.2 Manual Diagnostics

If the tool fails to obtain or analyze the VIN information automatically, you can also perform vehicle diagnosis manually. In this mode, you need to execute the menu-driven command and then follow the on-screen instruction to proceed.

*Notes:

- Before diagnosing a vehicle, make sure the corresponding vehicle manufacturer software has been installed in your tool.
- The diagnostic menus may vary by the vehicle's make, model and year.

Refer to the flowchart illustrated as below to diagnose a vehicle manually:



Take DEMO as an example to demonstrate how to diagnose a vehicle.

*Note: Illustrations used in this manual are samples, and the actual testing screens may vary for each vehicle being tested. The following screens are for reference only.


- 1). Select diagnostic software version: Tap "DEMO" to go to Step 2.
- 2). Select vehicle model (varies with different versions): Select the desired vehicle model.
- 3). Select test item: Select the desired test item to proceed.



4.2.2.1 Health Report (Quick Test)

This function varies from vehicle to vehicle. It enables you to quickly access all the electronic control units of the vehicle and generate a detailed report about vehicle health.

Tap **Health Report** on the test item selection screen, the system starts scanning the ECUs. Once the scanning is complete, the following screen will appear:



In the above figure, the fault codes for the tested system appear in red and the normally working system displays **Normal** in green.

On-Screen Buttons:

≥: Tap to select other test functions. For detailed operations, refer to Chapter **4.2.2.3 System Selection**.

Report: Tap to save the diagnostic result as a diagnostic report. All diagnostic reports can be accessed from **Mine -> My Report**.

Clear Code: Tap to clear the existing diagnostic trouble codes.


4.2.2.2 System Scan

This option allows you to quickly scan which systems are installed on the vehicle. After the scanning is completed, tap the system to be tested, and the test function screen is displayed. For details of the test functions, refer to Chapter **4.2.2.3 System Selection**.

4.2.2.3 System Selection

This option allows you manually select the test system and function step by step.

Tap **System Selection** on the test item selection screen, and tap the desired system (take **TCM** for example) to enter the test function selection screen.



*Note: Different vehicles may have different diagnostic menus.

A. Version Information

This function is used to read the version information of the selected system.

B. Read Fault Code

This function displays the detailed information of DTC records retrieved from the vehicle's control system.

Tap **Read Fault Code** on the test function selection screen; the screen will display the diagnostic result.

*Note: Retrieving and using DTCs for troubleshooting vehicle operation is only one part of an overall diagnostic strategy. Never replace a part based only on the DTC definition. Each DTC has a set of testing procedures, instructions and flow charts that must be followed to confirm the location of the problem. This information can be found in the vehicle's service manual.

On-Screen Buttons:

Help: Tap to view the help information.

LAUNCH

Code Search: Tap to search for more information about the current DTC online.

Report: To save the current data in text format. All diagnostic reports can be accessed from **Mine -> My Report**.

C. Clear Fault Code

After reading the retrieved codes from the vehicle and certain repairs have been carried out, you can use this function to erase the codes from the vehicle. Before performing this function, make sure the vehicle's ignition key is in the ON position with the engine off.


*Notes:

- If you plan to take the vehicle to a Service Center for repair, DO NOT erase the codes from the vehicle's computer. If data is erased, valuable information that might help the technician troubleshoot the problem will also be erased.
- Clearing DTCs does not solve the underlying problems that triggered the codes. If appropriate repairs are not made to fix the problems, the codes will reappear, triggering the check engine light as soon as the problems causing the DTCs manifest themselves.

D. Read Data Stream

This option retrieves and displays live data and parameters from the vehicle's ECU.

Tap **Read Data Stream** on the test function selection screen; the system will display data stream items.



On-Screen Buttons:

Select All: Tap to select all the items of the current page. To select certain data stream item, just check the box before the item name.

Unselect: Tap to deselect all data stream items.

OK: Tap to confirm the selection and jump to the next step.

After selecting the desired items, tap **OK** to enter the data stream reading page.

Data Stream		
DEMO V15.66 > FORD > Expedition > System Selection > TCM(Transmission Control Module)		
Name	Value	
Accelerator Pedal Position Sensor 1	15.69 %	
Brake Switch Input Status	On	
Clutch A Actuator Current - Measured	8.84 A	
Clutch A Actuator Motor - Desired	25.66 %	
Clutch B Actuator Current - Measured	0 A	
Graph Report Record		

*Note: If the value of the data stream item is out of the range of the standard (reference) value, the whole line will display in red. If it is within the reference value, it displays in blue (normal mode).

On-Screen Buttons:

: Tap it to view the waveform graph of the current data stream item.

Graph: Tap to display the parameters in wave patterns.

Report: Tap to save the current data as a diagnostic report. All diagnostic reports can be accessed from **Mine -> My Report**.

Record: Tap to start recording diagnostic data. Recorded Live Data can serve as valuable information to help you in troubleshooting and diagnosing vehicle problems. All diagnostic records can be accessed from **Toolbox -> Diagnostic Record**.

E. Actuation Test

This option is used to access vehicle-specific subsystem and component tests. Available tests vary by vehicle manufacturer, model, and year.

During the actuation test, the device outputs commands to the ECU in order to drive the actuators, and then determines the integrity of the system or parts by reading the ECU data, or by monitoring the operation of the actuators, such as switching the injector between two operating states.

Simply follow the on-screen instructions and make appropriate selections to complete the test.

F. Special Function

This option allows you to access special functions supported by each specific system. Different vehicle models and systems often have different special functions. The supported special functions also vary by the year and ECU type even for the same system of the same vehicle model.

4.3 OBDII Diagnostics

This option presents a quick way to check for DTCs, isolate the cause of the illuminated Malfunction Indicator Lamp (MIL), check monitor status prior to emissions certification testing, verify repairs, and perform a number of other services that are emission-related.

After the tool is properly connected to the vehicle's DLC, tap **OBD II** on the **Local Diagnose** screen. The tool will automatically start a check of the vehicle's computer to determine which type of communication protocol it is using. When the tool identifies the computer's communication protocol, a communication link is established and then the screen will display the Monitor Status.

Tap **ENTER**, and the following functions may appear.

1. Read I/M Readiness

This function checks whether or not the various emissions-related systems on the vehicle are operating properly, and are ready for Inspection and Maintenance testing.

It can also be used to check the Monitor Run Status, and to confirm if the repair of a car fault has been performed correctly.

2. Read Live Data

This function retrieves and displays live data and parameters from the vehicle's ECU.

3. Read Freeze Frame

This function takes the snapshot of the operating conditions when an emission-related fault occurs.

4. Read Fault Code

This function can identify which section of the emission control system has malfunctioned.

5. Clear Fault Code

This function erases the codes from the vehicle, after retrieving codes from the vehicle and certain repairs have been carried out.

Make sure the vehicle's ignition key is in the ON position with the engine off before the operation.

6. Test Results: O2 Sensor Monitor

This function retrieves O2 sensor monitor test results of the most recently completed tests from the vehicle's on-board computer.

7. Test Results: On-Board Monitoring Test

This function retrieves test results for emission-related powertrain components and systems that are not continuously monitored. The test's availability is determined by the vehicle manufacturer.

8. Control Operation of On-Board Component/System

This function is used to access vehicle-specific subsystem and component tests. Available tests vary by vehicle manufacturer, year, and model.

9. Read Vehicle Information

This function retrieves a list of information (provided by the vehicle manufacturer) from the vehicle's on-board computer.

This information may include: Vehicle Identification Number (VIN), Calibration ID (CID), Calibration Verification Number (CVN), etc.

10. EU OBFCM

The On-Board Fuel Consumption Monitoring (OBFCM) function, which collects fuel and energy consumption data of the vehicle to check whether the CO₂ emissions and fuel or energy consumption comply with EU

regulations.

The information may include: Vehicle Identification Number, Total Fuel Consumed (Lifetime), Total Distance Traveled (Lifetime), etc.

4.4 I/M

This function provides a quick access to the I/M Readiness diagnostics.

4.5 History

Generally, once a vehicle diagnosis is performed, the tool will record every detail of the diagnostic session. The **History** function provides direct access to the previously tested vehicles. You can resume from the last operation rather than starting a new test.

Tap **History** on the Local Diagnose screen, and all diagnostic records will be listed on the screen in date sequence.

- Tap certain vehicle model to view the details of the last diagnostic report.
- To delete certain diagnostic history, select it and then tap **Delete**. To delete all historical records, tap **Select All** and then tap **Delete**.

Tap **Quick access** to directly navigate to the function selection page of last diagnostic operation. Choose the desire option to proceed.


5 Service Function

It offers coding, reset, relearn and more service functions, to help vehicles get back to functional status after repair or replacement. Available tests vary by vehicle manufacturer, year, and model.

Due to continuing improvements, available service functions are subject to change without prior written notice. To enjoy more service functions, it is recommended to check for updates on a regular basis.

There are two methods to perform resetting operations: Manual Reset or Auto Reset. Auto Reset follows the principle of sending command from the tool to vehicle's ECU to do resetting. While using Manual Reset, users just follow the on-screen instructions to select appropriate execution options, enter correct data or values, and perform necessary actions, the system will guide you through the complete performance for various service operations.

Follow the flowchart shown as below to perform resetting.



6 Toolbox

6.1 Battery Voltage

This option can measure the current voltage of the vehicle's battery.

6.2 Diagnostic Software Clear


This item allows you to delete the diagnostic software that is not frequently used.

6.3 Firmware Fix

Use this module to upgrade and fix diagnostic firmware. During fixing, do not cut power or switch to other interfaces.

6.4 DTC Library

This option allows you to retrieve the detailed descriptions of certain DTC from the DTC database.



Swipe upwards or downwards to alter the value, then press **OK** button, and the screen will display the definition of the DTC.

6.5 Diagnostic Record

This module stores the recorded running parameters or waveform graphs.

Tap **Diagnostic Record** to enter and select the desired data stream items and tap **OK** to jump to the playback screen.

On-screen Buttons:

Graph – Displays the parameters in waveform graphs.

Combine – Merges graphs for data comparison. Items are marked in different colors.

Value (default) – Displays the parameters as texts in a list format.

Auto Playback – Automatic playback of the selected data stream items.

6.6 DLC

This option helps you to find the location of the vehicle's DLC.

6.7 Feedback

This module allows you to send the feedback of your diagnostic problems to us for further analysis and troubleshooting.

6.8 FAQ

This module lists some frequently asked questions and answers related to this tool.

6.9 Image

This module allows you to manage or share the screenshots.

6.10 User Manual

A detailed operation manual is integrated in the tool for quick reference.

7 Software Update

This function allows you to update the diagnostic software. All software is updated periodically. It is recommended to update the diagnostic software on a regular basis for the best service, functions and experience.

If any new diagnostic software or APK updates are available, a numeric indicator will appear on the Software Update module on the Main Menu.

*Note: Software updates require a stable network connection.

Tap **Software Update** on the Main Menu to enter the update center.

Select the target software, and tap **Update** to start downloading. It may take several minutes to finish it.

Once the download is complete, the software packages will be installed automatically.

8 Mall

This function allows you to subscribe to additional vehicle diagnostic software and reset software that are not pre-installed on the tool.

All diagnostic software in the mall covers full systems and full functions. Pricing varies according to the specific vehicle software.

Tap **Mall** to enter the online software mall. Select the target software and follow the on-screen instructions to finish the transaction.

*Note: The software activates immediately upon purchase, so it is generally non-refundable. Always double check your order details before payment.

The pre-installed diagnostic software is provided free of charge for the life of the tool, but its free update period is limited to the first two years. Once it expires, you need to renew your subscription to access the latest version.

9 Mine

9.1 My Report

This option allows you to view and manage your saved reports.

All diagnostic reports are sorted by date and make. If too many reports are stored, tap the search icon to filter and locate them quickly.

9.2 My Order

This option allows you to check your order information.

9.3 Settings

This module allows you to make some system settings to your preference.

9.3.1 Units of Measurement

This option can set the measurement unit. Both Metric System and Imperial System are available.

9.3.2 Screen capture

This option can set the Screen Capture icon to be shown or not on the screen. When set as ON, a screenshot icon will float on upper right corner of the screen. Tap it to capture the screen.

9.3.3 Automatic detection on connect

This option enables you to determine whether to start an automatic VIN detection once the tool is properly connected to the vehicle's DLC.

9.3.4 Brightness

This option allows you to set the standby time and screen brightness.

*Note: Reducing the screen brightness helps conserve the battery power of the device.

9.3.5 Sound

You can use the option to adjust the volume and other sound settings.

9.3.6 Network

The built-in WLAN module allows you to register the tool, update diagnostic software & APK, and send emails on a wireless network.

9.3.7 Time Zone

This option allows you to set the time zone.

9.3.8 Language

The tool supports multiple languages. You can use this option to change the system language to the target language.

9.3.9 Workshop Information

This option allows you to configure the workshop information.

*Note: Once the workshop information has been configured, it will automatically be added to the report every time you generate a report successfully.

9.3.10 Expiration Date

This option allows you to check the expiration date of the software configuration and renew the subscription.

9.3.11 Recovery

This option can reset this tool to the default factory setting.

Warning: Resetting the device may result in data loss. Exercise caution when performing this operation.

9.3.12 Clear Cache

This option allows you to clear some cache files and free up the storage space.

9.4 About

This option displays the hardware configuration information of the tool and license agreement.

10 Other Modules

It includes some add-on modules, which can extend the functionalities of the diagnostic tool. These modules cannot work properly on the tool, which need to work with the separate compatible hardware (sold separately).

Due to continuing improvements, the available add-on modules are subject to change at any time. To enjoy more functions, it is recommended to check for updates on a regular basis.

10.1 TPMS

This module allows you to configure the tool as TPMS activation and diagnostic tool, which provides the ability to activate TPMS sensors, program TPMS sensors, and perform the relearning procedure. It needs to work with the compatible i-TPMS device (sold separately).

For more details, refer to the User Manual included with the module.

10.2 Camera

This function allows you to take pictures or record videos with the device camera.

10.3 Remote Assistance

Remote Assistance aims to help repair shops or technicians launch remote diagnosis, getting repair job fixed faster.

You can initiate remote assistance via third-party software. Simply provide your device ID to the remote technician or after-sales personnel, granting them authorization to remotely operate the device. This enables troubleshooting of any issues encountered during device operation.

10.4 BST

This module allows you to fix battery detection faster and easier. It needs to work with the specific Bluetooth battery tester (sold separately).

For more details, refer to the User Manual included with the module.

Warranty

THIS WARRANTY IS EXPRESSLY LIMITED TO PERSONS WHO PURCHASE LAUNCH PRODUCTS FOR PURPOSES OF RESALE OR USE IN THE ORDINARY COURSE OF THE BUYER'S BUSINESS.

LAUNCH electronic product is warranted against defects in materials and workmanship for one year (12 months) from date of delivery to the user.

This warranty does not cover any part that has been abused, altered, used for a purpose other than for which it was intended, or used in a manner inconsistent with instructions regarding use. The exclusive remedy for any automotive meter found to be defective is repair or replacement, and LAUNCH shall not be liable for any consequential or incidental damages.

Final determination of defects shall be made by LAUNCH in accordance with procedures established by LAUNCH. No agent, employee, or representative of LAUNCH has any authority to bind LAUNCH to any affirmation, representation, or warranty concerning LAUNCH automotive meters, except as stated herein.

Order Information

Replaceable and optional parts can be ordered directly from your LAUNCH authorized tool supplier. Your order should include the following information:

1. Quantity
2. Part number
3. Item description

Customer Service

If you have any questions on the operation of the unit, contact the seller, or contact LAUNCH TECH Service Center:

Website: www.launchauto.com

Email: hello@launchauto.com

To resolve your problems quickly and efficiently, please clearly indicate the **Serial Number** of your device when submitting feedback.