



## **ELECTRIC or GAS DRYER USE AND CARE GUIDE**

## **SÉCHEUSE ÉLECTRIQUE ou À GAZ GUIDE D'UTILISATION ET D'ENTRETIEN**

Para una versión de estas instrucciones en español, visite [www.whirlpool.com](http://www.whirlpool.com)

### **Table of Contents**

|                                                                                   |            |
|-----------------------------------------------------------------------------------|------------|
| DRYER SAFETY .....                                                                | 2          |
| CHECK YOUR VENT SYSTEM<br>FOR GOOD AIRFLOW .....                                  | 4          |
| USE SENSOR DRY/AUTO DRY CYCLES FOR<br>BETTER FABRIC CARE AND ENERGY SAVINGS ..... | 4          |
| CONTROL PANEL & FEATURES.....                                                     | 5          |
| CYCLE GUIDE.....                                                                  | 6          |
| USING YOUR DRYER .....                                                            | 7          |
| DRYER CARE.....                                                                   | 9          |
| TROUBLESHOOTING .....                                                             | 11         |
| ACCESSORIES.....                                                                  | 12         |
| WARRANTY.....                                                                     | 13         |
| ASSISTANCE OR SERVICE.....                                                        | BACK COVER |

### **Table des matières**

|                                                                                                                                                  |    |
|--------------------------------------------------------------------------------------------------------------------------------------------------|----|
| SÉCURITÉ DE LA SÉCHEUSE .....                                                                                                                    | 14 |
| VÉRIFICATION D'UNE CIRCULATION D'AIR<br>ADÉQUATE POUR LE SYSTÈME D'ÉVACUATION ...                                                                | 17 |
| UTILISATION DES PROGRAMMES DE<br>SÉCHAGE PAR DÉTECTION/AUTOMATIQUE<br>POUR UN MEILLEUR SOIN DU TISSU ET<br>DAVANTAGE D'ÉCONOMIES D'ÉNERGIE ..... | 17 |
| TABLEAU DE COMMANDE<br>ET CARACTÉRISTIQUES .....                                                                                                 | 18 |
| GUIDE DE PROGRAMMES .....                                                                                                                        | 19 |
| UTILISATION DE LA SÉCHEUSE .....                                                                                                                 | 20 |
| ENTRETIEN DE LA SÉCHEUSE.....                                                                                                                    | 22 |
| DÉPANNAGE.....                                                                                                                                   | 25 |
| ACCESSOIRES.....                                                                                                                                 | 26 |
| GARANTIE.....                                                                                                                                    | 27 |
| ASSISTANCE OU SERVICE...COUVERTURE ARRIÈRE                                                                                                       |    |

## DRYER SAFETY

### Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol and either the word “DANGER” or “WARNING.”

These words mean:

**⚠ DANGER**

You can be killed or seriously injured if you don't immediately follow instructions.

**⚠ WARNING**

You can be killed or seriously injured if you don't follow instructions.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.



### **WARNING - “Risk of Fire”**

- Clothes dryer installation must be performed by a qualified installer.
- Install the clothes dryer according to the manufacturer's instructions and local codes.
- Do not install a clothes dryer with flexible plastic venting materials or flexible metal (foil type) duct. If flexible metal duct is installed, it must be of a specific type identified by the appliance manufacturer as suitable for use with clothes dryers. Flexible venting materials are known to collapse, be easily crushed, and trap lint. These conditions will obstruct clothes dryer airflow and increase the risk of fire.
- To reduce the risk of severe injury or death, follow all installation instructions.
- Save these instructions.

**IMPORTANT:** The gas installation must conform with local codes, or in the absence of local codes, with the National Fuel Gas Code, ANSI Z223.1/NFPA 54.

The dryer must be electrically grounded in accordance with local codes, or in the absence of local codes, with the National Electrical Code, ANSI/NFPA 70.

State of California Proposition 65 Warnings:

WARNING: This product contains one or more chemicals known to the State of California to cause cancer.

WARNING: This product contains one or more chemicals known to the State of California to cause birth defects or other reproductive harm.

## IMPORTANT SAFETY INSTRUCTIONS

**WARNING:** To reduce the risk of fire, electric shock, or injury to persons when using the dryer, follow basic precautions, including the following:

- Read all instructions before using the dryer.
- Do not place items exposed to cooking oils in your dryer. Items contaminated with cooking oils may contribute to a chemical reaction that could cause a load to catch fire.
- Do not dry articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances as they give off vapors that could ignite or explode.
- Do not allow children to play on or in the dryer. Close supervision of children is necessary when the dryer is used near children.
- Before the dryer is removed from service or discarded, remove the door to the drying compartment.
- Do not reach into the dryer if the drum is moving.
- Do not install or store the dryer where it will be exposed to the weather.
- Do not tamper with controls.
- Do not repair or replace any part of the dryer or attempt any servicing unless specifically recommended in this Use and Care Guide or in published user-repair instructions that you understand and have the skills to carry out.
- Do not use fabric softeners or products to eliminate static unless recommended by the manufacturer of the fabric softener or product.
- Do not use heat to dry articles containing foam rubber or similarly textured rubber-like materials.
- Clean lint screen before or after each load.
- Keep area around the exhaust opening and adjacent surrounding areas free from the accumulation of lint, dust, and dirt.
- The interior of the dryer and exhaust vent should be cleaned periodically by qualified service personnel.
- See “Electrical Requirements” located in the installation instructions for grounding instructions.

## SAVE THESE INSTRUCTIONS

**WARNING:** For your safety, the information in this manual must be followed to minimize the risk of fire or explosion, or to prevent property damage, personal injury, or death.

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- **WHAT TO DO IF YOU SMELL GAS:**
  - Do not try to light any appliance.
  - Do not touch any electrical switch; do not use any phone in your building.
  - Clear the room, building, or area of all occupants.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency, or the gas supplier.

**WARNING:** Gas leaks cannot always be detected by smell.

Gas suppliers recommend that you use a gas detector approved by UL or CSA.

For more information, contact your gas supplier.

If a gas leak is detected, follow the “What to do if you smell gas” instructions.

## IMPORTANT SAFETY INSTRUCTIONS

When discarding or storing your old clothes dryer, remove the door.

## SAVE THESE INSTRUCTIONS

## CHECK YOUR VENT SYSTEM FOR GOOD AIRFLOW

### **WARNING**



#### Fire Hazard

**Use a heavy metal vent.**

**Do not use a plastic vent.**

**Do not use a metal foil vent.**

**Failure to follow these instructions can result in death or fire.**

### Good airflow


Along with heat, dryers require good airflow to efficiently dry laundry. Proper venting will reduce your drying times and improve your energy savings. See "Installation Instructions."

The venting system attached to the dryer plays a big role in good airflow.


Service calls caused by improper venting are not covered by the warranty and will be paid by the customer, regardless of who installed the dryer.

### Maintain good airflow by:

- Cleaning your lint screen before each load.
- Replace plastic or foil vent material with 4" (102 mm) diameter heavy, rigid vent material.



- Use the shortest length of vent possible.
- Use no more than four 90° elbows in a vent system; each bend and curve reduces airflow.





- Remove lint and debris from the exhaust hood.
- Remove lint from the entire length of the vent system at least every 2 years. When cleaning is complete, be sure to follow the "Installation Instructions" supplied with your dryer for final product check.
- Clear away items from the front of the dryer.

## USE SENSOR DRY/AUTO DRY CYCLES FOR BETTER FABRIC CARE AND ENERGY SAVINGS

Use the Sensor Dry or Auto Dry cycles to provide the most energy savings and enhanced fabric care from the dryer. During Sensor Dry or Auto Dry cycles, drying air temperature or moisture level are sensed in the load. This sensing occurs throughout the drying cycle and the dryer shuts off when the load reaches the selected dryness. The Energy Preferred cycle will provide optimal energy savings.

With Timed Dry, the dryer runs the amount of time set and sometimes results in shrinkage, wrinkling, and static due to over-drying. Use Timed Dry for the occasional damp load that needs a little more drying time or when using the drying rack.

# CONTROL PANEL & FEATURES



Not all features and options are available on all models.  
Appearance may vary.

## 1 DRYER CYCLE KNOB

Use your Dryer Cycle Knob to select available cycles on your dryer. Turn the knob to select a cycle for your laundry load. See "Cycle Guide" for detailed descriptions of cycles.

### SENSOR DRY/AUTO DRY

Senses moisture in the load or air temperature and shuts off when the load reaches the selected dryness level. Gives the best drying in the shortest time. Drying time will vary based on fabric type, load size, and temperature setting.

### TIMED DRY

Will run the dryer for the specified time on the control. On models with a selectable temperature knob, you may choose a setting based on the fabrics in your load. On some models, temperature is included in the cycle selections. Drying time and temperature will depend on your dryer model.

## 2 TEMPERATURE (on some models)

Select a drying temperature based on the fabrics in your load. If you are unsure of the temperature to select for a load, select the lower setting rather than the higher setting.

## 3 WRINKLE PREVENT Feature (on some models)

The WRINKLE PREVENT feature will run after your drying cycle is complete. It periodically starts and stops the dryer, tumbling the load without heat to help avoid wrinkling.

On some models, WRINKLE PREVENT automatically starts at the end of the cycle. Opening the door will stop this feature.

**NOTE:** A signal will sound periodically when the WRINKLE PREVENT setting is selected, but only if the End of Cycle signal is also selected.

## 4 PUSH TO START/END OF CYCLE SIGNAL

The End of Cycle Signal produces an audible sound when the drying cycle is finished. Promptly removing clothes at the end of the cycle reduces wrinkling.

Turn the END OF CYCLE SIGNAL knob to select the desired setting (On or Off). Press the PUSH TO START knob to start the dryer.

## CYCLE GUIDE – SENSOR DRY/AUTO DRY CYCLES

**SENSOR DRY/AUTO DRY** – Senses moisture in the load or air temperature and shuts off when the load reaches the selected dryness level. Choose ENERGY PREFERRED cycle for optimal energy savings.

Not all cycles and settings are available on all models. Settings and options shown in **bold** are default settings for that cycle.

| Items to dry:                                                                  | Dryness Level:                                                       | Temperature:         | Available Options:                     | Cycle Details:                                                                                                                                                                                                                                                                                                          |
|--------------------------------------------------------------------------------|----------------------------------------------------------------------|----------------------|----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Jeans, heavy work clothes, towels                                              | Heavy Dry<br>Very or More Dry<br><b>Energy Preferred</b><br>Less Dry | <b>High</b>          | Wrinkle Prevent<br>End of Cycle Signal | Automatic cycles give the best drying in the shortest time. Drying time varies based on fabric type, load size, and dryness setting. Select a drying temperature based on the fabrics in your load. If you are unsure of the temperature to select for a load, select the lower setting rather than the higher setting. |
| Work clothes, medium weight fabrics, sheets                                    | Heavy Dry<br>Very or More Dry<br><b>Energy Preferred</b><br>Less Dry | <b>Medium or Low</b> | Wrinkle Prevent<br>End of Cycle Signal |                                                                                                                                                                                                                                                                                                                         |
| Casual, shirts, pants, lightweight items, synthetics, delicates, athletic wear | Heavy Dry<br>Very or More Dry<br><b>Energy Preferred</b><br>Less Dry | <b>Low</b>           | Wrinkle Prevent<br>End of Cycle Signal |                                                                                                                                                                                                                                                                                                                         |

**NOTE:** If loads do not seem as dry as you would like, select Heavy Dry or Very Dry/More Dry next time you dry a similar load. If loads seem drier than you like, select Less Dry next time you dry a similar load.

## CYCLE GUIDE – TIMED DRY CYCLES

**TIMED DRY** – Will run the dryer for the specified time on the control.

Not all cycles and settings are available on all models.

| Items to dry:                                      | Cycle:                     | Temperature:             | Available Options:  | Cycle Details:                                                                       |
|----------------------------------------------------|----------------------------|--------------------------|---------------------|--------------------------------------------------------------------------------------|
| Large or heavy items such as thick towels or robes | <b>Heavy Dry</b>           | <b>High</b>              | End of Cycle Signal | Choose high to dry large or heavy loads.                                             |
| Heavy or bulky items                               | <b>Timed Dry High Heat</b> | <b>High</b>              | End of Cycle Signal | Completes drying if items are still damp.                                            |
| Small loads, lightweight items                     | <b>Timed Dry</b>           | <b>Low</b>               | End of Cycle Signal | Dries items to a damp level or for items that do not require an entire drying cycle. |
| Rubber, plastic, heat-sensitive fabrics            | <b>Air Dry/ No Heat</b>    | <b>Air Only/ No Heat</b> | End of Cycle Signal | No-heat drying.                                                                      |

### Setting the Drying Temperature

If your dryer has multiple heat settings:

A High temperature setting may be used for drying heavyweight items such as towels and work clothes.

A Low to Medium temperature setting may be used for drying medium-weight items such as sheets, blouses, dresses, underwear, permanent press fabrics, and some knits.

Use the Air Dry/No Heat setting for foam, rubber, plastic, or heat-sensitive fabrics.

Line-dry bonded or laminated fabrics.

**NOTE:** If you have questions about drying temperatures for various loads, refer to the care label directions.

## USING YOUR DRYER

### ⚠ WARNING



#### Explosion Hazard

Keep flammable materials and vapors, such as gasoline, away from dryer.

Do not dry anything that has ever had anything flammable on it (even after washing).

Failure to follow these instructions can result in death, explosion, or fire.

**WARNING:** To reduce the risk of fire, electric shock, or injury to persons, read the "IMPORTANT SAFETY INSTRUCTIONS" before operating this dryer.

Before using your dryer, wipe the dryer drum with a damp cloth to remove dust from storing and shipping.

### ⚠ WARNING



#### Fire Hazard


No washer can completely remove oil.

Do not dry anything that has ever had any type of oil on it (including cooking oils).

Items containing foam, rubber, or plastic must be dried on a clothesline or by using an Air Cycle.

Failure to follow these instructions can result in death or fire.


### 1. Clean the lint screen



Clean the lint screen before each load. Pull the lint screen out of its holder. Roll lint off the screen with your fingers. Do not rinse or wash screen to remove lint. Push the lint screen firmly back into place.

For additional cleaning information, see "Dryer Care."

### 2. Load the dryer




Place laundry in the dryer. Close the door.

**NOTE:** Your model may have a different door than the one shown. Some models have drop down doors.

Do not tightly pack the dryer; clothes should be able to tumble freely.

### 3. Select the desired cycle



Select the desired cycle for your load. See the "Cycle Guide" for more information about each cycle.

#### SENSOR DRY/AUTO DRY Cycles


You can select a different dryness level, depending on your load, by turning the knob to dryness level.

Selecting Heavy Dry, Very Dry/More Dry, ENERGY PREFERRED, or Less Dry automatically adjusts the dryness level at which the dryer will shut off. Once a dry level is set, it cannot be changed without stopping the cycle.

SENSOR DRY/AUTO DRY cycles give the best drying in the shortest time. Drying time varies based on fabric type, load size, and dryness setting.

**NOTE:** Heavy Dry or Very Dry/More Dry removes more load moisture. ENERGY PREFERRED is used for a starting point for Sensor Dry/Auto Dry cycles. Choose ENERGY PREFERRED for optimal energy savings. Less Dry removes less moisture and is used for loads you may want to put on a hanger to complete drying.

## 4. Set temperature and options (on some models)



Select temperature and options by turning the knob to the desired position or select the Automatic Dry Cycle that has the temperature included in the cycle selections.

**NOTE:** Not all options and settings are available with all cycles.


### TEMPERATURE

Turn the TEMPERATURE knob to change the drying temperature setting. See “Setting the Drying Temperature.”

### Wrinkle Prevent feature (on some models)

- Get up to 40 minutes of heat-free, periodic tumbling at the end of a cycle. Turn the WRINKLE PREVENT knob to select ON or OFF at any time before the cycle has ended.


## 5. Select End of Cycle Signal (if desired)



Turn the END OF CYCLE SIGNAL knob to select the desired setting (On or Off). The End of Cycle Signal produces an audible sound when the drying cycle is finished. Promptly removing clothes at the end of the cycle reduces wrinkling.

**NOTE:** When the Wrinkle Prevent setting is selected and the End of Cycle Signal is on, the tone will sound every 5 minutes until the clothes are removed, or the Wrinkle Prevent setting ends.

## 6. Press PUSH TO START to begin cycle



Push and hold the PUSH TO START knob to begin the cycle.

Promptly remove garments after cycle has completed to reduce wrinkling. Use the Wrinkle Prevent feature to avoid wrinkling when you are unable to remove a load from the dryer as soon as it stops.

## Drying Rack (optional on some models)

Use the Drying Rack to dry items such as sweaters and pillows without tumbling. The drum turns, but the drying rack does not move.

If your model does not have a drying rack, you may be able to purchase one for your model. To find out whether your model allows drying rack usage and for information on ordering, please refer to the “Accessories” section or contact the dealer from whom you purchased your dryer.

**NOTE:** The drying rack must be removed for normal tumbling.

### To use the drying rack

1. Place drying rack in dryer. Slide rear pegs into the dimples on the back wall of the dryer. Lower the front legs to rest on the dryer opening.
2. Put wet items on top of drying rack, leaving space between items. Do not allow items to hang over the edge of the drying rack. Close the door.
3. Select a Timed Dry cycle and temperature, or an air cycle (on some models). Items containing foam, rubber, or plastic must be dried on a clothesline or by using an air cycle. Refer to the following table.
4. Start the dryer. Reset cycle to complete drying, if needed.

| Rack Dry:                                                     | Cycle:        | Temp.: | Time:   |
|---------------------------------------------------------------|---------------|--------|---------|
| Washable wool items (block to shape, lay flat on drying rack) | Timed Dry     | Low    | 60 min. |
| Stuffed toys/pillows (cotton or polyester filled)             | Timed Dry     | Low    | 60 min. |
| Stuffed toys/pillows (foam rubber filled) (on some models)    | Air (no heat) | N/A    | 90 min. |

# DRYER CARE

## Cleaning the dryer location

Keep dryer area clear and free from items that would block the airflow for proper dryer operation. This includes clearing piles of laundry in front of the dryer.

## ⚠ WARNING



### Explosion Hazard

Keep flammable materials and vapors, such as gasoline, away from dryer.

Place dryer at least 18 inches (460 mm) above the floor for a garage installation.

Failure to do so can result in death, explosion, or fire.

## Cleaning the dryer interior

### To clean dryer drum

1. Apply a liquid, nonflammable household cleaner to the stained area of the drum and rub with a soft cloth until stain is removed.
2. Wipe drum thoroughly with a damp cloth.
3. Tumble a load of clean cloths or towels to dry the drum.

**NOTE:** Garments that contain loose dyes, such as denim blue jeans or brightly colored cotton items, may discolor the dryer interior. These stains are not harmful to your dryer and will not stain future loads of clothes. Dry these items inside out to avoid drum staining.

## Removing accumulated lint

### From Inside the Dryer Cabinet

Lint should be removed every 2 years, or more often, depending on dryer usage. Cleaning should be done by a qualified servicer.

### From the Exhaust Vent

Lint should be removed every 2 years, or more often, depending on dryer usage.


## Cleaning the lint screen

### Every load cleaning

Clean lint screen before each load. A screen blocked by lint can increase drying time.

### To clean:

1. The lint screen is located on top of the dryer. Pull the lint screen out of its holder. Roll lint off the screen with your fingers. Do not rinse or wash screen to remove lint. Wet lint is hard to remove.



2. Push the lint screen firmly back into place.

### IMPORTANT:

- Do not run the dryer with the lint screen loose, damaged, blocked, or missing. Doing so can cause overheating and damage to both the dryer and fabrics.
- If lint falls off the screen into the dryer during removal, check the exhaust hood and remove the lint. The exhaust hood is located where the dryer exhaust exits your home.


### As needed cleaning

Laundry detergent and fabric softener residue can build up on the lint screen. This buildup can cause longer drying times for your clothes, or cause the dryer to stop before your load is completely dry. The screen is probably clogged if lint falls off while the screen is in the dryer.

Clean the lint screen with a nylon brush every 6 months, or more frequently, if it becomes clogged due to a residue buildup.

### To wash:

1. Roll lint off the screen with your fingers.
2. Wet both sides of lint screen with hot water.
3. Wet a nylon brush with hot water and liquid detergent. Scrub lint screen with the brush to remove residue buildup.



4. Rinse screen with hot water.
5. Thoroughly dry lint screen with a clean towel. Reinstall screen in dryer.

## **⚠ WARNING**



### **Electrical Shock Hazard**

**Disconnect power before servicing.**

**Replace all parts and panels before operating.**

**Failure to do so can result in death or electrical shock.**

## **Vacation, storage, and moving care**

### **Non-Use or Storage Care**

Operate your dryer only when you are at home. If you will be on vacation or not using your dryer for an extended period of time, you should:

1. Unplug dryer or disconnect power.
2. For gas dryers only: Close shut-off valve to gas supply line.
3. Clean lint screen. See “Cleaning the Lint Screen.”

### **Moving Care**

#### **For power supply cord-connected dryers:**

1. Unplug the power supply cord.
2. Make sure leveling legs are secure in dryer base.
3. Use tape to secure dryer door.

#### **For direct-wired dryers:**

1. Turn off power at fuse or breaker box.
2. Disconnect wiring.
3. Make sure leveling legs are secure in dryer base.
4. Use tape to secure dryer door.

#### **For gas dryers:**


1. Unplug or disconnect power to dryer.
2. Close shut-off valve in gas supply line.
3. Disconnect gas supply line pipe and remove fittings attached to dryer pipe.
4. Cap the open fuel supply line.
5. Make sure leveling legs are secure in dryer base.
6. Use tape to secure dryer door.

### **Reinstalling the Dryer**

Follow the “Installation Instructions” to locate, level, and connect the dryer.

## **Changing the drum light (on some models)**

1. Unplug dryer or disconnect power.
2. Open the dryer door. Locate the light bulb cover on the back wall of the dryer. Using a Phillips-head screwdriver, remove the screw located in the lower right-hand corner of the cover. Remove the cover.



3. Turn bulb counterclockwise. Replace the bulb with a 10-watt appliance bulb only. Replace the cover and secure with the screw.
4. Plug into a grounded outlet or reconnect power.

# TROUBLESHOOTING

First try the solutions suggested here or visit our website and reference FAQs (Frequently Asked Questions) to possibly avoid the cost of a service call.

| If you experience                                                | Possible Causes                                                                            | Solution                                                                                                                                                                                                                                                                                                      |
|------------------------------------------------------------------|--------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Clothes are not drying satisfactorily, drying times are too long | Lint screen clogged with lint.                                                             | Lint screen should be cleaned before each load.                                                                                                                                                                                                                                                               |
|                                                                  | The Air Dry/No Heat cycle has been selected.                                               | Select the correct cycle for the types of garments being dried. See "Cycle Guide."                                                                                                                                                                                                                            |
|                                                                  | Load too large and heavy to dry quickly.                                                   | Separate the load to tumble freely.                                                                                                                                                                                                                                                                           |
|                                                                  | Exhaust vent or outside exhaust hood clogged with lint, restricting air movement.          | Run the dryer for 5–10 minutes. Hold your hand under the outside exhaust hood to check air movement. If you do not feel air movement, clean exhaust system of lint or replace exhaust vent with heavy metal or flexible metal vent. Make sure vent is not crushed or kinked. See "Installation Instructions." |
|                                                                  | Fabric softener sheets blocking the grille.                                                | Use only one fabric softener sheet, and use it only once.                                                                                                                                                                                                                                                     |
|                                                                  | Exhaust vent not the correct length.                                                       | Check that the exhaust vent is not too long or has too many turns. Long venting will increase drying times. Make sure vent is not crushed or kinked. See "Installation Instructions."                                                                                                                         |
|                                                                  | Exhaust vent diameter not the correct size.                                                | Use 4" (102 mm) diameter vent material.                                                                                                                                                                                                                                                                       |
|                                                                  | Dryer located in a room with temperature below 45°F (7°C).                                 | Proper operation of dryer cycles requires temperatures above 45°F (7°C).                                                                                                                                                                                                                                      |
|                                                                  | Dryer located in a closet without adequate opening.                                        | Closet doors must have ventilation openings at the top and bottom of the door. The front of the dryer requires a minimum of 1" (25 mm) of airspace, and, for most installations, the rear of the dryer requires 5" (127 mm). See "Installation Instructions."                                                 |
| Dryer will not run                                               | Door not closed completely.                                                                | Make sure the dryer door is closed completely.                                                                                                                                                                                                                                                                |
|                                                                  | PUSH TO START knob not pressed firmly or held long enough.                                 | Press and hold the PUSH TO START knob until you hear the dryer drum moving.                                                                                                                                                                                                                                   |
|                                                                  | Household fuse is blown or circuit breaker has tripped.                                    | Electric dryers use 2 household fuses or circuit breakers. The drum may be turning, but you may not have heat. Replace both fuses or reset the circuit breaker. If the problem continues, call an electrician.                                                                                                |
|                                                                  | Incorrect power supply.                                                                    | Electric dryers require 240-volt power supply. Check with a qualified electrician.                                                                                                                                                                                                                            |
|                                                                  | Wrong type of fuse.                                                                        | Use a time-delay fuse.                                                                                                                                                                                                                                                                                        |
| Unusual sounds                                                   | Dryer had a period of non-use.                                                             | If the dryer hasn't been used for awhile, there may be a thumping sound during the first few minutes of operation.                                                                                                                                                                                            |
|                                                                  | A coin, button, or paper clip is caught between the drum and front or rear of the dryer.   | Check the front and rear edges of the drum for small objects. Clean out pockets before laundering.                                                                                                                                                                                                            |
|                                                                  | It is a gas dryer.                                                                         | The gas valve clicking is a normal operating sound.                                                                                                                                                                                                                                                           |
|                                                                  | The four legs are not installed, or the dryer is not level front to back and side to side. | The dryer may vibrate if not properly installed. See "Installation Instructions."                                                                                                                                                                                                                             |
|                                                                  | Clothing knotted or balled up.                                                             | When balled up, the load will bounce, causing the dryer to vibrate. Separate the load items and restart the dryer.                                                                                                                                                                                            |
| No heat                                                          | Household fuse is blown or circuit breaker has tripped.                                    | The drum may be turning, but you may not have heat. Electric dryers use 2 household fuses or circuit breakers. Replace both fuses or reset the circuit breaker. If the problem continues, call an electrician.                                                                                                |
|                                                                  | Supply line valve not open.                                                                | For gas dryers, the valve is open on the supply line.                                                                                                                                                                                                                                                         |
|                                                                  | Incorrect power supply.                                                                    | Electric dryers require a 240-volt power supply. Check with a qualified electrician.                                                                                                                                                                                                                          |

## TROUBLESHOOTING cont.

First try the solutions suggested here or visit our website and reference FAQs (Frequently Asked Questions) to possibly avoid the cost of a service call.

| If you experience      | Possible Causes                                                                                   | Solution                                                                                                                                                                                                                                                                  |
|------------------------|---------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Cycle time too short   | Sensor cycle ending early.                                                                        | The load may not be contacting the sensor strips. Level the dryer.<br>Use Timed Dry for very small loads. Change the Dry Level setting on Sensor Dry/Auto Dry cycles.<br>Increasing or decreasing the Dry Level setting will change the amount of drying time in a cycle. |
| Lint on load           | Lint screen clogged.                                                                              | Lint screen should be cleaned before each load.                                                                                                                                                                                                                           |
| Stains on load or drum | Dryer fabric softener not properly used.                                                          | Add dryer fabric softener sheets at the beginning of the cycle. Fabric softener sheets added to a partially dried load can stain your garments.<br>Drum stains are caused by dyes in clothing (usually blue jeans). These will not transfer to other clothing.            |
| Loads are wrinkled     | Load not removed from dryer at the end of the cycle.                                              | Select Wrinkle Prevent feature to tumble the load without heat to avoid wrinkling.                                                                                                                                                                                        |
|                        | Dryer tightly packed.                                                                             | Dry smaller loads that can tumble freely to reduce the chance of wrinkles forming.                                                                                                                                                                                        |
| Odors                  | You have recently been painting, staining, or varnishing in the area where your dryer is located. | Ventilate the area. When the odors or fumes are gone from the area, rewash and dry the clothing.                                                                                                                                                                          |
|                        | The electric dryer is being used for the first time.                                              | The new electric heating element may have an odor. The odor will be gone after the first cycle.                                                                                                                                                                           |
| Load is too hot        | Laundry items were removed from the dryer before the end of the cycle.                            | Allow Cool Down cycle to finish before removing laundry from dryer. All cycles are cooled slowly to reduced wrinkling and make it easier to handle. Items removed before Cool Down may feel very warm.                                                                    |
|                        | A high temperature cycle was used or TEMPERATURE control was set to high.                         | Select a lower temperature, and use a Sensor Dry/Auto Dry cycle. These cycles sense the temperature or the moisture level in the load and shut off when the load reaches the selected dryness. This reduces overdrying.                                                   |

## ACCESSORIES

Enhance your dryer with these premium accessories.

For more high-quality items or to order, call **1-800-901-2042**, or visit us at **www.applianceaccessories.com**. In Canada, call **1-800-807-6777** or visit us at **www.whirlpoolparts.ca**.

| Part Number | Accessory                                                                                            |
|-------------|------------------------------------------------------------------------------------------------------|
| 3404351     | Drying rack – fits 29" (737 mm) Super Capacity, 6.5 cu. ft. (0.18 cu. m) – side swing or hamper door |
| 3406839     | Drying rack – fits 29" (737 mm) Super Capacity Plus, 7.0 cu. ft. (0.20 cu. m) – side swing door only |

# CROSLEY® CORPORATION LAUNDRY WARRANTY

## LIMITED WARRANTY

For one year from the date of purchase, when this major appliance is installed, operated, and maintained according to instructions attached to or furnished with the product, Whirlpool Corporation or Whirlpool Canada LP (hereafter "Whirlpool") will pay for Factory Specified Replacement Parts and repair labor to correct defects in materials or workmanship that existed when this major appliance was purchased.

YOUR SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPAIR AS PROVIDED HEREIN. Service must be provided by a Whirlpool designated service company. This limited warranty is valid only in the United States or Canada and applies only when the major appliance is used in the country in which it was purchased. This limited warranty is effective from the date of original consumer purchase. Proof of original purchase date is required to obtain service under this limited warranty.

## ITEMS EXCLUDED FROM WARRANTY

### This limited warranty does not cover:

1. Replacement parts or repair labor if this major appliance is used for other than normal, single-family household use or when it is used in a manner that is inconsistent to published user or operator instructions and/or installation instructions.
2. Service calls to correct the installation of your major appliance, to instruct you on how to use your major appliance, to replace or repair house fuses, or to correct house wiring or plumbing.
3. Service calls to repair or replace appliance light bulbs, air filters, or water filters. Consumable parts are excluded from warranty coverage.
4. Damage resulting from accident, alteration, misuse, abuse, fire, flood, acts of God, improper installation, installation not in accordance with electrical or plumbing codes, or use of products not approved by Whirlpool.
5. Cosmetic damage, including scratches, dents, chips or other damage to the finish of your major appliance, unless such damage results from defects in materials or workmanship and is reported to Whirlpool within 30 days from the date of purchase.
6. Pick up and delivery. This major appliance is intended to be repaired in your home.
7. Repairs to parts or systems resulting from unauthorized modifications made to the appliance.
8. Expenses for travel and transportation for product service if your major appliance is located in a remote area where service by an authorized Whirlpool servicer is not available.
9. The removal and reinstallation of your major appliance if it is installed in an inaccessible location or is not installed in accordance with Whirlpool published installation instructions.
10. Replacement parts or repair labor on major appliances with original model/serial numbers that have been removed, altered, or cannot be easily determined.

**The cost of repair or replacement under these excluded circumstances shall be borne by the customer.**

## DISCLAIMER OF IMPLIED WARRANTIES

IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR OR THE SHORTEST PERIOD ALLOWED BY LAW. Some states and provinces do not allow limitations on the duration of implied warranties of merchantability or fitness, so this limitation may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state or province to province.

## DISCLAIMER OF REPRESENTATIONS OUTSIDE OF WARRANTY

Whirlpool makes no representations about the quality, durability, or need for service or repair of this major appliance other than the representations contained in this Warranty. If you want a longer or more comprehensive warranty than the limited warranty that comes with this major appliance, you should ask Whirlpool or your retailer about buying an extended warranty.

## LIMITATION OF REMEDIES; EXCLUSION OF INCIDENTAL AND CONSEQUENTIAL DAMAGES

YOUR SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPAIR AS PROVIDED HEREIN. WHIRLPOOL SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states and provinces do not allow the exclusion or limitation of incidental or consequential damages, so these limitations and exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state or province to province.

If outside the 50 United States and Canada, contact your authorized Crosley® dealer to determine if another warranty applies.

If you think you need repair service, first see the "Troubleshooting" section of the Use & Care Guide. If you are unable to resolve the problem after checking "Troubleshooting," additional help can be found by checking the "Assistance or Service" section or by calling Whirlpool. In the U.S.A., call **1-800-253-1301**. In Canada, call **1-800-807-6777**.

7/12

**Keep this book and your sales slip together for future reference. You must provide proof of purchase or installation date for in-warranty service.**

Write down the following information about your major appliance to better help you obtain assistance or service if you ever need it. You will need to know your complete model number and serial number. You can find this information on the model and serial number label located on the product.

Dealer name \_\_\_\_\_  
Address \_\_\_\_\_  
Phone number \_\_\_\_\_  
Model number \_\_\_\_\_  
Serial number \_\_\_\_\_  
Purchase date \_\_\_\_\_

## Assistance or Service

Before calling for assistance or service, please check "Troubleshooting."  
It may save you the cost of a service call. If you still need help, follow the instructions below.  
When calling, please know the purchase date and the complete model and serial number of your appliance.  
This information will help us to better respond to your request.

### If you need replacement parts or to order accessories

We recommend that you use only FSP® Factory Specified Parts.  
These parts will fit right and work right because they are made with the same precision  
used to build every new WHIRLPOOL® appliance.

#### To locate FSP® replacement parts, assistance in your area, or accessories:

Whirlpool Corporation  
Customer eXperience Center  
**1-800-253-1301**  
**www.crosley.com**

Whirlpool Canada LP  
Customer eXperience Centre  
**1-800-807-6777**  
**www.crosley.com**

or call your nearest designated service center or refer to your Yellow Pages telephone directory.

### Our consultants provide assistance with

#### In the U.S.A.

- Features and specifications on our full line of appliances.
- Installation information.
- Specialized customer assistance (Spanish speaking, hearing impaired, limited vision, etc.).

#### In the U.S.A. and Canada

- Use and maintenance procedures.
- Accessory and repair parts sales.
- Referrals to local dealers, repair parts distributors, and service companies. Whirlpool® designated service technicians are trained to fulfill the product warranty and provide after-warranty service, anywhere in the United States and Canada.

You can write with any questions or concerns at:

Crosley Corporation  
111 Cloverleaf Drive, Suite 200  
Winston-Salem, NC 27103

Customer eXperience Centre  
Whirlpool Canada LP  
Unit 200-6750 Century Ave  
Mississauga, Ontario L5N 0B7

Please include a daytime phone number in your correspondence.

## Assistance ou service

Avant de faire un appel pour assistance ou service, veuillez vérifier la section "Dépannage".

Cette vérification peut vous faire économiser le coût d'une visite de réparation.

Si vous avez encore besoin d'aide, suivre les instructions ci-dessous.

Lors d'un appel, veuillez connaître la date d'achat et les numéros au complet de modèle et de série de votre appareil.  
Ces renseignements nous aideront à mieux répondre à votre demande.

### Si vous avez besoin de pièces de rechange ou pour commander des accessoires

Si vous avez besoin de commander des pièces de rechange, nous vous recommandons d'utiliser seulement des pièces spécifiées par l'usine FSP®. Ces pièces conviendront et fonctionneront bien parce qu'elles sont fabriquées selon les mêmes spécifications précises utilisées pour construire chaque nouvel appareil WHIRLPOOL®.

#### Pour trouver des pièces de rechange FSP® ou des accessoires dans votre région :

Whirlpool Canada LP Centre pour l'eXpérience de la clientèle  
**1-800-807-6777** **www.crosley.com**

#### Nos consultants fournissent l'assistance pour :

- Procédés d'utilisation et d'entretien.
- Vente d'accessoires et de pièces de rechange.
- Les références aux concessionnaires, compagnies de service de réparation et distributeurs de pièces de rechange locaux. Les techniciens de service désignés par Whirlpool® sont formés pour remplir la garantie des produits et fournir un service après la garantie, partout au Canada.

#### Pour plus d'assistance

Vous pouvez nous soumettre toute question ou problème en écrivant à l'adresse ci-dessous :

Centre pour l'eXpérience de la clientèle  
Whirlpool Canada LP  
Unit 200-6750 Century Ave  
Mississauga, Ontario L5N 0B7

Dans votre correspondance, veuillez indiquer un numéro de téléphone où on peut vous joindre dans la journée.

**W10096992B**  
**W10097009B - LP**

© 2016  
All rights reserved  
Tous droits réservés

© Crosley is a Registered Trademark of The Crosley Group, Inc.  
© Crosley est une marque déposée de The Crosley Group, Inc.