


Portable Power Station G300

User Manual



ATTENTION:

1. **IMPORTANT:** Recharge the power station every 3 months.
2. Never disassemble, puncture, shock, crash, short or incinerate.
3. Keep dry and do not expose to high temperature environment.

1


PRODUCT SPECIFICATIONS

Model Number	G300
Capacity	260Wh(7000mAh, 3.7V)
Input	Charging Port: DC 5.5 x 2.1mm, 19V/3.42A max
Charging Time	DC 19V: About 6-7 hours
Output	AC Output: 110V 60Hz, 300W, Pure Sine Wave
	DC Output: DC 1: 12V/8A DC 2: 24V/3A
	USB-A Output: 5V/2.4A
	USB-C Output: 5V/2.4A, 9V/2A, 12V/1.5A
	Wireless charging: 5V/2A
Lifecycle	> 1000 Times to 80% Capacity Remained
Working temperature	0°C - 40°C / 32°F - 104°F
Weight	8.3 lbs / 3.8 kg
Dimensions	12 x 7.5 x 8 in

PACKAGE INCLUDED



PRODUCT DIAGRAM




2

Tip:

When the temperature inside the power station reaches 45°C / 113°F, the fan will automatically run to help dissipate the heat.

DISPLAY SCREEN



Battery Status	Flashes when charging or the battery power of the power station is below 20%.
AC Status	Lights up when AC Output is activated, or short circuit/overload occurs.
High Temperature Alert	Reminds you when the temperature inside the power station reaches 140°F / 60°C.
AC Output Indicator	Displays the current digits when the Output/Input is operating.
DC Output Indicator	
USB Output Indicator	
DC Input Indicator	

WHAT YOU NEED TO KNOW

Q: What devices can G300 power to?

A: Please kindly be noted it can only charge/power your devices that less than 300 Watts, please check out the operating power of your device before use.

Q: How long can it power my devices??

A: Working time = Fully charged 260Wh * 0.85 / operating power of your device.
For your information, if the power consumption of your device was 30W, The running time will be 260Wh * 0.85 / 30W = 7 hrs (rough calculation).

Q: Can I charge this power station while supplying power at the same time?

A: Yes, it support pass-through charging, you can charge your devices while it is charging. But, for the safety of use, the AC outputs won't pass while being charged.

Q: What kind of solar panel can pair with this power bank?

A: This unit can accept 12V-25V max Voltage input and a 5.5x2.1mm DC connector. We suggest buying a solar panel with 100W+ power. The charging time depends on the intensity of sunlight and the power of solar panel.

3

TROUBLESHOOTING GUIDE

Q1. Why can't I charge my devices via the DC Output, USB Output or AC Output?

- * Please make sure to press the Power Button to turn on the power of the DC, USB and AC output.
- * Make sure the power station has enough power.
- * Make sure the power of your device within 300W.

Q2. Why the AC adapter cannot charge the power station?

- * Check if the light indicator of the adapter is on.
- * Check if there any abnormal phenomenon of the adapter (such as heat, abnormal noise, etc.)
- * Try to charge the power station in other ways(such as use the car charger or solar panel to charge it). If other charging ways are workable, the adapter malfunctioned. If all the charging ways are unworkable, please contact us for support.

Q3. Is this power station allowed in airplanes?

* According to the regulation of the International Civil Aviation Organization, the Lithium-Ion battery under 100 Watt-hour is acceptable with carry-on ONLY. However, SinKeu G300 reaches 260 Watt-hour which is forbidden for transport in airplanes.

Q4. Why the fan is still working when the power station is off?

The fan will continue working even the product is turned off due to the built-in cooling function. It will stop working after the product drops to normal temperature.


OPERATION GUIDE

Charge

This power station has an internal rechargeable lithium battery. Please charge this power station at your first use.

Option 1: Charge with the AC Adapter

Plug one end of the AC Adapter to any socket, and the other end to the DC Input to charge.



Tips:

1. It will take 6-7 hours to reach a full charge.
2. Please do not touch the adapter when charging.
3. Unplug the AC Adapter after the power station is fully charged.


4

Option 2: Charge with the Car Charger

Plug one end of the Car Charger to the Cigarette Lighter of your vehicle, and the other end to the DC Input of the power station. Start the engine of your vehicle to automatically charge the power station.

Notes:


- * Please make sure that the output voltage of the Cigarette Lighter reaches 13V when charging with the car charger.
- * Before charging the power station with the Car Charger, please start the engine of your vehicle to ensure a steady power supply.



Tip:
The charging time varies with the power of your vehicle.


Option 3: Charge with the Solar Panel

Step 1: Place your solar panel where it can collect as much direct sunlight as possible.
Step 2: Connect the DC Output of your solar panel to the DC Input of the power station.



Tip:
The charging time depend on the power of the solar panel and the intensity of the sunlight.


Charging status



5

Power ON/OFF


Press Power Button once to turn on the power station.
Press Power Button twice to constantly supply the power for outputs after powering on.
Long press Power Button to turn off the power station.



Connections

1. DC Output, USB Output and USB-C Output

Step 1: Press the Power Button once to turn on the power station.
Step 2: Connect the electronic devices to the power station with the corresponding cables.




Tips:

- *The power of DC Output, USB Output and USB-C Output will be automatically off if there is no any external devices connected within 30 seconds.
- *After powering on the power station, press Power Button twice, the power of DC Output, USB Output and USB-C Output will always be on.

6


2. AC Output

Step 1: Press the Power Button once to turn on the power station.
Step 2: Press the AC On/Off button.
Step 3: Connect the devices to the power station with the AC Connector.



3. Wireless Charging

Power on the power station and the wireless charging will be enabled. Place the device supporting wireless charging on the top of the power station to get it charged.



Tip:
The mobile device should be placed at the center of the wireless charging area; otherwise, it may not be charged.

PRODUCT WARRANTY

The warranty period is 12 months by starting the date of purchase, we warrants to all original customers that the product will be free from defects in workmanship and material under normal use. The warranty does not apply to any misused, abused, modified, damaged by accident or used for any other than normal consumer use.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following conditions:
* This device may not cause harmful interference.
* This device must accept any interference received, including interference that may cause undesired operation.

7

SECURITY AND MAINTENANCE

- * DO NOT disassemble, repair or modify the unit or the battery.
- * DO NOT charge, use or store the unit in a bathroom or in an area exposed to rain or moisture.
- * Only use the output socket to power external devices. Never connect the output to mains power under any circumstances.
- * DO NOT touch the unit or the plug-in points if your hands are wet.
- * DO NOT connect any metallic objects to the AC input or output.
- * DO NOT rub your eyes if fluid from inside the unit should get in your eyes.
- * DO NOT dispose the unit together with household waste.
- * DO NOT use any inappropriate power cords.
- * DO NOT operate the unit above the specified input voltage.
- * DO NOT use the unit if it is not functioning correctly.
- * DO NOT move the unit if it is recharging or in use.
- * DO NOT put fingers or hands into the product.
- * DO NOT use a battery pack or appliance that is damaged or modified. The damaged or modified battery may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- * DO NOT disassemble the power pack, take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or electric shock.

ATTENTION

- * Not permitted on airplanes.
- * To preserve the battery lifespan, please use and recharge at least once in every 3 months.
- * Use original or certified charger and cables.
- * Avoid extreme temperature, use and store the unit within an ambient temperature range of 0°C - 40°C / 32°F - 104°F.
- * Avoid dropping.
- * Do not disassemble.
- * It's not waterproof, do not expose to liquids.
- * Please dispose of batteries and electronic goods in accordance with local regulations

CONTACT US

support@sinkeu.com



8