

SUSTEAS PULL CHOPPER

Model: A603-B

Includes: 1 x Tri-blade Chopper



650 ml
Capacity



Lockable
Lid



Non-Slip
Base



Quick Pour
Lid

Instruction Manual

Read all instructions carefully before use. Always use parts as intended to avoid injury or damage. Save this information for future reference. This product is designed and intended for multiple reuse.

Ecommerce Website Customer Service Email:
susteas.shop@gmail.com



WARNING! Sharp blades.

Handle with care. Keep out of reach of children.
Never leave blades unattended.

CAUTION

- Improper use may cause injury or damage.
- Place the chopper on an even surface.
- Do not use hands to remove food from blades. If food is stuck in the blade, use a soft bristled dish brush, or rinse under running water.
- Do not place objects, such as forks, knives or spoons, in the pull chopper.
- Do not use to chop ice cubes, tough, hard or frozen foods.
- Do not pull the handle to its maximum length.

Care Instructions

Wash before first use. Not suitable for dishwasher or microwave. Rinse well. Do not use abrasive soaps or scourers. Do not use water above 80°C (176°F). To prevent stains, clean soon after each use. To prevent marks or rust, wipe dry straight after washing and store in a dry place. To avoid injury when not in use always store blade in the container. We recommend using a handled brush to clean the blades.

Lid with pull cord: Wipe clean with a damp cloth. Do not immerse in water. Do not soak. Hand wash only with warm soapy water.

Product Features

Quick Pour Lid

Pull Handle

Lockable Lid

Tri-Blade Chopper

Clear Container

Non-slip Base

Directions for Use

1. Prepare and load the food:
Cut food into smaller pieces to fit into the container. For best results only fill to two thirds of container.
Note: for harder vegetables (like carrot) you may need to experiment with the size of the food you initially put into the unit, if the blade is getting stuck simply remove the food, cut into more smaller pieces and start again.
2. Secure the lid:
Close the lid by aligning with the top of the blade holder, turn the lid anti-clockwise to lock in place.
3. Pull the cord:
Hold the lid and chopper firmly with one hand and use the other hand to pull the cord handle in quick, short motions. Continue pulling until food reaches the desired size. Softer food may need fewer pulls than harder food.

Approximate Chopping Guide

- Coarse: Pull 1-5 times
- Medium: Pull 6-10 times
- Fine: Pull 11-19 times
- Puree: Pull 20 times or more

