

Model: CC008704-001 (1.5 QT Rice Cooker)

## 1. Overview

The GreenLife Rice Cooker is a compact appliance designed for cooking rice and other grains. It features a PFAS-free ceramic nonstick interior pot, a simple one-switch operation, and an automatic keep-warm function.



### Key Components:

- Main cooker unit with control switch
- Removable ceramic nonstick inner pot
- Glass lid with steam vent
- Rice paddle
- Measuring cup

## 2. Features & Specifications

### 2.1 Physical Specifications

- **Capacity:** 3 cups uncooked / 6 cups cooked rice
- **Inner Pot Material:** PFAS-Free Ceramic Nonstick
- **Lid Material:** Glass
- **Exterior Finish:** Cool-touch, wood-print handles
- **Product Dimensions:** 9.61"D x 18.7"W x 15.75"H
- **Item Weight:** 1.45 kg

### 2.2 Electrical Specifications

- **Power Source:** Corded Electric
- **Voltage:** 120 Volts
- **Wattage:** 300 watts

**Note:** This product is designed for use with 120V outlets. Use outside the United States may require a voltage converter.

### 2.3 Control & Operation Features

- **One-Touch Operation:** Single switch with positions for OFF, WHITE RICE, and BROWN RICE.
- **Automatic Keep-Warm:** Automatically switches to keep-warm mode after cooking is complete.
- **See-Through Lid:** Allows you to monitor cooking progress.

## 3. Safety Information

**WARNING:** To reduce the risk of fire, electric shock, or injury:

- Read all instructions before using the rice cooker.
- Do not immerse the main cooker unit, cord, or plug in water or other liquids.
- Only the removable inner pot and lid are dishwasher safe. Wipe the main unit exterior with a damp cloth.
- Always use the provided measuring cup. The "cup" measurement for this appliance is specific and differs from a standard US cup.
- Ensure the inner pot is correctly seated and the lid is securely closed before operation.
- Do not operate the appliance if the cord or plug is damaged.

- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities.
- Keep the appliance and its cord out of reach of children.

## 4. Use Guide

### 4.1 Before First Use

1. Remove all packaging materials and stickers.
2. Wash the removable inner pot, glass lid, and rice paddle in warm, soapy water. Rinse and dry thoroughly.
3. Wipe the exterior of the main unit with a damp cloth. Do not submerge it in water.

### 4.2 Cooking Rice



1. **Measure:** Use the provided measuring cup to portion uncooked rice. Do not exceed 3 level cups of uncooked rice.
2. **Rinse:** Rinse the rice in cold water until the water runs clear, if desired.

3. **Add Water:** Place the rinsed rice and the corresponding amount of water into the inner pot. Refer to the water level lines inside the pot or use the general guideline of 1:1.5 to 1:2 ratio of rice to water.
4. **Assemble:** Place the inner pot into the main cooker unit. Ensure it sits flat. Close the glass lid securely.
5. **Select Mode:** Plug in the appliance. Slide the control switch to the **WHITE RICE** or **BROWN RICE** position, depending on the grain type. The indicator light will turn on.
6. **Cook:** The cooker will begin heating. Cooking time varies by quantity and type of rice. Do not open the lid during cooking.
7. **Keep Warm:** When cooking is finished, the switch will automatically click to the **KEEP WARM** position, and the indicator light will remain on. Rice can be kept warm for several hours.
8. **Serve:** Unplug the appliance. Use the rice paddle to fluff and serve. The handles will remain cool to the touch.

### 4.3 Cooking Other Grains & Oatmeal

The appliance can also be used for grains like quinoa, barley, and oatmeal. Use the **BROWN RICE** setting for harder grains and adjust water ratios according to the grain's requirements. Monitor the first few uses to determine optimal water levels.

## 5. Cleaning & Maintenance

- **Inner Pot & Lid:** Allow to cool. These components are **dishwasher safe** (top rack recommended). For hand washing, use a soft sponge with mild detergent. Avoid abrasive cleaners or scouring pads.
- **Main Unit:** Always unplug and let cool. Wipe the exterior and the heating plate inside the unit with a **damp cloth only**. Ensure no water enters the appliance.
- **Rice Paddle & Measuring Cup:** Wash with warm, soapy water.

**Care Instructions:** Dishwasher Safe (for removable parts), Hand Wash, Wipe with Damp Cloth.

## 6. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in. Faulty outlet.	Check power connection. Try a different outlet.
Rice is undercooked or too hard.	Insufficient water. Lid not closed properly.	Add more water for next use. Ensure lid is securely closed during cooking.
Rice is mushy or overcooked.	Too much water.	Use less water for next use.
Rice is burning or sticking to the bottom.	Insufficient water. Nonstick coating damaged.	Ensure correct water ratio. Avoid using metal utensils that can scratch the pot.
Steam escaping excessively from lid.	Overfilled pot. Water boiling over.	Do not exceed the maximum 3-cup uncooked rice capacity.

### Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.