

Model: CRD50LB1BSS | Capacity: 5.3 QT (10 Cups Uncooked / 20 Cups Cooked)

Overview

This appliance is a programmable rice cooker and multi-cooker with 14 digital cooking functions. It is designed for cooking a variety of grains, steaming, slow cooking, sautéing, and more.



Features & Specifications

Key Features

- **14 Digital Cooking Programs:** White rice, brown rice, quick rice, rolled oats, steel-cut oats, quinoa, barley, mixed grains, steam, slow cook, sauté, soup, cake, and jam.
- **Large Capacity:** 5.3-quart (10 cups uncooked) inner pot yields up to 20 cups of cooked rice or grains.
- **Digital Control Panel:** Features an LED display, one-touch program selection, and a delay timer.
- **Keep Warm Function:** Automatically switches to keep warm mode for up to 24 hours after cooking completes.
- **Delay Timer:** Up to 15-hour delay start for meal planning.
- **Safety Features:** Built-in overheating protection, BPA-free food-grade materials, and a cool-touch handle.
- **Easy Cleaning:** Stainless steel exterior. The inner pot, measuring cup, spatula, and steamer basket are dishwasher safe.

Technical Specifications

- **Model:** CRD50LB1BSS
- **Power Source:** Corded Electric
- **Voltage:** 120 Volts (For use in the United States)
- **Wattage:** 860 watts
- **Product Dimensions:** 11.14"D x 10.83"W x 11.26"H
- **Item Weight:** 6.2 Pounds
- **Material:** Stainless Steel and Plastic housing. Plastic lid.
- **Included Components:** Inner Pot, Measuring Cup, Spatula, Steamer Basket.



Parts & Controls

Main Unit Components

- **Main Housing:** Stainless steel exterior.
- **Lid:** Plastic with a steam vent.
- **Inner Pot:** Non-stick, removable cooking pot with volume markings.
- **Control Panel:** Located on the front of the unit.
- **Power Cord:** Attached to the rear of the unit.
- **Cool-Touch Handle:** For safely opening the lid.

Control Panel and Display

The digital panel includes the following elements:

- **LED Display:** Shows the selected program, timer, and cooking status.
- **Program Buttons:** 14 dedicated buttons for selecting the cooking function (e.g., White Rice, Brown Rice, Steam, Slow Cook).

- **Timer Button:** Used to set the delay start timer.
- **Keep Warm Indicator:** Illuminates when the unit is in keep warm mode.
- **Start/Cancel Button:** Begins the selected cooking cycle or cancels an ongoing operation.



Use Guide

Before First Use

1. Remove all packaging materials and stickers.
2. Wash the inner pot, steamer basket, measuring cup, and spatula in warm, soapy water. Rinse and dry thoroughly. These parts are dishwasher safe.
3. Wipe the exterior and interior of the main housing with a damp cloth. Do not immerse the main unit in water.
4. Place the inner pot into the cooker.

Basic Cooking Instructions (e.g., White Rice)

1. Measure the desired amount of rice using the provided cup. One cup uncooked rice typically yields approximately two cups cooked.
2. Rinse the rice in a separate bowl until the water runs clear.
3. Add the rinsed rice and the corresponding amount of water to the inner pot. Refer to the water level markings inside the pot or standard rice-to-water ratios.
4. Close the lid securely.
5. Plug the power cord into a 120V outlet.
6. Press the **White Rice** program button. The LED display will show the estimated cooking time.
7. Press the **Start** button. The cooking cycle will begin.
8. When cooking is complete, the unit will beep and automatically switch to **Keep Warm** mode. The Keep Warm indicator will light up.
9. Use the cool-touch handle to open the lid. Fluff the rice with the provided spatula before serving.
10. Unplug the unit when finished.



Using the Delay Timer

1. Add food and liquid to the inner pot and close the lid.
2. Select your desired cooking program (e.g., Brown Rice, Oatmeal).
3. Press the **Timer** button. Use the "+" or "-" buttons (or similar controls) to set the number of hours until you want cooking to begin.
4. Press **Start**. The display will show the countdown until cooking starts. Cooking will begin automatically after the set delay.

Using the Steamer Basket

1. Add water to the inner pot, ensuring the water level is below the bottom of the steamer basket.
2. Place the steamer basket into the inner pot.
3. Arrange food to be steamed (vegetables, dumplings, fish) in the basket.
4. Close the lid.
5. Select the **Steam** program and adjust the time if necessary. Press **Start**.



Other Functions

The process for other functions (Slow Cook, Sauté, Soup, Cake, Jam) follows a similar pattern:

1. Prepare ingredients as directed by your recipe.
2. Add them to the inner pot.
3. Select the corresponding program button.
4. For some programs (like Slow Cook), you may need to set a cooking duration.
5. Press **Start**.

Cleaning & Maintenance

- **Always unplug** the unit and allow it to cool completely before cleaning.
- **Main Housing & Lid:** Wipe the exterior and the inside of the lid with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- **Inner Pot, Steamer Basket, Measuring Cup, Spatula:** These are dishwasher safe. For hand washing, use mild dish soap and a non-abrasive sponge. Avoid using metal utensils on the non-stick inner pot to prevent scratching.
- **Never immerse** the main cooker body, power cord, or plug in water or any other liquid.
- Ensure the steam vent on the lid is clear of food debris.



Troubleshooting

- **Unit does not turn on:** Check that the power cord is securely plugged into a working 120V outlet.
- **Food is undercooked or overcooked:** Ensure you are using the correct program for the food type. Verify the amount of liquid used. For grains, use the provided measuring cup and follow recommended water ratios.
- **Steam is escaping from the sides:** Ensure the lid is closed completely and securely.
- **Keep Warm function does not activate:** The unit automatically switches to keep warm after cooking. If it does not, the cycle may have been interrupted or canceled.
- **Error message or unusual display:** Unplug the unit, wait for 10 minutes, then plug it back in. If the problem persists, discontinue use.

Safety Information

- This appliance is for household use only.
- Use on a stable, level, heat-resistant surface away from edges.

- Do not operate the appliance without the inner pot in place.
- Do not cover the steam vent during operation.
- The exterior surfaces, lid, and steam can become very hot during and after use. Use the cool-touch handle and always open the lid away from your face to avoid steam burns.
- Do not move the appliance while it is in operation or contains hot food/liquid.
- Unplug the unit when not in use and before cleaning.
- This product is designed for 120V outlets. Using it with an incorrect voltage may cause damage and void the warranty.
- Keep the cord away from hot surfaces.
- Do not use the appliance for any purpose other than its intended use as described in this manual.



Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

