

Overview

The CARORI 9-in-1 Electric Pressure Cooker is a multifunctional kitchen appliance designed to perform various cooking tasks. It features a 1000W heating element, an 8-quart capacity, and an IMD touchscreen control panel.



Features

Multifunctional Cooking

This unit combines nine cooking functions into one appliance:

- Pressure Cook

- Steam
- Slow Cook
- Sauté
- Warm
- Sterilize
- Rice Cook

It is designed to replace multiple separate kitchen appliances.

Control Panel and Display

The appliance is operated via an IMD (In-Mold Decoration) touchscreen panel. The interface includes 12 preset cooking programs for different food types such as rice, meat, and desserts.

Capacity and Power

- **Capacity:** 8 Quarts. Suitable for households of 6-10 people or for batch cooking. The pot can hold up to 32 cups of rice.
- **Wattage:** 1000 watts for quick heat-up and faster cooking times.
- **Voltage:** 120 Volts. For use with standard US outlets.

Key Components and Accessories

The following items are included with the pressure cooker:

- Main cooker unit with stainless steel exterior
- Ceramic-coated, non-stick inner pot (BPA and PFAS free)
- Steam rack
- Measuring cup
- Rice spoon
- Condensation collector
- Recipe book
- User manual
- Power cord

9 Cookers in 1

Replace 9 kitchen appliances in one pressure cooker



Safety Features

The appliance incorporates over 16 safety mechanisms, including:

- Steam vent control
- Overheating protection
- Secure lid lock
- Anti-blockage vent
- Pressure regulation system

Over 16 Safety Features



Lid Safety Lock

Prevent opening under pressure



Safety Float

Rise to indicate the cooker is pressurized



Pressure Limiting Valve

Release excess pressure safely



Leak-Proof Sealing Ring

Stop steam leaks, locks in flavor



Overheat Protection

Shut off if temperature is too high

Use Guide

Before First Use

1. Remove all packaging materials and stickers.
2. Wash the inner pot, steam rack, measuring cup, rice spoon, and condensation collector with warm, soapy water. Rinse and dry thoroughly. These parts are dishwasher-safe.
3. Wipe the exterior of the main unit and the inside of the lid with a damp cloth. Do not immerse the main unit in water.

Basic Operation

1. **Place the Inner Pot:** Insert the clean, dry ceramic inner pot into the cooker base.
2. **Add Ingredients:** Place food and any required liquid into the inner pot. Do not exceed the maximum fill lines indicated inside the pot.
3. **Close the Lid:** Align the lid with the base and rotate it clockwise until it locks into place. Ensure the steam release valve is in the sealing position.
4. **Connect to Power:** Plug the power cord into the cooker and then into a standard 120V wall outlet.
5. **Select a Program:** Press the power button to turn on the display. Touch the icon for your desired cooking program (e.g., Rice, Meat/Stew, Steam).
6. **Adjust Settings (Optional):** Use the "+" and "-" buttons to adjust cooking time or pressure level if the program allows.
7. **Start Cooking:** Press the "Start" button. The display will show the cooking progress. The cooker will beep when the cycle is complete.

8. **Release Pressure:** After cooking, allow pressure to release naturally or use the quick-release method by carefully turning the steam release valve to the venting position, keeping hands and face away from steam.
9. **Open the Lid:** Once all pressure is released and the float valve has dropped, unlock and open the lid by rotating it counterclockwise.

Upgrade to 8 Qt Capacity

Hold more food than 6qt, perfect for big meals and families of 8-10

The image shows two panels comparing the capacity of the cooker. The left panel, titled '6 Qt Capacity', shows a cooked chicken and vegetables in a pot. Below it, a small cup icon is followed by 'X24 Approximately', and then '24 cups of cooked rice' and '12 cups of uncooked rice'. The right panel, titled 'NEW 8 Qt Capacity', shows a larger cooked chicken and vegetables in a pot. Below it, a small cup icon is followed by 'X32 Approximately', and then '32 cups of cooked rice' and '16 cups of uncooked rice'. A red arrow points from the 6 Qt panel to the 8 Qt panel. At the bottom of the image, the word 'CARORI' is repeated five times.

Capacity	Approximate Multiplier	Cups of Cooked Rice	Cups of Uncooked Rice
6 Qt	X24	24	12
8 Qt (NEW)	X32	32	16

Using the Delay Start Function

You can program the cooker to begin cooking at a later time, up to 24 hours in advance.

1. Add ingredients to the inner pot and close the lid.
2. Select your desired cooking program.
3. Press the "Delay Start" or "Timer" button.
4. Use the "+" and "-" buttons to set the number of hours until you want cooking to begin.
5. Press "Start". The display will count down until the cooking cycle begins automatically.

Note: Do not use the delay start function for perishable ingredients that will be left at room temperature for an extended period.

Keep Warm Function

After a cooking cycle finishes, the appliance will automatically switch to the "Keep Warm" mode to maintain food temperature. This function can typically be turned off manually via the control panel if not desired.

Sauté Function

Use this function to brown meats or sauté vegetables before pressure cooking.

1. Place the inner pot in the cooker.
2. Press the "Sauté" button. The display will indicate the temperature setting.
3. Add oil or butter, then your ingredients.
4. Stir as needed. Press "Cancel" when finished browning.
5. You can then add remaining ingredients and liquid to proceed with a pressure cooking program.

Cleaning and Maintenance

After Each Use

1. Unplug the appliance and allow it to cool completely.
2. Remove the inner pot and accessories. These are dishwasher-safe for easy cleaning.
3. Wipe the interior of the cooker base, the lid (especially the silicone sealing ring and float valve), and the exterior with a soft, damp cloth. Dry all parts.
4. Empty and clean the condensation collector.



Important: Never immerse the main cooker base, lid, or power cord in water or any other liquid. Do not use abrasive cleaners or scouring pads.

Descaling

Mineral deposits from water may build up over time. To descale:

1. Mix 2 cups of white vinegar with 2 cups of water in the inner pot.
2. Place the pot in the cooker, close the lid (but do not lock it), and select the "Steam" function for 5 minutes.
3. Let the solution sit for 15 minutes after the cycle, then discard it.
4. Rinse the inner pot thoroughly and wipe the interior of the cooker.

Specifications

- **Brand:** CARORI
- **Model Number:** HPC-812-SUSN
- **Capacity:** 8 Quarts
- **Material (Exterior):** Stainless Steel, Metallic Finish
- **Material (Inner Pot):** Ceramic-coated, Non-stick
- **Product Dimensions:** 12.83"D x 12.83"W x 14.49"H
- **Special Features:** Dishwasher Safe parts, IMD Touchscreen, Keep Warm Setting, Locking Lid, Programmable
- **Wattage:** 1000 watts
- **Control Method:** Touch
- **Voltage:** 120 Volts
- **Included Components:** 1*pressure cooker, 1*ceramic non-stick pot, 1*condensation cup, 1*steaming rack, 1*measuring cup, 1*rice spoon, 1*recipe book, 1*user's manual, 1*power cord.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.