


Features

Package contents

- 17 / 21 cubic foot upright freezer
- Door handle, screws and hex wrench

Interi

Notes The illustrations shown in this user guide are only for reference. The actual product may differ slightly.



1 Air flow outlet

2 Wire shelf


3 Air flow inlet

4 Wire drawer

5 Door tray

6 Leveling feet (2 - bottom front) Wheels (2 - Bottom back)

Touch pad controls



Setting up your freezer

Before using your freezer

- Remove the exterior and interior packing, especially the foam packing between the outside condenser and the cabinet.
- Let the freezer stand upright for approximately two hours before connecting it to power. This reduces the possibility of a malfunction in the cooling system from improper handling during transportation.
- Wash the inside with a damp, warm cloth and a baking soda solution (two tablespoons in a quart of water), then wipe dry with a dry cloth. Do this periodically to keep your freezer looking new.
- For proper operation, it's very important that you level the freezer using the leveling feet. If this is not done, the door may not close or seal properly, causing cooling, frost and moisture problems. Turn the leveling feet clockwise to raise that side of the freezer or counterclockwise to lower that side. The leveling feet are easier to adjust if you have someone push against the top of the freezer to take some weight off.
- When moving your freezer, DO NOT tilt it beyond 45° from upright.

Finding a suitable location

- Place your freezer on a floor that is strong enough to support the freezer when it is fully loaded.
- This freezer is designed to be free standing only, and should not be recessed or built-in.
- Allow 7.9 inches (20 cm) of space between the sides of the freezer and the walls, 3.9 inches (10 cm) between the back of the freezer and the wall, and 11.8 inches (30 cm) between the top of the freezer and the ceiling. This allows for proper air ventilation. Adjust the feet to keep the freezer level.

If you locate the freezer next to a fixed wall, allow sufficient space on the hinge side for the door to swing open.

- Locate the freezer away from direct sunlight and sources of heat, such as a stove, heater or radiator. Direct sunlight may affect the acrylic coating and heat sources may increase electrical consumption. Extremely cold temperatures may also prevent the freezer from performing properly.
- Avoid locating the freezer in moist areas.

Leveling your freezer


- It is very important for the freezer to be level. If the freezer is not leveled during installation, the doors may not close or seal properly, causing cooling, frost or moisture problems.
- To level your freezer, rotate the leveling feet clockwise (to raise) the freezer or counter-clockwise (two lower).

Providing a proper power supply


Check your local power source. This freezer requires a 115V, 60Hz power supply.

Use a receptacle that accepts the grounding prong. The power cord is equipped with a 3-prong (grounding) plug which mates with a standard 3-prong (grounding) wall outlet to minimize the possibility of electric shock hazard from this freezer. We recommend that the freezer be plugged into an electrical circuit serving only this appliance and that the circuit cannot be turned off with a switch or pull-chain

Using a 3-prong plug and outlet



Using a grounding adapter




Installing the door handle

Notes


- The illustrations shown in this user guide are only for reference. The actual product may differ slightly.
- The screws and wrench are in the plastic bag.

1. Unplug the freezer.

2. Screw the extended-head screws into the door holes with a Phillips screwdriver. DO NOT overtighten. The screw heads should extend above the surface of the door.



3. Loosen the hex screws on top and bottom of the handle with the hex wrench (provided) so that you can fit the handle over the extended head screws in the door.



4. Place the door handle over the heads of the screws, then tighten the hex screws.

Using your freezer

The storage life of frozen foods varies and the recommended storage time should not be exceeded.

Place frozen food into the freezer as quickly as possible after purchase. If there are instructions on the packet, carefully follow these instructions regarding storage times.

Pre-packed, commercially frozen food should be stored in accordance with the frozen food manufacturer's instructions for a three star frozen food storage compartment or home freezer.

Shelves are provided for the organization of odd-shaped items.

- 1.Plug in your freezer. Wait for 30 minutes, then open the freezer door to determine if the freezer is working properly.
- 2.Press and hold lock for three seconds, then or on the control panel touch pad to set the temperature inside the freezer. A beep sounds when the MAX or MIN temperatures are reached.

The default temperature is 0° F (-18° C). The temperature range of Freezer mode is 10° F ~ -11° F (-12° C ~ -24° C). The temperature range for Fridge mode is 35° ~ 46° F (2° C ~ 8° C).

Notes

- If the freezer is unplugged or loses power, you must wait three to five minutes before resterting it. The freezer will not start if you attempt to restart it sooner.
- Largr amounts of food lower the cooling efficiency of the freezer.
- If you choose to change the thermostat setting, adjust the thermostat control by one increment at a time. Allow several hours for the temperature to stabilize between adjustments.
- DO NOT put bottled food or drinks in the freezer.

Using the Lock button

To prevent accidental activation, the control panel automatically locks after 30 seconds of inactivity. To use the control panel, you must unlock it first.

Press and hold the **Lock** button on the control panel for three seconds to lock the control panel. The lock icon turns on and the control panel beeps. Press again for another three seconds to unlock it. The lock icon turns off and the panel beeps.

Switching between Freezer and Refrigerator modes

This freezer has an advanced design feature that lets you change it from a freezer to a refrigerator. You can only use the control panel to switch modes.

The Freezer / Fridge light on the control panel indicates the current mode.

- 1.Press and hold **Lock** for three seconds to unlock the control panel.
- 2.Press and hold the **Freezer / Fridge** button for three seconds to change modes. The panel beeps and the indicator changes to the new mode.

Quick Freezing foods


The quick freezer mode lowers the temperature below the normal operating temperature to quickly freeze foods. You can only use the control panel to quick freeze foods.

1. Press and hold **Lock** for three seconds to unlock the control panel.
2. Press the **Quick Freeze** button to enter quick freezer mode. The blue snowflake turns on.

The quick freeze mode turns off after three hours, if the temperature falls below -13° F (-25° C). If the temperature does not fall below -13° F (-25° C), the quick freeze mode turns off after 24 hours. You can press the button a second time to exit quick freeze mode.

Switching between Fahrenheit and Celsius

Using the Control Panel

1. Press and hold **Lock** for three seconds to unlock the control panel.
2. Press and hold  for three seconds to switch settings.

Maintaining your freezer

Your freezer is designed for year-round use with only minimal cleaning and maintenance. We recommend that you do the following every time you defrost it to keep your freezer running odor free and efficiently:

Caution To prevent damage to the finish, DO NOT use gasoline, benzene, thinner or other solvents, and DO NOT use abrasive cleaners.

1. Unplug your freezer from the wall outlet.
2. Remove all food.
3. Wash the shelves with a mild detergent solution.
4. Wash the inside with a damp warm cloth soaked in a solution of one quart of lukewarm water to two tablespoons of baking soda solution.
5. Dry the interior and exterior with a soft cloth.
6. Be sure to keep the door gasket (seal) clean to keep the unit running efficiently.

Storing your freezer

1. Unplug your freezer from the wall outlet.
2. Remove all food.
3. Clean the freezer.
4. Leave the door open slightly to avoid possible formation of condensation, mold or odor.

Caution Use extreme caution with children. The unit should not be accessible to child's play.

Moving your freezer

1. Unplug your freezer from the wall outlet.
2. Remove all food.
3. Securely tape down all loose items inside your freezer.
4. Tape the door shut.

Be sure the freezer does not tilt more than 45° from the upright position during transportation.

Tips on saving energy

- Locate your freezer in the coolest area of the room, away from heat producing appliances or heating ducts and out of the direct sunlight.
- Let hot foods cool to room temperature before placing them in the freezer. Overloading the freezer forces the compressor to run longer. Foods that freeze too slowly may lose quality or spoil.
- Wrap foods properly and wipe containers dry before placing them in the freezer. This cuts down on frost build-up inside the freezer.
- The freezer storage shelves should not be lined with aluminum foil, wax paper or paper toweling. Liners interfere with cold air circulation, making the freezer less efficient.
- Organize and label food to reduce door openings and extended searches. Remove as many items as needed at one time, and close the door as soon as possible.

Understanding Alerts

High Temp Alert

The freezer is having trouble maintaining a cold temperature. You will get this alert if:

- FREEZER MODE: The inside temperature is over 18° F (-8° C) for 36 hours.
- FRIDGE MODE: If the inside temperature is over 59° F (15° C) for 36 hours.

The LED on control panel turns on and a beep sounds. If the temperature returns to a normal range, the alert turns off. You can also press any button to turn it off. Here are some possible causes:

- The room is too warm. For example, the freezer is in a garage in the summer next to a car with a hot engine.
- The ventilation openings are blocked or dusty.

- There is too much frost build up.
- There are door seal gaps.

Temp Out of Range Alert


The freezer is having trouble maintaining its temperature. You will get this alert if internal temperature is at least 44.6° F (7° C) different from the temperature you set, 42 hours after you shut the door. If the temperature returns to a normal range, the alert turns off. You can also press any button to turn it off. Here are some possible causes:

- The room is too warm or cold. Adjust the room's temperature.
- The ventilation openings are blocked or dusty.
- There is too much frost build up.
- There are door seal gaps.

Door Open Alert

If the door is open for more than five minutes, the door open alert is activated a buzzer sounds intermittently. Close the door to turn off the alert and check to make sure that nothing is blocking the door, preventing it from closing. Also, check to make sure that the freezer is level. An unlevel freezer may prevent the door from closing properly.

How do I reset my freezer to factory defaults?

- 1.Press and hold **Lock** for three seconds to unlock the control panel.
- 2.Press the **Lock** and  buttons at the same time for three seconds to reset the freezer to factory defaults. The panel beeps and all of the indicators turn on for three seconds. If the compressor is running, it pauses for five minutes, then restarts.

Troubleshooting

Fault indication

If a fault is detected, the display shows one of the following codes. If a fault is indicated, call for service:

Fault code	E2	E5	E7
Description	Temperature sensor fault	Defrost sensor fault	Ambient Temperature sensor fault



General

Problem	Possible cause	Possible solution
E2 appears on the display	Temperature sensor failure.	Call for service.
E5 appears on the display	Defrost sensor failure.	Call for service.
E7 appears on the display	Ambient temperature sensor failure.	Call for service.
High Temp and Door Open alerts		See “Understanding Alerts” on page 16.
The freezer does not operate	The freezer is unplugged.	Make sure that the freezer is plugged in and that the plug is pushed completely into the outlet.
	The fuse on the circuit is blown or the circuit breaker is tripped.	Check the house fuse / circuit breaker box and replace the fuse or reset the circuit breaker.
	Power failure.	If a power failure occurs, the freezer turns off. Wait until the power is restored.
The freezer door does not close completely	Food packages are interfering with the door.	Move the food packages or remove some food.
	The door gaskets are dirty.	Clean the door gaskets.
	The freezer may not be level.	Level the freezer.



Food in the freezer is not cold	The door has been opened too often or was not closed properly.	Make sure that the door is closed properly.
	You have just added a large amount of food to the freezer.	Allow time for the new food to cool, then check again.
	The door is not closed completely.	Check the door gasket and food distribution and make sure that the door closes completely.
	The freezer has recently been disconnected for a period of time.	Allow time for the freezer to cool before adding food. Four hours are required for the freezer to cool down completely.
	The thermostat is set too warm.	Set the thermostat to a colder setting.
The freezer makes unusual noises or vibrations	The freezer may not be level on the floor.	Level the freezer with the leveling feet.
	The body of the freezer is touching a wall.	Move the freezer out from the wall.
	Metal parts undergo expansion and contraction.	This is normal.
	Refrigerant is circulating throughout the system.	This is normal.

Moisture is building up in the interior of the freezer	The door has been opened too often or was not closed properly.	Make sure that the door is closed properly.
	The freezer is in a location that is very humid.	Move the freezer to a dryer location.
	The weather is hot and humid.	This is normal.
The freezer door does not close completely	Food packages are interfering with the door.	Move the food packages or remove some food.
	The door gaskets are dirty.	Clean the door gaskets.
	The freezer is not level.	Level the freezer with the leveling feet.
The compressor turns on and off frequently.	The room temperature is hotter than normal.	This is normal.
	You have just added a large amount of food to the freezer.	Allow time for the new food to cool, then check again.
	The door is not closed completely or was opened too often.	Check the door gasket and food distribution and make sure that the door closes completely.
	The freezer has recently been	



	disconnected for a period of time.	Allow time for the freezer to cool before adding food. Four hours are required for the freezer to cool down completely.
	The thermostat was not set correctly.	Set the thermostat to the correct setting.

Control Panel

Problem	Possible cause	Possible solution
The control panel is unresponsive	The control panel is locked.	Press and hold the Lock button for three seconds to unlock the control panel.
Door open alert	The door is open.	Close the door. Make sure that nothing is blocking the door. Make sure that the freezer is level.
Temperature is out of range	Warm foods may have recently been added to the freezer.	Wait for the foods to cool.
	The temperature is set too high or too low.	Adjust the temperature.
	The room that the freezer is located in is too warm.	Wait for the room temperature to drop.

Specifications

Dimension(WxDxH)	17 cu.ft. - 32.8 x 28.9 x 65 in. (83.2 x 73.5 x 165 cm) 21 cu.ft. - 32.8 x 28.9 x 76.8 in. (83.2 x 73.5 x 195 cm)
Weight	17 cu.ft. - 179.7 lbs. (81.5 kg) 21 cu.ft. - 200.6 lbs. (91 kg)
Power requirements	115 V ~ 60 Hz
Power cord length	65 in. (165 cm)

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.