


## Getting to Know Your TV


### FRONT PANEL













#### Remote Sensor and Power Indicator

When using the remote, aim it directly at this sensor. The power indicator flashes on when the TV turns on, then goes out after several seconds. To keep the power indicator on, see [Turning the Power Indicator On or Off](#) on page 32.

### REAR PANEL




**Note:** The image shown here is for illustrative purposes only and may be subject to change. The actual number of ports and their locations may vary, depending on the model.

-  **HDMI**  
Connect an HDMI device
-  **Composite**  
Connect a composite
-  **Audio Out**  
Connect to an RCA device, such as sound bar
-  **Coaxial**  
Connect to a coaxial cable from cable, satellite, or antenna
-  **USB**  
Connect a USB thumb drive to play photo, music, or video
-  **Optical Audio Out**  
Connect to an optical/SPDIF audio device, such as home audio receiver
-  **Ethernet**  
Connect an Ethernet cable to modem/ router
-  **Power**  
Press to turn on the TV. Press and hold to turn the TV off
-  **Volume**  
Press to increase or decrease the TV volume level
-  **Input**  
Press to access the input menu

### Connecting a device — AUDIO & VIDEO CABLE TYPES

Your TV can be used to display output from most devices :


1. Verify that your device has a video port that matches an available port on the TV (HDMI, Composite, etc .)
2. Connect the appropriate cable (not included) to the TV and the device .
3. Turn the TV and your device on .
4. Set the TV's input to match the connection you used (HDMI-1, HDMI-2, etc.)



### Connecting a device — AUDIO CABLE TYPES

Your TV can be output sound to an audio device, such as a receiver or sound bar:

1. Verify that your device has an audio port that matches an available port on the TV (optical, RCA, etc)
2. Connect the appropriate cable (not included) to the TV and the device .
3. Turn the TV and your device on



### WALL-MOUNTING THE TV

First you will need a wall mount. Consult the provided table below to find the appropriate mount for your TV .

Be sure the mount you choose is capable of supporting the weight of the TV .


#### To install your TV on a wall:

1. Disconnect any cables connected to your TV .

2. Place the TV face-down on a clean, flat, stable surface. Be sure the surface is clear of debris that can scratch or damage the TV .
3. If attached, remove the stands by loosening and removing the screws .
4. Attach your TV and wall mount to the wall by carefully following the instructions that came with your mount . Use only with a UL-listed wall mount bracket rated for the weight/ load of your TV


NOTE : Installing a TV on a wall requires lifting . To prevent injury or damage to the TV, ask someone to help you

WARNING: Do not use the screws that are included inside the wall mount holes to mount TV



## USING THE REMOTE

Note that specific buttons may vary depending on your model.



## Replacing the Batteries

1. Find the notch on the back of the remote . Insert a coin and pry open the back cover
- 2 . Insert two batteries into the remote control . Make sure that the (+) and (-) symbols on the batteries match the (+) and (-) symbols inside the battery compartment .
3. Replace the battery cover

In many places batteries cannot be thrown away or discarded with household waste. Please ensure you properly dispose of your batteries consistent with the laws and/or regulations where you live.

**WARNING:** Keep the remote control batteries away from children . It may cause choking and/or lead to a fire or chemical burn if mishandled. Do not dispose of batteries in fire. Replace only with batteries of the correct type

**NOTE :** When needed, VIZIO recommends replacing the batteries that came with this remote with two, new Duracell 'AAA' alkaline batteries


## Completing The First-Time Setup

**Before you begin the first-time setup:**


- Your TV should be installed and the power cord should be connected to an electrical outlet .
- If you have a wireless network, have the network password ready .

- If you are connecting to your network with an Ethernet cable, connect it to the Ethernet port on the TV .


The first time you turn on the TV, the on-screen instructions will guide you through each of the steps necessary to get your TV ready for use:



1 . Choose your language




2 . Choose home use



3 . Choose your country



4 . Choose your Wi-Fi network and enter the password




5 . Name your TV





## 6 . Scan for channels



## 7 . Accept the Terms & Conditions and register your device

# Using the On-Screen Menu

## NAVIGATING THE ON-SCREEN MENU

To open the on-screen menu:


1. Press the MENU button on the remote .
2. Use the Arrow buttons to highlight a menu option, and press the OK button to select that option

## CHANGING THE INPUT SOURCE

External devices, such as DVD players, Blu-ray Players, and video game consoles, can be connected to your TV . To use one of these devices with your TV, you must first change the input source using the Input menu.

To change the input sources:

1. Press the INPUT button on the remote . The input menu is displayed
2. Use the Arrow buttons or the INPUT button on the remote to highlight the input you wish to view . The corresponding inputs are named on the back of your TV .
3. Press OK or release the INPUT button . The selected input is displayed



**Input Name**

The underlined input on the left is the current input selected . Inputs may vary by TV

### CHANGING THE SCREEN ASPECT RATIO


To change the screen aspect ratio:

1. Press the **Wide** button on the remote.
2. Use the **Arrow** buttons to highlight the aspect ratio you wish to view and press **OK**

Your TV can display images in different modes: Normal, Stretch, Wide, Zoom, and Panoramic .

- **Normal (default)**— No change to aspect ratio .
- **Stretch\***—When the 16:9 signal is a 4:3 image with black bars left and right, stretches to fill the screen.
- **Wide** – Stretches a 4:3 aspect ratio to fill 16:9 screen. If a 16:9 image, adds black bars to top and bottom .
- **Zoom** – Expands image both horizontally and vertically by 14% .
- **Panoramic\***—Stretches a 4:3 image to fill 16:9 screen with an algorithm so the center doesn't look stretched

Some programs have black bars on the top or sides of the screen so that the picture keeps its original shape . Examples include widescreen movies and older TV programs



## ADJUSTING THE PICTURE SETTINGS

Your TV can be adjusted to suit your preferences and viewing conditions

To adjust the picture settings:

### Menu > Picture > Picture Mode


1. Use the **Arrow** buttons on the remote to highlight **Picture Mode**, then use the **Left/Right Arrow** buttons to change the picture mode:

- **Standard** — Sets the picture settings to the default settings .
- **Calibrated** — Sets the picture settings to values ideal for watching TV in a brightly-lit room .
- **Calibrated Dark** — Sets the picture settings to values ideal for watching TV in a dark room .
- **Vivid** — Sets the picture settings to values that produce a brighter, more vivid picture .
- **Game** — Reduces throughput delays and optimizes the picture settings for displaying game console output .
- **Computer** — Optimizes the picture settings for displaying computer output

2. To manually change each of the picture settings, use the **Up/Down Arrow** buttons on the remote to highlight that picture setting, then use the **Left/Right Arrow** buttons to adjust the setting:

- **Backlight** — Adjusts the LED brightness to affect the overall brilliance of the picture . Backlight cannot be adjusted when starting from some picture modes .

- **Brightness**—Adjusts the black level of the picture . When this setting is too low, the picture may be too dark to distinguish details . When this setting is too high, the picture may appear faded or washed out .
- **Contrast**—Adjusts the white level of the picture . When this setting is too low, the picture may appear dark . When this setting is too high, the picture may appear faded or washed out . If the setting is too high or too low, detail may be difficult to distinguish in dark or bright areas of the picture .
- **Color**—Adjusts the intensity of the picture colors .
- **Tint**—Adjusts the hue of the picture . This setting is useful in adjusting the flesh tones in the picture. If flesh appears too orange, reduce the level of color before adjusting tint .
- **Sharpness**—Adjusts the edge sharpness of picture elements . It can be used to sharpen non-HD (high definition) content; however, it will not produce detail that does not otherwise exist



### Adjusting More Picture Settings


To adjust more picture settings:

**Menu > Picture > More Picture**

Use the **Arrow** buttons to highlight the setting you wish to adjust, then press the **Left/ Right Arrow** buttons to change the setting:

- **Color Temperature**—Change the white balance of the picture . Refer to the section on Adjusting the Color Temperature on page 17.
- **Black Detail**—Adjusts the average brightness of the picture to compensate for large areas of brightness .

- **Backlight Control**—When ON, it will improve the contrast ratio of the picture by adjusting backlight zones. Specific adjustments are based on content .
- **Reduce Noise:** – Reduce Signal Noise: Lessens artifacts in the image caused by the digitizing of image motion content . – Reduce Block Noise: Reduces pixelation and distortion for mpeg files.
- **Game Low Latency**—Reduces video delay (lag) when gaming .
- **Film Mode**—Optimizes the picture for watching films. Select On or Off .
- **Gamma**—Set the shape of the Gamma curve . Use lower Gamma values for bright room conditions, and higher values when it's dark



### Adjusting the Color Temperature


Adjusting the color temperature changes the white balance of the picture .

To adjust the color temperature:

#### Menu > Picture > More Picture > Color Temperature

Use the **Arrow** buttons on the remote to highlight a color temperature preset and then press **OK** .

- **Normal**—Optimized for television viewing .
- **Cool**—Produces a blue-hued picture .
- **Computer**—Optimizes the picture for use as a PC monitor .



### Adjusting the Picture Mode Edit Settings

Picture Mode Edit Settings allow you to make precise adjustments to the picture .


To adjust the Picture Mode Edit settings:

#### Menu > Picture > Picture Mode Edit

Use the **Arrow** buttons to highlight the setting you wish to adjust, then press **OK** to change the setting:

- **Save Picture Mode**— Save a custom picture mode .
- **Lock Picture Mode**— Prevent changes to custom picture modes .
- **Reset Picture Mode**— Reset the picture mode settings to factory default values .

Only available on customized preset modes .



### Saving a Custom Picture Mode

Custom picture modes allow you to save a group of custom settings for various viewing conditions and video sources .

To save a custom picture mode:

**Menu > Picture > Picture Mode Edit > Save Picture Mode > Enter a Name > Save**

- Changes made while on any preset picture mode will add an asterisk on the top right corner of the preset mode .
- The custom picture mode is not automatically saved



## Locking/Unlocking a Custom Picture Mode

Custom picture modes can be locked/unlocked with a unique PIN to prevent accidental changes to their settings . If not previously set, you can set up your system PIN code here .

To lock all custom picture modes:

**Menu > Picture > Picture Mode Edit > Lock Picture Mode > Enter Your PIN > Save**


To unlock all custom picture modes:

**Menu > Picture > Picture Mode Edit > Lock Picture Mode > Off > Enter Your PIN**

## Deleting a Custom Picture Mode

Custom picture modes that are no longer needed can be deleted .

To delete a custom picture mode: **Menu > Picture > Picture Mode Edit > Delete Picture Mode > Delete**




## Resetting a Picture Mode

A preset picture mode that has been edited can be restored to the factory default settings

To reset a customized preset picture mode:

**Menu > Picture > Picture Mode Edit > Reset Picture Mode > Reset**



## Adjusting the Color Tuner Settings

The Color Tuner settings allow you to adjust the color management system, 2 point white balance, 11 point white balance, turn color channels off for testing, and display SMPTE, flat, ramp, and uniformity analyzer test patterns.

To access the color tuner table: **Menu > Picture > Color Calibration > Color Tuner**

**To turn color channels off and on:**

1. Use the Arrow buttons on the remote to highlight Red, Green, or Blue .

2. Press the OK button to turn the color channel off or on. An X appears over a color channel that has been turned off.
3. Only two color channels can be turned off at the same time.

#### **To adjust the color management system/2 point white balance settings:**

1. Use the **Arrow** buttons on the remote to highlight the Hue, Saturation, Brightness, Offset, or Gain of the color you wish to adjust. Press the OK button .
2. Use the **Left/Right Arrow** buttons to adjust the value. When you are finished press the OK button to save the setting .

#### **To adjust the 11 Point White Balance settings:**

1. From the Color Tuner table, use the **Arrow** buttons to highlight the top bar and then press the **Left/Right Arrow** buttons until the 11 POINT WHITE BALANCE menu is displayed
- 2 . Use the **Arrow** buttons on the remote to highlight the **Gain** and **Color values** you wish to adjust . Press the **OK** button and use the **Left/Right Arrow** buttons to adjust the value. When you are finished, press the **OK** button to save the setting

#### **To show or hide the SMPTE Test Pattern:**

##### **Menu > Picture > Color Calibration > Color Tuner > SMPTE Test Pattern**

- 1 . Use the **Arrow** buttons on the remote to highlight **Off** . Use the **Left/Right Arrow** buttons to select **On** to show the SMPTE Pattern.

—or—

- 2 . To hide the SSMPTE Test Pattern,, use the **Left/Right Arrow** buttons to select **Off**

#### **To show or hide the Flat Test Pattern:**

##### **Menu > Picture > Color Calibration > Color Tuner > Flat Test Pattern**

1. Use the **Arrow** buttons on the remote to highlight **Off**. Use the **Left/Right Arrow** buttons to select the percentage brightness for the flat test pattern. Selecting a percentage immediately shows the flat pattern at that brightness.

—or—

2. To disable the Flat Test Pattern, use the **Left/Right Arrow** buttons to select **Off**.

#### **To show or hide the Ramp Test Pattern:**

##### **Menu > Picture > Color Calibration > Color Tuner > Ramp Test Pattern**

1. Use the **Arrow** buttons on the remote to highlight **Off**. Use the **Left/Right Arrow** buttons to select the color for the ramp test pattern. Selecting a color immediately shows that color ramp.

—or—

2. To hide the Ramp Test Pattern, use the **Left/Right Arrow** buttons to select **Off**.

#### **To show or hide the Uniformity Analyzer Test Pattern:**

**Menu > Picture > Color Calibration > Color Tuner > Uniformity Analyzer Test Pattern**

1. Use the **Arrow** buttons on the remote to highlight **Off**. Use the **Left/Right Arrow** buttons to select **On** to show the Uniformity Analyzer Test Pattern.

—or—

2. To hide the Uniformity Analyzer Test Pattern, use the **Left/Right Arrow** buttons to select **Off**.

### **ADJUSTING THE AUDIO SETTINGS**

To adjust the audio settings: **Menu > Audio > OK**

Use the **Arrow** buttons to highlight the setting you wish to adjust, then press **Left/Right Arrow** buttons to change the setting:

- **Speakers**— Turn the built-in speakers On or Off.
  - **Volume Control Display**— Turn the on-screen volume display slider On or Off.
  - **Surround Sound**— Surround sound uses DTS TruSurround™ to deliver an immersive surround sound experience from the TV's internal speakers . TruSurround completes the entertainment experience by providing deep, rich bass, crisp details, and clear, intelligible dialog. Select On or Off.
  - **Volume Leveling**— Volume leveling uses DTS TruVolume™ to maintain consistent volume levels during transitions between program content, AV formats, and input sources. Select On or Off. In a few cases, volume leveling may artificially suppress volume increases, making it difficult to hear dialog or flattening sudden noises. If this occurs, turn volume leveling off.
  - **Balance**— Adjusts the loudness of the audio output from the left and right speaker
  - **Lip Sync**— Adjusts the synchronization between the display image and the accompanying audio track .
  - **Digital Audio Out**— Changes the type of processing for digital audio out and HDMI ARC output when connected to a home theater audio system . Select Auto, PCM, Dolby D or Bitstream .
- To hear talk back when **Talk Back** function is enabled, digital audio out must be set to PCM .
- **Analog Audio Out**— Sets the volume control properties for the RCA connector when connected to a home theater audio system . Select Variable if you are controlling the volume with the TV's volume controls, or select Fixed if an external audio device (sound bar or AV receiver) will control the volume

### **ADJUSTING THE NETWORK SETTINGS**

Your TV is Internet-ready, featuring both an Ethernet port and built-in high-speed wireless internet .

### **Connecting to a Wireless Network**

To connect to a wireless network whose network name (SSID) is being broadcast:

**Menu > Network > Choose your network > Enter in the password > Connect**

If you do not see your wireless network displayed, click on:

**More Access Points > Highlight your wireless network > Enter in the password > Connect**

### **Changing the Manual Setup Settings**

Advanced users can fine-tune the network settings using the Manual Setup feature. The security settings on your router may require you to enter the TV's MAC address .

**To change advanced network settings:**

**Menu > Network > Manual Setup > DHCP > Off**

1. Use the **Arrow** and **OK** buttons to adjust each setting:

- **IP Address** — The IP address assigned to the TV .
- **Subnet Mask** — The subnet Exit 2D .
- **Default Gateway** — Your network's default gateway address
- **Pref. DNS Server** — Your preferred domain name server address .
- **Alt. DNS Server** — Your alternate domain name server address .

2. Use the **Arrow** buttons on the remote to highlight Save and press **OK**

**To find the TV's MAC address:**

**Menu > Network > Manual Setup**

You can find your TV's MAC address at the bottom of the list. The MAC addresses for the connections in use are displayed:

**RJ45 MAC** — The Ethernet or RJ45 MAC address may be needed to set up your network when you have connected the TV to your network when you have connected the TV to your network with an Ethernet (Cat 5) cable .

**Wireless MAC** — The Wireless (Wi-Fi) MAC address may be needed to connect your TV to your network with Wi-Fi

### **Connecting to a Hidden Network**

To connect to a wireless network whose network name (SSID) is not being broadcast:

**Menu > Network > Hidden Network > Enter the Access Point Name > Connect > Enter in the password**

### **Testing Your Network Connection**

To test your network connection:

### **Network Menu > Test Connection**

## **SETTING TIMERS**

When activated, the TV's timer will turn the TV off after a set period of time.

### **To setup a sleep timer: Menu > Timers**

Use the **Left/Right Arrow** buttons on the remote to highlight the period of time after which you want the TV to go to sleep: 30, 60, 90, 120, or 180 minutes . If you don't want the sleep timer to activate, change the setting to Off.

### **Setting the Auto Power Off Feature**

To help save energy, your TV is set by default to turn off after 10 minutes without a video or audio signal . This feature can be deactivated .

### **To set the Auto Power Off feature: Menu > Timers > Auto Power Off > Off**

### **Using the Blank Screen Feature**

To help save LED life, your TV screen can turn on or off while audio is streaming.

### **To use the Blank Screen feature: Menu > Timers > Blank Screen**

To **exit** Blank Screen, press any key (except the volume and mute keys)

## **SETTING UP CHANNELS**

### **You can use the TV's Channels menu to:**

- Find channels
- Select channels to skip
- Select analog audio mode
- Select the language for digital audio
- Set parental controls

### **Scanning for Channels**

The TV may need to scan for channels before it can display programs and their associated information . A channel scan is required for free over-the-air channels (using an antenna) and cable channels from an out-of-the-wall connection (without a cable box). Moving the TV to an area with different channels requires the TV to scan for channels again .

### **To perform an Auto Channel Scan: Menu > Channels > Find Channels**

Wait until the channel scan is 100% complete . Highlight **Done** and press **OK** .

- If the channel scan is canceled, the channels that were already discovered are retained .  
A new channel scan will clear all channels

## Skipping Channels

After a channel scan is completed, you may find that some channels are too weak to watch comfortably . There may also be some channels you do not want to view . You can remove these channels from the TV's memory with the Skip Channel feature

### To remove a channel:

1. From the CHANNELS menu, highlight **Skip Channel**, and press **OK** . The SKIP CHANNEL menu is displayed .
2. For each channel you wish to remove, use the **Up/Down Arrow** buttons on the remote to highlight the channel and press **OK** . A appears to the right of each channel you select

## USING PARENTAL CONTROLS

The TV's parental controls allow you to prevent the TV from displaying certain channels or programs unless a PIN is used .

### Accessing the Parental Controls Menu

To access the PARENTAL CONTROLS menu you must first set up a system PIN:

#### Menu > Channels > Parental Controls > Enter in PIN

The **Parental Controls** menu only appears when:

- You are using the tuner to receive your TV signals, such as when you are using an antenna for Over-the-Air signals or when connected to cable TV directly from the wall (no cable box) .
- You have a device connected using a composite video cable or a coaxial cable, such as a VCR, satellite or cable box, or DVR

### Enabling or Disabling Program Ratings

To manage program content according to its rating, you must first enable the Program Rating feature .

#### To enable or disable the Program Rating feature:

#### Menu > Channels > Parental Controls > Locks > ON/OFF

### Locking and Unlocking Channels

When a channel is locked, it cannot be accessed . Locking a channel is a good way to prevent children from viewing inappropriate material .

#### To lock or unlock a channel:

#### Menu > Channels > Parental Controls > Channel Locks

Highlight the channel you want to lock or unlock and press **OK** .

- When a channel is locked, the Lock icon appears locked . The channel is not accessible unless the system PIN is entered .
- When a channel is unlocked, the Lock icon appears unlocked

### **Blocking and Unblocking Content by Rating**

A channel may sometimes broadcast programs that are meant for a variety of audiences (some for children and some for adults) . You might not want to block the channel completely using a channel lock, but you can block certain programs from being viewed .

You can use the TV's Rating Block feature to block content based on its rating .

#### **To block or unblock content by its rating:**

1. From the Parental Controls menu, highlight the content type you want to adjust and press **OK**:

- **USA TV** — USA television program broadcasts .
- **USA Movie** — USA movie broadcasts .
- **Canadian English** — Canadian English television program broadcasts .
- **Canadian French** — Canadian French television program broadcasts

2 . For each rating type you want to block or unblock, use the **Arrow** buttons to highlight the rating type and press **OK** .

- When the rating type is **blocked**, the Lock icon appears locked . Content with this rating and all higher ratings cannot be viewed .
- When the rating type is unblocked, the Lock icon appears unlocked . Content with this rating and all lower ratings can be viewed .
- If you want to block all unrated content, highlight **Block Unrated Shows** and use the **Arrow** buttons on the remote to select **On**

### **SETTING UP CLOSED CAPTIONING**

Your TV can display closed captions for programs that include them . Closed captions display a transcription of a program's dialogue .

#### **To activate or deactivate closed captions:**

**Menu > Closed Captions > Closed Captions > Off/On**

1. Use the **Arrow** buttons on the remote to highlight either Analog or **Digital Closed Captions** .
2. Use the **Left/Right Arrow** buttons on the remote to select the caption channel you wish to display, then press **EXIT** .

### **Changing the Appearance of Digital Closed Captions**

Digital closed captions can be displayed according to your preference . See the diagram on the next page for an explanation of the parts of the closed caption area .

### To change the appearance of digital closed captions:

#### Menu > Closed Captions > Digital Style

1. Use the **Left/Right Arrow** buttons on the remote to select **Custom** . The Digital Style menu appears as shown .

2 . Use the **Up/Down Arrow** buttons on the remote to highlight the setting you wish to change, then use the **Left/Right Arrow** buttons to change the setting:

- **Caption Style** — Choose As Broadcast to keep default settings or Custom to manually change each setting .
- **Text Style** — Change the font used for the closed captioning text .
- **Text Size** — Make the text larger or smaller .
- **Text Color** — Change the color of the text .
- **ext Opacity** — Change the transparency of the text .
- **Text Edges** — Change the effects at the edges of the text, such as raising the edges or adding drop shadows .
- **Text Edges Color** — Change the color of the text edge effects.
- **Background Color** — Change the color of the background directly behind the text .
- **Background Opacity** — Change the transparency of the background directly behind the text .
- **Window Color** — Change the color of the closed captioning box .
- **Window Opacity** — Change the opacity of the closed captioning box

#### Typical choices include:

- **Opaque background, transparent window** — Only a strip of background appears behind the text, expanding as the text appears .This is the typical "As Broadcast" mode .
- **Opaque background and window in the same color** — When text appears, the entire line fills with color at once.

In the example, the closed caption text is green, the background is black, and the window is red

## CHANGING INPUT SETTINGS

### To access input settings menu:

#### Menu > Input Settings

Highlight the input device that you want to view/change and press **OK** .

### Renaming Devices on the Input Menu

You can rename the inputs to make them easier to recognize on the Input menu . For example, if you have a DVD player connected to the component input, you can rename that input to display “DVD Player .” See Changing the Input Source on page 14 .

### To change the name of an input:

#### Menu > Input Settings

#### To use a preset input name:

- Highlight the **Name Input** row and press **OK** .
- Highlight the input name and use the Left/Right **Arrow** buttons on the remote to cycle through preset input names

—or—

#### To enter a custom name:

- Highlight the **Name Input** row and press **OK** .
- Enter your custom label using the on-screen keyboard and press **OK** .

Other settings include the following:

- **Full UHD Color\*** — expanded color display.
- **Picture Size\*** — configure the display size to enlarge or shrink the image to fill the screen
- **Picture Position\*** — move the vertical and horizontal position of the picture in relation to the screen .
- **Hide from Input Source** — hide inputs that are not being used . Hidden inputs will not be displayed in the input list .

\*Only available if there is an input source . Not available for WatchFree . Menu items will be grayed out if not available

## CHANGING THE TV SETTINGS

Using the System menu, you can:

- Check for updates
- View system information
- Change the on-screen menu language
- Set time zone and local settings
- Adjust the CEC settings
- Adjust the power mode settings
- Adjust to preserve aspect ratio or fill the screen
- Name the TV

- Review and maintain the list of paired devices
- Adjust accessibility settings
- Reset the TV settings and setup administrative controls

## Checking for System Updates

**To check for a system update:**

**Menu > System > Check for Updates**

If an update is found, the TV will ask to confirm the update. If no update is found, the screen will note *The TV is up-to-date.*

## Viewing System Information

**To view technical data and status information about your TV and network connection:**

**Menu > System > System Information**

## Changing the On-Screen Menu Language

Your TV can display the on-screen menu in different languages.

**To change the on-screen menu language:**

**Menu > System > Menu Language**

Highlight your preferred language (English, Español, or Français) and press **OK** .

## Setting the Time and Local Settings

To ensure the correct time is displayed when you press the **INFO** button, set the TV's time zone:

**Menu > System > Time & Local > Settings > Time Zone**

**To turn Daylight Saving Time on or off:**

1. Highlight Daylight Saving Time and press **OK** . The Daylight Saving Time menu is displayed .
2. Choose **On** if it is currently Daylight Savings Time, **Off** if it is Standard Time, or **Auto** to have the system automatically detect Daylight Savings Settings .

## Adjusting the CEC Settings

The CEC function on your TV enables you to control devices connected to HDMI (ARC) input with the included remote, without any programming . Using CEC, your VIZIO TV remote can control:

- Power On/Off
- Volume
- Mute

**To enable, disable, or adjust CEC settings:**

Set up your audio device and connect it to the HDMI-1(HDMI Arc) input on the TV. On your audio device, select the HDMI ARC input .

### **Menu > System > CEC**

Select a setting and then press OK .

- **CEC:** To use CEC, you must select Enable .
- **Device Discovery:** To determine if your device is connected and supports CEC, select Device Discovery and then press **OK**

### **Adjusting the Power Mode**

Your TV is set to Eco Mode by default. When the TV is powered off, the Eco Mode setting uses less than 0 .5W of power . Quick Start Mode enables your display to power on faster and also to turn on when powered from another device (such as when you are casting onto the TV)

**To switch between Eco Mode and Quick Start Mode:**

### **Menu > System > Power Mode**

Highlight either Eco Mode or Quick Start Mode and press **OK**

### **Changing the TV Name**

Naming your TV helps differentiate it from other cast devices you may have in your home .

**To edit your TV name:**

### **Menu > System > TV Name > Enter a Name**

### **Manging Mobile Devices**

Your TV can be paired with a mobile device so you can easily control your TV across multiple devices .

**To see a list of paired devices or unpair a device:**

### **Menu > System > Mobile Devices**

Highlight a device name to delete it and press **OK**

### **Accessibility Settings**

VIZIO is committed to providing intuitive, user-friendly products . Your new VIZIO TV offers several accessibility features that can help you with easy navigation.

**To access the Accessibility menu:**

### **Menu > System > Accessibility**

1. **Talk Back**— Enables your TV to speak all settings changes and adjustments using the remote in English .
2. **Speech Rate\*** —Adjusts the rate in which Text-to-Speech is spoken . Select Slow, Normal (Default), or Fast .

3. **Zoom Mode** — Enlarges a section of the screen by approximately 200% .
4. **Video Description** — If included by the broadcaster, provides a narrated description of the action for the content .

**To access the Closed Caption menu:**

**Menu > Closed Captions**

**To access the Video Description menu:**

**Menu > Channels > Digital Audio**

## **USING THE RESET & ADMIN MENU**

You can use the TV's Reset & Admin menu to restore the TV to its factory default settings as well as access other system settings.

**Using the RESET & ADMIN menu, you can:**

- Reset the TV to factory settings
- Force the system to power off and on
- Create a system pin code to lock content and picture settings
- Turn USB power on or off.
- Enable or disable program offers and suggestions
- Enable or disable anonymous debug data for system performance .
- Start or stop the store demo mode

## **Restoring the TV to Factory Default Settings**

All of the on-screen menu settings can be reset to the factory defaults .

**To restore the TV to its factory default settings:**

**Menu > System > Reset & Admin > Reset to Factory Settings**

1. If you set a system PIN code, enter it now .
2. The TV displays, "Select Reset to restore all TV settings to factory defaults ."
3. Highlight **Reset** and press **OK** .
4. Wait for the TV to turn off. The TV will turn back on shortly afterward and the setup process will begin .

## **Performing a Soft Power Cycle**

A soft power cycle forces the TV to turn off then on again.

**Menu > System > Reset & Admin > Soft Power Cycle > YES**

## **Turning the Power Indicator On or Off**

The power indicator on the front of your TV normally does not glow when the TV is on . You can change this setting if you prefer the light to be on .

#### **To turn the Power Indicator Light On or Off:**

**Menu > System > Reset & Admin > Power Indicator > ON/OFF**

#### **Setting a System PIN**

You can set a system pin to lock content and picture modes, as well as prevent accidental system resets. The first time you select System PIN code, you will need to create a PIN .

#### **To create a PIN .**

**Menu > System > Reset & Admin > System PIN Code > Enter Your PIN > Save**

#### **Using the USB Power Feature**

The USB port can be used to charge devices .

The two options for this feature are:

- **Always On** — Power is always available .
- **Off When TV Off** — Power is only available with the TV is on .

#### **About Viewing Data**

Video ACR collects data related to publicly available content displayed on your television/display, such as the identity of your broadcast, cable, or satellite television provider, and the television programs and commercials viewed (including time, date, channel, and whether you view them live or at a later time) . We also collect unique identifiers about this TV, including the IP address. This data is collectively referred to as “Viewing Data .” For more information about Viewing Data and how VIZIO protects its customers’ privacy, please consult our privacy policy at [www.vizio.com/privacy](http://www.vizio.com/privacy) .

When ACR collection is turned on, we may share Viewing Data with authorized data partners including analytics companies, media companies and advertisers . VIZIO and its authorized data partners use Viewing Data to generate summary analysis and reports of how users engage with content on their TVs and other devices . VIZIO Viewing Data is sometimes enhanced with household demographic data and data about digital actions (e .g . digital purchases and other consumer behavior taken by devices associated with the IP Address we collect) . Viewing Data also enables our authorized data partners to deliver advertising relevant to your profile that you might find useful, both on the VIZIO TV/display and other devices sharing your IP Address . Viewing Data is also used to help content publishers, broadcasters or content distribution services create or recommend more relevant entertainment based on summary insights, as well as helps us improve the design of our products, software and services

You can easily turn this feature On or Off in the RESET & ADMIN menu. If you have trouble enabling or disabling Viewing Data, please contact VIZIO Customer Support by going to support.vizio.com and selecting Contact Us.

## USING THE INFO WINDOW

Press the **INFO** button one time to display:

- TV name
- Current input
- Picture mode
- Audio type
- Network name
- Time

## SmartCast HomeSM

### What is SmartCast Home?

SmartCast Home lets you discover, stream, and control your content like never before! Access top apps, like Netflix, Hulu, and Amazon Prime Video, by using the remote to easily browse and launch content directly from the home screen. SmartCast Home makes finding something to watch easy and fun.

### How to Launch SmartCast Home

Begin streaming with SmartCast Home by:

- Press the **V-Logo** button on your remote.

—or—

- Select **SmartCast** from the list of inputs

### What you can do with SmartCast Home

- Stream high quality entertainment.
- Launch top tier apps directly from the home screen.
- Unlock your photos and videos by mirroring your laptop or mobile device onto your TV.
- Rearrange apps on your home screen just the way you like it.
- Works with Google Assistant and other popular voice assistants

### Control your TV with the SmartCast Mobile™ App

Download the VIZIO SmartCast Mobile app and turn your smartphone into a remote to control and configure your TV.

**Get it here, to download:**

### **With SmartCast Mobile, you can:**

- Power on/off devices, play/pause content, and modify advanced settings, all from the palm of your hand .
- Easily enter text onto your TV/display from your mobile device using a full keyboard .
- Browse and discover movies, TV shows, music, live streams, and more, across multiple apps at once .
- Access a quick look at show ratings, synopsis, cast, crew, clips, and other details .

## **WatchFree**

### **What is WatchFree?**

VIZIO WatchFree takes your cord-cutting entertainment experience one step further! With the simple press of a button, enjoy free streaming TV with over 100 live TV channels to choose from – news, movies, sports, comedy, music and more . A built-in on-screen guide makes finding something to watch easier than ever.

**And it's all FREE – no fees, no subscriptions, or logins.**

### **What you can do with WatchFree**

- Stream over 100 live TV channels absolutely free – news, movies, sports, comedy, music and more .
- Navigate through channels, organized by genre, with an intuitive on-screen guide .
- Watch 1000's of free movies from major studios .
- Watch the best of internet TV .
- No logins, subscriptions or transactions fees

### **How to Launch WatchFree**

To launch and begin watching entertainment offered on WatchFree:

- Push the **WatchFree button** or the **INPUT** button on your remote .

-or-

- Simply select the **WatchFree app logo** from the SmartCast Home app row .

## **Playing USB Media**

The USB Media Player allows you to connect a USB flash drive to your TV and play music, video, or photos

### **Preparing Your USB Drive to Play USB Media**

To display USB media, you must first save your videos onto a USB flash drive:

- The USB flash drive must be formatted as FAT32.
- Files on the USB flash drive must end in a supported file extension ( .mp3, .jpg, etc) .
- The player is not designed to play media from external hard drives, MP3 players, cameras, or smartphones .

### **Displaying USB Media**

To display your USB media:

1. Connect your USB flash drive to the USB port on the side of the TV.
2. The TV will recognize the USB . Use the **Arrow** Keys on the remote to select the content you want to play .

—or—

3. Select **USB** from the bottom streaming icons on the SmartCast HomeSM page

### **Removing the USB Drive from the TV**

To safely remove your USB flash drive from the TV:

Turn the TV **off** .

Disconnect your USB flash drive from the USB port on the side of the TV.

### **Playing USB Media: Music**

### **Playing USB Media: Video**

### **Playing USB Media: Photo**

## **Product Registration and Technical Support**

### **Help Topics**

#### **The remote is not responding .**

- Make sure the batteries are properly inserted matching the - and + symbols .
- Replace the batteries with fresh ones .

#### **The TV displays “No Signal .”**

- Press INPUT button on the remote control to select a different input source.
- If you are using cable TV or antenna connected directly to the TV, scan for channels . See Scanning for Channels on page 24.

**There is no power .**

- Ensure the TV is plugged into a working electrical outlet .
- Ensure the power cable is securely attached to the TV .
- Press the Power/Standby button on the remote or on the back of the TV to turn the TV on .

**The power is on, but there is no image on the screen .**

- Ensure all cables are securely attached to the TV .
- Ensure all devices are connected correctly. Devices differ; see your device's user manual for details .
- Adjust Brightness, Contrast, or Backlight . See Adjusting the Picture Settings on page 16 .
- Press the INPUT button on the remote to select a different input source.

**The sound is flat or dialog is not audible.**

- Turn off Volume Leveling. See Adjusting the Audio Settings on page 21.

**Where do I find information on the accessibility features of this product and other VIZIO products?**

Give us a call at 1-877-698-4746 .

**How do I stream apps like Netflix to my VIZIO SmartCast™ TV?**

- Download and open a Chromecast-enabled apps on your mobile device . Then tap the Cast button .

**The colors on the TV don't look right.**

- Adjust the Color and Tint settings in the Picture menu . See Adjusting the Picture Settings on page 16.
- Select a pre-set picture mode . VIZIO recommends selecting Calibrated .
- Check all cables to ensure they are securely attached .

**There is no sound .**

- Press Volume Up on the remote control .
- Press the Mute button on the remote to ensure mute is off.
- Check the audio settings . See Adjusting the Audio Settings on page 21.
- Check the audio connections of external devices (Blu-ray player, game console, cable/ satellite box) that are connected to the TV .
- If you are using an antenna, the signal strength of the channel may be low . Ensure your antenna is connected securely to the TV and move the antenna around the room or close to a window for the best signal .

### **The image quality is not good .**

- For the best image quality, view high-definition programs using digital sources. Connect your devices with HDMI cables .
- If you are using an antenna, the signal strength of the channel may be low . Ensure your antenna is connected securely to the TV and move the antenna around the room or close to a window for the best signal .

### **The picture is distorted .**

- Move the TV away from electrical appliances, cars, and fluorescent lights.
- Ensure all cables are securely attached .

### **The TV image does not cover the entire screen .**

- If you are using TV, AV, or Component with 480i input, go to Menu > System > Aspect Ratio .

### **The TV has pixels (dots) that are always dark .**

- Your HD TV is precision-manufactured using an extremely high level of technology . However, sometimes pixels may not display correctly . These types of occurrences are inherent to this type of product and do not constitute a defective product .

### **The buttons on the remote aren't working.**

- Ensure you are only pressing one button at a time .
- Point the remote directly at the TV when pressing a button .
- Replace the remote batteries with new ones . See Replacing the Batteries on page 12 .

### **I see “noise” or static on the screen .**

- When your TV's digital capabilities exceed a digital broadcast signal, the signal is up-converted (improved) to match your TV's display capabilities . This up-converting can sometimes cause irregularities in the image .
- If you are using an antenna, the signal strength of the channel may be low . Ensure your antenna is connected securely to the TV and move the antenna around the room or close to a window for the best signal .

### **When I change input source, the TV image changes size .**

- The TV remembers the viewing mode on each input source . If the viewing mode on the new input source differs from the one on the input source you switch from, the difference may be noticeable.
- See Changing the Screen Aspect Ratio on page 15 .

### **How do I download the VIZIO SmartCast Mobile™ App?**

- Make sure your phone or tablet is connected to a Wi-Fi network . Open a browser on your phone or tablet .

### **How do I change the Inputs?**

- Press the INPUT button on the back of the TV to cycle through the Inputs .
- Press the INPUT button on the basic remote to cycle through the Inputs .
- Make sure the VIZIO SmartCast Mobile™ app is installed on your phone or tablet . Open the VIZIO SmartCast Mobile app . Tap on the Device list and select your TV . Tap on the Input key and select the Input of your choice

### **How do I connect to my Wi-Fi network?**

- On your TV remote, press the Menu button then go to Network > Select your Wi-Fi name > Enter password .
- Open the VIZIO SmartCast Mobile™ app on your phone or tablet . Tap on the device list and select your Display .
- Tap on the Settings icon > Network > Wireless Access Points . Select your Wi-Fi network from the list, enter the Wi-Fi password, and tap Connect .

### **How do I exit Demo Mode**

- Press and hold the INPUT button on the back of the TV to exit the demo mode .

### **How do I watch Cable/Antenna TV channels?**

- If you subscribe to cable or satellite, simply connect an HDMI cable (not included) to the receiver .
- If you use external antennas to watch local broadcast channels, use a coaxial cable to connect .

### **Some of my Channels are missing .**

- Press the MENU button on your TV remote and select the channels option . Then select Find Channels .
- Open the VIZIO SmartCast Mobile app on your phone or tablet .
- Click on: Control > Your TV/Device Name > Settings Icon > Channels > Find Channels .

### **How do I disable/enable Viewing Data?**

- Press the MENU button on your remote and select the System option . Select Reset & Admin. Then select Viewing Data to turn the feature on or off.
- Open the VIZIO SmartCast Mobile app on your phone or tablet .
- Click on: Control > Your TV/Device Name > Settings Icon > System > Reset & Admin > Viewing Data Slider .

## The television will not turn on using Alexa or Google Assistant .

- Ensure the television is in Quick Start mode .
- Tap on Menu > System > Power Mode > Quick Start

## How do I know I am getting 4K resolution or HDR content such as Dolby Vision?

- As you are watching content on the television, press the INFO button on the remote or VIZIO SmartCast Mobile app . You will see the current resolution being displayed along with the version of video .
- HDR will show as a Dolby Vision icon, HDR10 or HLG

## Specifications

### Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.