

BEFORE OPERATING

Before operating your new microwave oven, make sure you read and understand this operation manual completely. Follow these steps:

1. Plug in the microwave oven. ENJOY YOUR MICROWAVE TOUCH CLEAR will appear.
2. Touch the STOP/CLEAR pad. : will appear.
3. Set clock.

TO SET THE CLOCK

1. Touch TIMER/CLOCK two times. The display shows TO SET CLOCK ENTER TIME.
2. Touch number pads for correct time of day
3. Touch START/+30 SEC. This is a 12 hour clock. If you attempt to enter an incorrect clock time, ERROR will appear in the display. Touch the STOP/ CLEAR pad and re-enter the time.

- If the electrical power supply to your microwave oven should be interrupted, the display will intermittently show ENJOY YOUR MICROWAVE TOUCH CLEAR after the power is reinstated. If this occurs during cooking, the program will be erased. The time of day will also be erased. Simply touch STOP/ CLEAR pad and reset the clock.

Note: The microwave oven can be programmed with the oven door open except for START/+30 SEC. The oven can be programmed while the door is opened, but it must be closed to begin cooking.

STOP/CLEAR

Touch the STOP/CLEAR pad to:

1. Erase if you make a mistake during programming.
2. Cancel timer.
3. Stop the microwave oven temporarily during timed cooking. You can restart the oven by closing the door and touching START/+30 SEC.
4. Return the time of day to the display.
5. Cancel a program during cooking. Touch 2 times for timed cooking.

MICROWAVE OVEN COOKING

TIME COOKING

Your microwave oven can be programmed for 99 minutes 99 seconds (99.99). Always enter the seconds after the minutes, even if they are both zeros.

- Suppose you want to cook for 5 minutes at 100%.

1. Enter cooking time 5 0 0.

2. To cook at 100% power (High), touch START/+30 SEC pad.

TO SET POWER LEVEL

There are eleven preset power levels. Using lower power levels increases the cooking time, which is recommended for foods such as cheese, milk and long slow cooking of meats. Consult a microwave cookbook or recipes for specific recommendations.

- Suppose you want to defrost for 5 minutes at 30%.

1. Enter defrost time 5 0 0.

2. Touch POWER LEVEL pad 8 times.

3. Touch START/+30 SEC pad.

COVERING FOODS:

Some foods work best when covered. Use the cover recommended in the charts for these foods. See charts beginning at the bottom of this page and continuing on the following pages. You may refer to the hints by touching the SETTINGS pad. Recommended covers include:

1. Casserole lid.

2. Plastic wrap: Use plastic wrap recommended for microwave cooking. Cover dish loosely, allowing approximately 1/2 inch to remain uncovered to allow steam to escape. Plastic wrap should not touch food.

3. Wax paper: Cover dish completely, folding excess wrap under dish to secure. If dish is wider than paper, overlap two pieces at least one inch to cover. Be careful when removing any covering to allow steam to escape away from you.

SENSOR POPCORN, REHEAT, COOK

You can cook or reheat many foods and don't need to calculate cooking time or power level. • Suppose you want to cook baked potatoes.

1. Touch COOK pad once.

2. See Menu Label. Select desired food by touching number pad.

Ex: Touch 1 for baked potatoes.

3. Touch START/+30 SEC pad. Note: To heat or cook other foods or foods above or below the quantity allowed on the chart, cook manually

DEFROST

Use this feature to defrost the foods shown in the DEFROST CHART below.

1. Touch DEFROST pad.

2. See Menu Label. Select desired food by touching the number pad.

Ex: Touch 2 for steaks/chops.

3. Enter weight by touching number pads.
4. Touch START/+30 SEC pad. The oven will stop so the food can be checked.
5. After the audible signal, open the microwave and turn food over or break food apart. Close the microwave oven. Touch START/+30 SEC pad.
6. After each audible signal, turn food over or break food apart and touch START/+30 SEC again.
7. After defrost cycle ends, cover and let stand as indicated in the chart below.

Notes:

- To defrost other foods or foods above or below the weights allowed on the DEFROST CHART, see MANUAL DEFROST below.
- Check foods when oven signals. After final stage, small sections may still be icy. Let stand to continue thawing. Do not cook until all ice crystals are thawed.

MANUAL DEFROST

If the food you wish to defrost is not listed on the DEFROST CHART or is above or below the limits in the AMOUNT column on the DEFROST CHART, you need to defrost manually. You can defrost any frozen food, either raw or previously cooked, by using POWER LEVEL at 30%. Follow the exact 3-step procedure found under TO SET POWER LEVEL on page 14. Estimate defrosting time and touch POWER LEVEL pad eight times for 30% power.

For either raw or previously cooked frozen food the rule of thumb is approximately 4 minutes per pound. For example, defrost 4 minutes for 1 pound of frozen spaghetti sauce.

Always stop the oven periodically to remove or separate the portions that are defrosted. If food is not defrosted at the end of the estimated defrosting time, program the oven in 1 minute increments with POWER LEVEL at 30% until totally defrosted. When using plastic containers from the freezer, defrost only long enough to remove from the plastic in order to place in a microwave safe dish.

MORE MENUS

MELT/SOFTEN/WARM

These features automatically compute the correct heating time and microwave power level for melting, softening and warming foods shown in the chart below.

1. Touch MORE MENUS pad once.
2. See Menu Label. Select desired food by touching number pad.

Ex: Touch 2 for chocolate.

3. Repeat touching same number pad to select quantity.

Ex: Touch 2 two more times for 1 square.

4. Touch START/+30 SEC pad.



Note: To melt, soften or warm other food or foods above or below the quantity allowed on the MELT/SOFTEN/WARM CHART, use manual operation.

BEVERAGE REHEAT/HOT WATER/HOT CEREAL

These features enable you to reheat coffee or tea to restore to a more suitable drinking temperature or to make instant coffee, tea or hot cereal.

- Suppose you want to make 2 cups of coffee.

1. Touch MORE MENUS pad once.

2. See Menu Label. Select desired selection by touching number pad.

Ex: Touch 8 to make coffee.

3. Repeat touching same number pad to select quantity.

Ex: Touch 8 two more times for 2 cups of coffee.

4. Touch START/+30 SEC pad.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.