


## Getting Started


### Front panel



#### 1 Display Window

- Display window will be darkened automatically if there is no key input for 15 seconds. When you press any button, the display window will brighten.

#### 2 Remote sensor

-  (Standby): Switches the unit ON or OFF
- F (Function): Select the function and input source by pressing F repeatedly

Input source / Function	Display
Optical LG Sound Sync (Wired)	OPT
<b>Bluetooth</b>	BT
LG Sound Sync (Wireless)	LG TV
USB	USB


#### 3.

#### + /- (Volume)

- Adjusts volume level.

This unit will turn itself off to save electric consumption when the main unit is not connected to an external device and is not used for 15 minutes.

## Rear panel



### 1. DC IN

- Connect to the AC adapter.


### 2. OPTICAL IN

- Connect the OPTICAL IN jack on the back of the unit to OPTICAL OUT jack on the TV.


### 3. USB Port


- Connect USB memory device to the USB port on the back of the unit.

## Remote control






Replacement of Battery: Remove the battery cover on the rear of the remote control, and insert the battery with + and - matched correctly.




1.  (Standby): Switches the unit ON or OFF
2. VOL (Volume) +/-: Adjusts speaker volume.

3.  /  (Skip/Search) - Press  or  to go to next or previous file. -

Press and hold  /  during playback and release it at the point you want

•   
(Play/Pause) - Starts playback. / Pauses playback.

4. BT (Bluetooth) connection Lock: It allows you to connect a Bluetooth device only on Bluetooth

and LG TV functions. To turn on or off the Bluetooth connection lock, press and hold  for about 3 seconds and press it again in BT (Bluetooth) function.

5. SOUND EFFECT: Selects a sound effect mode by using SOUND EFFECT


On Display -- Description


- ASC (Adaptive Sound Control): Analyzes the property of the input sound and provides the sound optimized for the content in real time.
- BASS BLAST or BASS BLAST+: Reinforces the bass and powerful sound.
- STANDARD: You can enjoy optimized sound.
- CINEMA: You can enjoy more immersive and cinematic surround sound

TV remote: It allows you to control the volume of this unit by your TV remote control even by other company's product. To turn on or off the TV Remote function, press and hold SOUND EFFECT for about 3 seconds and press it again.

Supported TV brands:

LG	Panasonic	Philips	Samsung	Sharp	Sony	Toshiba	Vizio
----	-----------	---------	---------	-------	------	---------	-------


  
(Sound tuning)

Adjusts sound level of each speaker. Select the speaker you want to adjust by using  and adjust the sound level by using VOL +/-.




Adjusting rear speakers level is applied only when the rear speakers are connected.

Speaker	Display	Range
Sub Woofer	WF	-15 ~ 6
Treble	TRE	-5 ~ 5
Bass	BAS	-5 ~ 5
Rear	R	-6 ~ 6



6.

- Surround sound: It allows you to enjoy surround sound with rear speakers. To turn on or off the surround sound, press and hold  for about 3 seconds and press it again.

7. F (Function) - Select the function and input source by pressing F repeatedly

8.  (Mute) - Press  to mute your unit. To cancel it, press  again.

9.  (Information)


- You can display various information of the input source by pressing .
  - OPT (Optical): Audio format
  - BT (Bluetooth): Connected Bluetooth device name
  - USB: File information contained on a USB.
- Auto Power ON/OFF: It allows the unit to turn on and off automatically by input signals: Optical, LG TV or Bluetooth. To turn on or off AUTO POWER function, press and hold  for about 3 seconds and press it again

10. REPEAT - Press REPEAT to select desired repeat or random mode

11. FOLDER  - Searches a folder on USB device.

## Installing the sound bar

- You can hear the sound by connecting the unit to the other device: TV, Blu-ray disc player, DVD player, etc.
- Place the unit in front of the TV and connect it to the device you want.
- You can place the wireless subwoofer anywhere in your room. But it is better to place the subwoofer near the main unit. Turn it slightly toward the center of the room to reduce the wall reflections.
- For the best surround sound, place the speakers as shown below.



#### Note


- If the sound bar covers the remote sensor of the TV, please separate distance between the sound bar and TV by 10 ~ 15 cm (3.9 ~ 5.9 inch) or more.
- The illustration above may differ from actual units.
- You can enjoy surround sound by using Wireless Rear Speaker kit. Wireless Rear Speakers Kit sold separately (SPK8-S).

#### Caution

- For best performance of wireless connection such as Bluetooth or wireless subwoofer, do not install the unit on Metallic furniture because wireless connection communicates through a module positioned on the bottom of the unit.
- Be careful not to make scratches on the surface of the Unit /Subwoofer when installing or moving them.

#### Installing the additional foot

You can extend the height of the unit by using additional foot (height: 14 mm (0.55 inch))



1. Turn the unit upside down.
2. Peel off a sticker attached to the additional foot. Then place it on the existing foot of the unit.
3. Press the additional foot with adequate force to get it firmly fixed.


### **Mounting the main unit on a wall**

You can mount the main unit on a wall.




Caution: Because it is difficult to make a connection after installing this unit, you should connect the cables before installation.

### **Preparation materials**




1. Match the TV's BOTTOM EDGE of Wall bracket install guide with the bottom of TV and



attach to the position.




2. When you mount it on a wall (concrete), use the wall plugs. You should drill some holes. A guide sheet (Wall bracket install guide) is supplied to drill. Use the sheet to check the



point to drill.


3. Remove the Wall bracket install guide.
4. Fix the brackets with screws (A) as shown in the illustration below. Note: Screws (A) and Wall Plugs are not supplied for mounting the unit. We recommend the Hilti (HUD-1 6 x




30) for the mounting



5. Put the unit on the brackets to match screw holes on the bottom of the unit.



6.



Fix the unit with the screws firmly.

Note: To detach the unit, perform it in reverse order

#### Caution


- Do not install this unit upside down. It can damage the parts of this unit or be the cause of personal injury.
- Do not hang onto the installed unit and avoid any impact to the unit.
- Secure the unit firmly to the wall so that it does not fall off. If the unit falls off, it may result in an injury or damage to the product.
- When the unit is installed on a wall, please make sure that a child does not pull any of connecting cables, as it may cause it to fall.

## Connecting

### Organizing cables (Optional)

You can organize the cable with cable ties.

1. Hold the cables together with cable ties as shown below.
2. Tighten cable ties.




#### Note

- After all connections are completed, you can arrange cables as needed.
- Cable ties are not supported.

### Connecting the AC Adapter

Connect the speaker to the power supply with the supplied AC adapter.

1. Connect the supplied AC power cord to the AC adapter.
2. Connect the AC adapter cable to DC IN adapter input.
3. Plug the AC power cord into an AC outlet.



Caution: Only use the AC adapter supplied with this device. Do not use a power supply from another device or manufacturer. Using any other power cable or power supply may cause damage to the device and void your warranty

## Wireless subwoofer and rear speaker (Sold Separately) connection

### Wireless subwoofer connection

LED indicator of wireless subwoofer

LED -- Color Status


- Yellow - green (Blink): The connection is trying.
- Yellow - green: The connection is completed.
- Red: The wireless subwoofer is in standby mode or the connection is failed.
- Off (No display): The power cord of wireless subwoofer is disconnected.

Setting up the wireless subwoofer for the first time

1. Connect the power cord of the sound bar and the wireless subwoofer to the outlet.
2. Turn on the sound bar. The sound bar and the wireless subwoofer will be automatically connected.
  - Yellow - green LED on the front of wireless subwoofer turns on.

Manually pairing wireless subwoofer: When your connection is not completed, you can check red LED on the wireless subwoofer and the wireless subwoofer does not make sound. To solve the problem, follow the steps. below

1. Press PAIRING on the rear of the wireless subwoofer




The yellow - green LED on the front of the wireless subwoofer blinks quickly. (If the yellow - green LED does not blink, press and hold the PAIRING.)

2. Turn on the sound bar.

- Pairing is completed. The yellow - green LED on the front of the wireless subwoofer turns on.

#### Note


- It takes a few seconds (and may take longer) for the main unit and the subwoofer to communicate with each other and make sounds.
- The closer the main unit and the subwoofer, the better sound quality. It is recommended to install the main unit and the subwoofer as close as possible and avoid the cases below.
  - There is an obstacle between the main unit and the subwoofer.
  - There is a device using same frequency with this wireless connection such as a medical equipment, a microwave or a wireless LAN device.
  - Keep the sound bar and the subwoofer away from the device (ex. wireless router, microwave oven, etc.) over 1 m (3.3 ft) to prevent wireless interference



## Rear speakers connection (Sold Separately)

### Connecting the rear speakers

1. Connect the black stripe wire to the terminal marked - (minus) and the other end to the terminal marked + (plus).



2. Connect the wireless receiver and the rear speakers (right, left) with the speaker cables.

- Grey: Rear right
- Blue: Rear left

Note: You need to purchase the wireless rear speakers kit (SPK8-S) to enjoy surround sound.

**Caution**

- Use the speaker supplied with this unit only. Using any other speaker may cause malfunction. y Be sure to match the speaker cable to the appropriate terminal on the components: + to + and – to –
- If the cables are reversed, the sound will be distorted and will lack bass.



## LED indicator of wireless receiver

- Yellow - green (Blink): The connection is trying.
- Yellow - green: The connection is completed.
- Red: The wireless receiver is in standby mode or the connection is failed.
- Off (No display): The power cord of wireless receiver is disconnected.


## Setting up the wireless receiver for the first time

1. Connect the power cord to the wireless receiver to the outlet.
2. Turn on the main unit: The sound bar and wireless receiver will be automatically connected. - Yellow - green LED on the wireless receiver turns on.

## Manually pairing wireless receiver

When your connection is not completed, you can see the red LED on the wireless receiver and rear speakers do not make sound. To solve the problem, follow the below steps.

1. Press PAIRING on the rear of the wireless receiver




. The yellow - green


LED on the wireless receiver blinks quickly

2. Turn on the main unit. Paring is completed. The yellow - green LED on the wireless receiver turns on.

















## Surround sound

- You can enjoy magnificent surround sound for all the input sound source with rear speakers.
- If you turn on the surround function, the whole speaker outputs sound.
- When you turn off the surround function, the speakers output sound as an original input sound channel.

















- To turn on surround function, press and hold  on the remote control for about 3 seconds and press it once again while "OFF - SURROUND" is scrolled.

- To turn off surround function, press and hold  on the remote control for about 3 seconds and press it once again while “ON - SURROUND” is scrolled.

### Surround function ON

Sound Effect	Input	Output	
		No rear speakers	Rear speakers connected
ASC	2.0 Ch		
	5.1 Ch		
STANDARD	2.0 Ch		
	5.1 Ch		
BASS BLAST or BASS BLAST +	2.0 Ch		
	5.1 Ch		
CINEMA	2.0 Ch		
	5.1 Ch		

### Surround function OFF


Sound Effect	Input	Output	
		No rear speakers	Rear speakers connected
ASC	2.0 Ch		
	5.1 Ch		
STANDARD	2.0 Ch		
	5.1 Ch		
BASS BLAST or BASS BLAST +	2.0 Ch		
	5.1 Ch		
CINEMA	2.0 Ch		
	5.1 Ch		

### How to Affix the Ferrite Core

Ferrite core may not be provided depending on each nation's regulations.

Affix the Ferrite Core for speaker cables: You must affix a ferrite core in order to reduce or eliminate electrical interference.


1. Pull the stopper [a] of the ferrite core to open.
2. Wind the speaker cables around the ferrite core twice.
3. Close the ferrite core until it clicks.



#### Note

- If there is a strong electromagnetic wave product nearby, interference may occur. Put the main unit and wireless receiver away from there.
- The wireless receiver will automatically switch to standby mode in a few minutes after the sound bar is turned off. When the wireless receiver is in standby mode, the LED will turn on in red.
- When you turn on the sound bar, the wireless receiver will turn on and the LED will change to yellow - green and then the rear speakers makes sound within a few seconds.

- It takes a few seconds (and may take longer) for the main unit and Wireless Receiver to communicate with each other.
- Use the rear speaker at least 30 cm (11.8 inch) away from either TV screen or PC monitor.
- When the wireless receiver is being connected or disconnected with the main unit, output sound may be interrupted.
- Set the distance between the sound bar and the wireless receiver as close as possible and keep them away from the device (ex. wireless router, microwave oven, etc.) over 1 m (3.3 ft) to prevent wireless interference




## Connecting to your TV

Please connect with this unit and TV using the optical digital cable or HDMI cable considering the state of the TV

### Using an OPTICAL cable

1. Connect the OPTICAL IN jack on the back of the unit to OPTICAL OUT jack on the TV using an OPTICAL cable.



2. Select the input source to OPT by pressing F repeatedly. You can see "OPT" on the display window if connecting normally between this unit and your TV.

## Note

- Before connecting the optical cable, be sure to remove the protection plug cover if your cable has the cover.
- You can enjoy the TV audio through the speakers of this unit. In the case of some TV models, you must select the external speaker option from the TV menu. (For details, reference your TV user manual.)
- Set up the sound output of TV to listen to the sound through this unit: TV setting menu -> [Sound] -> [TV Sound output] -> [External speaker (Optical)]
- Details of TV setting menu vary depending on the manufacturers or models of your TV.

## LG Sound Sync




- You can control some functions of this unit by your TV's remote control with LG Sound Sync. It is compatible with the LG TV that is supported LG Sound Sync. Make sure of the LG Sound Sync logo on your TV.
- Controllable function by LG TV's remote control: Volume up/down, mute Refer to the TV's instruction manual for the details of LG Sound Sync.
- Make one of the following connections, depending on the capabilities of your equipment.

## Note


- You can also use the remote control of this unit while using LG Sound Sync. If you use TV's remote control again, the unit synchronizes with the TV. According to TV Specifications, the volume and mute of this unit synchronize with TV.
- When the connection fails, make sure of the condition of the TV and power.
- Make sure of the condition of this unit and the connection in the cases below when using LG Sound Sync.
  - The unit is turned off.
  - Changing the function to the others.
  - Disconnecting the optical cable.
  - Disconnecting the wireless connection caused by interference or a distance.
- The amount of time to turn off this unit is different depending on your TV when you set AUTO POWER function to ON.
- Details of TV setting menu vary depending on the models of your TV.

## LG Sound Sync with wired connection

1. Connect your LG TV to the unit by using an optical cable.




2. Set up the sound output of TV to listen to the sound through this unit: TV setting menu -> [Sound] -> [TV Sound output] -> [LG Sound Sync (Optical)]

3. Turn on the unit by pressing  .

4. Select the input source to OPT by pressing F repeatedly. You can see “LGOPT” on the display window if connecting normally between this unit and your TV.

Note: Details of TV setting menu vary depending on the models of your TV.

### LG Sound Sync with wireless connection

1. Turn on the unit by pressing  .


2. Select the LG TV function by pressing F repeatedly.

3. Set up the sound output of TV to listen to the sound through this unit: TV setting menu -> [Sound] -> [TV Sound output] -> [LG Sound Sync (Wireless)] “PAIRED” appears on the display window for about 3 seconds and then you can see “LG TV” on the display window if connecting normally between this unit and your TV.

Note: If you turned off the unit directly by pressing  (Power), LG Sound Sync (Wireless) will be disconnected.

### Optional equipment connection

**OPTICAL IN connection:** Connect an optical output jack of external devices to the OPTICAL IN jack.




1. Connect the OPTICAL IN jack on the back of the unit to optical out jack of your external device.
2. Select the input source to OPT by pressing F repeatedly. You can see “OPT” on the display window if connecting normally between this unit and your device.

Note: Before connecting the optical cable, be sure to remove the protection plug cover if your cable has the cover

### USB connection

- Connect USB memory device to the USB port on the back of the unit.



- For more information of playing files on a USB
- Removing the USB Device from the unit.
  1. Choose a different function/mode.
  2. Remove the USB device from the unit.

### Compatible USB devices

- MP3 Player: Flash type MP3 player.
- USB Flash Drive: Devices that support USB 1.1.
- The USB function of this unit does not support some USB devices.

## USB device requirement

- Devices which require additional program installation connected to a computer, are not supported.
- Do not extract the USB device while in operation.
- For a large capacity USB, it may take longer than a few minutes to be searched.
- To prevent data loss, back up all data.
- This unit is not supported when the total number of files is 999 or more.
- The unit's USB Port cannot be connected to PC. The unit can not be used as a storage device.
- FAT16/FAT32 file system is supported on this unit.
- Depending on some devices, it may not available to recognize the followings on this unit.
  - External HDD
  - Card readers
  - Locked devices
  - Hard type USB devices
  - USB hub
  - Using USB extension cable
  - iPhone/iPod/iPad - Android device

## Playable file

### Sampling Frequency


- MP3: within 32 to 48 kHz
- WMA: within 32 to 48 kHz



Bitrate resolution MP3: within 80 to 320 kbps; WMA: within 56 to 128 kbps

- Maximum files: Under 999
- Maximum directories: Under 99
- A protected file by DRM (Digital rights management) cannot be played on the unit.
- Video files in the USB storage device can not be played.
- Depending on the performance of your USB device, playback may not work well.

### Note

- Folders and files on the USB are recognized as below.



- If there is no file in a folder, the folder will not appear.
- File will be played from file  to file  one by one.
- Files will be played in order recorded and it may be different depending on the record circumstances.
- This unit can display file or folder names that contain numbers or English characters only.
- \*ROOT: The first screen you can see when a this unit recognize the USB is "ROOT".

## Operating

### Basic operations


#### USB operation

1. Connect the USB device to the USB port.
2. Select the USB function by pressing F repeatedly.

- Playback: Press  on the remote control.



- Pause: During playback, press  on the remote control.

- Skip to the next/ previous file:

- During playback, press  on the remote control to go to the next file.

- Playing less than 3 seconds, press  on the remote control to go to the previous file.

- Playing after 3 seconds, press C on the remote control to go to the beginning of the file

- Search for a section within a file: Press and hold  /  on the remote control during playback and release it at the point you want to listen to.

- Play repeatedly or randomly: Press REPEAT on the remote control repeatedly. Refer to the note for details about the display change.

- Search a folder: Press FOLDER  /  on the remote control.

- Resume playback: This unit memorizes a current song which is played before changing the function or turning off the unit.

#### Note

- The resume point may be cleared when you pull out the power cord or removing the USB device from the unit.
- Repeat/Random playback operates as follows.
  - OFF: Plays songs on USB device in order.
  - ONE: Plays a same song repeatedly.
  - FOLDER: Plays songs in a folder repeatedly.
  - ALL: Plays all the songs on USB device repeatedly.
  - SHUFFLE: Plays all the songs once randomly, and stops the playback.

## Other operations

Using your TV remote control:




- You can control some functions of this unit by your TV remote control even by other company's product. Controllable functions are volume up/down and mute.
- Press and hold SOUND EFFECT on the remote control for about 3 seconds. "ON - TV REMOTE" appears and you can control this unit by your TV remote control.

- To check the status of this function, press and hold SOUND EFFECT on the remote control .
- To turn off this function, press and hold SOUND EFFECT on the remote control and press it once again while “ON - TV REMOTE” is scrolled.

#### Note

- Make sure that the sound output of your TV is set to [External speaker].
- This function does not operate on LG TV's magic remote control.
- Some remote control may not be supported.

### **AUTO POWER On/Off**

- This unit automatically turns on by an input source: Optical, LG TV or Bluetooth.
- When you turn on your TV or an external device connected to this unit, this unit recognizes the input signal and selects the suitable function. You can hear the sound from your device.
- If you try to connect your Bluetooth device, this unit turns on and the unit will be connected to your Bluetooth device.
- To turn on this function, press and hold  on the remote control for about 3 seconds and press it once again while “OFF - AUTO POWER” is scrolled.
- To check the status of this function, press and hold  on the remote control. To turn off this function, press and hold  on the remote control for about 3 seconds and press it once again while “ON - AUTO POWER” is scrolled.

#### Note

- After the unit is turned on by AUTO POWER function, it will be automatically turned off if there is no signal for a certain period of time from the TV connected by LG Sound Sync (Optical/Wireless).
- After the unit is turned on by AUTO POWER function, it will be automatically turned off if there is no signal for a certain period of time from the external device.
- If you turned off the unit directly, it cannot be turned on automatically by AUTO POWER function. However the unit can be turned on by AUTO POWER function when optical signal comes in after 5 seconds of no signal.
- Depending on the connected device, this function may not operate.
- If you disconnect Bluetooth connection by this unit, some Bluetooth devices try to connect to the unit continually. Therefore it is recommended to disconnect the connection before turning off the unit.

- When you turn on this unit for the first time, status of Auto Power function is turned on.
- To use this function, the main unit must be registered in paired devices list of Bluetooth device.
- You can set the Auto Power function only when this unit is turned on.

### **Auto function change**

- This unit recognizes input signals such as Optical, Bluetooth and LG TV and then changes suitable function automatically
- When optical signal comes in: When you turn on the external device connected to this unit by an optical cable, this unit changes the function to optical. You can hear the sound from your device.
- When you try to connect BLUETOOTH device: When you try to connect your Bluetooth device to this unit, Bluetooth function is selected. Play your music on the Bluetooth device.
- When LG TV signal comes in: When you turn on your LG TV connected by LG Sound Sync (Wireless connection), this unit changes the function to LG TV. You can hear the sound from your TV.

Note: If the Bluetooth connection lock function is set, Bluetooth connection will be only available on Bluetooth and LG TV function.

## **Using a Bluetooth Wireless Technology**

### About Bluetooth

- Bluetooth is wireless communication technology for short range connection.
- The sound may be interrupted when the connection interfered by the other electronic wave or you connect the Bluetooth in the other rooms.
- Connecting individual devices under Bluetooth wireless technology does not incur any charges. A mobile phone with Bluetooth wireless technology can be operated via the Cascade if the connection was made via Bluetooth wireless technology.
  - Available Devices: Smart phone, MP3, Notebook, etc.
  - Version: 4.0
  - Codec: SBC

Bluetooth profiles: In order to use Bluetooth wireless technology, devices must be able to interpret certain profiles. This speaker is compatible with following profile. A2DP (Advanced Audio Distribution Profile)

Listening to Music of a Bluetooth Device: Before you start the pairing procedure, make sure that the Bluetooth feature on your smart device is turned on. Refer to your Bluetooth device's user guide. Once a pairing operation is performed, it does not need to be performed again.

1. Select the Bluetooth function by pressing F repeatedly. Appears "BT" and then "READY" in display window.
2. Operate the Bluetooth device and perform the pairing operation. When searching for this speaker on your Bluetooth device, a list of the devices found may appear in the Bluetooth device display depending on the type of Bluetooth device. Your speaker appears as "LG SL4Y(XX)".
3. Select the "LG SL4Y(XX)".

#### Note

- XX means the last four digits of address. For example, if your unit has a MAC address such as 9C:02:98:4A:F7:08, you will see "LG SL4Y(08)" on your Bluetooth device.
  - Depending on the Bluetooth device type, some devices have a different pairing way. For details about Bluetooth pairing, refer to your Bluetooth device manual.
4. When this unit is successfully connected with your Bluetooth device, "PAIRED" -> your device's name -> "BT" appears on the display window.

Note: If it is unavailable to display device name on the unit, "i" will be displayed. To check the connected device's name, press J on the remote control. The connected Bluetooth device's name is displayed.

5. Listen to music. To play music in your Bluetooth device, refer to your Bluetooth device's user guide.

#### Note



- When using Bluetooth technology, you have to make a connection between the unit and the Bluetooth device as close as possible and keep the distance. However it may not work well in the case below:
  - There is an obstacle between the unit and the Bluetooth device.
  - There is a device using same frequency with Bluetooth technology such as a medical equipment, a microwave or a wireless LAN device.
- If Bluetooth connection does not work well, try pairing it again.
- The sound may be interrupted when the connection has interference by the other electronic waves.
- Pairing is limited to one Bluetooth device per unit and multi-pairing is not supported.
- Depending on the type of the device, you may not be able to use the Bluetooth function.
- You can enjoy Bluetooth function using smart phone, MP3, Notebook, etc..

- The more distance between the unit and the Bluetooth device, the lower the sound quality becomes.
- Bluetooth connection will be disconnected when the unit is turned off or the Bluetooth device gets to far from the unit.
- When Bluetooth connection is disconnected, connect the Bluetooth device to the unit again.
- When the unit is not connected, “READY” appears in the display window.
- When you connect Bluetooth device (iOS device etc.) to this unit or operate the device, the volume level can be synchronized with each other.
- If you change to another function after connecting Bluetooth, Bluetooth connection will be disconnected. And you return to Bluetooth function, Bluetooth connection will be connected automatically

#### Controls connected Bluetooth device

- You can control the connected Bluetooth device from the unit; play, pause, skip, volume.
- Note
  - Only Android OS and iOS is available to use this function.
  - This function may not be supported depending on the Bluetooth device or some of TV operated differently.

#### Bluetooth connection lock (BT LOCK)

- You can limit Bluetooth connection to only BT (Bluetooth) and LG TV function to prevent unintended Bluetooth connection.
- - To turn on this function, press and hold  on the remote control for about 3 seconds in BT (Bluetooth) function and press it once again while “OFF - BT LOCK” is scrolled. Then you can limit Bluetooth connection.
  - - To turn off this function, press and hold  on the remote control for about 3 seconds in BT (Bluetooth) function and press it once again while “ON - BT LOCK” is scrolled.
- Note: Even if you set up BT LOCK function to On, this sound bar turns on by Auto Power function. Turn off Auto Power function to prevent it.

### Using BLUETOOTH App

#### Note

- Only Android OS is available to use “Music Flow Bluetooth” app with this unit.

- Additional data charges may occur if installed over 3G/4G, according to your device plan.

#### About

- “Music Flow Bluetooth” App “Music Flow Bluetooth” app brings a suite of new features to this unit.
- To enjoy more features, you are recommended to download and install free “Music Flow Bluetooth” app.

#### **Install “Music Flow Bluetooth” App onto Your BLUETOOTH Device**

There are two ways to install “Music Flow Bluetooth” app onto your Bluetooth device.

##### Install “Music Flow Bluetooth” App through QR code

1. Install “Music Flow Bluetooth” app through QR code. Use the scanning software to scan the QR code.



2. Tap an icon for installation.

#### Note

- Make sure that your Bluetooth device is connected to the Internet.
- Make sure that your Bluetooth device has a scanning software application. If you don't have one, download one from “Google Android Market (Google Play Store)”.
- Depending on area, QR code may not work.
- You can find the available application of this unit by using “LG Audio” app. Android OS: Ver 5.0 (or later)

##### Install “Music Flow Bluetooth” App through “Google Android Market (Google Play Store)”

1. Tap the “Google Android Market (Google Play Store)” icon.
2. In the search bar, type in the “Music Flow Bluetooth” and search it.
3. In the search result list, find and tap “Music Flow Bluetooth” to start downloading Bluetooth app.
4. Tap an icon for installation.

#### Note

- Make sure that your Bluetooth device is connected to the Internet.

- Make sure that your Bluetooth device is equipped with “Google Android Market (Google Play Store)”

### **Activate BLUETOOTH with “Music Flow Bluetooth” App**

“Music Flow Bluetooth” app helps to connect your Bluetooth device to this unit.

1. Tap “Music Flow Bluetooth” app icon on the home screen to open “Music Flow Bluetooth” app, and go to the main menu.
2. If you want to get more information to operate, tap [Setting] and tap [Help] menu.

#### **Note**

- “Music Flow Bluetooth” app will be available in the software version as follow;
  - Android O/S: Ver 4.0.3 (or later)
- If you use “Music Flow Bluetooth” app for operation, there would be some differences between “Music Flow Bluetooth” app and the supplied remote control. Use the supplied remote control as necessary.
- Depending on the Bluetooth device, “Music Flow Bluetooth” app may not work.
- After connection of “Music Flow Bluetooth” app, music may be output from your device. In this case, try connecting procedure again.
- If you operate the other applications or change the settings on your Bluetooth device while using “Music Flow Bluetooth” app, “Music Flow Bluetooth” app may operate abnormally.
- When “Music Flow Bluetooth” app operates abnormally, check your Bluetooth device and the connection of “Music Flow Bluetooth” app and then try to connect again.
- Depending on the smart phone's operating system, you have some differences for “Music Flow Bluetooth” operation.
- Even though Bluetooth connection will be disconnected, you can use “Music Flow Bluetooth” app when you change the function.
- Additional features offered by "Music Flow Bluetooth" app may not work depending on the distance between this unit and Bluetooth device and wireless conditions.

## **Troubleshooting**

### **General**

#### **Symptoms -- Cause & Solution**


1. The unit does not work properly
  - Turn off the power of this unit and the connected external device (TV, Woofer, DVD-player, Amplifier, etc.) and turn them on again.

- Disconnect the power cord of this unit and the connected external device (TV, Woofer, DVD-player, Amplifier, etc.) and then try connecting again.
- Previous setting may not be saved when device power is shut off

## 2. No Power

- The power cord is unplugged. Plug in the power cord.
- Check whether electricity failed. Check the condition by operating other electronic devices.

## 3. No sound

- Incorrect input source is selected. Check the input source and select the correct input source.
- The mute function is activated. Press  (Mute) or adjust the volume level to cancel the mute function.
- When you are using connection with a external device (set top box, Bluetooth device etc.), adjust volume level of the device.

## 4. No woofer sound

- The power cord of the subwoofer is not connected. Plug the power cord into the wall outlet securely.
- Pairing between the unit and the subwoofer gets disconnected. Connect the unit and the subwoofer.

## 5. The remote control does not work properly.

- The remote control is too far from the unit. Operate the remote control within about 7 m (23 ft).
- There is an obstacle in the path of the remote control and the unit. Remove the obstacle.
- The batteries in the remote control is exhausted. Replace the batteries with new one.

## 6. The AUTO POWER function does not work.

- Check connection of the external device such as TV, DVD/Blu-Ray player or Bluetooth device.
- Depending on the connected device, this function may not operate.

## 7. LG Sound Sync does not work.

- Check whether your LG TV supports LG Sound Sync.
- Check connection of LG Sound Sync (Optical or wireless).
- Check sound setting of your TV and this unit.

8. The unit does not connect with Bluetooth device.

- Turn off the Bluetooth connection lock function.

9. When you feel the output sound of the unit is low. Check the details below and adjust the unit according to them.

- With the sound bar connected with TV, change the AUDIO DIGITAL OUT setting on TV Setup Menu from [PCM] to [AUTO] or [BITSTREAM].
- With the sound bar connected with Player, change the AUDIO DIGITAL OUT setting on Player Setup Menu from [PCM] to [PRIMARY PASS-THROUGH] or [BITSTREAM].
- Change Audio DRC setting on connected device setup menu to [OFF] state.
- Make sure Night time mode is not On. Turn [OFF] Night time mode.

## NOTES to use wireless

1. This device may have wireless interference.

- Wireless may not operate normally in weak signal area.
- Please install the device close enough to wireless subwoofer.
- Do not install the device on metal furniture for optimum performance

2. Bluetooth device may malfunction or make noise in the following cases.

- When any part of your body contact the transceiver of the Bluetooth device or sound bar.
- When there is an obstacle or wall or the device is installed in a secluded spot.
- When there is a device (a wireless LAN, a medical equipment or a microwave) using same frequency, make the distance between the products as far away as possible each other.
- When connecting the device to the Bluetooth device, make the distance between the products as close as possible each other.
- When the device gets too far from the Bluetooth device, the connection is disconnected and also malfunction may occur

### Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.