



Beko Refrigerator User manual



Models: BFBF2414*

Your Refrigerator



1. Door shelf
2. Egg section
3. Bottle shelf
4. Adjustable feet
5. Fridge crisper
6. Chiller compartment
7. Glass Shelf
8. Fan
9. Temperature setting button
10. Ion Guard
11. Freezer Crisper
12. Moving door shelf
13. Ice box /Ice-making
14. Air Filter
15. Freezer compartment
16. Fridge compartment

Figures that take place in this instruction manual are schematic and may not correspond exactly with your product.

If the subject parts are not included in the product you have purchased, then it is valid for other models.

Important Safety Warnings

Please review the following information. Failure to observe this information may cause injuries or material damage. Otherwise, all warranty and reliability commitments will become invalid.

The service life of your product is 10 years. During this period, original spare parts will be available to operate the product properly.

Intended use

This appliance is intended to be used in household and similar applications such as

- + staff kitchen areas in shops, offices and other working environments;
- + farm houses and by clients in hotels, motels and other residential type environments;
- + bed and breakfast type environments;
- + catering and similar non-retail applications

General safety

- + When you want to dispose/scrap the product, we recommend you to consult the authorized service in order to learn the required information and authorized bodies.
- + Consult your authorized service for all your questions and problems related to the refrigerator. Do not intervene or let someone intervene to the refrigerator without notifying the authorized services.
- + For products with a freezer compartment; Do not eat ice cream and ice cubes immediately after you take them out of the freezer compartment! (This may cause frostbite in your mouth.)
- + For products with a freezer compartment; Do not put bottled and canned liquid beverages in the freezer compartment. Otherwise, these may burst.
- + Do not touch frozen food by hand; they may stick to your hand.
- + Unplug your refrigerator before cleaning or defrosting.
- + Vapor and vaporized cleaning materials should never be used in cleaning and defrosting processes of your refrigerator. In such cases, the vapor may get in contact with the electrical parts and cause short circuit or electric shock.
- + Never use the parts on your refrigerator such as the door as a means of support or step.
- + Do not use electrical devices inside the refrigerator.
- + Do not damage the parts where the refrigerant is circulating with drilling or cutting that might blow out when the gas channels of the evaporator, pipe extensions or surface causes skin irritations and eye injuries.
- + Electrical devices must be repaired by only authorized persons. Repairs performed by incompetent persons create a risk for the user.

- + In case of any failure or during a maintenance or repair work, disconnect your refrigerators mains supply by either turning off the relevant fuse or unplugging your appliance.
- + Do not pull by the cable when pulling off the plug.
- + Ensure highly alcoholic beverages are stored securely with the lid fastened and placed upright.
- + Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- + Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- + This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- + Do not operate a damaged refrigerator. Consult with the service agent if you have any concerns.
- + Electrical safety of your refrigerator shall be guaranteed only if the earth system in your house complies with standards.
- + Exposing the product to rain, snow, sun and wind is dangerous with respect to electrical safety.
- + If the SUPPLY CORD is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.
- + Never plug the refrigerator into the wall outlet during installation. Otherwise, risk of death or serious injury may arise.
- + This refrigerator is intended for only storing food items. It must not be used for any other purpose.
- + Label of technical specifications is located on the left wall inside the refrigerator.
- + Never connect your refrigerator to electricity saving systems; they may damage the refrigerator.
- + If there is a blue light on the refrigerator, do not look at the blue light with optical tools.
- + For manually controlled refrigerators, wait for at least 5 minutes to start the refrigerator after power failure.
- + This operation manual should be handed in to the new owner of the product when it is given to others.
- + Avoid causing damage on power cable when transporting the refrigerator. Bending cable may cause fire. Never place heavy objects on power cable.



- + Do not touch the plug with wet hands when plugging the product.
 - + Do not plug the refrigerator if the wall outlet is loose.
 - + Water should not be sprayed on inner or outer parts of the product for safety purposes.
 - + Do not spray substances containing inflammable gases such as propane gas near the refrigerator to avoid fire and explosion risk.
 - + Never place containers filled with water on top of the refrigerator. in the event of spillages. this may cause electric shock or fire.
 - + Do not overload the refrigerator with food. If overloaded. the food items may fall down and hurt you and damage refrigerator when you open the door.
 - + Never place objects on top of the refrigerator; otherwise. these objects may fall down when you open or close the refrigerators door.
 - + As they require a precise temperature. vaccines. heat-sensitive medicine and scientific materials and etc. should not be kept in the refrigerator.
 - + If not to be used for a long time. refrigerator should be unplugged. A possible problem in power cable may cause fire.
 - + The plug's tip should be cleaned regularly with a dry cloth; otherwise. it may cause fire.
 - + Refrigerator may move if adjustable legs are not properly secured on the floor. Properly securing adjustable legs on the floor can prevent the refrigerator to move.
 - + When carrying the refrigerator. do not hold it from door handle. Otherwise. it may be snapped.
 - + When you have to place your product next to another refrigerator or freezer. the distance between devices should be at least 8 cm. Otherwise. adjacent side walls may be humidified.
- WARNING: Keep ventilation openings. in the appliance enclosure or in the built-in structure. clear of obstruction.

WARNING: Do not use mechanical devices or other means to accelerate the defrosting process. other than those recommended by the manufacturer.

WARNING: Do not use electrical appliances inside the food storage compartments of the appliance. unless they are of the type recommended by the manufacturer.

WARNING: Do not damage the refrigerant circuit.

The product shall never be used while the compartment which is located at the top or back of your product and . in which electronic boards are available (electronic board box cover) (1) is open.



For products with a water dispenser

+ Pressure for cold water inlet shall be maximum 90 psi (6.2 bar). If your water pressure exceeds 80 psi (5.5 bar), use a pressure limiting valve in your mains system. If you do not know how to check your water pressure ask for the help of a professional plumber.

+ If there is risk of water hammer effect in your installation, always use a water hammer prevention equipment in your installation. Consult Professional plumbers if you are not sure that there is no water hammer effect in your installation.

+ Do not install on the hot water inlet. Take precautions against the risk of freezing of the hoses. Water temperature operating interval shall be 33°F (0.6°C) minimum and 100°F (38°C) maximum.

+ Use only potable water.

Child safety

+ If the door has a lock, the key should be kept away from reach of children.

+ Children should be supervised to ensure that they do not play with the appliance.

WARNING: Risk of child entrapment.

Before you throw away your old refrigerator or freezer:

+ Take off the doors.

+ Leave the shelves in place so that children may not easily climb inside.

Installation

In case the information which are given in the user manual are not taken into account, manufacturer will not assume any liability for this.

Points to be paid attention to when the relocation of the refrigerator

1. Your refrigerator should be unplugged. Before transportation of your refrigerator, it should be emptied and cleaned.

2. Before it is re-packaged, shelves, accessories, crisper, etc. inside your refrigerator should be fixed with adhesive tape and secured against impacts. Package should be bound with a thick tape or sound ropes and the transportation rules on the package should be strictly observed.

3. Original packaging and foam materials should be kept for future transportations or moving.

Before you start the refrigerator.

Check the following before you start to use your refrigerator:

1. Clean the interior of the refrigerator as recommended in the "Maintenance and cleaning" section.
2. Connect the plug of the refrigerator to the wall socket. When the fridge door is opened, fridge internal lamp will turn on.
3. When the compressor starts to operate, a sound will be heard. The liquid and gases sealed with in the refrigeration system may also give rise to noise, even the compressor is not running and this is quite normal.
4. Front edges and both sides of the refrigerator may feel warm. This is normal. These areas are designed to be warm to avoid condensation.

Important:

The connection must be in compliance with national regulations.

- + The power plug must be easily accessible after installation.
- + Electrical safety of your refrigerator shall be guaranteed only if the earth system in your house complies with standards.
- + The voltage stated on the label located at left inner side of your product should be equal to your network voltage.
- + Extension cables and multi plugs must not be used for connection.

A damaged power cable must be replaced by a qualified electrician. Product must not be operated before it is repaired!

There is the risk of electric shock!

Disposing of the packaging

The packing materials may be dangerous for children. Keep the packing materials out of the reach of children or dispose of them by classifying them in accordance with the waste instructions stated by your local authorities. Do not throw away with regular house waste. throw away on packaging pick up spots designated by the local authorities The packing of your refrigerator is produced from recyclable materials.

Disposing of your old refrigerator

Dispose of your old refrigerator without giving any harm to the environment.

- + You may consult your authorized dealer or waste collection center of your municipality about the disposal of your refrigerator.

Before disposing of your refrigerator, cut out the electric plug and, if there are any locks on the door, make them inoperable in order to protect children against any danger.



Placing and Installation

If the entrance door of the room where the refrigerator will be installed is not wide enough for the refrigerator to pass through, then call the authorized service to have them remove the doors of your refrigerator and pass it sideways through the door.

1. Install your refrigerator to a place that allows ease of use.
2. Keep your refrigerator away from heat sources, humid places and direct sunlight.
3. There must be appropriate air ventilation around your refrigerator in order to achieve an efficient operation. If the refrigerator is to be placed in a recess in the wall, there must be at least 5 cm distance with the ceiling and at least 5 cm with the wall. Do not place your product on the materials such as rug or carpet.
4. Place your refrigerator on an even floor surface to prevent jolts.

Door Open Warning (This feature is optional)

An audio warning signal will be given when the door of your product is left open for at least 1 minute. This warning will be muted when the door is closed or any of the display buttons (if any) are pressed.



	K60340N
Height (cm/inch) unpacked	172 / 67.8 "
Width (cm/inch) unpacked	60 / 23.6 "
Depth (cm/inch) unpacked	67 / 26.4 "
Height (cm/inch) packed	181 / 71.3 "
Width (cm/inch) packed	65 / 25.7 "
Depth (cm/inch) packed	73 / 28.7 "
Gross Weight (Kg)/lbs	70 / 154
Net Weight (Kg)/lbs	66 / 145

Appropriate location for installation

Contact an Authorized Service for the installation of the product. In order to prepare the product for use, refer to the information in the user manual and ensure that electrical installation and water installation are appropriate. If not, all a qualified electrician and technician to have any necessary arrangements carried out.

WARNING: Manufacturer shall not be held liable for damages that may arise from procedures carried out by unauthorized persons.

WARNING: Product must not be Plugged in during installation. Otherwise, there is the risk of death or serious injury!

WARNING: If the door clearance of the room where the product will be placed is so tight as to prevent passing of the product, remove the door of the room and pass the product through the door by turning it to its side; if this does not work, contact the authorized service.


WARNING: If the door of the room, where the product will be placed is too small for the product to pass, then the product's doors must be removed and the product must be turned aside to pass it through.

- + Install the product where it will not be exposed to temperatures below freezing or exposed to outdoor weather conditions.
- + Do place the product near a grounded electrical outlet
- + Do not place the product on materials such as rugs or carpets.

Adjusting the legs

If your refrigerator is unbalanced; You can balance your refrigerator by turning its front legs as illustrated in the figure. The corner where the leg exists is lowered when you turn in the

direction of black arrow and raised when you turn in the opposite direction. Taking help from someone to slightly lift the refrigerator will facilitate this process.



Compliance with RoHS Directive :

+The product you have purchased complies with EU RoHS Directive(2011/65/EU). It does not contain harmful and prohibited materials specified in the Directive.

Package information

+ Packing materials of The product are manufactured from recyclable materials in accordance with our National Environment Regulations. Do not dispose of the packaging materials together with the domestic or other wastes. Take them to the packaging material collection points designated by the local authorities.

DANGER: Risk of fire or explosion. Flammable refrigerant used. do not use mechanical devices to defrost refrigerator. Do not puncture refrigerant tubing”.

DANGER: Risk of fire or explosion. Flammable refrigerant used-To be repaired only by trained service personnel. Use only manufacturer-authorized service parts. Any repair equipment used must be designed for flammable refrigerants. Follow all manufacturer repair instructions. Do not puncture Refrigerant tubing”

CAUTION : Risk Of Fire Or Explosion. Flammable Refrigerant Used. Consult Repair Manual/ Owner's Guide Before Attempting To Service This Product. All Safety Precautions Must be Followed.

CAUTION : Risk of Fire or explosion. dispose of refrigerator properly In accordance with applicable} federal or local regulations. Flammable} refrigerant used.

CAUTION :: Risk of fire or explosion due to puncture of refrigerant tubing; Follow handling instructions carefully. Flammable refrigerant used”.

Changing the illumination lamp

To change the Bulb/LED used for illumination of your refrigerator. call your Authorized Service. The lamp(s) used in this appliance is not suitable for house hold room illumination.

The intended purpose of this lamp is to assist the user to place food stuffs in the refrigerator food stuffs in the refrigerator/freezer in a safe and comfortable way. The lamps. used in this appliance have to withstand extreme physical conditions such as temperatures below -20°C. (only chest and upright freezer)

Electrical connection

WARNING: Do not make connection via extension cable or multi-plus.

WARNING: Damaged power cable must be replaced by the Authorized Service Agent.

If two coolers are to be installed side by side there should be at 1.5 inches distance between them.

+ Our company shall not be liable for any damages that will arise when the product is used without grounding and electrical connection in accordance with the national regulations.

+ Power cable plug must be within easy reach after installation.

+ Do not use extension cords or cordless multi outlet between your product and the wall outlet.

Hot Surface Warning !

Side wall of your product is equipped with refrigerant pipes to improve the cooling system. Refrigerant with high temperature may flow through these areas, resulting in hot surfaces on the side wall this is normal and does not need any servicing. Please pay attention while touching these areas.

Preparation

+ Your cooler/freezer should be installed at least 30 cm away from heat sources such as hobs, ovens, central heater and stoves and at least 5 cm away from electrical ovens and should not be located under direct sunlight.

+ Please make sure that the interior of your cooler/freezer is cleaned thoroughly.

+ If two coolers are to be installed side by side, there should be at least 2 cm distance between them.

+ When you operate your cooler/freezer for the first time, please observe the following instructions during the initial six hours.

+ Its door should not be opened frequently.

+ It must be operated empty without placing any food in it.

+ Do not unplug your cooler/freezer. If a power failure occurs out of your control, please see the warnings in the "Recommended solutions for the problems" section.

+ The baskets/drawers that are provided with the chill compartment must always be in use for low energy consumption and for better storage conditions.

+ Food contact with the temperature sensor in the freezer compartment may increase energy consumption of appliance.

Thus any contact with the sensor(s) must be avoided.

+ This product has been designed to function at ambient temperatures up to 43°C (90 SDgr F). Even if the ambient temperature falls to -15 °C. frozen food in the freezer does not thaw thanks to its Advanced Electronic Temperature Control System. For the first installation. the product should NOT be placed underlow ambient temperatures. This is because the freezer cannot go down to standard operation temperature.

When reaching continuous operation. the product can be moved to another place. Thus. later you can place your product in the garage or an unheated room without the concern of causing frozen food to get rotten. However. itis likely that above mentioned low temperatures may cause the freezing of the food in the fridge compartment; thus. please consume the food items in the fridge in a controlled way as needed. When ambient temperature goes back to normal. you may change button setting according to your need.

+ Ifthe ambient temperature is below 0°C. the food in fridge compartment will freeze. Therefore. we recommend not using the fridge compartment in such low ambient temperatures.

You may continue to use the freezer compartment as usual.


+ In some models. the instrument panel automatically turns off 5 minutes after the door has closed. It will be reactivated when the door has opened or pressed on any key.

+ Due to temperature change asa result of opening/closing the product door during operation. condensationon the door/body shelves and the glass containers is normal.

Using your refrigerator

Indicator panel (Internal Display) *Optional

Indicator panels may vary according to the product model. Audio - visual functions on the indicator panel helps you in using your product.



Figures that take place in this instruction manual are schematic and may not correspond exactly with your product. If the subject parts are not included in the product you have purchased. then itis valid for other models.

1. Freezer compartment indicator

Fridge compartment light is illuminated while the freezer compartment temperature is set.

2. Error status indicator

If your refrigerator does not perform enough cooling or in case of a sensor fault, this indicator is activated. When this indicator is activated, "E" is displayed on the freezer compartment temperature indicator, and numbers such as "1. ." are displayed on the fridge compartment temperature indicator. These numbers on the indicator inform service personnel about the error.

3. Temperature indicator

Indicates freezer, fridge compartment temperature.

4. Vacation function button

Press on Vacation Button for 3 seconds to activate this function. When the vacation function is activated, "- -" is displayed on the fridge compartment temperature indicator and no active cooling is performed on the fridge compartment. It is not suitable to keep the food in the fridge compartment when this function is activated.

Other compartments shall be continued to be cooled as per their set temperature. To cancel this function, press Vacation button again.

5. Temperature setting button

Changes the temperature of the relevant compartment between -24°C -18°C and 8°C 1°C.

6. Compartment selection button

Selection button: Press compartment selection button to switch between fridge and freezer compartments.

7. Fridge compartment indicator

Fridge compartment light is illuminated while the fridge compartment temperature is set.

8. Economy mode indicator

Indicates that the refrigerator operates in energy saving mode. This display shall be activated if the freezer compartment temperature is set to -18°C.

9. Vacation function indicator

Indicates that vacation is activated.

Freezing fresh food

- + It must be preferred to wrap or cover the food before placing them in the refrigerator.
- + Hot food must cool down to the room temperature before putting them in the refrigerator.
- + The food stuff that you want freeze must be fresh and in good quality.
- + Food stuff must be divided into portions according to the family' daily or meal based consumption needs.

+ The food stuff must be packaged in an airtight manner to prevent them from drying even if they are going to be kept for a short time.

+ Materials to be used for packaging must be tear-proof and resistant to cold, humidity, odor, oils and acids and they must also be airtight. Moreover, they must be well closed and they must be made from easy to use materials that are suitable for deep freeze usage.

+ Frozen food must be used immediately after they are thawed and they should never be re-frozen.

+ Please observe the following instructions to obtain the best results.

1. Do not freeze too large quantities of food at one time. The quality of the food is best preserved when it is frozen right through to the core as quickly as possible.

2. Placing warm food into the freezer compartment causes the cooling system to operate continuously until the food is frozen solid.

3. Take special care not to mix already frozen food and fresh food.


+ Maximum frozen food storage volume is achieved without using the drawers and the upper shelf cover provided in the freezer compartment. Energy consumption of your appliance is declared while the freezer compartment is fully loaded on shelves without the use of the drawers and upper shelf cover.

+ If there is a power failure do not open the freezer door. Even if the power failure lasts up to the "Temperature Increasing Time" indicated in the "Technical specifications of your refrigerator" section, frozen food will not be affected. In case the failure lasts longer, the food must be checked and when necessary, must be consumed immediately or must be frozen after cooked.

+ Please pay attention to the expiry date, maximum allowed storage period and recommended storage temperature of food stuffs when purchased. If expiry date is passed, do not consume

Freezer Compartment Setting	Fridge Compartment Setting	Remark
-18° C/4° F	4° C/40° F	This is the normal recommended setting.
-20/-4°F-22/-6°F or -24° C/-11°F	4° C/40° F	These setting are recommended when the ambient temperature exceeds 30 °C/86°F
Quick Freeze	4° C/40° F	Use when you wish to freeze your food in a short time. Your product will return to its previous mode when the process
-18° C/4° F or colder	2° C/37° F	Use these setting if you think that your fridge compartment is not cold enough because of hot ambient conditions or frequent opening and closing of the door

Recommendations for preservation of frozen food

+ Prepacked commercially frozen food should be stored in accordance with the frozen food manufacturer's instructions for a  (4 star) frozen food storage compartment.

+To ensure that the high quality achieved by the frozen food manufacturer and the food retailer is maintained. the following should be remembered:

- 1.Put packages in the freezer as quickly as possible after purchase.
- 2.Ensure that contents are labeled and dated.
- 3.Do not exceed "Use By". "Best Before" dates on the packaging.

Defrosting

The freezer compartment defrosts automatically.

Placing the food

Freezer compartment shelves	Various frozen food such as meat, fish, ice cream, vegetables and etc.
Egg tray	Egg
Fridge compartment shelves	Food in pans, covered plates and closed containers
Fridge compartment door shelves	Small and packaged food or drinks (such as milk, fruit juice and beer)
Crisper	Vegetables and fruits
Freshzone compartment	Delicatessen products (cheese, butter, salami and etc.)

Deep-freeze information

Food must be frozen as rapidly as possible when they are put in a refrigerator in order to keep them in good quality.

It is possible to keep the food for a long time only at -18°C or lower temperatures.

You can keep the freshness of food for many months (at -18°C or lower temperatures in the deep freeze).

WARNING!

- + Food stuff must be divided into portions according to the family's daily or meal based consumption needs.
- + Foodstuff must be packaged in an airtight manner to prevent them from drying even if they are going to be kept for a short time.
- + Materials necessary for packaging:
 - + Cold resistant adhesive tape
 - + Self adhesive label
 - + Rubber rings
 - + Pen

Materials to be used for packaging the foodstuff must be tear-proof and resistant to cold, humidity, odor, oils and acids.

Foodstuff to be frozen should not be allowed to come in contact with the previously frozen items to prevent their partial thawing.

Frozen food must be used immediately after they are thawed and they should never be re-frozen.

Fan


Fan is designed to ensure homogeneous distribution and circulation of the cold air inside your refrigerator.

Operation time of the fan may vary depending on the properties of your product.

While the fan works only with the compressor in some products, the control system determines its operation time in some products in accordance with the cooling requirement.

Description and cleaning of odor filter: optional *

Odour filter prevents unpleasant odor build-up in your refrigerator. Pull the cover into which the odour filter is installed downwards from the front section and remove as illustrated. Leave the filter under sunlight for one day. Filter will be cleaned during this time. Install the filter back to its place. Odour filter must be cleaned once in a year.



Chiller compartment (This feature is optional)

Use this compartment to store delicatessen that shall be stored in a lower temperature or meat products that you will consume in a short time.

Chiller compartment is the coolest place in your refrigerator where you can keep dairy products, meat, fish and poultry under ideal storage conditions. Fruits and vegetables should not be stored in this compartment.


Crisper

Crisper of the product is designed specially to keep the vegetables fresh without losing their humidity.

For this purpose, cool air circulation is intensified around the crisper in general.

Reversing the doors

Proceed in numerical order .



Maintenance and cleaning

Never use gasoline, benzene or similar substances for cleaning purposes.

We recommend that you unplug the appliance before cleaning.



Never use any sharp abrasive instrument, soap, household cleaner, detergent and wax polish for cleaning.

Use lukewarm water to clean the cabinet of your refrigerator and wipe it dry. (Use a damp cloth wrung out in a solution of one teaspoon of bicarbonate of soda to one pint of water to clean the interior and wipe it dry.)

Make sure that no water enters the lamp housing and other electrical items.

If your refrigerator is not going to be used for a long period of time, unplug the power cable, remove all food, clean it and leave the door ajar. (i) check door seals regularly to ensure they are clean and free from food particles.

To remove door racks, remove all the contents and then simply push the door rack upwards from the base.

Never use cleaning agents or water that contain chlorine to clean the outer surfaces and chromium coated parts of the product. Chlorine causes corrosion on such metal surfaces.

Do not use sharp, abrasive tools, soap, household cleaning agents, detergents, kerosene, fuel oil, varnish etc. to prevent removal and deformation of the prints on the plastic part.

Use lukewarm water and a soft cloth for cleaning and then wipe it dry.

Avoiding bad odours Materials that may cause odour are not used in the production of our refrigerators. However, due to inappropriate food preserving conditions and not cleaning the inner surface of the refrigerator as required can bring forth the problem of odour. Pay attention to following to avoid this problem:

- + Keeping the refrigerator clean is important. Food residuals, stains, etc. can cause odour. Therefore, clean the refrigerator with carbonate dissolved in water every 15 days. Never use detergents or soap.
- + Keep the food in closed containers. Microorganisms spreading out from uncovered containers can cause unpleasant odours.
- + Never keep the food that have expired best before dates and spoiled in the refrigerator

Protection of plastic surfaces

Do not put the liquid oils or oil-cooked meals in your refrigerator in unsealed containers as they damage the plastic surfaces of your refrigerator.

In case of spilling or smearing oil on the plastic surfaces, clean and rinse the relevant part of the surface at once with warm water.

Troubleshooting

Please review this list before calling for service. It will save your time and money. This list includes frequent complaints that are not arising from defective workmanship or material usage. Some of the features described here may not exist in your product.

The refrigerator does not operate.

- + The plug is not inserted into the socket correctly. >>>Insert the plug into the socket securely.
- + The fuse of the socket which your refrigerator is connected to or the main fuse have blown out.>>Check the fuse.

Condensation on the side wall of the fridge compartment (MULTIZONE, COOL CONTROL and FLEXI ZONE).

- + Door has been opened frequently. >>>Do not open and close the door of refrigerator frequently.
- + Ambient is very humid. >>>Do not install your refrigerator into highly humid places.
- + Food containing liquid is stored in open containers. >>>Do not store food with liquid content in open containers.
- + Door of the refrigerator is left ajar. >>>Close the door of the refrigerator.
- + Thermostat is set to a very cold level. >>>Set the thermostat to a suitable level.

Compressor is not running

- + Protective thermic of the compressor will blow out during sudden power failures or plug-out plug-ins as the refrigerant pressure in the cooling system of the refrigerator has not been balanced yet. The refrigerator will start running approximately after 6 minutes. Please call the service if the refrigerator does not startup at the end of this period.
- + The fridge is in defrost cycle. >>>This is normal for a full-automatically defrosting refrigerator. Defrosting cycle occurs periodically.
- + The refrigerator is not plugged into the socket. >>>Make sure that the plug is fit into the socket.
- + Temperature settings are not made correctly. >>>Select the suitable temperature value.
- + There is a power outage. >>>Refrigerator returns to normal operation when the power restores.

The operation noise increases when the refrigerator is running.

- +The operating performance of the refrigerator may change due to the changes in the ambient temperature. It is normal and nota fault.

The refrigerator is running frequently or for a long time.

- + New product may be wider than the previous one. Larger refrigerators operate for a longer period of time.
- + The room temperature may be high. >>>!It is normal that the product operates for longer periods in hot ambient.
- + The refrigerator might be plugged in recently or might be loaded with food. >>>When the refrigerator is plugged in or loaded with food recently. it will take longer for it to attain the set

temperature. This is normal.

+ Large amounts of hot food might be put in the refrigerator recently. >>>Do not put hot food into the refrigerator. » Doors might be opened frequently or left ajar for a long time. >>>The warm air that has entered into the refrigerator causes the refrigerator to run for longer periods. Do not open the doors frequently.

+ Freezer or fridge compartment door might be left ajar. >>>Check if the doors are closed completely.

+ The refrigerator is adjusted to a very low temperature. >>>Adjust the refrigerator temperature to a warmer degree and wait until the temperature is achieved.

+ Door seal of the fridge or freezer may be soiled. worn out. broken or not properly seated.

>>>Clean or replace the seal. Damaged/broken seal causes the refrigerator to run for a longer period of time in order to maintain the current temperature.

Freezer temperature is very low while the fridge temperature is sufficient.

+ The freezer temperature is adjusted to a very low value. >>>Adjust the freezer temperature to a warmer degree and check.

Fridge temperature is very low while the freezer temperature is sufficient.

+ The fridge temperature is adjusted to a very low value. >>>Adjust the fridge temperature to a warmer degree and check.

Food kept in the fridge compartment drawers is frozen.

+ The fridge temperature is adjusted to a very high value. >>>Adjust the fridge temperature to a lower value and check.

The refrigerator is running frequently or for a long time.

+ The fridge temperature is adjusted to a very high value. >>> Fridge compartment temperature setting has an effect on the temperature of the freezer. Change the temperatures of the fridge or freezer and wait until the relevant compartments attain a sufficient temperature.

+ Doors are opened frequently or left ajar for a long time. >>> Do not open the doors frequently.

+ Door is ajar. >>> Close the door completely.

+ The refrigerator is plugged in or loaded with food recently. >>>This is normal. When the refrigerator is plugged in or loaded with food recently. it will take longer for it to attain the set temperature.

+ Large amounts of hot food might be put in the refrigerator recently. >>>Do not put hot food into the refrigerator.

Vibrations or noise.

+ The floor is not level or stable. >>> If the refrigerator rocks when moved slowly. balance it by adjusting its feet. Also make sure that the floor is strong enough to carry the refrigerator. and level.

+The items put onto the refrigerator may cause noise. >>> Remove the items on top of the refrigerator.

There are noises coming from the refrigerator like liquid flowing, spraying, etc.

+ Liquid and gas flows occur in accordance with the operating principles of your refrigerator. It is normal and not a fault.

Whistle comes from the refrigerator.

+ Fans are used in order to cool the refrigerator. It is normal and nota fault.

Condensation on the inner walls of refrigerator.

+ Hot and humid weather increases icing and condensation. It is normal and nota fault.

+ Doors are opened frequently or left ajar for a long time. Do not open the doors frequently. Close them if they are open.

+ Door is ajar. >>>Close the door completely.

Humidity occurs on the outside of the refrigerator or between the doors.

+ There might be humidity in the air; this is quite normal in humid weather. When the humidity is less, condensation will disappear.

Bad odour inside the refrigerator.

+ No regular cleaning is performed. >>>Clean the inside of the refrigerator regularly with a sponge, lukewarm water or carbonate dissolved in water.

+ Some containers or package materials may cause the smell. >>>Use a different container or different brand packaging material.

+ Food is put into the refrigerator in uncovered containers. >>>Keep the food in closed containers. Microorganisms spreading out from uncovered containers can cause unpleasant odours.

+ Remove the foods that have expired best before dates and spoiled from the refrigerator.

The door is not closing.

+ Food packages are preventing the door from closing. >>>Replace the packages that are obstructing the door.

+ The refrigerator is not completely even on the floor. >>>Adjust the feet to balance the refrigerator.

+ The floor is not level or strong. >>>Make sure that the floor is level and capable to carry the refrigerator.

Crispers are stuck.

+The food is touching the ceiling of the drawer. >>>Rearrange food in the drawer.



Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

Document generated by [ManualsFile](#)