


## Your new appliance









Get to know your appliance. You will find information on the control panel, the oven, types of heating and accessories.






1. Electronic clock
2. Function selector
3. Indicator light
4. Temperature selector

### Function selector

Use the function selector to set the heating function.

<b>Setting</b>	<b>Use</b>
 Off position	The oven is switched off.
 Top/bottom heating	For cakes, bakes and lean joints. Heat is emitted evenly from the top and bottom.
 Hot air	For cakes and pastries on one or two levels. The fan distributes the heat from the ring heating element in the back panel evenly around the cooking compartment.
 Hot air eco*	The fan distributes the heat from the ring heating element in the back panel evenly around the cooking compartment. Not recommended for desserts that need to rise.  With this heating function, the oven lighting remains switched off.
 Air recirculation	For cakes, pastries and fresh pizza on one or two levels. The fan distributes heat from the heating elements evenly around the cooking compartment.
 Pizza setting	Quick preparation of frozen products without preheating, e.g. pizza, chips or strudel. The bottom heating element and the ring heating element in the back panel heat up.
 Hot air grill	For baking or roasting meat, poultry and whole fish. The fan causes the hot air to circulate around the dish.
 Full-surface grill	For grilling steaks, sausages, toast and pieces of fish. The whole area below the grill element becomes hot.

\* Heating function used to determine the energy efficiency class in accordance with EN 60350-1.

Setting	Use
 Centre-area grill	For grilling small amounts of steak, sausages, toast and pieces of fish. The centre part of the grill heating element becomes hot.
 Bottom heating	For extending the cooking time. The heat is emitted only from below.
 Lighting	The oven lighting is switched on.

Note: When you set the heating function, the oven light in the cooking compartment switches on.

Note: With the "Hot air eco" heating function, the oven lighting remains switched off.

### Temperature selector

- Set the temperature or grill setting using the temperature selector.

Setting	Description	
	Off position	The oven does not heat up.
50-260	Temperature range	The temperature in the cooking compartment in °C.

- The indicator light is lit when the oven is heating up. It goes out during pauses in heating.

### The electronic clock

- You can use the electronic clock to control your oven. You can therefore preselect, for example, the time at which the oven is to switch on or at which time the automatic timer is to end the baking or cooking process. The electronic clock can also be used as a timer.



### Function buttons for the electronic clock

Symbol	Meaning	Use
⌚	Electronic clock	Sets the cooking time or the time
-	Minus	Reduces the cooking time or the time
+	Plus	Increases the cooking time or the time

## Before using the oven for the first time

- In this section, you can find out what you must do before using your appliance to prepare food for the first time. Read the Safety information section beforehand.
- Remove the appliance packaging and dispose of it appropriately

## Setting the clock

After the appliance has been connected to the mains or after a power cut, three zeros and the "A" symbol flash on the display.

1. Press the ⌚ button until the dot flashes on the display.
2. Set the current time with the "+" and "-" buttons. After seven seconds, the time that has been set is adopted.

Note: To change the set time, press the "+" and "-" buttons until the dot flashes on the display. Then set the current time with the "+" and "-" buttons.

## **Baking out the oven**

### **Precleaning the oven**

1. Remove the accessories and the hook-in racks from the cooking compartment.
2. Completely remove any leftover packaging, e.g. small pieces of polystyrene, from the cooking compartment.
3. Some parts are covered with a protective film. Remove this scratch protection film.
4. Clean the outside of the appliance with a soft, damp cloth.
5. Clean the cooking compartment with hot soapy water.

### **Heating up the oven**

To remove the new cooker smell, heat up the oven when it is empty and closed.

1. Turn the function selector to the Top/bottom heating operating mode.
2. Turn the temperature selector to the maximum temperature.
3. Switch the oven off after 40 minutes.

Note: When the appliance is heating up for the first time, you may hear crackling noises coming from the oven.

### **Recleaning the oven**

1. Clean the cooking compartment with hot soapy water.
2. Refit the hook-in racks.

## **Cleaning the accessories**

- Before using the accessories, clean them thoroughly using a cloth and warm soapy water.

## **How to operate your oven**

### **Pop-out operating controls**

- The function selector and the temperature selector can be popped out. Press the operating control in question to pop it in or out.

### **Switching on the oven**

1. Use the function selector to set the heating function. An acoustic signal sounds.
2. Use the temperature selector to set the temperature.

The oven begins to heat up

## Switching off the oven

- Turn the function selector and temperature selector to the off position.

## Changing settings



- The heating function and temperature or grill setting can be changed at any time using their respective selectors.

## Heating up

- To heat up the cooking compartment as quickly as possible, use the "Circulated air" heating function. If the set temperature has been reached (indicator light has gone out), set the required heating function.


## Operating the electronic clock

In addition to the clock time and remaining time, the following symbols may appear on the display

Symbol	Meaning
•	Dot between the displayed hours and minutes. Flashes when it is possible to set the clock time.
	Timer Displays the operating statuses for the timer.
A	Automatic mode Displays the operating statuses for Automatic mode.
	Operating readiness If this symbol is displayed, the oven is ready to use.

## Setting the time on the clock



After the appliance has been connected to the mains or after a power cut, three zeros and the "A" symbol flash on the display.

1. Press the  button until the dot flashes on the display. Set the current time with the "+" and "-" buttons. After seven seconds, the time that has been set is adopted.




Note: To change the set time, press the "+" and "-" buttons until the dot flashes on the display. Then set the current time with the "+" and "-" buttons.

## Setting the timer



The timer has no influence on the functions of the oven. The duration of the timer can be set to between 1 minute and 23 hours and 59 minutes.

1. Press the  button until the  symbol flashes on the display and three zeros are displayed.
2. Set the required cooking time with the "+" and "-" buttons. An audible signal sounds once the time has elapsed.

#### Notes


- To change the remaining time, press the  button until the  symbol flashes on the display. Then change the remaining time with the "+" and "-" buttons.
- To cancel the setting, press the  button until the symbol flashes on the display. Then press the "+" and "-" buttons at the same time.

#### Switching off the acoustic signal

- Press the "" button until the  symbol disappears.
- After seven minutes, the signal switches off automatically.

#### Changing the audible signal




Three different audible signals are available.

1. Press the "+" and "-" buttons simultaneously.
2. Press the  button. The current audible signal is shown in the display panel, e.g. "Tone 1".
3. Press the "-" button to select a different audible signal.


#### Setting the automatic timer


The electronic clock can be used to switch the oven on or off automatically

##### Automatic switch-off

1. Press the  button until the  symbol flashes on the display and three zeros are displayed.
2. Press the  function button again until "dur" and "0.00" flash alternately on the display panel and the "A" symbol flashes. et the cooking time
3. e with the "+" and "-" buttons. The cooking timSe can be set to between 1 minute and 10 hours.
4. Set the required heating function and temperature. The oven starts and the A symbol and the current clock time appear on the display panel.






#### The cooking time has elapsed

An audible signal sounds, the  symbol disappears from the display panel and the A symbol flashes.


1. Switch off the temperature selector and function selector.
2. Press the 0 button until the  symbol appears. The oven switches back to manual mode.



### Automatic switch-on and switch-off

Baking or roasting starts for the set duration at a later time which you chose.

1. Press the  button until the  symbol flashes on the display and three zeros are displayed.
2. Press the  function button again until "dur" and "0.00" flash alternately on the display panel and the "A" symbol flashes. The current time may be 17:30, for example.
3. Set the cooking time (e.g. 1 hour) with the "+" and "-" buttons. The cooking time can be set to between 1 minute and 10 hours.
4. Press the  function button again until "End" and the switchoff time "18:30" (i.e. the current time plus the set cooking time) flash alternately on the display panel.
5. Set the switch-off time (e.g. 19:30) using the "+" and "-" buttons. The switch-off time can be set to up to 23 hours and 59 minutes.
6. Set the required heating function and temperature. The  symbol disappears from the display panel. In this example, the oven starts at 18:30 and switches off again at 19:30.

### The cooking time has elapsed



An audible signal sounds, the  symbol disappears from the display panel and the A symbol flashes.

1. Switch off the temperature selector and function selector.
2. Press the  button until the  symbol appears. The oven switches back to manual mode.





### Displaying and changing set values

The set values and the remaining time for the various operating modes of the electronic clock can be viewed and changed on the display panel at any time.

#### Displaying the remaining time for the timer

- Press the  button until the  symbol flashes on the display.
- The remaining time appears on the display and can be changed with the "+" and "-" buttons.

Displaying and changing the cooking time and switch-off time.

1. Press the  button until the  symbol flashes on the display panel.
2. Press the  button again until "dur" and the remaining cooking time flash alternately on the display panel and the A symbol flashes. The cooking time can be changed with the "+" and "-" buttons. Press the "+" and "-" buttons at the same time to switch off the automatic timer.
3. Press the  button again until "End" and the set switch-off time flash alternately on the display panel.

The switch-off time can be changed with the "+" and "-" buttons. Press the "+" and "-" buttons at the same time to switch off the automatic timer.

## Care and cleaning

With good care and cleaning, your oven will remain clean and fully-functioning for a long time to come. Here we will explain how to maintain and clean your oven correctly

Notes

- Slight differences in the colours on the front of the oven are caused by the use of different materials, such as glass, plastic and metal.
- Shadows on the door panel which look like streaks, are caused by reflections made by the oven light.
- Enamel is baked on at very high temperatures. This can cause some slight colour variations. This is normal and does not affect their function. The edges of thin trays cannot be completely enamelled. As a result, these edges can be rough. This will not impair the anti-corrosion protection.

Risk of electric shock! Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.

Risk of burns! The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.

## Cleaning agents

Damage to the various different surfaces caused by using the wrong cleaning agent can be avoided by observing the following instructions.

Do not use

- harsh or abrasive cleaning agents
- cleaning agents with high concentrations of alcohol

- hard scouring pads and sponges
- high-pressure cleaners or steam cleaners.

Wash new sponge cloths thoroughly before use.

Area	Cleaning agents
Appliance exterior	<p>Hot soapy water:</p> <p>Clean with a dish cloth and dry with a soft cloth. Do not use glass cleaners or glass scrapers.</p>
Stainless steel	<p>Hot soapy water:</p> <p>Clean with a dish cloth and dry with a soft cloth. Remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately. Corrosion can form under such residues.</p> <p>Special stainless steel cleaning products suitable for hot surfaces are available from our after-sales service or from specialist retailers. Apply a very thin layer of the cleaning product with a soft cloth.</p>
Aluminium and plastic	<p>Glass cleaner:</p> <p>Clean with a soft cloth.</p>
Enamel surfaces (smooth surfaces)	<p>To facilitate cleaning, you can switch on the interior lighting and detach the appliance door if necessary. Apply commercially available washing-up liquid or a vinegar solution with a soft, damp cloth or chamois; dry with a soft cloth. Loosen baked-on food residues with a damp cloth and detergent. We recommend using oven cleaning gel if the oven is very dirty. This can be applied to the affected area. Leave the cooking compartment open after cleaning to allow it to dry.</p>
Self-cleaning surfaces (rough surfaces)	<p>Please see the notes in section: Selfcleaning surfaces</p>
Door panels	<p>Glass cleaner:</p> <p>Clean with a soft cloth. Do not use a glass scraper.</p>
Glass cover for the oven light bulb	<p>Hot soapy water: Clean with a dish cloth.</p>
Seal Do not remove.	<p>Hot soapy water: Clean with a dish cloth. Do not scour.</p>
Shelves	<p>Hot soapy water: Soak and clean with a dish cloth or brush.</p>

Accessories

Hot soapy water: Soak and clean with a dish cloth or brush.

## Catalytic cooking compartment panels

- The catalytic cooking compartment panels are coated with selfcleaning enamel.
- The surfaces clean themselves while the oven is in operation. Larger splashes will only be removed after the oven has been used several times.

## Self-cleaning surfaces

- The side walls are covered with catalytic panelling. Never clean these surfaces with oven cleaner. Slight discolouration of the enamel does not affect automatic self-cleaning


## Removing and installing the door panels

To facilitate cleaning, you can remove the glass panels from the oven door.

### Removing the door panels


1. Open the oven door fully.
2. Lock both hinges on the left and right using the locking pin.

Note: The locking pins must be fully inserted into the holes in the hinges.




3. Lift the bottom of the inner panel slightly until the fastening pins come out of the holder (1).
4. Carefully lift the top of the inner panel until the fastening pins come out of the holder (2).

Caution! When lifting the inner panel, the middle panel may stick to the inner panel. Make sure that the middle panel does not fall.




5. Remove the inner panel.

6. Remove the middle panel.



Note: The middle panel is kept in place with rubber bushings rather than retaining pins.



Clean the panels with glass cleaner and a soft cloth.

Risk of injury! Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.

### Fitting the door panels

1. Reinsert the middle panel. Notes
  - If the Low-E symbol can be read, the middle panel is inserted correctly.
  - Make sure that the panel is seated correctly. All rubber mounts must lay flat against the outer panel.
2. Reinsert the inner panel. Note: All four fastening pins must engage in the holders provided for them.
3. Remove the locking pins and close the oven door.

### Removing and fitting the appliance door


If the oven is very heavily soiled, the oven door can be removed for easier cleaning. Normally, however, this is not necessary

#### Removing the appliance door

1. Open the oven door fully.
2. Lock both hinges on the left and right using the locking pin (a).

Note: The locking pins must be fully inserted into the holes in the hinges.

3. Grip the oven door on either side with both hands and close the oven door by approx. 30° (b)




4. Raise the oven door slightly and pull it out.

Note: Do not fully close the oven door. The hinges could become bent and the enamel could be damaged.

## Fitting the appliance door

1. Grip the oven door on either side with both hands.
2. Slide the hinges into the slots in the oven (a).

Note: The notch below the hinges must engage into the frame of the oven (b).



3. Lower the door downwards.
4. Remove the locking pins.

Risk of injury! Do not reach into the hinge if the oven door falls out unintentionally or a hinge snaps closed. Call after-sales service.


## Removing and inserting the hook-in racks

You can remove the hook-in racks for easier cleaning.

### Removing the hook-in racks

The hook-in racks are each fixed to the side panels of the cooking compartment at three points.

1. Grip the front of the hook-in rack and pull it to the middle of the cooking compartment.  
The front hook of the hook-in rack will release from the hole.
2. Fold out the hook-in rack further and pull it from the rear holes of the side panel.
3. Hold the catalytic cooking compartment panel in place.
4. Remove the hook-in rack from the cooking compartment



### Inserting the hook-in rack

1. Hold the catalytic cooking compartment panel in place.
2. Insert the hooks of the hook-in rack into the rear holes in the side panel.
3. Press the front hook of the hook-in rack into the hole.

### Troubleshooting

Malfunctions often have simple explanations. Please read the following notes before calling the aftersales service.

<b>Problem</b>	<b>Possible cause</b>	<b>Notes/remedy</b>
The appliance does not work.	Circuit breaker faulty.	Look in the fuse box and check that the circuit breaker for the cooker is in working order.
	Power cut	Check whether the kitchen light works.
The oven can- The electronics not be switched are faulty. off.		Switch off the circuit breaker. Contact the aftersales service.
A beep sounds every second	The temperature probe is faulty.	Turn the function selector to the Off position.
A beep sounds twice per second.	The temperature in the oven interior is too high.	If the beeping persists when setting a new heating function, switch off the appliance and contact the aftersales service.
The clock display flashes.	Power cut	Reset the clock.
The oven does not heat up	Circuit breaker faulty	Check the circuit breaker and replace if necessary
	The function selector has not been set	Set the function selector.
The door glass is broken.		Switch off the appliance. Contact the after-sales service.
Fruit juice or albumen stains on enamelled surfaces	Moist cake or meat juices.	Harmless change in the enamel, cannot be removed


Risk of electric shock! Incorrect repairs are dangerous. Repairs may only be carried out by one of our trained after-sales engineers. Incorrect repairs may result in significant risk to the user.

### **Replacing the oven light bulb**

If the oven light bulb fails, it must be replaced. Replacement heat-resistant bulbs can be obtained from the after-sales service or from specialist retailers. Please specify the E number and FD number of your appliance. Do not use any other type of bulb.

Risk of electric shock! When replacing the cooking compartment bulb, the bulb socket contacts are live. Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

1. Allow the cooking compartment to cool down.
2. Open the appliance door.
3. Place a tea towel in the cooking compartment to prevent damage.
4. Remove the hook-in racks.
5. Remove the glass cover. To do this, open the glass cover at the front with your hand. Should you experience difficulties removing the glass cover, use a spoon to help.
6. Remove the oven light bulb.



7. Replace the oven light bulb with a bulb of the same type:
  - Voltage: 230 V;
  - Power: 40 W;
  - Fitting: G9;
  - Temperature resistance: 300 °C
8. Refit the glass cover for the oven light bulb.
9. Refit the hook-in racks.
10. Remove the tea towel.
11. Switch the circuit breaker back on.
12. Check that the oven lighting is working again.

## Tips for using your appliance

Here you will find a selection of tips on ovenware and preparation methods.

## Notes

- Use the accessories provided. Additional accessories may be obtained as special accessories from specialist retailers or from the after-sales service. Before using the oven, remove any unnecessary accessories and ovenware from the cooking compartment.
- Always use an oven cloth or oven gloves when taking accessories or cookware out of the cooking compartment.

## Baking

### Baking tins

- Use light-coloured baking tins and trays wherever possible.
- Always place the baking tins on the middle of the baking and roasting wire rack.

### Baking tips

How to establish whether sponge cake is baked through.	Approx. 10 minutes before the end of the baking time stated in the recipe, insert a cocktail stick into the cake at its deepest point. If no cake crumbs stick to the wood, the cake is ready.
The cake collapses.	Use less fluid next time or set the oven temperature 10 degrees lower. Note the stirring times indicated in the recipe.
The cake has risen high in the middle and less around the edges.	Do not grease the sides of the springform cake tin. After baking, carefully loosen the cake using a knife.
The cake is too dark on the top.	Place it lower in the oven, select a lower temperature and bake the cake a little longer.
The cake is too dry.	When it is done, make small holes in the cake using a cocktail stick. Then drizzle fruit juice or an alcoholic drink over it. Next time, set the temperature 10 degrees higher and reduce the baking time.
The bread or cake (e.g. cheesecake) looks good but is sticky on the inside (soggy with wet streaks).	Next time, use less liquid and bake at a lower temperature for slightly longer. For cakes with a moist topping, bake the base first. Sprinkle it with almond bread crumbs and then place the topping on top. Take care to follow recipe and baking times.
The pastries are not evenly browned.	Select a slightly lower temperature to ensure that the cake is baked evenly. Excess greaseproof paper can affect the air circulation. Always use greaseproof paper to suit the size of the baking tray.
The bottom of a fruit flan is too light.	Place the cake one level lower the next time.
The fruit juice overflows.	Next time, use the deeper universal pan, if you have one.
Small baked items made out of yeast dough stick to one another during baking.	There should be a gap of approx. 2 cm around each item. This gives enough space for the baked items to expand and turn brown on all sides.
Condensation forms when you bake moist cakes.	Baking may create water vapour, which escapes above the door. The steam may settle and form water droplets on the control panel or on the fronts of adjacent units. This is a natural process.

## Roasting and grilling

### Ovenware

- You may use any heatresistant ovenware. Always place the ovenware in the middle of the wire rack. The enamelled baking tray is also suitable for large roasts.

## Roasting tips

- A lower temperature produces more even browning.
- Depending on the size of the joint, add 2 or 3 tablespoons of liquid to lean meat and 8 to 10 tablespoons of liquid to pot roasts.
- When cooking duck or goose, pierce the skin on the underside of the wings to allow the fat to run out.
- Poultry will turn out particularly crispy and brown if you baste it towards the end of the roasting time with butter, salted water or orange juice.
- Turn pieces of meat halfway through the cooking time.
- When the roast is ready, turn off the oven and allow it to rest for an additional 10 minutes. This will allow the meat juices to distribute themselves better inside the roast.
- When roasting large pieces of meat, you may find that the amount of steam and condensation on the oven door is more than usual. This is a normal occurrence which has no effect on the oven's performance. Once roasting is complete, dry the oven door and window with a cloth.
- If you are roasting on the wire rack, insert the enamelled baking tray into shelf position 1 to collect the drips of fat.

## Grilling tips

- If possible, grill items should be of equal thickness. They should be at least 2 to 3 cm thick. This ensures that they brown evenly while also remaining succulent.
- Place the food to be grilled in the centre of the wire rack. Pour a little water into the enamelled baking tray and insert this into the shelf position underneath the grill to collect the drips of fat. Never place it on the cooking compartment floor.
- Drizzle some oil over the food to be grilled before you place it on the wire rack under the grill.
- If the food to be grilled is thin, turn it over halfway through grilling; if it is thick, turn it over several times during grilling. Use tongs when turning the food to avoid piercing it and, in the case of meat, to keep the meat juices inside the meat.
- Dark meats such as lamb and beef brown better and more quickly than light meats such as pork and veal.

## Roasting tips

How can you tell when the roast is ready?	Use a meat thermometer (available from specialist retailers) or carry out the "spoon test". Press down on the roast with a spoon. If it feels firm, it is ready. If the spoon can be pressed in, it needs to be cooked for a little longer.
The roast is too dark and the crackling is burnt in places.	Check the shelf position and temperature.
The roast looks good but the juices are burnt	Next time, use a smaller roasting dish and add more liquid.
The roast looks good, but the juices are too clear and watery.	Next time, use a larger roasting dish and add less liquid.

### Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.