

## INSTALLATION INSTRUCTIONS


### Location

This machine must not be installed and operated on a plinth.

### Levelling the machine

It is IMPORTANT to level the machine to ensure good spin performance, and to minimise noise, vibrations and wear and tear on the washer.

1. Before positioning the machine in its final position, check that the machine is level, front to back and side to side.
2. Manoeuvre the product into its final position (we suggest a minimum clearance of 20mm each side).
3. Use a spirit level to check that the machine is correctly level. If needed, pull the machine out. Loosen the lock nut using the spanner provided and wind the feet up or down to correctly level the machine.
4. Using the spanner provided, tighten the lock nuts against the base of the machine to lock the feet in position.




Locking the feet

### Connecting to the water supply

#### Inlet hose(s)


1. Connect the straight end(s) of the inlet hose(s) to the tap(s) and the elbow end(s) to the corresponding machine inlet valve(s). If present, the hot valve is colour coded orange. Tighten the inlet hose end(s) by hand until the hose seal just makes contact with the tap sealing face and then tighten a further half-turn. Make sure there are no kinks in the hose(s).
2. Turn the tap(s) on and check for leaks. Check for leaks again after 24 hours.



## Draining

Drain hose placement in a stand pipe or tub


1. To guide the drain hose over the tub or standpipe the hose guide must be fitted to the drain hose. The height of the standpipe or tub should be between 800 – 1200mm.
2. Secure the hose guide so it cannot become dislodged from the standpipe or tub.
  - If the drain hose is placed on the ground or if the standpipe or tub is less than 800mm high, the washing machine will continuously drain while being filled (siphon).
  - Regularly check that your standpipe or tub is free from lint or other obstructions, which may affect how your machine works or may cause flooding.



## Attaching drain hose to spigot

1. Guide drain hose through hose guide.
2. Secure hose guide to back wall of cupboard using a screw. The height of the drain hose should be between 500 – 800mm from ground level.
3. Attach drain hose to spigot and secure using a hose clamp ensuring the blanking insert is cleared from spigot.
4. Check for leaks.
  - The drain hose should be checked from time to time and replaced if any damage (eg wear, cuts, bulges, kinks, leaks, etc) is found. Do not bend the drain hose sharply, as this may cause it to split.

- In multi-storey apartments or any upper floor, the machine should be installed on a floor equipped with a drain.
- Draining must comply with local by-laws.



### Electrical connection

1. This appliance must be connected to a 220V – 240V, 50Hz, sinusoidal, minimum 10A electrical supply.
2. Uncoil the power cord, remove and discard the plastic pin cover and plug into a wall socket.
3. Connect the appliance to an earthed outlet protected by a fuse of suitable capacity.
  - Check the power cord for damage and make sure it is not squashed or twisted when installing the washer.
  - Always remove the power cord from a socket by the plug, not by the cord.

SPARE PARTS*	PART NO.
Hose inlet long (2m)	422680P
Hose inlet large bore	426123P
Drain hose extension (not suitable for attaching to a spigot)	425627P

### Completing the installation

#### Installation test cycle

Do this before you wash any items in your washer. This is to check that your washer is installed correctly and that it is functioning correctly prior to use.

1. Turn your washer on by pressing 'Power'.
2. Select the 'Quick' or 'Super Quick' cycle. Ensure the drum is empty and the door closed.
3. Touch the ▶|| button. The machine will start to fill.
  - Observe the machine for any problems (eg leaking from the hose(s), excess noise or vibrations).

- The washer will beep and display any faults on the screen if there are any problems. Refer to 'Before you call for service' at the back of this book.

4. Wait until you see water in the bottom of the drum.

5. Touch ▶|| to stop the cycle, then press 'Power' to turn the machine off.

6. Press 'Power' again, select the 'Spin' cycle and touch ▶||.

- Check the drain hose is firmly secured to the standpipe or tub, or spigot.
- Observe that the machine pumps out the water, and spins.

If there are any problems, you must address these before proceeding with normal use. The washer will automatically turn off at the end of the cycle if there are no problems.

## BEFORE YOUR FIRST WASH

**Before you start, it is a good idea to go through the following checklist:**

1. Have the packaging and transit bolts been removed?
2. Is the drain hose threaded through the 'U bend' (with no more than 20mm extended) and hooked into your standpipe or tub, or attached to a spigot?
3. Is the hot hose connected to the hot valve (colour-coded orange, if present)? Is the cold hose connected to the cold valve (colour-coded white)? Have the taps been turned on?
4. Is the machine correctly levelled, feet are locked and cabinet corners clear of the floor and walls?
5. Has the power cord been connected to an appropriate power supply and the power turned on?
6. Have you performed the installation test cycle?
7. We recommend you complete your first cycle with a half-load amount of detergent and without a load in order to remove any residues remaining in the machine from the manufacturing process.

## CONTROL PANEL

### SmartTouch™ Control Dial

The SmartTouch™ Control Dial provides easy and efficient wash cycle selection. As you rotate the dial, the icon of the wash cycle selected will be illuminated, along with the default settings for that cycle on the right side of the control panel.

### SmartTouch™ buttons

The smooth, easy clean buttons enable easy selection of options with lights clearly showing the selections you are making.

## Digital display screen

The digital display screen provides feedback on how long the wash cycle has to go. If you have programmed a 'Delay Start', the time remaining until the cycle will start will be displayed here, along with any messages to help you with the overall running of your washer (eg user warnings).

## Time to go

Your washer displays approximately how many minutes the cycle you are running has remaining, so that you can tell at a glance when your washing will be finished.

Please be aware that a number of factors can influence the overall cycle time, eg the water flow rate, water pressure, whether hot water is being used from the tap or the water is heated by the internal heater, load size, cycle and option selections. Therefore cycle times will vary. Unexpected events in a wash cycle (eg out of balance, oversudsing) can lengthen the cycle time.

## Progress lights

The progress lights indicate what part of the cycle the washer is currently on (wash, rinse or spin). All three lights are on at the beginning of the cycle. The light for the current part of the cycle flashes, and each one goes out when that part of the cycle is complete.


## Keylock mode

Keylock can be used to lock the buttons on your washer. This will avoid accidental button pushes. For more detail please refer to 'Wash cycle options'.

## Drum light (WH8560F, WH8060F models only)

Your machine has a drum light to help assist you when loading and unloading your washing machine. When you press 'Power', the LED light in the drum will turn on, after 2 minutes it will automatically turn off. At the end of the cycle, the drum light will turn on again for 5 minutes to help facilitate unloading.

## WH8560F and WH8060F models



### 1 POWER

Press to turn the washer ON/OFF.

## **2 Keylock**

Touch to disable all buttons on the display panel, except the 'Power' button. This prevents accidental button presses.

## **3 SmartTouch™ Control Dial**

Rotate to select your desired wash cycle.

- Red LED illuminates to indicate the selected wash cycle.

## **4 Digital display screen**

Shows the following:

- 'Time to go' – the remaining time in the cycle that is currently running.
- Delayed start time of wash cycle.
- Notifications if an error is detected or a warning is necessary.

## **5 Progress lights**

Indicate the current status of the wash cycle.

- All lights are illuminated at the start of the wash cycle.
- The light of the current status flashes, and then turns off once completed.

## **6 Delay Start**

Touch to increase or decrease the delay start time.

## **7 Time Saver**

Touch to turn Timer Saver on or off.

## **8 Wash Temp**

Touch to increase or decrease wash water temperature.

## **9 Spin Speed**

Touch to increase or decrease washer spin speed.

## **10 Options**

Touch to select Eco Rinse, Wrinkle Free and/or Soak.

## **11 Wash Boost**

Touch to select Pre Wash or Rinse+.


## **12 Add a Garment**

Touch to interrupt the wash part of the cycle to add or remove a garment.

## **13 START/PAUSE**

Touch to start or pause the selected wash cycle.

## WH8560P, WH8060P and WH7560P models



### 1 POWER

Press to turn the washer ON/OFF.

### 2 Keylock

Touch to disable all buttons on the display panel, except the 'Power' button. This prevents accidental button presses.

### 3 SmartTouch™ Control Dial

Rotate to select your desired wash cycle.

- Red LED illuminates to indicate the selected wash cycle.

### 4 Digital display screen

Shows the following:

- 'Time to go' – the remaining time in the cycle that is currently running.
- Delayed start time of wash cycle.
- Notifications if an error is detected or a warning is necessary

### 5 Progress lights

Indicate the current status of the wash cycle.

- All lights are illuminated at the start of the wash cycle.
- The light of the current status flashes, and then turns off once completed.

### 6 Delay Start

Touch to increase or decrease the delay start time.

### 7 Wash Temp

Touch to increase or decrease wash water temperature.

### 8 Spin Speed

Touch to increase or decrease washer spin speed.

### 9 Soil Level

Touch to select the level of soil in your load.

## 10 Wash Boost

Touch to select Pre Wash or Rinse+.

## 11 Options

Touch to select Eco and/or Wrinkle Free.


## 12 Add a Garment

Touch to interrupt the wash part of the cycle to add or remove a garment.

## 13 START/PAUSE

Touch to start or pause the selected wash cycle.

## WH9060J, WH8560J, WH8060J and WH7560J models



### 1 POWER

Press to turn the washer ON/OFF.

### 2 Keylock

Touch to disable all buttons on the display panel, except the 'Power' button. This prevents accidental button presses.

### 3 SmartTouch™ Control Dial

Rotate to select your desired wash cycle.

- Red LED illuminates to indicate the selected wash cycle.

### 4 Digital display screen

Shows the following:

- 'Time to go' – the remaining time in the cycle that is currently running.
- Delayed start time of wash cycle.
- Notifications if an error is detected or a warning is necessary.

### 5 Progress lights

Indicate the current status of the wash cycle.

- All lights are illuminated at the start of the wash cycle.
- The light of the current status flashes, and then turns off once completed.

### **6 Delay Start**

Touch to increase or decrease the delay start time.

### **7 Wash Temp**

Touch to increase or decrease wash water temperature.

### **8 Spin Speed**

Touch to increase or decrease washer spin speed.

### **9 Wash Boost**

Touch to select Pre Wash or Rinse+.

### **10 Options**

Touch to select Eco.

### **11 START/PAUSE**

Touch to start or pause the selected wash cycle.

## **WASH CYCLES**

### **WH8560F and WH8060F models**

Your washer has a number of wash cycles to suit your laundering needs. Selecting the most appropriate cycle for each particular wash load will help ensure you get the best wash result.

CYCLE	DESIGNED FOR	DESCRIPTION	MAX. LOAD SIZE (KG)*	DEFAULT WASH TEMP. (°C)	MAX. WASH TEMP. (°C)	DEFAULT SPIN SPEED (RPM)	MAX. SPIN SPEED (RPM)
<b>Cottons**</b>	Normally soiled everyday cotton loads, eg whites.	A comprehensive cycle specifically designed for cottons.	8.5 or 8.0	40	90	1400	1400
<b>Everyday</b>	Mixed everyday items, eg towels, sheets, sweatshirts, t-shirts.	A cycle designed for mixed loads.	8.5 or 8.0	40	90	1400	1400
<b>Heavy</b>	Heavy soiled durable garments eg tea towels, rugby shorts.	A stronger, hotter wash for more durable items.	8.5 or 8.0	60	90	1400	1400
<b>Delicate</b>	Delicate, lightly soiled items, eg tops, blouses.	Gentler wash with more water to look after delicate items.	4	40	60	500	800
<b>Easy Iron</b>	Minimising creasing eg shirts, trousers.	Less spinning with 'Wrinkle Free' option to help minimise the need for ironing.	4	40	60	800	800
<b>Bulky</b>	Washing bulky items.	A warm, gentle wash and slow spin for special care of bulky items.	4	60	90	800	800
<b>Allergy</b>	Asthma sufferers and people with skin sensitivities.	Hot wash to kill dust mites and extra rinses to remove all traces of detergent.	8.5 or 8.0	60	90	1400	1400
<b>Wool***</b>	Machine washable woollen items.	Extra gentle wash action that complies with Woolmark Apparel Care criteria.	2	40	40	800	800
<b>Super Quick</b>	Freshening up small musty or lightly soiled items.	A quick cycle for small lightly soiled loads.	2	30	60	800	1400
<b>Sports</b>	Cotton/synthetic sports clothing.	A cycle tailored to washing sports type clothing.	4	40	40	1100	1400
<b>Rinse</b>	Items that require rinsing only.	Two rinses followed by a spin.	8.5 or 8.0	Cold	Cold	1400	1400
<b>Spin</b>	Spinning wet items.	Spin only.	8.5 or 8.0	n/a	n/a	1400	1400
<b>Drum Clean</b>	Maintaining the cleanliness of your washer.	A hot cycle to remove any residues inside the washer.	n/a	90	90	1400	1400

\*Depends on your model of washer (8.5kg or 8.0kg capacity).

\*\*'Cottons', '40°C', '1400 rpm', 'Eco Rinse' selected is the recommended water and energy saving cycle for normally soiled, everyday washing. WH8560F and WH8060F models

\*\*\*Woolmark Apparel Care – The wool wash cycle of this machine has been approved by The Woolmark Company for the washing of machine washable wool products provided that the products are washed according to the instructions on the garment label and those issued by the manufacturer of these washing machines M1528. Only the WH8560F and WH8060F models comply with Woolmark Apparel Care requirements.

### WH8560P, WH8060P and WH7560P models

Your washer has a number of wash cycles to suit your laundering needs. Selecting the most appropriate cycle for each particular wash load will help ensure you get the best wash result.

CYCLE	DESIGNED FOR	DESCRIPTION	MAX. LOAD SIZE (KG)*	DEFAULT WASH TEMP. (°C)	MAX. WASH TEMP. (°C)	DEFAULT SPIN SPEED (RPM)	MAX. SPIN SPEED (RPM)
<b>Cottons**</b>	Normally soiled everyday cotton loads, eg whites.	A comprehensive cycle specifically designed for cottons.	8.5, 8.0 or 7.5	40	90	1400	1400
<b>Everyday</b>	Mixed everyday items, eg towels, sheets, sweatshirts, t-shirts.	A cycle designed for mixed loads.	8.5, 8.0 or 7.5	40	90	1400	1400
<b>Heavy</b>	Heavy soiled durable garments eg tea towels, rugby shorts.	A stronger, hotter wash for more durable items.	8.5, 8.0 or 7.5	60	90	1400	1400
<b>Delicate</b>	Delicate, lightly soiled items, eg tops, blouses.	Gentler wash with more water to look after delicate items.	4	40	60	500	800
<b>Easy Iron</b>	Minimising creasing eg shirts, trousers.	Less spinning with 'Wrinkle Free' option to help minimise the need for ironing.	4	40	60	800	800
<b>Bulky</b>	Washing bulky items.	A warm, gentle wash and slow spin for special care of bulky items.	4	60	90	800	800
<b>Allergy</b>	Asthma sufferers and people with skin sensitivities.	Hot wash to kill dust mites and extra rinses to remove all traces of detergent.	8.5, 8.0 or 7.5	60	90	1400	1400
<b>Handwash</b>	Very delicate lightly soiled garments, eg woollens.	Very gentle wash action for extra special items.	2	30	40	500	500
<b>Quick</b>	Lightly soiled garments.	A quick cycle for lightly soiled loads.	4	40	60	800	1400
<b>Super Quick</b>	Freshening up small musty or lightly soiled items.	A quick cycle for small lightly soiled loads.	2	30	60	800	1400
<b>Rinse</b>	Items that require rinsing only.	Two rinses followed by a spin.	8.5, 8.0 or 7.5	Cold	Cold	1400	1400
<b>Spin</b>	Spinning wet items.	Spin only.	8.5, 8.0 or 7.5	n/a	n/a	1400	1400
<b>Drum Clean</b>	Maintaining the cleanliness of your washer.	A hot cycle to remove any residues inside the washer.	n/a	90	90	1400	1400

\*Depends on your model of washer (8.5kg, 8.0kg or 7.5kg capacity).

\*\*'Cottons', '40°C', '1400 rpm', 'Eco' selected is the recommended water and energy saving cycle for normally soiled, everyday washing.

### WH9060J, WH8560J, WH8060J and WH7560J models

Your washer has a number of wash cycles to suit your laundering needs. Selecting the most appropriate cycle for each particular wash load will help ensure you get the best wash result.

CYCLE	DESIGNED FOR	DESCRIPTION	MAX. LOAD SIZE (KG)*	DEFAULT WASH TEMP. (°C)	MAX. WASH TEMP. (°C)	DEFAULT SPIN SPEED (RPM)	MAX. SPIN SPEED (RPM)
Cottons**	Normally soiled everyday cotton loads, eg whites.	A comprehensive cycle specifically designed for cottons.	9.0 or 8.5 or 8.0 or 7.5	40	90	1200	1200
Everyday	Mixed everyday items, eg towels, sheets, sweatshirts, t-shirts.	A cycle designed for mixed loads.	9.0 or 8.5 or 8.0 or 7.5	40	90	1200	1200
Heavy	Heavy soiled durable garments eg tea towels, rugby shorts.	A stronger, hotter wash for difficult stains on durables.	9.0 or 8.5 or 8.0 or 7.5	60	90	1200	1200
Delicate	Delicate, lightly soiled items, eg tops, blouses.	Gentler wash with more water to look after delicate items.	4	40	60	500	800
Easy Iron	Minimising creasing eg shirts, trousers.	Less spinning to help minimise the need for ironing.	4	40	60	800	800
Quick	Lightly soiled garments.	A quick cycle for lightly soiled loads.	4	40	60	800	1200
Rinse	Items that require rinsing only.	Two rinses followed by a spin.	9.0 or 8.5 or 8.0 or 7.5	Cold	Cold	1200	1200
Spin	Spinning out wet items.	Spin only.	9.0 or 8.5 or 8.0 or 7.5	n/a	n/a	1200	1200
Drum Clean	Maintaining the cleanliness of your washer.	A hot cycle to remove any residues inside the washer.	n/a	90	90	1200	1200

\*Depends on your model of washer (9.0kg or 8.5kg or 8.0kg or 7.5kg capacity).

\*\*'Cottons', '40°C', '1200 rpm', 'Eco' selected is the recommended water and energy saving cycle for normally soiled, everyday washing.

## DETERGENT AND FABRIC SOFTENER



### Detergent type

Your washer requires low sudsing detergent to prevent oversudsing problems. Low sudsing detergent comes in powder, liquid or pod form and is labelled 'Front Loading', 'Low Suds', 'High Efficiency' or 'HE'.

Using top loading detergent in your front loader washer may lead to excessive suds formation, which will lengthen the cycle time as the machine waits for the suds to dissolve.

### Where do I put my detergent?


#### WH8560F, WH8060F, WH8560P, WH8060P and WH7560P models only

Liquid detergent is added to the main wash compartment on the left side of the dispenser drawer marked with a  . As the machine fills, water is flushed into this compartment and is mixed with the detergent, the detergent solution is then delivered into the drum. There may be a small volume of water left in the liquid detergent dispenser at the end of the cycle. This is normal.

#### Powdered detergent

If you wish to use powdered detergent, the liquid detergent compartment MUST be removed from the dispenser drawer. To do this firmly grasp and twist the left hand side of the internal

compartment and pull upwards **Ⓐ**. To replace the liquid detergent compartment slide it back into the drawer marked **Ⓘ** **ⓐ**. Press down in the middle until it clicks **ⓑ**.




*Detergent dispenser drawer*



*Removing the liquid detergent compartment*



*Replacing the liquid detergent compartment*



*Clicking in the liquid detergent compartment*


- If using liquid detergent ensure the liquid detergent compartment is installed.
- If using powder ensure the liquid detergent compartment has been removed.
- Ensure the detergent drawer is completely closed before starting the cycle.

**WH9060J, WH8560J, WH8060J and WH7560J models only**

**Powdered or liquid detergent**

Is added to the main wash detergent compartment on the left side of the dispensing drawer marked with a ②. As the machine fills, water is flushed through this compartment to deliver a detergent solution into the drum.

- Ensure the detergent drawer is completely closed before starting the cycle.
- If you select the 'Pre Wash' option, you must use a powdered detergent in the main wash detergent compartment.




## Pods

Detergent pods are a 'no mess' alternative to powdered or liquid detergent. They must be placed at the back of the drum prior to loading your clothes. This will ensure they are activated quickly in the wash. Do not place pods in the detergent dispenser drawer or on top of your clothes.

## Pre Wash

If you wish to use the 'Pre Wash' option, liquid or powdered detergent only must be placed in the pre wash detergent compartment on the right side of the drawer, marked with a ①. When you select 'Pre Wash', the pre wash compartment is flushed at the start of the cycle. For more information refer to 'Wash cycle options'.



- **WH9060J, WH8560J, WH8060J and WH7560J models: If using 'Delay Start' we recommend you use powdered detergent for the main wash.**

## How much detergent?

The correct detergent dosage varies depending on the amount of soil in your load, the size of the load and the water quality, so getting the correct dose takes some trial and error. Use

the instructions stated on the detergent package as a guide, then alter the dosage according to the results.

If you overdose, you will get over foaming issues, but if you under-dose you will get poor performance and over time your washer will start to smell as scum builds up inside it.


### **Detergent advice**

If your washer smells you are probably not using enough detergent for the soil level in your loads. Run a 'Drum Clean' cycle and either buy a better quality detergent or use a higher dose. If you are using an 'Eco' detergent, alternate the use of this with a mainstream detergent.

Add the detergent BEFORE starting the cycle, close the dispenser and do not open it while the cycle is running.

If you find foam leaking from your washer, check you are using a low sudsing or front loader type detergent and check the quantity you are using against the detergent manufacturers recommendation. You may need to reduce the amount you are using.

### **Fabric softener**

Add fabric softener to the middle compartment of the dispenser marked with a . The washer will automatically flush the fabric softener during the rinse part of the cycle.

### **If you wish to use fabric softener we recommend to:**

1. Use it sparingly. Measure it carefully and do not use more than 25ml (1/2 cap), some thicker varieties may need diluting.
2. Clean your dispenser regularly.
3. Clean your machine regularly using the 'Drum Clean' cycle.
4. Complete wash cycles at a wash temperature of 40°C or above at regular intervals (eg every 5th wash) as washing in cold water increases the chance of scrud occurring (see below).

If you fill beyond the MAX mark, the fabric softener will be dispensed into the bowl prematurely and contribute to scrud.

### **Scrud**

Scrud is the name of the waxy build-up that can occur within any washer when fabric softener comes in contact with detergent. This build-up is not brought about by a fault in the machine. If scrud is allowed to build up in the machine it can result in stains on clothes and an unpleasant smell in your washer.



If you wash a particularly dirty load, we recommend putting the washer through a 'Rinse' cycle once the cycle has finished and the load has been removed, to clean out any remnants from that cycle.

# WASH CYCLE OPTIONS

## Wash cycle options

All wash cycles default to the recommended options for that cycle based on the average expected load to be washed. You can vary the options (eg 'Wash Temp', 'Spin Speed') to create your desired cycle. Some options are not available on some cycles, for clothes care reasons, or because the option is not appropriate for the cycle.

## To change a wash option or options you have selected after a cycle has started

- Touch  and select your new setting, then touch  again to resume the cycle with the new setting or settings.

Note: Some options may not be available for selection under certain conditions and after particular stages of the cycle have passed.

## Wash Temp

Your washer offers five wash temperatures:

Cold	30°C	40°C	60°C	90°C
------	------	------	------	------

- Simply touch the 'Wash Temp' button to increase or decrease the wash temperature.
- The washer will fill with both hot and cold water (if possible) to achieve the selected wash temperature. If required, ie for cold supply or cold connection only, the washer will heat the water to the selected temperature.
- Some temperatures are not available on some cycles as a safeguard for your clothes (eg 90°C on the 'Delicate' cycle).

Note: If the wash temperature is set to cold the washing machine will heat the water to 20°C using the internal heater. This is to ensure that the detergent is fully dissolved during the wash cycle.

## Time Saver (WH8560F and WH8060F models only)

- Your washer offers a 'Time Saver' feature that when selected adjusts the cycle programming, by combining special temperature profiling and a unique tumble sequence. The result – excellent wash performance combined with time savings.
- This option can be selected on the 'Everyday', 'Cottons', 'Heavy', 'Easy Iron', 'Allergy' and 'Sports' cycles.

- Please be aware that a number of factors can influence the amount of time saved on a cycle, including the load size, cycle chosen, water flow rate and load distribution during spin.

## Spin Speed

- Your WH8560F, WH8060F, WH8560P, WH8060P or WH7560P model of washer offers four spin speeds: 500 rpm, 800 rpm, 1100 rpm and 1400 rpm, plus an additional 'No Spin' option.
- Your WH9060J, WH8560J, WH8060J or WH7560J model of washer offers three spin speeds: 500 rpm, 800 rpm, 1200 rpm, plus an additional 'No Spin' option.
- Simply increase or decrease the spin speed by touching the 'Spin Speed' button.
- Selecting 'No Spin' will end the cycle after the rinse, allowing you to remove items you wish to drip dry. The washer will complete the default wash and rinse spins for the cycle; only the final spin will not be completed. If you have removed the items you wish to drip dry and there are items remaining that you would like to proceed to spin, press 'Power' and select the 'Spin' cycle. If necessary, modify the spin speed to best care for your load (ie spin delicate items at 500 rpm for best garment care).


## Soil Level (WH8560P, WH8060P and WH7560P models only)


The 'Soil Level' option lets you adjust the wash to suit the amount of soil in your load. For example, select 'Heavy' for dirty clothes; for items that are only lightly soiled, select 'Light'. This adjusts the wash time accordingly to give the load the right amount of agitation to remove the soil.

## Wash Boost


### Pre Wash

For extra dirty loads you can perform a 'Pre Wash'. Your washer will start the wash with a short wash in cool water to remove excess soil. After this the machine will drain and then fill at the selected temperature for the main wash.


Simply touch the 'Wash Boost' button and select 'Pre Wash' when choosing your wash options. 'Pre Wash' cannot be selected after a wash cycle has been started, ie if you touch  and try to select 'Pre Wash' it will be unavailable. 'Pre Wash' must be selected at the start of the cycle.

If you use the 'Pre Wash' option, liquid or powdered detergent needs to be placed in the correct detergent compartment. The pre wash compartment is on the right hand side of the drawer, marked . When you select 'Pre Wash', the compartment is flushed at the start of the cycle.

## WH8560F, WH8060F, WH8560P, WH8060P and WH7560P models only

The detergent for the main wash can either be a powder or a liquid. Place this in the compartment marked . If using liquid, ensure the internal compartment is installed.

#### **WH9060J, WH8560J, WH8060J and WH7560J models only**

The detergent for the main wash **MUST** be a powder, and should be placed in the compartment marked .

#### **Rinse+**

If you have a particularly dirty load, or you have sensitive skin and wish to give your clothes an extra rinse, select 'Rinse+' from the 'Wash Boost' options. Your load will undergo an extra rinse to get rid of any residual detergent or soil in the items.

Note: 'Rinse+' will not be available if the 'Eco'/'Eco Rinse' option has been selected.

### **Options**

#### **Soak (WH8560F and WH8060F models only)**



A soak option is available on selected wash cycles. When this option is chosen the machine will add a one hour soak sequence, which combines periods of tumbling with soaking to help lift stubborn stains.

If 'Soak' and 'Time Saver' are selected in the same cycle, the soak duration will be reduced to 30 minutes.

'Soak' is not available on 'Wool', 'Drum Clean', or 'Super Quick' cycles.

#### **Wrinkle Free (WH8560F, WH8060F, WH8560P WH8060P and WH7560P models only)**

We recommend you remove the clothes from the washer immediately after the completion of the cycle to minimise wrinkling and creasing of items and to prevent dye run. However, if you will not be present at the end of the wash you can select 'Wrinkle Free'.

When 'Wrinkle Free' is selected, the washer will tumble the clothes once every 15 minutes for up to 12 hours after the cycle has finished. The 'Wrinkle Free' light and  button will flash, and the washer will beep at regular intervals to remind you to remove your load. To remove the load during this phase, simply press the  button.

#### **Eco/Eco Rinse**



Use the 'Eco'/'Eco Rinse' option to save water and energy. Selecting 'Eco'/'Eco Rinse' will reduce the wash temperature slightly and alter the wash and rinse programming.

This option will not be available if 'Pre Wash' has been selected.

- If you wish to, you can select both the 'Pre Wash' and 'Rinse+' 'Wash Boost' options to perform on the same cycle. Likewise, you can select 'Eco'/'Eco Rinse' and 'Wrinkle Free' to perform on the same cycle. Touch the appropriate button until both options are selected. Repeat to deselect an option.

- For clothes care and performance reasons not all options may be available on some cycles.

### **Add a Garment (WH8560F, WH8060F, WH8560P, WH8060P and WH7560P models only)**



The 'Add a Garment' option enables you to add or remove items during the wash stage of the cycle, under certain conditions. Once the 'Add a Garment' button is touched, the  button and time to go will flash. Wait until you hear the door unlock. Open the door and add or remove items. Close the door and touch  to restart the cycle.

The 'Add a Garment' button will only operate during the wash part of the cycle and when the temperature selected is lower than 60°C. 'Add a Garment' can be used when the total wash volume has been reached, as your washer will drain the water to a lower level if necessary, so the door can be opened.



### **Keylock**

This option enables you to deactivate the buttons on the display panel, except for the 'Power' and 'Keylock' buttons. This prevents accidental button presses.

#### **To turn Keylock mode ON or OFF when the washer is powered on:**





- Touch and hold the  button for 2 seconds. When activated, the light above the  button is illuminated.


#### **If Keylock mode is activated and the machine is powered off:**

- To turn your washer on, press the 'Power' button, then touch and hold the  button for two seconds. Select your wash cycle, options and then touch  to start the cycle.
- To turn the washer off at anytime when keylock is activated simply press the 'Power' button.

### **Delay Start**

The 'Delay Start' option enables you to delay the start of the wash cycle from between 5 minutes and 12 hours. Times you can select are 5 min, 15 min, 30 min, 1 hour, then hourly up to 12 hours. This can be useful to time your washing to finish when you arrive home from work, or to start once you have finished in the shower. Some stain removers also require you to spray them on then leave for several minutes, before washing. Your washer will wait for the selected time then start without you having to wait or remember to start your machine.

To programme a 'Delay Start' time, simply touch the 'More'  button to increase the delay time and 'Less'  button to decrease the time or turn 'Delay Start' off. Touch  to confirm your selection and start the countdown. Once started, the time will count down on the digital display screen in 1 minute increments, the 'Delay Start' light will flash and the  light will stop flashing and turn on solid.

If you hold the 'More'  button down, the time displayed on the screen will increase after every half a second (more convenient than touching the button repetitively).

To remove a 'Delay Start' time once it is counting down, simply touch ▶||, then touch the 'Less' - button to decrease the time to zero. Touch ▶|| to start the cycle immediately.


Avoid using 'Delay Start' for damp, non-colourfast items as this may cause dye run to occur. We also recommend you use powder detergent when you use the 'Delay Start' function (WH9060J, WH8560J, WH8060J and WH7560J models only).

## CUSTOMISING A WASH CYCLE

After using your washer a few times you may discover there are some wash options you prefer for some cycles.

You can programme your washer to remember the wash options you prefer for each wash cycle. For instance, you may want to set the 'Easy Iron' cycle to cold wash temperature or set the 'Everyday' cycle so it gives you Rinse+ every cycle.

### To customise a cycle:

1. Press 'Power' to turn the machine on.
2. Turn the dial to select the cycle you wish to customise.
3. Touch and hold any of the wash option buttons for 3 seconds. The cycle icon will flash on and off to indicate that the product is in cycle adjustment mode. The display will show **SEt**.
4. Select the wash options you prefer by touching the relevant option button.
5. Touch  to save the selected settings.

Your washer will automatically remember your changes for all future washes you do on this cycle.

### Factory Reset

You can reset your washer to the default settings it left the factory with:

1. Turn the dial to select 'Spin'.
2. Touch and hold the 'Delay Start' 'More' +, the 'Delay Start' 'Less' - and 'Options' buttons together for 3 seconds **dEF** will appear on the screen and the machine will beep.
3. Your washer will now be reset to the default settings.

## CARING FOR YOUR WASHER

### When you have finished using your washer

- Unplug the machine from the power socket.
- Wipe around the door and in the rubber gasket to remove any remaining water and foreign matter.
- Turn off the taps to prevent the chance of flooding should a hose burst.

## Cleaning your washer


Before you start cleaning your washer, ensure that it is disconnected from the power (ie unplug the machine from the power socket).

### Cleaning the control panel and outer surfaces of the washer

Use a soft damp cloth to wipe all surfaces, then wipe dry. Avoid using chemical or scouring cleaners, as these will damage the paint and plastic surfaces of your washer.


### Cleaning the detergent dispenser drawer

Wipe out the detergent dispenser drawer with a damp cloth. Clean it regularly, especially if you use fabric softener. To remove the drawer, pull it open, push down on the tab in the fabric softener compartment and pull out. Rinse it out under warm water and re-insert into the machine.



#### *Removing the dispenser drawer for cleaning*


### Cleaning the inside of your washer

It is important that you regularly clean the inside of your machine using the 'Drum Clean' cycle. After 100 cycles  icon will flash every time you turn your washer on to remind you to do this. If your washer starts to smell this is a sign that you should complete a 'Drum Clean' cycle. We recommend that you do not have any items in the washer when you run this cycle.



'Drum Clean'  
cycle

### Cleaning steps

1. We recommend the use of commercial washing machine cleaners only.
2. Add the washing machine cleaner directly into the main wash detergent compartment of the dispenser drawer (marked ) , follow manufacturer's instructions.
3. Press 'Power' to turn your machine on and select the 'Drum Clean' cycle.
4. Touch to start the cycle.


### Cleaning the drum and the door

- Use a soft damp cloth to wipe the door, cleaning any water marks or residue off it.

- Wipe the rubber seal around the door. Remove any items or lint accumulating in the bottom of the seal catchment and wipe out any water accumulated here. If this is not cleaned out, unpleasant odours will develop.
- If the drum has any residual dirt or lint stuck to it, remove this and wipe the drum clean. Do not leave any metal objects in the drum as these may rust and cause staining.
- WH8560F and WH8060F models also have a self cleaning door flush that directs a portion of the rinse water over the door during various stages of the cycle to help to clean hair and insolubles from the inside of the door and surrounding parts. We still recommend that you manually clean it with a soft cloth periodically as per the instructions above.

### Cleaning the pump filter

The pump has a filter to trap foreign objects that enter the washer along with clothing. The pump filter can be accessed from the front of the washer.



Drain residual water


#### To clean the filter:

This should be cleaned out approximately once a month.

1. Turn the power off and unplug the machine.
2. Use a coin to open the filter cover. Place the edge of the coin into the slot and tilt upwards whilst levering the cover open.
3. Unhook the pump outlet hose and pull it out (about 150mm). Remove the plug and allow any water (approximately 250ml) to drain into a shallow dish.
4. After the draining process is complete, replace the plug into the hose and refit the hose back into the housing.
5. Remove the filter by turning anti-clockwise. Clean and rinse under a tap. Check the pump filter cavity for any further obstruction.
6. Replace the filter by turning clockwise until the white mark on the filter is in line with the white line on the pump housing.



Replacing filter



7 Close the filter cover.

### **Cleaning the hose(s)**

Each hose has a filter in it, preventing any solid contaminants in the water entering your washing machine. Occasionally you should disconnect the water inlet hose(s) where they connect to the tap(s), check these for any build up of dirt and wash this out.

### **Nappy sanitisers/bleach**

Nappy sanitisers and bleach are very corrosive to metal surfaces. DO NOT tip the contents of a nappy bucket into your machine. Rinse and wring items out thoroughly before placing them in the machine.

### **Moving your washer**

If you need to move your washer a considerable distance (eg moving house), remember to replace the transit bolts before moving it. These will protect internal components of the washer from damage.

To replace the transit bolts, pull out the bolt-hole covers in the back of the machine. Push the transit bolt rubber grommets and plastic spaces into the hole left and tighten it with the spanner provided with the product.

Make sure any water in the washer is drained out. This can be done by cleaning out the pump filter, refer to 'Caring for your washer' 'Cleaning the pump filter'.

- Leave the door to your washer open when it is not in use to allow the washer to dry out, otherwise it will develop unpleasant odours. When leaving the door open like this, it is extremely important that children and pets are kept away from the washer so they cannot be accidentally trapped inside it.
- Aside from the detergent dispenser, water hose(s), and the pump filter, no other parts are designed to be removed from the machine for cleaning. Do not attempt to remove any other part of the machine.

### **User warnings**

Your washer is capable of diagnosing a number of its own problems. In most cases, your washer will sound a continuous series of beeps and display a code when it has a problem that you can correct yourself. All control panel lights will turn off and the code will be displayed to inform you

what the problem is. To stop the beeps, press any button on the control panel. Do not try to continue washing once you stop the noise. You must address the problem the washer is alerting you to.

**Check this chart before you call for service.**

Keylock is activated

• KEY  
LOC

Touch and hold the 'Keylock' button for 2 seconds.

Pump filter is blocked

• CLR  
FLTR

Clear the pump filter, refer to 'Cleaning the pump filter'.

Water is not getting to the machine

• NO  
WRP

Check the taps have been turned on.

If there is no hot water connection the machine will heat the water itself, but there must be a cold water connection to the cold valve.

Check the hose connections. If the cold water supply is connected to the hot valve and there is no connection to the cold valve the machine will not fill.

Check the inlet hose filters are not blocked, the hose(s) are not kinked and are attached correctly.

Check that the drain hose is not too low or pushed into the standpipe too far. This will cause the water to siphon out of the machine.

Check the cold water temperature does not exceed the 35°C temperature requirement.

Check the water flow rate. It maybe too low.

Wash load is out of balance

• OUT  
OF  
BAL

Touch ▶|| to try the spin again.

If the out of balance persists, pause the cycle, manually redistribute the load and touch ▶|| to spin again. If necessary, stop the cycle, select 'Spin' and touch ▶||.

If the problem persists, check the machine is correctly levelled.

Too many suds

• Sud  
LOC

Machine will stop and flash *Sud LOC* for 10 minutes while waiting for suds to dissipate. The machine will not beep during this time. After 10 minutes the machine will automatically restart. At any point during that 10 minutes you can touch ►|| to restart the machine, but it is recommended that the machine be left to restart automatically.

Check you are using a suitable detergent.

Check you are not overdosing the detergent.

Check the standpipe height for the drain does not exceed 1200mm.

Door is locked

• door  
Locd

The temperature in the drum is over 60°C therefore it is not safe to open the door. Wait until the temperature drops below 60°C.

Check the water level in the drum. If the level is above the bottom of the door seal, the door cannot be opened. Use the 'Add a Garment' button if you wish to add or remove items (WH8560F, WH8060F WH8560P, WH8060P and WH7560P models only).

If the drum is still moving, wait for it to stop before attempting to open the door.

Door is open

• door  
DPEn

Close the door fully and touch ►||.

Try opening and closing the door again.

Reposition the load, make sure the load is correctly in the drum and that protruding items are not stopping the door from closing.

## FAULT CODES

When a continuous series of beeps is sounded, all the lights turn off on the control panel and a number appears on the display, a fault has occurred. The washer will automatically enter this mode if a fault occurs. The fault code will be displayed as followed by a number on the digital display. To stop the sound, touch any button and perform the following steps:

1. Turn your machine off at the power point.
2. Wait one minute and turn it back on.

3. Check your machine is correctly levelled, refer to 'Levelling the machine'
4. Remove your wash load.
5. Perform a 'Rinse' cycle.
6. If the fault re-occurs repeat steps 1 and 2.
7. If the machine still will not work you will be required to call a Fisher & Paykel trained and supported service technician to arrange service (refer to 'Customer Care'). Record the fault code number displayed and the serial number of your washer (located on the rear of the machine, and/or above the drum opening when the door is open) before calling. The fault code will indicate to the Repairer what the problem could potentially be.

If a fault code is being displayed, you can still turn your washer off by pressing 'Power'.

## TROUBLESHOOTING

The following is a list of problems you may encounter when using this appliance and some suggestions that may help to correct the problem. If you still have problems, please contact your Fisher & Paykel trained and supported service technician.

### Operating problems

#### Washer does not work

- Power not switched on at the wall.  
Switch the power on at the wall. Then press 'Power'.
- Household power supply not working.  
Try plugging in another electrical appliance.
- Keylock may be activated.  
Touch and hold the 'Keylock' button for 2 seconds.

#### Touching ►|| does not start the fill

- Washer door not closed properly.  
Open and reclose door.
- The washer is waiting for a command from you.  
If it is flashing then the washer is waiting for a command from you.
- The washer has detected a fault.  
Check if a code is being displayed on the panel, refer to 'Before you call for service'.
- Hot and cold taps not turned on.

Check that both hot and cold taps are turned on (if using cold inlet only ensure inlet valve cap is installed on the hot valve on the machine, if present).

- Hot and cold taps not connected to the corresponding valve on the machine.

Check the cold tap is connected to the cold valve on the machine and the hot tap is connected to the hot valve (if present).

- Blocked hose filters.

Check the tap end of the inlet hose(s) for blockages.

- Inlet hose leaking, twisted or damaged.

Check the inlet hose for leaks or damage. Check that the inlet hose is not twisted.

- Faulty water supply.

Check taps that aren't connected to the machine are working.

- Delay start may be set.

Refer to 'Delay Start'

### **Washer stops working mid cycle**

- The washer has detected a fault.

Refer to 'Fault Codes'

- Power or water failure.

Check the power and/or water is working correctly.

- Washer has been paused.

Touch the button to continue.

- Too many suds.

Washer is waiting for suds to dissolve before continuing the cycle.

### **Washer drains while filling**

- Drain hose too low.

Ensure the height of the drain hose is at least 800mm from the floor level, refer to 'Draining'.

- Drain hose sitting in water.

Clear the drain.

### **Washer is not draining**

- Drain hose blocked.

Clear the drain hose.

- Pump filter blocked.

Clear the pump filter, refer to 'Cleaning the pump filter'.

- Drain hose higher than 1200 mm above floor level.

Lower the level of the drain hose, refer to 'Drainage'.

### **Filling continuously**

- Drain hose not connected to standpipe or tub.

Connect drain hose correctly, refer to 'Drainage'.

- Machine siphoning.

Ensure standpipe or tub is at least 800mm from the floor level.

### **Poor rinsing**

- Incorrect detergent used.

Use low sudsing, front loader detergent only, refer to 'Detergent and Fabric Softener'.

- Too much detergent used.

Ensure the correct dose of detergent is used for the load size and soil level, refer to 'Detergent and Fabric Softener'

### **Not spinning properly**

- Load has gone out of balance.

Open door and redistribute load, then restart the washer.

- Machine is not level.

Ensure machine is correctly levelled, refer to 'Levelling the machine'

- Suds build up.

Check the amount of detergent used, reduce if necessary

### **Too many soap suds**

- Incorrect type of detergent used.

Use low sudsing, front loader detergent only, refer to 'Detergent and Fabric Softener'.

- Too much detergent used.

Ensure the correct dose of detergent is used for the load size and soil level. refer to 'Detergent and Fabric Softener'.

### **Small puddle of water from under the machine**

- Inlet hose or drain hose leaking.

Check inlet hose(s) and the drain hose are correctly attached and not damaged.

- Lots of suds.

Suds may have leaked and then dissolved.

- Detergent dispenser blocked.

Clean detergent dispenser drawer, refer to 'Cleaning the detergent dispenser drawer'.

- Detergent dispenser drawer not fully closed.

Close detergent dispenser drawer fully and ensure it remains closed during the cycle.

- Damage to door seal.

Check seal inside door for damage. If it sustains any damage it will need to be replaced.

### **Cycle time longer than usual/Inaccurate time reading/Adjustment of time remaining during cycle**

- Wash time is approximate.

Wash time may be influenced by a number of factors, refer to 'Time to go'.

- Low water pressure or flow rate.

Ensure that inlet hose filters are not blocked.

- Out of balance or oversudsing.

Recovery from out of balance or oversudsing will extend cycle time, refer to 'Before you call for Service'

- Washing a large load.

Be aware that it will take longer for the machine to fill.

- Selecting various options.

Be aware that some options will extend cycle time.

### **Detergent or fabric softener remaining in detergent dispenser at the end of the cycle**

- Detergent drawer not properly closed or was opened part way through the cycle.

Ensure the detergent dispenser drawer is fully closed at the start of the cycle and remains closed throughout the cycle.

- Dirty or blocked detergent dispenser.

Clean the detergent dispenser, refer to 'Cleaning the detergent dispenser drawer'.

- Liquid sitting at the 'Max' level at the end of the cycle indicates a blockage.

Clean the fabric softener dispenser, refer to 'Cleaning your dispenser drawer'.

- Dispenser over loaded with detergent.

Clean out remaining detergent and refer to 'Detergent and Fabric Softener' for dosing information.

### **Washing very wet at the end of the cycle**

- Cycle selected not appropriate.

Particularly short or delicate cycles have shorter spins which can result in wetter washing at the end of the cycle.

- Incorrect spin speed for load selected.

Select a faster spin speed.

- An out of balance load has occurred.

The washer compensates for the out of balance by using a lower spin speed, to reduce noise and potential damage to itself

### **Vibrating**

- Transit bolts left in place.

Ensure transit bolts are removed prior to use of the machine, refer to 'Removing your transit bolts'.

- Washer may not be level.

Ensure washer is installed on an appropriate surface and levelled correctly, refer to 'Levelling your machine'.

- Load is out of balance.

Wash an average sized load rather than a smaller load or a single item. Washing one item at a time is not recommended as it is difficult for the washer to balance a single item during spin.

## **Wash problems**

### **Poor soil Removal**

- Incorrect wash cycle selected.

Select a wash cycle that is appropriate for the amount of dirt, refer to 'Wash cycle options'.

- Insufficient detergent.

Ensure the correct dose of detergent is used for the load size and soil level, refer to 'Detergent and fabric softener'.

- Washer overloaded.

Ensure the washer is not overloaded in terms of its capacity or the cycle selected, refer to 'Wash cycle options'.

- Items require a longer wash time.

Select a higher soil level option if available (WH8560P, WH8060P and WH7560P models only).

- Load was particularly dirty.

Select 'Pre Wash' for particularly dirty loads, refer to 'Pre Wash'.

- Items not sorted correctly.

Wash heavily and lightly soiled garments separately.

- Washer dirty from previous wash.

After washing particularly dirty clothing, we recommend putting the washer through a 'Rinse' cycle after the load has been removed, to wash away any remnants of dirt and to prevent it contaminating future washes.

- Incorrect wash temperature selected in relation to the type of soil.

Select a wash temperature suitable for the type of soil, eg warm for greasy soils, cold for muddy soils. Increasing the wash temperature generally improves soil removal and overall wash performance.

## **Dye transfe**

- Coloured items not washed separately from white/light coloured items.

Remember to separate whites and colours.

- New or non-colourfast items not washed separately.

Wash non-colourfast items separately and select 'Cold' wash temperature.

- Wet items have been left sitting for too long.

Remove items from washer as soon as the cycle is finished, or if items are not to be removed from the washer immediately select 'Wrinkle Free' (WH8560F, WH8060F, WH8560P, WH8060P and WH7560P models only).

- Wash temperature.

Consider the wash temperature you select for your coloured items. Lower the temperature if you are concerned.

## **Black or grey marks on clothes**

- Correct amount of detergent.

Ensure the correct dose of detergent is used for the load size and soil level, refer to 'Detergent and fabric softener'.

- Washer needs to be cleaned.

Empty the machine and complete a 'Drum Clean' cycle

## **Tangling**

- Items not sorted correctly.

Separate larger items from smaller items.

- Washer loaded incorrectly.

Load items loosely and individually into the washer (ie not folded).

- Incorrect cycle for load type selected.

Use the 'Easy Iron' cycle to wash shirts.

- Washer overloaded in terms of its capacity or the cycle selected.

Reduce the load size.

- Delicate items.

Wash pantyhose, bras and any other delicate items prone to tangling in a mesh laundry bag.

## **Creasing**

- Washer overloaded.

Do not overload washer.

- Incorrect cycle for load type.

Use the 'Easy Iron' or 'Handwash' cycle for creasable items.

- Spin speed too fast.

Select a slower spin speed.

- Wet clothes left in washer or laundry basket.

Laundry left sitting wet is more likely to crease. If not removing clothes from washer immediately at end of cycle, select the 'Wrinkle Free' option (WH8560F, WH8060F, WH8560P, WH8060P and WH7560P models only). Do not leave wet washing sitting in a washing basket.

- Wash temperature too hot for load type.

Select a lower wash temperature. Check items care label for correct care.

- Items not sorted correctly.

Sort load so that items of similar weight are washed together, refer to 'Sorting'.

### **Warning**

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.