


User Manual

Controls

Features and appearance will vary.



Air Conditioner Controls



1. Temperature Control

Setting determines how much cooling is provided. Max Cool - 10 provides the most cooling and **Min Cool** - 1 provides the least.

Fan Only turns off the cooling function.

NOTE: If you move the Temperature control from a cool setting to a fan setting or power off the unit while cooling, wait at least 3 minutes before switching back to a cool setting.

Cooling Descriptions

For Normal Cooling—Select 4-7 on the dial with the FAN SPEED set to HI or LOW.

For Maximum Cooling—Select 8-10 on the dial with the FAN SPEED set to HI.

For Quieter and Nighttime Cooling—Select 1-4 on the dial with the FAN SPEED set to LOW.

2. Fan Speed

The fan speed button can be set on HI or LOW. In both cooling mode and fan only mode.

3. Power

Turns the unit on or off.

Air Direction

Use the lever to adjust the air direction left to right.





CARE AND CLEANING

Care and Cleaning

Do Not Operate in Freezing Outdoor Conditions

This cool-only air conditioner was not designed for freezing outdoor conditions. It must not be used when the outdoor temperature is below freezing (32°F).

<p>Grille and Case</p> <p>Turn the air conditioner off and remove the plug from the wall outlet before cleaning.</p>	<p>To clean, use water and a mild detergent. Do not use bleach or abrasives.</p>
<p>Air Filter</p> <p>The air filter behind the front grille should be checked and cleaned at least every 30 days or more often if necessary.</p> <p>To remove:</p> <p>Slide the filter from the left side of the unit. Remove the filter.</p> <p>Clean the filter with warm, soapy water. Rinse and let the filter dry before replacing it. Do not clean the filter in a dishwasher.</p>	<p>CAUTION: DO NOT operate the air conditioner without a filter because dirt and lint will clog it and reduce performance.</p> 
<p>Outdoor Coils</p> <p>The coils on the outdoor side of the air conditioner should be checked regularly. If they are clogged with dirt or soot, they may be professionally cleaned.</p>	

TROUBLESHOOTING

Troubleshooting Tips... Before you call for service

Save time and money! Review the charts on the following pages first and you may not need to call for service.


Problem	Possible Cause	What To Do
Air conditioner does not start	The unit is unplugged.	Make sure the air conditioner plug is pushed completely into the outlet
	The fuse is blown/ circuit breaker is tripped.	Check the house fuse/circuit breaker box and replace the fuse or reset the breaker.
	Power Failure.	The unit will automatically restart in the setting last used after the power is restored There is a protective time delay (approximately 3 minutes) to prevent tripping of the compressor overload. For this reason, the unit may not start normal cooling for 3 minutes after it is turned back on.
	The current interrupter device is tripped.	Press RESET button located on the power cord plug. If the RESET button will not stay engaged, discontinue use of the air conditioner and contact a qualified service technician
Air conditioner does not cool as it should.	Indoor airflow is restricted.	Make sure there are not curtains, blinds or furniture blocking the front of the air conditioner
	The temp control may not be set properly.	Turn the temperature control to a higher number.
	The air filter is dirty.	Clean the filter at least every 30 days. See Care and Cleaning section.
	The room may have been hot.	When the air conditioner is first turned on, you need to allow time for the room to cool down.
	Cold air is escaping.	Check for open furnace registers and cold air returns
	Cooling coils have iced up.	See "Air conditioner freezing up" below.



Air conditioner freezing up	Ice blocks the air flow and stops the air conditioner from cooling the room.	On models with control knobs, set the mode control at High Fan or High Cool with the Temp at 1 or 2.
Water drips outside	Hot, humid weather.	This is normal.
Water drips inside	The air conditioner is not tilted to the outside.	For proper disposal, make sure the air conditioner slants slightly from the case front to the rear.
Water collects in base pan	Moisture removed from air and drain into base pan.	This is normal for a short period in areas with little humidity; normal for a longer period in very humid areas.

Normal Operating Sounds

- You may hear a pinging noise caused by water being picked up and thrown against the condenser on rainy days or when the humidity is high. This design feature helps remove moisture and improve efficiency.
- You may hear the thermostat click when the compressor cycles on and off.
- Water will collect in the base pan during high humidity or on rainy days. The water may overflow and drip from the outdoor side of the unit.
- The fan may run even when the compressor does not.
- Water droplets being thrown against the outside coils can make a pinging noise. This helps cool the condenser. You can reduce this noise by removing the subbase water plug.



Removing this plug will lower the Energy Efficiency of your unit.

NOTE: Do not drill hole in the base pan.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

Document generated by [ManualsFile](#)

