


## Features

### Package contents

- Air fryer
- *User Guide*

### Product overview




## Before using your fryer for the first time

- 1 Remove all packaging material, stickers, and labels from the air fryer.
- 2 Clean the basket and pan with hot water, dish soap, and a non-abrasive sponge.
- 3 Wipe the inside and outside of the appliance with a moist cloth.


## Using your air fryer

### Caution:

- This air fryer works with hot air. Do not fill the pan with oil or any liquid.
- Do not put anything on the air inlet located on top of the air fryer.
  1. Place the air fryer on a level, heat-resistant surface and plug the power cord into a wall outlet.
  2. Pull the pan out of the air fryer, place your food in the basket, then replace the pan. Do not fill the basket more than 2/3 full.




3. Turn the temperature knob to set the temperature from 180 to 400°F (82.2 to 204.4°C).



4. Turn the timer knob to set the cook time (from 0-60 minutes) and start heating. The power and heat indicators light and the timer starts counting down from the set cook time.





**Notes:**

- If you want to preheat your air fryer, add 1-2 minutes to your cook time. You can also preheat without any food in the fryer.
- The heat indicator may turn on and off while cooking as the heating element turns on and off to maintain the correct temperature.
- You can pull out the pan at any time to check your food. The air fryer will pause automatically and resume heating after you slide the pan back into the air fryer.

5. If you are cooking a large amount of food, remove the pan and shake its contents halfway through the cook time. The air fryer continues heating when the pan is replaced (the timer does not stop counting down).

**Notes:**

- The fryer will not beep at the halfway point.
- Remove the basket to reduce the weight while shaking. See ["Removing the basket" on page 10](#) for more information.

6. When the air fryer beeps, the cook time is finished. Pull the pan out of the air fryer and place it on a heat-resistant surface.

7. Check your food to see if it is done. If it's not finished, slide the pan back into the air fryer and set the timer for a few extra minutes.

8. Empty your food into a bowl or onto a plate. DO NOT turn the pan upside down as excess oil collects on the bottom.

- To remove small food, press the basket release button and lift the basket out of the pan.
- To remove large or fragile food, use a pair of tongs to lift the ingredients out of the basket.

## Cleaning your air fryer

Clean your air fryer after every use.

**Note:** Do not use abrasive cleaning materials to clean the pan or basket as they may damage the nonstick coating.

1. Unplug the air fryer from the wall outlet and wait for it to cool. **Note:** Remove the pan to let the air fryer cool down more quickly.
2. Wipe the outside of the air fryer with a moist cloth.
3. Clean the pan and the basket with hot water, dish soap, and a non-abrasive sponge. Use a degreasing liquid to remove any remaining residue.

### Notes:

- For tough-to-remove residue, fill the pan with hot water and dish soap, then place the basket in the pan and soak for approximately ten minutes.
  - You can also wash the pan and basket in the dishwasher.
4. Clean the inside of the air fryer with hot water and a non-abrasive sponge.
  5. Clean the heating element with a cleaning brush to remove any food residue.

## Storing your air fryer

1. Unplug the air fryer and let it cool down.
2. Make sure that all parts are clean and dry.
3. Put the air fryer in a clean and dry place.

# Troubleshooting



<b>PROBLEM</b>	<b>POSSIBLE CAUSE</b>	<b>SOLUTION</b>
The air fryer does not work.	The fryer is not plugged in.	Plug the power cord into a grounded wall outlet.
	You have not set the timer.	Turn the timer knob to the required preparation time to turn on the appliance.
	The pan is not put into the fryer properly.	Slide the pan into the fryer properly.
The food fried in the air fryer isn't done.	There's too much food in the air fryer.	Put smaller batches of ingredients in the basket. Smaller batches are fried more evenly.
	The set temperature is too low.	Increase the air fryer's temperature.
	The preparation time is too short.	Cook your food longer.
The ingredients are fried unevenly in the air fryer.	Certain types of ingredients need to be shaken halfway through the preparation time.	Shake foods that lie on top of or across each other (e.g. fries) halfway through the preparation time.
Fried snacks are not crispy when they come out of the air fryer.	You used a type of snacks meant to be prepared in a traditional deep fryer.	Use oven snacks or lightly brush some oil onto the snacks for a crispier result.

I cannot slide the pan into the fryer properly.	There is too much food in the basket.	Do not fill the basket beyond the MAX indication.
	The basket is not placed in the pan correctly.	Push the basket down into the pan until you hear a click.
White smoke comes out of the air fryer.	You are preparing greasy ingredients.	When you fry greasy ingredients in the air fryer, a large amount of oil will leak into the pan. The oil produces white smoke and the pan may heat up more than usual. This does not affect the fryer or the end result.
	The pan still has grease residue from a previous use.	White smoke is caused by grease heating up in the pan. Make sure that you clean the pan properly after each use.
Fresh fries are fried unevenly in the air fryer.	You did not use the right potato type.	Use fresh potatoes to make sure that they stay firm during frying.
	You did not rinse the fries properly before you fried them.	Rinse the fries properly to remove starch from the outside of the sticks.

Fresh fries are not crispy when they come out of the air fryer.	The crispiness of the fries depends on the amount of oil and water in the fries.	Make sure that you dry the potato sticks properly before you add the oil.
		Cut the potato sticks smaller for a crispier result.
		Add slightly more oil for a crispier result.

## Specifications

Dimensions (H × W × D)	12.8 × 11.1 × 13.7 in. (32.6 × 28.1 × 34.8 cm)
Weight	9.9 lbs. (4.5 kg)
Wattage	1500 W
Current	120V, 60HZ
Cooking temperature	180 ~ 400°F (82.2 ~ 204.4°C)
Cord length	3.3 ft. (1.0 m)

### Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.