Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's date code in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference. 25h

DOYLE™

1000A AC/DC CLAMP METER



Visit our website at: https://www.harborfreight.com
Email our technical support at: productsupport@harborfreight.com

59456

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-800-444-3353 as soon as possible.

Copyright© 2025 by Harbor Freight Tools®. All rights reserved.
No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

⚠WARNING

Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

SAFETY

SETUP

OPERATION

MAINTENANCE

Table of Contents

Safety 2
Specifications 5
Setup 6
Operation 8
Maintenance 15
Warranty 16

DOYLE™

WARNING SYMBOLS AND DEFINITIONS	
⚠	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
⚠DANGER	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
⚠WARNING	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
⚠CAUTION	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE CAUTION	Addresses practices not related to personal injury.

IMPORTANT SAFETY INFORMATION

Safety Warnings and Precautions

⚠WARNING

Read all safety warnings and all instructions.
Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

1. Electrical shock can cause death or injury! NEVER TOUCH exposed conductors of electricity.
2. **Test cable voltages with care.** One use one hand when securing the clamp around cable.
3. Inspect the Meter before use. In addition to a general inspection, look specifically for:
   a. Pay special attention to the insulation protecting the connectors.
   b. Check the leads for exposed metal, damaged insulation, and continuity.
   c. Replace damaged test lead immediately, before use.
4. Do not use the Meter if:
   a. Either of the test leads are damaged in any way.
   b. Test leads are dirty or have residue on them.
   c. The battery is low.
   d. Near any explosive gasses or fumes.
   e. Any abnormal operation is detected. (If in doubt about the condition of the Meter, have it serviced before use.)
   f. The battery cover is open.
5. Power this Meter using only the battery(ies) referenced in the Specifications Chart.
6. Use caution when working near voltages above 30 VAC rms, 42 VAC peak, or 60 VDC. Voltages this high present a risk of electric shock.
7. Disconnect the circuit's power before connecting the Meter in series, when measuring current.
8. Connect the common (COM) test lead first and disconnect it last.
9. Hold the probes with fingers behind guards.
10. Avoid electrical shock. Use extreme caution when working near uninsulated conductors or bus bars. Prevent body contact with grounded surfaces such as pipes, radiators, ranges, and cabinet enclosures when testing voltages.
11. Observe work area conditions. Do not test voltages in damp or wet locations. Don't expose to rain. Keep work area clean and well lit.
12. Keep children away. Children must never be allowed in the work area.
13. Stay alert. Watch what you are doing, use common sense. Do not operate any Meter when you are tired.
14. Do not operate Meter if under the influence of alcohol or drugs. Read warning labels on prescriptions to determine if your judgment or reflexes are impaired while taking drugs. If there is any doubt, do not operate the Meter.
15. People with pacemakers should consult their physician(s) before use. Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure.
16. Do not test voltage on circuits higher than 1000VDC or 1000VAC.
17. Do not test current on circuits higher than 1000A.
18. Dress properly. Protective, electrically nonconductive clothes and nonskid footwear are recommended when working.
19. Wear ANSI-approved safety goggles during use.
20. Only use accessories intended for use with this Meter.
21. Avoid damaging Meter. Use only as specified in this manual.
22. Prior to testing resistance, diodes, or continuity; disconnect all power to the circuit and discharge all high-voltage capacitors.
23. Performance of this Meter may vary depending on battery condition.
24. Use the proper settings, terminals, techniques, and range for the tests performed. Start with the range stated in the instructions.
25. Do not apply voltage to the Test Leads when the Meter is in the Ohms testing setting. Damage can occur to the Meter.
26. Do not switch between testing modes with the Meter connected to a circuit.

27. Do not use the Meter at a setting marked as blank on the scale.
28. Have Meter calibrated by a qualified technician every year to maintain accurate results.
29. Do not disassemble meter; take it to a qualified technician when service or repair is required. Incorrect reassembly may result in a risk of electric shock or fire.
30. The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

SAVE THESE INSTRUCTIONS.


Specifications

DC Voltage	Ranges: 600mV / 6V / 60V / 600V / 1000V
DC Voltage Accuracy	(@0-599.9mV) ± 0.5% + 5D, (@600mV-1000V) ± 1.5% + 2D
DC Current	Ranges: 600A / 1000A
DC Current Accuracy	(@600A) ± 2.5% + 5D, (@1000A) ± 2.8% + 5D
AC Voltage	Ranges: 6V / 60V / 600V / 1000V Frequency Range: 50-400Hz
AC Voltage Accuracy	(@1000V) ± 1.5% + 5D
AC Current	Ranges: 600A / 1000A Frequency Range: (@0-600A) 50-400Hz, (@600A-1000A) 50-60Hz
AC Current Accuracy	(@0-600A) ± 2.5% + 8D, (@0-1000A) ± 2.8% + 8D
Inrush Current	Ranges: 600A / 1000A Frequency Range: 50-400Hz
Inrush Integration Time	100mS
Resistance	Ranges: 600Ω / 6kΩ / 60kΩ / 600kΩ / 6MΩ / 60MΩ
Resistance Accuracy	(@0-599.9Ω) ± 1.0% + 4D, (@600Ω-599.9kΩ) ± 1.5% + 2D (@600kΩ-599.9MΩ) ± 2.5% + 3D, (@6MΩ-59.99MΩ) ± 3.5% + 5D
Continuity	Meter beeps at < 50Ω
Diode	Forward DC Current: ~ 0.3mA Reverse DC Voltage: ~ 3.2V
Capacitance	Ranges: 60nF / 600nF / 6uF / 60uF / 600uF / 6mF / 60mF / 100mF
Capacitance Accuracy	(@0-59.99nF) ± 4.0% + 20D, (@60-599.9uF) ± 3.0% + 5D, (@600uF-5.999mF) ± 5.0% + 5D, (@6mF-59.99mF) ± 5.0% + 8D, (@60mF-99.99mF) ± 5.0% + 15D,
Frequency	Current Mode Range: 100Hz / 1000Hz Voltage Mode Range: 100Hz / 1000Hz / 100kHz
Frequency Accuracy	Current Mode: ± 1.5% + 5D Voltage Mode: ± 1.5% + 5D Hz/Duty Mode: ± 0.3% + 5D
Duty Cycle	10.0%-90.0%
Duty Cycle Accuracy	± 1.2% + 2D
Sampling Rate	~2 samples per second
Operating Temperature	Range: 41°F - 104°F (5°C - 40°C)
Operating Humidity	Max 80% RH Non-Condensing
Storage Temperature	Range: 14°F - 122°F (-10°C - 50°C)
Storage Humidity	<80% RH Non-Condensing
Display	Liquid Crystal Display (LCD)
Battery	(3) AAA (Included)


Setup - Before Use:

Read the ENTIRE IMPORTANT SAFETY INFORMATION section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

Functions



Display



Symbol	Description
LoZ	Low impedance input mode
DC	Direct current
▬	Minus sign
AC	Alternating current
	Battery low
	Auto power-off
AUTO	Auto range mode
	Diode test mode
	Continuity test mode (audible)
MAX	The maximum value is being measured
MIN	The minimum value is being measured
REL	Relative measurement mode
H	Indicates that display data is being held
VFD	Variable frequency drive mode
INRUSH	Inrush current mode
Ω, kΩ, MΩ	Ohms, Kilohms, Megaohms (Resistance)
nF, µF, mF	Nanofarads, Microfarads, Millifarads (Capacitance)
mV, V	Millivolts, Volts (Voltage)
A	Amperes (Current)
Hz, kHz	Hertz, Kilohertz (Frequency)
%	Percent (Duty cycle)
°C, °F	Temperature (Celsius, Fahrenheit)
8888	Measurement reading

Operating Instructions

Read the ENTIRE IMPORTANT SAFETY INFORMATION section at the beginning of this manual including all text under subheadings therein before set up or use of this product. Electrical shock can cause death or injury! NEVER TOUCH exposed conductors of electricity.

General Operating Instructions

REL/Backlight

1. Press the **REL/Backlight** button once to enter relative measurement mode and store a reference value.
2. Take additional measurements to display difference between measured value and reference value.

Note: Relative measurement mode will turn off Auto Range mode.

3. Press **REL/Backlight** button for two or more seconds to enter backlight mode.
4. Press **REL/Backlight** button for two or more seconds to exit backlight mode.

Note: Frequent use of the backlight will shorten the life of the batteries. Only use the backlight when necessary.

Worklight

1. Press the **Data Hold/Worklight** button for two or more seconds to turn on the worklight.
2. Press the **Data Hold/Worklight** button again to turn the worklight off.

Data Hold

The data hold function keeps the current reading on the Display. To activate data hold:

1. Press the **Data Hold/Worklight** button and the reading will be held on the Display. The H symbol appears.
2. Press **Data Hold/Worklight** again to release the hold.

DOYLE™

Manual Range

The Meter's default range is **AUTO**. To select manual range, press **RANGE**. The Display will no longer read **AUTO**. Each press of the button increases the range. Hold the **RANGE** button for two seconds to return to auto range.

Note: Manual range cannot be used while measuring frequency.

Auto Power-Off

If the Meter is not used for approximately 15 minutes, it will automatically turn itself off to conserve battery power. To turn the Meter back on after auto-off, press the **MODE/INRUSH** button. To disable Auto Power-Off, hold the **MODE/INRUSH** button while powering the Meter on.

Maximum / Minimum Value / Variable Frequency Measurements

To enter MAX/MIN mode:

1. Press the **MAX/MIN/VFD** button one time.
2. Press **MAX/MIN/VFD** again to select between measuring the minimum or maximum value at any range.
3. Press and hold the **MAX/MIN/VFD** button for two seconds to exit.

Note: **MAX/MIN** does not work with capacitance.

To enter VFD mode:

Note: Exit **MAX/MIN** mode to enter **VFD** mode.

1. Turn the Rotary Switch to the $\widetilde{V}$ **Hz%** position.
2. Press and hold the **MAX/MIN/VFD** button for two or more seconds to enter **VFD** mode.
3. Press and hold the **MAX/MIN/VFD** button for two seconds to exit.

Note: The Meter should be set to selected range prior to entering **MAX/MIN** mode.

Note: Frequency and duty cycle modes cannot be used while in **MAX/MIN** mode.

Measurement Operation

Note: Remove plugs from ends of Test Leads (included) before connecting to Meter.

Note: Test Lead probes have removable covers for overvoltage protection. With covers in place, Test Leads are rated for use with CAT IV circuits. Exposed probes are rated for use with CAT II circuits.

Current Measurement

WARNING! TO PREVENT SERIOUS INJURY: To avoid electric shock, use only one hand to hold Meter when measuring current.

WARNING! TO PREVENT SERIOUS INJURY: Remove test leads before taking measurements with the Current Clamp.

Note: Amperage is always tested in series with circuit under test.

Note: To measure 2- and 3-wire power cords, use an AC Line Splitter (not included) and follow its instructions.

Note: When using manual range mode, always start with the highest range if the amperage is unknown.

Note: Center conductor between guides in Clamp jaws, as shown.



AC/DC Current

Measure AC and DC conductors carrying up to 1000 amperes.

1. Turn the Rotary Switch to the **A≂ 600** or **A≂ 1000** position, depending on the amperage of the conductor under test.
2. Always start with the highest range if the amperage is unknown.
3. Press **MODE/INRUSH** until **AC** or **DC** is displayed.
4. Press **REL/Backlight** button to zero display when in **DC** mode.
5. Using one hand, press Clamp Trigger to open Current Clamp. Position Clamp jaws around conductor to be tested.

Note: When measuring DC current, ensure that current flows in the direction indicated by the Positive (+) and Negative (-) Symbols on the Current Clamp.

6. Read measurement. Switch to lower ranges, as necessary, to get the most accurate reading.
7. When testing is complete, turn Rotary Switch to **OFF,** and store Meter.

Note: If the Display shows **OL** while in manual range mode, the measurement has exceeded the selected range. A higher range should be selected.

Inrush Current

Measure inrush current of AC conductors carrying up to 1000A.

1. Turn the Rotary Switch to the **A≂ 600** or **A≂ 1000** position, depending on the amperage of the conductor under test.
2. Press **MODE/INRUSH** for two or more seconds to switch to **INRUSH** current mode. INRUSH displays while waiting for the inrush current to be detected.
3. Using one hand, press Clamp Trigger to open Current Clamp and insert conductor inside the jaws.
4. Read measured inrush current on the Display. The current is only measured once and the reading is held on the Display.
5. When testing is complete, turn Rotary Switch to **OFF,** and store Meter.

Note: If the Display shows **OL** while in manual range mode, the measurement has exceeded the selected range. A higher range should be selected.

AC/DC Voltage Measurement

Measure AC conductors carrying up to 1000VAC, 50-400Hz.

Measure DC conductors carrying up to 1000VDC.

WARNING! TO PREVENT SERIOUS INJURY: Use caution when working near voltages above 30VAC rms, 42VAC peak, or 60VDC. Voltages this high present a risk of electric shock.

1. Plug black test lead into **COM** Jack. Plug red test lead into **INPUT** Jack.
2. Turn the Rotary Switch to the $\widetilde{V}$ or $\overline{\widetilde{V}}$ position, depending on the voltage of the conductor under test.
3. Press **MODE/INRUSH** until **AC** or **DC** is displayed.
4. Carefully touch exposed conductors with tips of probes.
5. Read measured voltage on the Display.
6. When testing is complete, turn Rotary Switch to **OFF**, remove Test Leads and store with Meter.

Note: If voltage is too high, Meter will sound.

Low Impedance Voltage Measurement

Measure AC conductors carrying up to 1000VAC, 50-400Hz.

WARNING! TO PREVENT SERIOUS INJURY: Use caution when working near voltages above 30VAC rms, 42VAC peak. Voltages this high present a risk of electric shock.

1. Plug black test lead into **COM** Jack. Plug red test lead into **INPUT** Jack.
2. Turn the Rotary Switch to the **LoZ** $\widetilde{V}$ **Hz %** position; **AC** and **LoZ** are displayed.
3. Carefully touch exposed conductors with tips of probes.
4. Read measured voltage on the Display.
5. When testing is complete, turn Rotary Switch to **OFF**, remove Test Leads and store with Meter.

Note: If voltage is too high, Meter will sound.

NCV (Non-Contact AC Voltage)

Move the Probe Tip of the Clamp close to the unshielded conductor or hot side of outlet. If detected voltage is >110VAC, the NCV Indicator will turn on.

WARNING! TO PREVENT SERIOUS INJURY: Even if no indication is given, voltage may still be present. Do not rely solely on NCV detection to determine the presence of voltage.



DOYLE™

Frequency/Duty Cycle Measurement

Measure frequency up to 10kHz.

Note: Frequency and duty cycle modes cannot be used while in minimum and maximum value mode.

In Current Mode:

WARNING! TO PREVENT SERIOUS INJURY: Remove test leads before taking measurements with the Current Clamp.

1. Turn the Rotary Switch to the **A≈ 600** or **A≈ 1000** position, depending on the amperage of the conductor under test.
2. Press the Clamp Trigger to open the Current Clamp and insert conductor inside the jaws.
3. Press **MODE/INRUSH** until **Hz** is displayed.
4. Read measured frequency or duty cycle on the Display.
5. When testing is complete, turn Rotary Switch to **OFF,** and store Meter.

Note: Current test range is 100Hz-10kHz.

In Voltage/Frequency Mode:

1. Plug black test lead into **COM** Jack. Plug red test lead into **INPUT** Jack.
2. Turn the Rotary Switch to the **V̅ Hz%** or **LoZ V̅ Hz %** position.
3. Press **MODE/INRUSH** until **Hz** is displayed.
4. Connect the Test Leads across the circuit to be measured.
5. Read measured frequency or duty cycle on the Display.
6. When testing is complete, turn Rotary Switch to **OFF**, remove Test Leads and store with Meter.

Note: Frequency test range is 100Hz-100kHz. If the frequency is lower than 100.0Hz, **00.0** is shown on the Display.

Note: If the duty cycle is less than 10%, **0.0** is displayed. If the duty cycle is greater than 94.9%, **OL** is displayed.

Resistance Measurement

Measure circuit resistance up to 60M Ohms.

WARNING! TO PREVENT SERIOUS INJURY: To prevent electric shock, turn off all power and fully discharge capacitors on the circuit under test before measuring.

1. Plug black test lead into **COM** Jack. Plug red test lead into **INPUT** Jack.
2. Turn the Rotary Switch to the **Ω →+ •)) CAP** position.
3. Carefully touch exposed conductors with tips of probes.
4. Read measured resistance on the Display.
5. When testing is complete, turn Rotary Switch to **OFF**, remove Test Leads and store with Meter.

Note: Sometimes the resistor value and measured resistance differ. This is due to the Meter's output test current going through all possible paths between leads.

Note: For resistance measurements above 1MΩ, allow a few seconds to get a steady reading.

Note: When leads are disconnected or measurement is out of range, **OL** is displayed.

DOYLE™

Continuity Measurement

Test continuity between two points of a circuit.

WARNING! TO PREVENT SERIOUS INJURY: To prevent electric shock, turn off all power and fully discharge capacitors on the circuit under test before measuring.

1. Plug black test lead into **COM** Jack. Plug red test lead into **INPUT** Jack.
2. Turn the Rotary Switch to the **Ω** ⊣◀ •)) **CAP** position.
3. Press **MODE/INRUSH** until •)) is displayed.
4. Connect the test leads across the circuit to be measured.
5. Read measured resistance on the Display. If the measured resistance is less than 50Ω, Meter will sound.
6. When testing is complete, turn Rotary Switch to **OFF**, remove Test Leads and store with Meter.

Note: If Test Leads are open or the resistance of the circuit is over 50Ω, **OL** is displayed.

Diode Measurement

Test voltage drop in diodes.

WARNING! TO PREVENT SERIOUS INJURY: To prevent electric shock, turn off all power and fully discharge capacitors on the circuit under test before measuring.

1. Plug black test lead into **COM** Jack. Plug red test lead into **INPUT** Jack.
2. Turn the Rotary Switch to the **Ω** ⊣◀ •)) **CAP** position.
3. Press **MODE/INRUSH** until ⊣◀ is displayed.
4. Connect red probe to diode's anode and black probe to its cathode.
5. Read measured forward-biased voltage drop on the Display.

Note: If the test leads are reversed or open, **OL** is displayed.

6. When testing is complete, turn Rotary Switch to **OFF**, remove Test leads and store with Meter.

DOYLE™

Capacitance Measurements

Measure capacitance up to 100mF.

WARNING! TO PREVENT SERIOUS INJURY: Turn off all power and fully discharge capacitors on the circuit under test before measuring.

1. Plug black test lead into **COM** Jack. Plug red test lead into **INPUT** Jack.
2. Turn the Rotary Switch to the Ω →|– •)) **CAP** position.
3. Press **MODE/INRUSH** until **nF** is displayed.
4. Carefully touch capacitor leads with tips of probes.
5. Read measured capacitance on the Display.

Note: Large capacitance values can take up to 6 seconds to display.

6. When testing is complete, turn Rotary Switch to **OFF**, remove Test leads and store with Meter.

Temperature Measurements

WARNING! TO PREVENT SERIOUS INJURY: Turn off all power and fully discharge capacitors on the circuit under test before measuring.

1. Plug Temperature Probe leads into **COM** and **INPUT** Jacks, observing correct polarity.
2. Turn the Rotary Switch to the **TEMP °C °F** position.
3. Press **MODE/INRUSH** until **°C** or **°F** is displayed.
4. Carefully touch temperature probe head to test area until temperature stabilizes (approximately 30 seconds).
5. Read measured temperature on the Display.
6. When testing is complete, turn Rotary Switch to **OFF**, remove Temperature Probe leads and store with Meter.

CAUTION! TO PREVENT INJURY: Make sure Temperature Probe is removed from Meter before selecting another measurement function.

DOYLE™

Procedures not specifically explained in this manual must be performed only by a qualified technician.

Cleaning, Maintenance, and Lubrication

1. Wipe unit with a dry, lint-free cloth. Do not use solvents or abrasives.
2. Remove batteries if not in use for long periods.
3. Store unit in a dry location.
4. Other than the batteries, there are no replaceable parts on this unit. **Repairs should be done by a qualified technician.**

Battery Replacement

If the sign appears on the Display, the battery should be replaced.

1. Remove Test Leads from the Meter.
2. Turn the unit over.
3. Remove screw on battery cover.
4. Open battery compartment.
5. Remove batteriest and replace with the same.

Note: Do not install old and new batteries together. Do not install alkaline, carbon-zinc or rechargeable batteries together. Position batteries in proper polarity. Do not use swollen or leaking batteries.

6. Replace battery cover and screw to secure.

Calibration

Have the Meter calibrated by a qualified technician every year.
A Meter that is not calibrated yearly may not yield accurate results.

Record Product's Date Code Here:_____

Note: If product has no date code, record month and year of purchase instead.

Note: Replacement parts are not available for this item. Reference UPC 193175471468.

3-YEAR LIMITED WARRANTY

This DOYLE product is warranted to the original purchaser to be free from defects in materials and workmanship for a period of three (3) years beginning on the date of purchase. To obtain warranty service, visit your local Harbor Freight retail store. Warranty registration is not required. The product or part must be returned with proof of purchase (e.g. in-store receipt or packing slip/invoice) and may require shipment by purchaser to a service center at purchaser's expense. If our inspection verifies a covered defect in materials or workmanship during the warranty period, we will, at our option, repair or replace the defective product. We will return repaired products within a reasonable time at our expense, but if we determine that there is no defect, or that the defect resulted from causes not within the scope of our warranty, then we will return the product to you if you pay return shipping costs. Fraudulent returns or claims will be denied. The repair or replacement described in this warranty shall be your sole and exclusive remedy.

This warranty does not cover any failure or damage that we determine is due directly or indirectly to:

- normal wear and tear, including, without limitation to, batteries, fuses, test leads, thermocouples, and other wear items
- accident, misuse, abuse, rental, use not for the intended purpose, or use not in accordance with the product manual
- modification, alteration, unauthorized repair, use of equipment or components we did not supply, improper installation
- any other failure not arising from defective materials or workmanship

THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESS WARRANTIES, WRITTEN OR ORAL, AND ANY IMPLIED WARRANTIES ARE DISCLAIMED TO THE EXTENT PERMITTED BY LAW AND OTHERWISE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN. HARBOR FREIGHT SHALL NOT BE LIABLE UNDER ANY CIRCUMSTANCES FOR ANY INCIDENTAL, INDIRECT, SPECIAL, CONSEQUENTIAL, OR PUNITIVE DAMAGES OR COSTS ARISING FROM THIS WARRANTY OR THE USE OF THIS PRODUCT. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THESE LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

DOYLE™

26677 Agoura Road • Calabasas, CA 91302 • 1-800-444-3353