
Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference. 21c

Bauer™

21702CR-B

20v HYPERMAX™ LITHIUM-ION



For Best Results, Use 3.0 Amp Hour Battery Or Greater (Sold Separately)

20v BRUSHLESS COMPACT RECIPROCATING SAW

Blade sold separately.
Visit our website at: http://www.harborfreight.com
Email our technical support at: productsupport@harborfreight.com

58458

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright© 2021 by Harbor Freight Tools®. All rights reserved.
No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

⚠WARNING

Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

Table of Contents

Safety 2
Specifications 7
Setup 8
Operation 10
Maintenance 12
Parts List and Diagram 14
Warranty 16

Bauer™

WARNING SYMBOLS AND DEFINITIONS	
⚠	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
⚠DANGER	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
⚠WARNING	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
⚠CAUTION	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE CAUTION	Addresses practices not related to personal injury.

IMPORTANT SAFETY INFORMATION

General Power Tool Safety Warnings

⚠WARNING

Read all safety warnings, instructions, illustrations and specifications provided with this power tool.
Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

1. **Work area safety**
   a. **Keep work area clean and well lit.** *Cluttered or dark areas invite accidents.*
   b. **Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** *Power tools create sparks which may ignite the dust or fumes.*
   c. **Keep children and bystanders away while operating a power tool.** *Distractions can cause you to lose control.*

2. **Electrical safety**

   a. **Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** *Unmodified plugs and matching outlets will reduce risk of electric shock.*

   b. **Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** *There is an increased risk of electric shock if your body is earthed or grounded.*

   c. **Do not expose power tools to rain or wet conditions.** *Water entering a power tool will increase the risk of electric shock.*

   d. **Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.** *Damaged or entangled cords increase the risk of electric shock.*

   e. **When operating a power tool outdoors, use an extension cord suitable for outdoor use.** *Use of a cord suitable for outdoor use reduces the risk of electric shock.*

   f. **If operating a power tool in a damp location is unavoidable, use a ground fault circuit interrupter (GFCI) protected supply.** *Use of a GFCI reduces the risk of electric shock.*

3. **Personal safety**

   a. **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** *A moment of inattention while operating power tools may result in serious personal injury.*

   b. **Use personal protective equipment. Always wear eye protection.** *Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.*

   c. **Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.** *Carrying power tools with your finger on the switch or energizing power tools that have the switch on invites accidents.*

   d. **Remove any adjusting key or wrench before turning the power tool on.** *A wrench or a key left attached to a rotating part of the power tool may result in personal injury.*

   e. **Do not overreach. Keep proper footing and balance at all times.** *This enables better control of the power tool in unexpected situations.*

   f. **Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing and gloves away from moving parts.** *Loose clothes, jewelry or long hair can be caught in moving parts.*

   g. **If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** *Use of dust collection can reduce dust-related hazards.*

   h. **Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles.** *A careless action can cause severe injury within a fraction of a second.*

   i. Only use safety equipment that has been approved by an appropriate standards agency. Unapproved safety equipment may not provide adequate protection. Eye protection must be ANSI-approved and breathing protection must be NIOSH-approved for the specific hazards in the work area.

   j. Do not lay the tool down until it has come to a complete stop. Moving parts can grab the surface and pull the tool out of your control.

   k. When using a handheld power tool, maintain a firm grip on the tool with both hands to resist starting torque.

   l. Do not leave the tool unattended when the Battery Pack is connected. Turn off the tool, and remove the Battery Pack before leaving.

   m. This product is not a toy. Keep it out of reach of children.

   n. People with pacemakers should consult their physician(s) before use. Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure.

   o. The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

4. **Power tool use and care**

   a. **Do not force the power tool. Use the correct power tool for your application.** *The correct power tool will do the job better and safer at the rate for which it was designed.*

   b. **Do not use the power tool if the switch does not turn it on and off.** *Any power tool that cannot be controlled with the switch is dangerous and must be repaired.*

c. **Disconnect the plug from the power source and/or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools.** *Such preventive safety measures reduce the risk of starting the power tool accidentally.*

d. **Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** *Power tools are dangerous in the hands of untrained users.*

e. **Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use.** *Many accidents are caused by poorly maintained power tools.*

f. **Keep cutting tools sharp and clean.** *Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.*

g. **Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.** *Use of the power tool for operations different from those intended could result in a hazardous situation.*

h. **Keep handles and grasping surfaces dry, clean and free from oil and grease.** *Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.*

5. **Service**

a. **Have your power tool serviced by a qualified repair person using only identical replacement parts.** *This will ensure that the safety of the power tool is maintained.*

b. Maintain labels and nameplates on the tool. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.

6. **Safety instructions for reciprocating saws**

a. **Hold the power tool by insulated gripping surfaces, when performing an operation where the cutting accessory may contact hidden wiring or its own cord.** *Cutting accessory contacting a "live" wire may make exposed metal parts of the power tool " live" and could give the operator an electric shock.*

b. **Use clamps or another practical way to secure and support the workpiece to a stable platform.** *Holding the workpiece by hand or against your body leaves it unstable and may lead to loss of control.*

7. Battery tool use and care

a. **Prevent unintentional starting.** *Ensure the switch is in the off-position before connecting to battery pack, picking up or carrying the power tool. Carrying the power tool with your finger on the switch or energizing power tool that have the switch on invites accidents.*

b. **Disconnect the battery pack from the power tool before making any adjustments, changing accessories, or storing power tool.** *Such preventive safety measures reduce the risk of starting the power tool accidentally.*

c. **Recharge only with the charger specified by the manufacturer.** *A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.*

d. **Use power tools only with specifically designated battery packs.** *Use of any other battery packs may create a risk of injury and fire.*

e. **When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another.** *Shorting the battery terminals together may cause burns or a fire.*

f. **Under abusive conditions, liquid may be ejected from the battery; avoid contact.** *If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.*

g. **Do not use a battery pack or power tool that is damaged or modified.** *Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.*

h. **Do not expose a battery pack or power tool to fire or excessive temperature.** *Exposure to fire or temperature above 265°F may cause explosion.*

i. **Follow all charging instructions and do not charge the battery pack or power tool outside of the temperature range specified in the instructions.** *Charging improperly or at temperatures outside of the specified range may damage the battery and increase the risk of fire.*

j. **Have servicing performed by a qualified repair person using only identical replacement parts.** *This will ensure that the safety of the product is maintained.*

k. **Do not modify or attempt to repair the power tool or the battery pack except as indicated in the instructions for use and care.**

l.  The battery Charger gets hot during use. The Charger's heat can build up to unsafe levels and create a fire hazard if it does not receive adequate ventilation, due

to an electrical fault, or if it is used in a hot environment. Do not place the Charger on a flammable surface. Do not obstruct any vents on the Charger. **Especially avoid placing the Charger on carpets and rugs; they are not only flammable, but they also obstruct vents under the Charger.** Place the Charger on a stable, solid, nonflammable surface (such as a stable metal workbench or concrete floor) at least 1 foot away from all flammable objects, such as drapes or walls. Keep a fire extinguisher and a smoke detector in the area. Frequently monitor the Charger and Battery Pack while charging.

8. **Lithium Battery Safety Warnings**



LITHIUM BATTERIES STORE A LARGE AMOUNT OF ENERGY AND WILL VENT FIRE OR EXPLODE IF MISTREATED:

a. **Keep Battery Pack dry.**

b. **DO NOT DO ANY OF THE FOLLOWING TO THE BATTERY PACK:**
   - **Open,**
   - **Drop,**
   - **Short-circuit,**
   - **Puncture,**
   - **Incinerate, or**
   - **Expose to temperatures greater than 265°F.**

c. Charge Battery Pack only according to its Charger's instructions.

d. Inspect Battery Pack before every use; do not use or charge if damaged.

9. **Vibration Safety**

This tool vibrates during use.
Repeated or long-term exposure to vibration may cause temporary or permanent physical injury, particularly to the hands, arms and shoulders.
To reduce the risk of vibration-related injury:

a. Anyone using vibrating tools regularly or for an extended period should first be examined by a doctor and then have regular medical check-ups to ensure medical problems are not being caused or worsened from use. Pregnant women or people who have impaired blood circulation to the hand, past hand injuries, nervous system disorders, diabetes, or Raynaud's Disease should not use this tool. If you feel any symptoms related to vibration (such as tingling, numbness, and white or blue fingers), seek medical advice as soon as possible.

b. Do not smoke during use. Nicotine reduces the blood supply to the hands and fingers, increasing the risk of vibration-related injury.

c. Wear suitable gloves to reduce the vibration effects on the user.

d. Use tools with the lowest vibration when there is a choice.

e. Include vibration-free periods each day of work.

f. Grip tool as lightly as possible (while still keeping safe control of it). Let the tool do the work.

g. To reduce vibration, maintain the tool as explained in this manual. If any abnormal vibration occurs, stop use immediately.

Grounding

⚠WARNING



TO PREVENT ELECTRIC SHOCK AND DEATH FROM INCORRECT GROUNDING: Check with a qualified electrician if you are in doubt as to whether the outlet is properly grounded. Do not modify the power cord plug provided with the charger. Do not use the charger if the power cord or plug is damaged. If damaged, have it repaired by a service facility before use. If the plug will not fit the outlet, have a proper outlet installed by a qualified electrician.

Extension Cords

Note: Extension cords must not be used with this item's Charger.

Symbology

	Double Insulated
V	Volts
~	Alternating Current
A	Amperes
n_0 xxxx/min.	No Load Revolutions per Minute (RPM)
	WARNING marking concerning Risk of Eye Injury. Wear ANSI-approved safety goggles with side shields.

	Read the manual before set-up and/or use.
	WARNING marking concerning Risk of Fire. Do not cover Charger ventilation ducts. Charge on fireproof surface only.
	WARNING marking concerning Risk of Electric Shock. Properly connect Charger's power cord to appropriate outlet.
	WARNING marking concerning Risk of Explosion. Do not puncture, short, or open battery packs and do not charge damaged battery packs.

Specifications

Battery Type	Bauer 20V 3.0Ah Li-Ion Battery Pack (64816, sold separately)
Charger Type	Bauer 3.0A Charger (57006, sold separately)
No Load Speed	n_0 0-3,000/min
Stroke Length	7/8″

Setup - Before Use:

Read the ENTIRE IMPORTANT SAFETY INFORMATION section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

Note: For additional information regarding the parts listed in the following pages, refer to *Parts List and Diagram* on page 14.

Charging Battery Pack

Charge the battery pack before using this tool. Follow instructions included with Battery Pack (64816, sold separately) and Charger (57006, sold separately).

Installing Battery Pack

Note: Battery Pack and Charger each sold separately.

1. With Trigger in "OFF" Position, push Trigger Lock on left side of tool inward to lock Trigger. Insert a fully charged battery pack into the Battery Receptacle until it clicks in place.
2. To remove, push the latch on the battery pack and slide it out.

Installing/Removing Blade


Warning! To prevent serious injury, remove battery pack before changing blade.

Note: Make sure spindle and blade clamp areas are clean. Metal chips and sawdust may prevent blade clamp from clamping securely.

1. The blade may be inserted with teeth facing up or down. To install a blade, twist collar in the direction of the arrow while inserting blade into clamp until the blade hits collar.
2. Release collar and spring loaded Blade Clamp will hold blade firmly in place.
3. Twist collar in opposite direction of the arrow to ensure that blade is properly locked into clamp.
4. Tug on blade to make sure it is securely locked in place.
5. To remove blade, twist collar in direction of the arrow while pulling on the blade.

Warning! Make sure blade is cooled before touching. Blade may be hot after use.

Components



Battery Receptacle
Collar and
Blade Clamp
Trigger
Lock
Trigger
Work Light
Pivoting Shoe
Bauer
HEAVY DUTY GUARANTEED

Read the ENTIRE IMPORTANT SAFETY INFORMATION section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

Workpiece and Work Area Set Up

1. Designate a work area that is clean and well lit. The work area must not allow access by children or pets to prevent distraction and injury.
2. Secure loose workpieces using a vise or clamps (not included) to prevent movement while working.
3. There must not be objects, such as utility lines, nearby that will present a hazard while working. This is especially critical for plunge cuts.
4. Using a glove, push blade holder all the way back. The workpiece must be thinner than minimum blade extension.
   CAUTION! To prevent injury, do not use on workpieces thicker than the minimum blade extension at their maximum thickness.
   Blade tip can strike workpiece and may shatter.

Properly Sized Workpieces



Workpieces that are Too Thick




Figure A: Maximum Workpiece Thickness

General Instructions for Use

1. Make sure that the Trigger is in the off-position and locked, then attach the Battery Pack.
2. Grip saw firmly with both hands, rest the front of the Pivoting Shoe on workpiece with blade above the work.

Warning! To prevent injury, do not start Saw if Saw Blade is in contact with anything.

3. Push Trigger Lock on right side of tool inward to release Trigger Lock, then press Trigger to start tool. Work Light will turn on when Trigger is pressed and turn off when Trigger is released.
4. The tool has variable speed. To increase speed, apply more pressure to Trigger. To decrease speed, apply less pressure to Trigger.

Note: Use faster speed when cutting softer materials. Use slower speed when cutting harder materials.

5. Allow Saw to come up to desired speed before touching the workpiece. Guide Saw Blade into workpiece.

Warning! To prevent serious injury, keep Shoe pressed firmly against workpiece while cutting to prevent kickback.

6. Maintain smooth motion, guiding blade through material as it is cut. Follow cut. Do not use excessive pressure when pushing down on Saw. If Saw slows down as it is cutting, apply less pressure on the saw.
7. To stop Saw, release Trigger.
8. Allow Saw to come to complete stop before setting down tool.
9. To prevent accidents, lock Trigger, turn off the tool and remove its Battery Pack after use. Clean, then store the tool indoors out of children's reach.

Plunge Cutting

Note: Plunge cut into plywood, sheetrock, and thin board panels. Do not attempt to plunge cut into thick, hard wood or metal panels.

1. Mark cut line on work piece.
2. Place Pivoting Shoe on workpiece with blade parallel to cut line, and NOT touching workpiece.

Warning! To prevent serious injury due to kickback, do not start a plunge cut with Saw Blade touching workpiece.

3. Push Trigger Lock on right side of tool inward to release Trigger Lock. Press Trigger to start tool.
4. Allow Saw to come up to desired speed, then slowly rotate saw on the Pivoting Shoe as the blade contacts the workpiece. Hold saw firmly.
5. Continue to slowly rotate the saw until blade has penetrated through the workpiece. Press the Pivoting Shoe firmly against the workpiece and continue to make the cut.
6. To stop the Saw, release the Trigger. Allow Saw to come to a complete stop before removing from cut.
7. To prevent accidents, lock Trigger, turn off the tool and remove its Battery Pack after use. Clean, then store the tool indoors out of children's reach.

Metal Cutting

1. Install a metal cutting blade. Refer to Installing/ Removing Blade instructions on page 8.
2. Coat the cutting surface with cutting oil to prevent the blade from overheating.
3. Follow General Instruction for Use on page 10.

Maintenance and Servicing Instructions

Procedures not specifically explained in this manual must be performed only by a qualified technician.

⚠WARNING

TO PREVENT SERIOUS INJURY FROM ACCIDENTAL OPERATION:
Make sure that the Trigger is in the off-position and remove its Battery Pack before performing any procedure in this section.

TO PREVENT SERIOUS INJURY FROM TOOL FAILURE:
Do not use damaged equipment. If abnormal noise or vibration occurs, have the problem corrected before further use.

Cleaning, Maintenance, and Lubrication

1. **BEFORE EACH USE,** inspect the general condition of the tool. Check for:
   - leaking, swollen, or cracked battery pack,
   - loose hardware,
   - misalignment or binding of moving parts,
   - cracked or broken parts, and
   - any other condition that may affect its safe operation.
2. **AFTER USE,** wipe external surfaces of the tool with clean cloth.
3. LI-ION BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY.
   Do not short, incinerate or open battery.
4. For blade changing instructions, see Installing/Removing Blade on page 8.
5. Disconnect battery pack and store battery pack, charger, and tool in dry, indoor area out of reach of children and away from metal objects (i.e., paperclips, coins) to prevent shorting.

Troubleshooting

Problem	Possible Causes	Likely Solutions
Tool will not start.	1. Battery Pack not properly connected.	1. Remove Battery Pack, make sure there are no obstructions, reinsert the Battery Pack according to its shape (it should only fit one way), and press firmly until the Battery Pack locks in place.
	2. Battery Pack not properly charged.	2. Make sure Charger is connected and operating properly. Give enough time for Battery Pack to recharge properly.
	3. Battery Pack burnt-out.	3. Dispose of old Battery Pack properly or recycle. Replace Battery Pack.
	4. Internal damage or wear. (Carbon brushes or Trigger, for example.)	4. Have technician service tool.
Tool operates slowly.	1. Forcing tool to work too fast.	1. Allow tool to work at its own rate.
	2. Battery Pack wearing out.	2. Dispose of old Battery Pack properly or recycle. Replace Battery Pack.
Performance decreases over time.	1. Carbon brushes worn or damaged.	1. Have qualified technician replace brushes.
	2. Blade dull or damaged.	2. Keep blades sharp. Replace as needed.
Excessive noise or rattling.	1. Internal damage or wear. (Carbon brushes or bearings, for example.)	1. Have technician service tool.
Overheating.	1. Forcing tool to work too fast.	1. Allow tool to work at its own rate.
	2. Blade dull or damaged.	2. Keep blades sharp. Replace as needed.
	3. Blocked motor housing vents.	3. Wear ANSI-approved safety goggles and NIOSH-approved dust mask/respirator while blowing dust out of motor using compressed air.

Follow all safety precautions whenever diagnosing or servicing the tool.
Disconnect Battery Pack and Charger power supply before service.

PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

Parts List

Part	Description	Qty
1	Pivoting Shoe	1
2	Hex Socket Pan Head Screw, M4x16	2
3	Cross Recessed Countersunk Head Screw, M4x10	1
4	Washer	1
5	Right Gear Case	1
6	Cylindrical Pin, Ø3x10	1
7	Deep Groove Ball Bearing 1	1
8	Pressing Plate	1
9	Cross Recessed Countersunk Head Screw, M4x10	3
10	Gear	1
11	Cylindrical Pin 2, Ø6x18	1
12	Cylindrical Pin 3, Ø3x31	1
13	Bushing 1	1
14	Reciprocating Lever	1
15	Left Gear Case	1
16	Hex Socket Pan Head Screw, M4x16	5
17	Left Housing	1


Part	Description	Qty
18	Hex Socket Pan Head Screw, M4x12	4
19	Hex Socket Pan Head Self-tapping Screw, ST3x16	6
20	Left Motor Housing	1
21	Right Motor Housing	1
22	Stator	1
23	Deep Groove Ball Bearing 2	1
24	Bushing 2	1
25	Rotor	1
26	Hex Socket Pan Head Screw, M4x10	2
27	Pressing Plate	1
28	Deep Groove Ball Bearing 3	1
29	Gear	1
30	Electronic Component Assembly	1
31	Locking Shuttle	1
32	Right Housing	1
33	Hex Socket Pan Head Self-tapping Screw, ST4x16	10

Record Product's Serial Number Here:_____

Note: If product has no serial number, record month and year of purchase instead.

Note: Some parts are listed and shown for illustration purposes only, and are not available individually as replacement parts. Specify UPC 193175439437 when ordering parts.

Assembly Diagram



Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Bauer™

26541 Agoura Road • Calabasas, CA 91302 • 1-888-866-5797