AOLION

无线游戏手柄

Wireless Gaming Controller

ワイヤレスゲームコントローラー

AL-K30

使用说明

User Manual

ユーザーマニュアル

ZSUSTOMI

◆ 产品示意图

平台	典型	连接方式	模式
Platform	System	Connection Method	Mode
SWITCH	NS	有线/无线	Switch Mode
ANDROID	Android系统	有线/无线	Android Mode
IOS	iOS/iPad	有线/无线	MFi Game Controller Mode

◆ 手柄开关机/回连

开机/关机：长按HOME按键约3秒钟震动两下，进入回连搜索模式，关机：长按HOME按键约3秒钟震动一下，关机。

回连：长按手柄开关机键3秒钟进行回连即可使用无线蓝牙之前连接的设备上

◆ PC平台使用

■有线模式无须连接

将手柄与电脑用数据线连接即可

SWITCH模式：适合Switch/Lite/OLED等Windows电脑，Steam平台等游戏

PC/SWITCH模式：适合支持SWITCH手柄模拟器，如SWITCH模拟器内游戏等

◆ IOS平台使用

■设备连接方式连接

将手柄与iOS设备蓝牙连接即可

◆ SWITCH平台使用

将手柄与SWITCH主机连接即可

■蓝牙无线连接

1.切换PC/NS开关至关机，开机一秒再按主机键2.

2.SWITCH主机进入设置-控制器-更换握手柄顺序进行握手匹配即可。

3.支持有线/无线蓝牙连接，支持双震动功能。

◆ ANDROID平台使用

将手柄与安卓手机连接

■蓝牙无线连接

1.切换PC/NS开关至关机，长按手柄HOME键3秒，进入回连搜索模式同时打开手机蓝牙

2.在手机蓝牙设置里搜索“Gamepad”或“扳机键”，选择连接后，出现“已连接”即表示连接成功

◆ IOS平台使用

将手柄与iOS设备连接

■蓝牙无线连接

1.切换PC/NS开关至关机，长按手柄HOME键3秒，进入回连搜索模式同时打开手机蓝牙

2.在手机蓝牙设置里搜索“Xbox Wireless Controller”并进行配对，连接成功后，出现“已连接”即表示连接成功

3.支持支持6轴体感功能，支持震动功能。

◆ ABXY键盘互换功能

手柄除了键盘配置，键盘可切换成东、西、任天堂三种布局，适应不同玩家习惯。

◆ 方向键与左摇杆互换

开机状态下，同时长按【FUNCTION】键和【左摇杆】，切换手柄左摇杆或方向键。

◆ 摇杆边际校准

开机状态下，长按【FUNCTION】键【7】秒震动两下，进入，左右摇杆重新校准，校准完成后震动一下。

◆ 摇杆死区设置

开机状态下，长按【FUNCTION】键【7】秒【8】秒【9】秒，分别为低中高3档死区调节。

◆ 体感模式切换

体感模式切换	体感模式关闭	长按【HOME】键【3】秒以上
	体感模式开启	长按【HOME】键【3】秒以上
一轴/多轴切换	一轴模式	长按【HOME】键【3】秒以上
	多轴模式	长按【HOME】键【3】秒以上
体感灵敏度调节	灵敏度减	【HOME】键【3】秒+【LB】键
	灵敏度增加	【HOME】键【3】秒+【RB】键
体感灵敏度调节	灵敏度减	【HOME】键【3】秒+【LT】键
	灵敏度增加	【HOME】键【3】秒+【RT】键
体感校准	开机状态下	【HOME】键【3】秒+【X】键
	关机状态下	【HOME】键【3】秒+【X】键+【FUNCTION】键

◆ RGB灯带设置

RGB灯带切换	静态【灯光模式】
静态/呼吸/流水/炫彩/跑马灯/渐变	静态【灯光模式】+【FUNCTION】键

◆ 宏编程设置

1.编程模式

【FUNCTION】+【M1】

2.宏键录制设置

【FUNCTION】+【M1】+【A,B,C,D,上,下,左,右,L1,R1,L2,R2,L3,R3,START,SELECT,HOME,MENU】

3.宏键设置参考

【FUNCTION】+【M1】+【A,B,C,D,上,下,左,右,L1,R1,L2,R2,L3,R3,START,SELECT,HOME,MENU】+【M1】+【A,B,C,D,上,下,左,右,L1,R1,L2,R2,L3,R3,START,SELECT,HOME,MENU】

◆ APP软件下载说明

支持iOS、Android手机下载“Joy-Con”APP或游戏类、完美虚拟键盘、开放设置、Playstore APP下载“Joy-Con”

◆ 注意事项

1.本产品含有磁铁，请勿靠近心脏起搏器。

2.请勿将本产品置于高温或明火环境中使用。

3.本产品含有精密电路板，请勿摔落或挤压，以免损坏电路板。

4.请勿将本产品放置在儿童无法触及的地方，以免误吞小零件造成危险。

5.充电时请使用原装充电线或符合规格的充电线，以确保充电安全。

6.如有部件损坏或功能异常，请联系售后客服，切勿自行拆解。

◆ 产品规格

产品型号	AL-K30
产品名称	无线游戏手柄
连接方式	2.4G/BT
充电电压	3.7V/500mA
工作电流	充电时最大500mA，正常使用约40mA
产品尺寸	约152*120*65mm
产品重量	约270g
工作温度	5~40℃
储存温度	-20~60℃

◆ 手柄键盘表

一般游戏模式	键盘	ANDROID	IOS	Android游戏模式	IOS
左摇杆	左摇杆	左摇杆	左摇杆	左摇杆	左摇杆
右摇杆	右摇杆	右摇杆	右摇杆	右摇杆	右摇杆
方向键	方向键	方向键	方向键	方向键	方向键
A	A	A	A	A	A
B	B	B	B	B	B
X	X	X	X	X	X
Y	Y	Y	Y	Y	Y
LB	LB	L1	L1	L1	L1
LT	LT	2L	L2	L2	L2
L3	L3	L3	L3	L3	L3
RB	RB	R1	R1	R1	R1
RT	RT	2R	R2	R2	R2
R3	R3	R3	R3	R3	R3
VIEW	BACK	BACK	SELECT	Screenshot	双击 截屏
MENU	START	+	START	Pause	
-	-	-	-	-	
HOME	HOME	HOME	HOME	HOME	HOME

◆ 产品保修卡

（盖章）（售货（退换货）凭此保修卡于保修期内享一年保修）

产品型号	产品名称
购买日期	购买方式
联系人	联系电话
联系地址	
故障简述	
备注	

◆ 保修条款

- 产品保修自之日起，在以下无其他损坏人为导致的前提，保修期自起算。
- 人为造成导致的产品损坏，包括但不限于：
- 未经授权拆解、改装或维修产品。
- 非本产品导致的损坏，如使用错误、意外事故等。
- 本公司保留对所有电话的最终解释权和修改权。

◆ 保修流程

- 如在保修期内出现问题，产品会提供维修、或换新产品。
- 请保留好购买凭证（如发票或收据），以作为保修期的证明。

合格证

检验员：01

检验日期：

2025年8月

深圳市奥龙创新科技有限公司 www.aolongame.com

◆ Product Diagram

Platform	System	Connection Method	Mode
SWITCH	NS	Wired/Wireless	Switch Mode
ANDROID	Android	Wired/Wireless	Android Mode
IOS	iOS/iPad	Wired/Wireless	MFi Game Controller Mode

◆ PC Platform Usage

■Receiver Connection

Set the platform switch to the PC position.

1. Insert the receiver into a USB port on your PC.
2. Press and hold the button on the receiver for about 1 second until its indicator light starts flashing.
3. Press and hold the pairing button on the controller until its indicator light flashes rapidly, then release it. The controller will enter pairing mode. In fast, sequential pattern, indicating it has entered pairing mode.
4. Wait for the connection to complete. The indicator light will turn solid (steady On).

PC Mode Switching

Make sure the PC/NS switch on the controller for about 2 seconds to enter PC mode. The indicator will flash once.

XINPUT Mode: Select on "Games for Windows" titles and controller settings in Steam for full compatibility.

PC DIRECTION: Suitable for controller games on the Steam platform and games within Switch emulators.

◆ Wired USB Connection

Set the USB switch to PC.

◆ USB Wireless Connection

Set the USB switch to PC.

XINPUT Mode: Select on "Games for Windows" titles and controller settings in Steam for full compatibility.

PC DIRECTION: Suitable for controller games on the Steam platform and games within Switch emulators.

◆ Power On/Off & Reconnection

Power On: Briefly press the [HOME] button to turn on and wake up the controller. The indicator will flash twice and then turn off.

Power Off: Press and hold the [HOME] button for 3 seconds. Reconnect: While the controller is powered on, toggle the platform switch to enter reconnection mode.

◆ PC Platform Usage

■Receiver Connection

Set the platform switch to the PC position.

1. Insert the receiver into a USB port on your PC.
2. Press and hold the button on the receiver for about 1 second until its indicator light starts flashing.
3. Press and hold the pairing button on the controller until its indicator light flashes rapidly, then release it. The controller will enter pairing mode. In fast, sequential pattern, indicating it has entered pairing mode.
4. Wait for the connection to complete. The indicator light will turn solid (steady On).

PC Mode Switching

Make sure the PC/NS switch on the controller for about 2 seconds to enter PC mode. The indicator will flash once.

XINPUT Mode: Select on "Games for Windows" titles and controller settings in Steam for full compatibility.

PC DIRECTION: Suitable for controller games on the Steam platform and games within Switch emulators.

◆ Wired USB Connection

Set the USB switch to PC.

◆ USB Wireless Connection

Set the USB switch to PC.

XINPUT Mode: Select on "Games for Windows" titles and controller settings in Steam for full compatibility.

PC DIRECTION: Suitable for controller games on the Steam platform and games within Switch emulators.

◆ BT Connection

Set the platform switch to NS.

XINPUT Mode

1. Open the PC's BT - Add a device page.
2. Press and hold the pairing button to enable the [HOME] button for 2 s mode until the [HOME] button flashes rapidly, then release it to enter pairing mode.
3. On the PC's BT page, search, search for and pair with "Xbox Wireless Controller".
4. Upon successful connection, the LED1-LED4 channel indicators will stay On.

5. Device Identifier Selection: [HOME] + [X]

◆ SWITCH Platform Usage

Set the platform switch to the NS position.

■BT Connection

1. On the SWITCH home screen, select Controllers -> Change Grip/Order.
2. With the controller powered on, press and hold the [HOME] button for 5 seconds to enter pairing mode. The LED1-LED4 channel indicators will flash in a rapid sequence, entering pairing mode.
3. Wait for the connection to complete. The LED1-LED4 channel indicators will stay On, indicating a successful connection.

SWITCH Console Wake-up Feature

1. When the BT/2.4G switch is set to BT mode and the controller is in BT mode, press the [HOME] button once to reconnect and wake up the console.
2. If the controller fails to wake the SWITCH console, make the connection manually.

■Wired Connection

1. On the SWITCH home screen, select System Settings -> Controllers and Sensors -> Pro Controller Wired Communication -> Enable.
2. Connect the controller to the SWITCH console using a USB-C cable to connect the controller for wired connection.
3. Once connected, the controller will automatically turn on.
4. Once the PC connection is fully charged, switching a second time.

Note: If using a different USB-C cable, reconnect the controller to the dock's USB port using a USB-C cable.

◆ Android Platform Usage

Set the platform switch to NS.

■BT Connection

1. With the controller powered on, press and hold the [HOME] button for 5 seconds. Release when the LED1-LED4 channel indicators flash rapidly, entering pairing mode.
2. Enable BT on your device and search for "Gamepad" to pair. Once connected, the LED1-LED4 channel indicators will stay On.
3. Supports 6-axis motion control and vibration. Press and hold the turn-off pairing mode and vibrate once after approximately 3 minutes and will turn off.

◆ IOS Platform Usage

Set the platform switch to NS.

■BT Connection

1. With the controller powered on, press and hold the [HOME] button for 5 seconds. Release when the LED1-LED4 channel indicators flash rapidly, entering pairing mode.
2. Enable BT on your device and search for "Xbox Wireless Controller" to pair. Once connected, the LED1-LED4 channel indicators will stay On.
3. Supports 6-axis motion control and vibration. Press and hold the turn-off pairing mode and vibrate once after approximately 3 minutes and will turn off.

◆ Controller Calibration Function

If the controller's joystick, motion sensor, or triggers are abnormal, perform the calibration operation.

Joystick Calibration: Press and hold [FUNCTION] + [Left Joystick] for 7 seconds to enter joystick calibration mode. The controller will vibrate twice. Move the joystick in a circular motion around the joystick edges. Then, press and hold [X] (XBOX), and [MENU] (PS) + [Left Joystick] for 7 seconds to exit calibration mode. The controller will vibrate once, indicating the calibration has been completed successfully.

Motion Sensor Calibration: Place the controller on a flat surface for 3-5 seconds. Then, press and hold [HOME] + [X] for 3 seconds. The controller will vibrate twice, indicating the calibration has been completed successfully.

Trigger Calibration: Press and hold [FUNCTION] + [LT] / [RT] for 7 seconds. The controller will vibrate twice. Fully press the LT/RT trigger to the end position, then release it. The controller will vibrate once, indicating the calibration has been completed successfully.

◆ ABXY Key Value Swap Function

After removing the magnetic faceplate of the controller, toggle the character switch to switch between Nintendo, Xbox, and PlayStation layouts to fit the key layout you are familiar with.

◆ D-pad/Left Joystick Swap Function

With the controller powered on, press and hold [HOME] and [MENU] for 1 second to swap the key values of the left joystick and the D-pad.

◆ Joystick Edge Switching

With the controller powered on, press and hold [HOME] and the [Capture Button] for 3 seconds to enter edge switching mode.

◆ Joystick & Dead Zone Setting

With the controller powered on, press and hold the key combination [C], [HOME] and [MENU] for 3 seconds to enter calibration mode. The controller will vibrate twice. Move the joystick and trigger.

◆ Motion Mapping Joystick

Enable/Disable Motion Mapping	Key Combination: [HOME] + [C] + [LB]
Axis Inversion Toggle	Key Combination: [HOME] + [C] + [RB]
Increase Sensitivity	Key Combination: [HOME] + [C] + [D-pad Up]
Decrease Sensitivity	Key Combination: [HOME] + [C] + [D-pad Down]
Switch Gyroscope Axis	Key Combination: [HOME] + [C] + [D-pad Left]
Toggle Gyroscope Axis	Key Combination: [HOME] + [C] + [D-pad Right]
Sensitivity Adjustment	Increase 1 key sensitivity: [HOME] + [C] + [LT] (Press 1 time) Decrease 1 key sensitivity: [HOME] + [C] + [RT] (Press 1 time)
Reset Motion Mapping	Restore to default: [HOME] + [C] + [MENU] (Press 3 times)

◆ RGB Lighting Settings

RGB Lighting Mode Switching	Increase Brightness
	Decrease Brightness
Static Color Switching	Switch between static colors and preset effects
Static Color Switching	Switch between static colors and preset effects

◆ Macro Programming Settings

1. Default Programming Key:
   [FUNCTION] + [M1]
2. Macro Recording Keys:
   [FUNCTION] + [M1] + [A, B, C, D, Up, Down, Left, Right, Right Stick Up, Down, Left, Right, L1, R1, L2, R2, L3, R3, START, SELECT, HOME, MENU]
3. Macro Playback Keys:
   [FUNCTION] + [M1] + [A, B, C, D, Up, Down, Left, Right, Right Stick Up, Down, Left, Right, L1, R1, L2, R2, L3, R3, START, SELECT, HOME, MENU] + [M1] + [A, B, C, D, Up, Down, Left, Right, Right Stick Up, Down, Left, Right, L1, R1, L2, R2, L3, R3, START, SELECT, HOME, MENU]

◆ Controller Vibration Settings

1. Vibration Set four intensity levels: Strong (100%), Medium (70%), Weak (40%), Off (0%).
2. Default setting: Medium (70%).
3. Press and hold [FUNCTION] + [TURBO] for over 3 seconds for the [Left 3D Stick/Joystick] to adjust vibration intensity.
4. Vibration intensity is saved automatically after setup.
5. Vibration intensity is restored to [Medium (70%)] after one Strong Vibration. Channel indicators LED1-LED4 flash once. Strong Vibration. Channel indicators LED1-LED4 flash once.

◆ Battery Level Display Instructions

Press and hold [HOME] + [Left Joystick] to check the battery level. Battery Level Indicators: LED1-LED4 channel indicators remains constantly On. Mode 1: Battery turns off after one minute, press and hold [HOME] for 1 sec to turn on. Mode 2: Battery remains constantly On.

◆ Charging Function

Charge using a USB-C cable.

1. Charging Power Source: Standard 5V/1A voltage. You can use a phone charger, power bank, or computer USB port to charge the controller.
2. Charging Indicator: The LED1-LED4 channel indicators will flash in a rapid sequence while charging. Once fully charged, the indicators will stop flashing and remain solid.
3. Charging Time: Approximately 2 hours when fully discharged.
4. Low Battery Alert: When the battery level is below 20%, the wireless RGB lighting turns off, and the current active channel indicator flashes slowly.

◆ Sleep Function

1. Manual Sleep: Press and hold the [HOME] button for 3 seconds to enter sleep mode. The controller will vibrate once.
2. Fast Host Pairing Mode: The controller enters sleep mode if no connection is established within 5 minutes.
3. Working State: The controller enters sleep mode after 5 minutes without any operation or connection.

Sleep Mode: Press the [HOME] button to wake the controller.

◆ Reset Function

Charge the controller before using it for the first time or if it has been stored for a long time. Use the Reset function on the controller to clear any previous connection data and restore it to factory settings.

Reset Method: Press and hold [HOME] + [LT] + [RT] for 3 seconds to activate. After resetting, [TURBO], [Wireless], and [Macro] Programming settings will be restored to factory defaults.

◆ APP Software Download Instructions

Supports downloading the “Xbox Gear” APP from iOS and Android phones, and can connect to the APP for personalized settings and upgrade functions. (Xbox Gear APP download)

◆ Precautions

1. Keep out of reach of children and pets to prevent swallowing hazards.
2. Do not use or store the product in damp environments.
3. Do not disassemble or modify the product without permission to prevent affecting its normal use.
4. If the product becomes overheated or wet, or damaged by impact or deformation, please stop using it immediately and contact customer service.
5. Please stop using it immediately if you feel discomfort, such as dizziness or nausea, during use, and consult a doctor if necessary.
6. If damaged, please send it to a repair department promptly. Do not disassemble it yourself.
7. Do not allow children to play with the product.

◆ Sleep Function

1. Manual Sleep: Press and hold the [HOME] button for 3 seconds to enter sleep mode. The controller will vibrate once.
2. Fast Host Pairing Mode: The controller enters sleep mode if no connection is established within 5 minutes.
3. Working State: The controller enters sleep mode after 5 minutes without any operation or connection.

Sleep Mode: Press the [HOME] button to wake the controller.

◆ Reset Function

Charge the controller before using it for the first time or if it has been stored for a long time. Use the Reset function on the controller to clear any previous connection data and restore it to factory settings.

Reset Method: Press and hold [HOME] + [LT] + [RT] for 3 seconds to activate. After resetting, [TURBO], [Wireless], and [Macro] Programming settings will be restored to factory defaults.

◆ APP Software Download Instructions

Supports downloading the “Xbox Gear” APP from iOS and Android phones, and can connect to the APP for personalized settings and upgrade functions. (Xbox Gear APP download)

◆ 产品规格

型号	AL-K30
产品名称	无线游戏手柄
连接方式	2.4G/BT
充电电压	3.7V/500mA
工作电流	充电时最大500mA，正常使用约40mA
产品尺寸	约152*120*65mm
产品重量	约270g
工作温度	5~40℃
储存温度	-20~60℃

◆ 手柄键盘表

一般游戏模式	键盘	ANDROID	IOS	Android游戏模式	IOS
左摇杆	左摇杆	左摇杆	左摇杆	左摇杆	左摇杆
右摇杆	右摇杆	右摇杆	右摇杆	右摇杆	右摇杆
方向键	方向键	方向键	方向键	方向键	方向键
A	A	A	A	A	A
B	B	B	B	B	B
X	X	X	X	X	X
Y	Y	Y	Y	Y	Y
LB	LB	L1	L1	L1	L1
LT	LT	2L	L2	L2	L2
L3	L3	L3	L3	L3	L3
RB	RB	R1	R1	R1	R1
RT	RT	2R	R2	R2	R2
R3	R3	R3	R3	R3	R3
VIEW	BACK	BACK	SELECT	Screenshot	双击 截屏
MENU	START	+	START	Pause	
-	-	-	-	-	
HOME	HOME	HOME	HOME	HOME	HOME

◆ 製品仕様

製品モデル	AL-K30
製品名	ワイヤレスゲームコントローラー
接続方式	2.4G/BT
充電電圧	3.7V/500mA
動作電流	充電時最大500mA、通常使用時約40mA
製品サイズ	約152*120*65mm
製品重量	約270g
動作温度	5~40℃
保管温度	-20~60℃

◆ スリープ機能

1. 手動スリープ：[HOME]ボタンを3秒間長押しすると、コントローラーがスリープモードに入ります。コントローラーが1回振動します。
2. 高速ホストペアリングモード：コントローラーは5分以内に接続が確立されない場合、スリープモードに入ります。
3. 動作状態：コントローラーは5分以内に操作や接続がない場合、スリープモードに入ります。

スリープモード：[HOME]ボタンを押すとコントローラーがウェイクアップします。

◆ リセット機能

初めて使用する前、または長期間保管した後は、コントローラーを充電してください。リセット機能を使用して、コントローラーの以前のペアリングデータをすべてクリアし、工場出荷時の設定に復元します。

リセット方法：[HOME]+[LT]+[RT]ボタンを3秒間長押しします。リセット後、[TURBO]、[ワイヤレス]、[マクロプログラミング]の設定は工場出荷時のデフォルトに戻ります。

◆ APPソフトウェアダウンロード説明

iOSおよびAndroidスマートフォンで「Xbox Gear」APPをダウンロードして、APPに接続してパーソナライズ設定やアップグレード機能を利用できます。（Xbox Gear APPをダウンロード）

◆ 注意事項

- 本製品には磁石が含まれています。心臓ペースメーカーを使用している方は、近づけないでください。
- 本製品を高温または火気のある環境で使用しないでください。
- 本製品には精密な回路基板が含まれています。落下や圧迫を避けてください。回路基板が損傷する恐れがあります。
- 本製品を子供の手の届かない場所に保管してください。誤って小さな部品を飲み込む危険があります。
- 充電時は、付属の充電線、または仕様を満たす充電線をご使用ください。安全な充電を確保するためです。
- 部品が破損したり、機能に異常が発生した場合は、アフターサービスにご連絡ください。自分で分解しないでください。

◆ コントローラー基本一键一览表

基本ゲームモード	キーボード	ANDROID	IOS	Androidゲームモード	IOS
左スティック	左スティック	左スティック	左スティック	左スティック	左スティック
右スティック	右スティック	右スティック	右スティック	右スティック	右スティック
方向キー	方向キー	方向キー	方向キー	方向キー	方向キー
A	A	A	A	A	A
B	B	B	B	B	B
X	X	X	X	X	X
Y	Y	Y	Y	Y	Y
LB	LB	L1	L1	L1	L1
LT	LT	2L	L2	L2	L2
L3	L3	L3	L3	L3	L3
RB	RB	R1	R1	R1	R1
RT	RT	2R	R2	R2	R2
R3	R3	R3	R3	R3	R3
VIEW	BACK	BACK	SELECT	スクリーンショット	双击 截屏
MENU	START	+	START	ポーズ	
-	-	-	-	-	
HOME	HOME	HOME	HOME	HOME	HOME