
WARNING:SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

D3019 **110V**

Chandelier Lighting




Parrot Uncle

D3019 **110V**

Installation & Operating Instructions for the
Parrotuncle Owner's Installation ,Manual

WARNING:SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

PACKAGE CONTENTS



PART	DES CRIP TION	QTY.
A	Canopy	1
B	Mounting bracket	1
C	Outlet box screw	2
D	Canopy lock ring	1
E	Chain	1
F	Loop	1
G	Rod	1

PART	DES CRIP TION	QTY.
H	Decorative part	1
I	Socket	5
J	Shade	5
K	Steel collar	5
L	Socket collar	5
M	Socket collar tool	1
N	Lamp body	1
O	Quick link	2


D3019 **110V**

Installation & Operating Instructions for the
Parrotuncle Owner's Installation ,Manual

WARNING:SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

HARDWARE CONTENTS

AA



Wire
Connector
Qty: 3

! SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.

! WARNING

- IMPORTANT: NEVER attempt any work without shutting off the electricity.
- Place the main power switch in the "OFF" position and unscrew the fuse(s), or switch "OFF" the circuit breaker switch(es), that control the power to the fixture or room you are working in.
- Place the wall switch in the "OFF" position. If the fixture to be replaced has a switch or pull chain, place it in the "OFF" position.
- Do not use bulbs with wattage greater than specified on this fixture.
- California Prop. 65: This lighting fixture contains chemicals known to the state of California to cause cancer, birth defects, and/or other reproductive harm. Wash hands after use.

CAUTION

- If you have any doubts about how to install this lighting fixture, or if the fixture fails to operate completely, please contact a licensed electrical contractor.
- All parts must be used as indicated in these instructions. Do not substitute any parts, leave parts out, or use any parts that are worn out or broken. Failure to obey this instruction could invalidate ETL listing and/or C.S.A. certification of this fixture.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated assembly time: 30 minutes to 1 hour

Tools Required for Assembly (not included): Phillips screwdriver, wire strippers, electrical tape, ladder.

D3019 **110V**

Installation & Operating Instructions for the
Parrotuncle Owner's Installation ,Manual


WARNING:SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

ASSEMBLY INSTRUCTIONS

1. Rod (G) Decorative part (H)


   Lamp body (N)

   Note: Unfold the support arms of the lamp body to proper locations. Guide the fixture wire with bare copper ground wire through the decorative part and the rod. Place the decorative part on top of the lamp body and secure with the rod.



2. Loop (F) Rod (G)

   Note: Guide the fixture wire with bare copper ground wire through the loop, and screw the loop onto the top of the rod securely.



D3019 **110V**


Installation & Operating Instructions for the
Parrotuncle Owner's Installation ,Manual

WARNING:SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

ASSEMBLY INSTRUCTIONS


3. Chain (E) Quick link (O) Loop (F)

Note: Adjust the chain to the desired length, removing links if necessary. Connect one end of the chain to the loop with one quick link and close the quick link.



4. Mounting bracket (B) Outlet box screw (C)


Note: Secure the mounting bracket to the outlet box (not included) with outlet box screws. Tighten until snug.



5. Mounting bracket (B) Canopy (A)

Canopy lock ring (D)

Note: Remove the pre-assembled canopy lock ring from the mounting bracket. Temporarily attach the canopy to the pre-assembled nipple on the mounting bracket. Secure with the canopy lock ring.




WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

ASSEMBLY INSTRUCTIONS


6. Mounting bracket (B) Quick link (O)

   Chain (E)

   Note: Connect the other end of the chain to the canopy chain loop preassembled to the mounting bracket with the remaining quick link.




7. Pull the supply wires and ground wire up through the chain alternating links. Push the ends of the supply wires and ground wire up through the canopy chain loop and into the outlet box. The remaining slack wire will be inserted into the outlet box in STEP 9.



8. Mounting bracket (B) Canopy (A)

   Canopy lock ring (D)

   Note: Unthread the canopy lock ring. Slide the canopy lock ring and the canopy down the quick link. Push all slack fixture wire through the canopy chain loop and into the outlet box.



WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

ASSEMBLY INSTRUCTIONS

9. Wire connection guide:

Ground wire:

. **For installation in the United States:** Wrap ground wire from outlet box around ground screw preassembled on mounting bracket (B) no less than 2 in. from wire end. Tighten ground screw. If fixture is supplied with a ground wire, connect to outlet ground wire with a wire connector (AA).

. **For installation in Canada:** If fixture is supplied with ground wire, wrap ground wire around ground screw on mounting bracket (B). Tighten ground screw. Connect fixture ground wire to outlet ground wire with the wire connector (AA).

Supply wires:

. Connect the Neutral (White) supply wire from the outlet box to the Neutral fixture wire (White or Parallel Cord "D" shaped and ribbed).


. Connect the Hot (Black) supply wire from the outlet box to the Hot fixture wire (Black or Parallel Cord round and smooth).

NOTE:


Fixture wires will either be:

. Black and White.

. Parallel Cord SPT-1 lamp wire with one round smooth wire and one "D" shaped ribbed wire.




Hardware Used

AA Wire Connector  x 3

10. Mounting bracket (B) Canopy (A)

Canopy lock ring (D)

Note: Attach the canopy back over the canopy chain loop. Secure with the canopy lock ring.



Parrot Uncle

D3019 **110V**

Installation & Operating Instructions for the
Parrotuncle Owner's Installation ,Manual


WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

ASSEMBLY INSTRUCTIONS

11. Socket collar tool (M) Socket collar (L)


    Steel collar (K) Shade (J) Socket (I)

    Note: Remove the socket collar and the steel collar from the socket. Place the shade and the steel collar over the socket as shown. Using the socket collar tool, thread the socket collar onto the socket to secure the steel collar and the shade. Hand-tighten until snug.



12. Install the correct bulbs (not included) referring to fixture markings and/or labels for maximum wattage.

NOTE: Use five 100W maximum medium base (E26) type "A" or 16W maximum medium base (E26) self-ballasted LED bulb (sold separately).



CARE AND MAINTENANCE

. Always be certain that electric current is turned off before cleaning this item.
. Use a soft, moist cloth with mild non-abrasive soap to clean fixture. Never use glass cleaner on fixture, as it will damage the metal finish.
. All glass shades may be washed in a towel-lined sink with warm water and mild soap. Do not wash shades in an automatic dishwasher.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Fixture does not light.	1. Fixture may be wired incorrectly.	1. Check wiring.
	2. Worn or broken bulb.	2. Replace bulb.

WARRANTY

Parrot Uncle warrants that its products will be free from defects in material and workmanship for one (1) year from the date of purchase by the Original Purchaser.

To replace a product that has a warranted defect, the Original Purchaser shall return any allegedly defective parts or products to the authorized Parrot Uncle warehouse that the product was purchased from with PROOF OF PURCHASE, Original Purchaser's name and return address and a description of the claimed product defect.

If any of the warranted products are found by Parrot Uncle, in its sole discretion, to be defective, such products will, at Parrot Uncle's sole option and cost, be replaced, repaired or refunded less an amount directly attributable to Original Purchaser's prior use of the product. Parrot Uncle will return the repaired or replaced product prepaid freight. This warranty does not cover labor or other costs or expenses to remove or install any defective, repaired or replaced product.

The parties here to expressly agree that Original Purchaser's sole and exclusive remedy against Parrot Uncle shall be for the repair, replacement or refund of defective products as provided here in. This warranty extends only to product ownership by the Original Purchaser; is not transferable whether to heirs, subsequent owners, or otherwise; and is void if the Original Purchaser ceases to own the product.

This warranty does not apply to any products that have been subjected to misuse, mishandling, misapplication, connected to voltage at more than 5% above standard North American voltage, unusual use (including but not limited to use in an environment where the annual average ambient operating temperature is below 27 or above 95 degrees Fahrenheit), neglect (including but not limited to improper maintenance), accident, acts of god such as high winds, improper installation or care, failure to follow the Product's written instructions for normal use and care, improper packaging of products returned to Parrot Uncle, modification (including but not limited to use of unauthorized parts or attachments), or adjustment or repair. Significant product exposure to chemicals, harsh cleaners, salt water or salt air will void any and all warranties on exterior finishes. This warranty only applies when all components, including transformers, have been provided by Parrot Uncle. Substituting another manufacturer's product and/or components will render the warranty completely void.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

THE FOREGOING WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THOSE OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR INFRINGEMENT. ORIGINAL PURCHASER SHALL IN NO EVENT BE ENTITLED TO, AND PARROT UNCLE SHALL NOT BE LIABLE FOR, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE, INCLUDING, BUT NOT LIMITED TO LOSS OF PROFIT, PROMOTIONAL AND/OR MANUFACTURING EXPENSES, OVERHEAD, INJURY TO REPUTATION AND/OR LOSS OF CUSTOMERS.