# Owner's Manual & Safety Instructions

**Save This Manual** Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's Date Code in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference. 26c

CENTRAL MACHINERY®

# 29" HEAVY DUTY TOOL STAND



**95128**

**Visit our website at: https://www.harborfreight.com**
**Email our technical support at: productsupport@harborfreight.com**

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please visit harborfreight.com/customer-service/contact-us as soon as possible.

Copyright© 2026 by Harbor Freight Tools®. All rights reserved.
No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.
Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein.
Tools required for assembly and service may not be included.

## ⚠WARNING

Read this material before using this product.
Failure to do so can result in serious injury.
SAVE THIS MANUAL.

## Specifications

| | |
|---|---|
| Max Load Capacity | 300 Lbs |

# IMPORTANT SAFETY INFORMATION

## Assembly Precautions

1. Assemble only according to these instructions. Improper assembly can create hazards.
2. Wear ANSI-approved safety goggles and heavy-duty work gloves during assembly.
3. Keep assembly area clean and well lit.
4. Keep bystanders out of the area during assembly.
5. Do not assemble when tired or when under the influence of alcohol, drugs or medication.
6. Weight capacity and other product capabilities apply to properly and completely assembled product only.

## Use Precautions

1. This product is not a toy. Do not allow children to play with or near this item.
2. Use as intended only.
3. Inspect before every use; do not use if parts are loose or damaged.
4. Do not modify this tool to perform a task for which it was not designed.
5. Do not stand on top of the Tool Stand.
6. Place stand on flat, level, sturdy surface capable of supporting stand, tool, and all workpieces.
7. Secure tool to stand before use. If tool does not bolt securely to stand, do not use it with this stand.
8. Do not exceed listed weight capacity. **Be aware of dynamic loading!** Sudden load movement may briefly create excess load causing product failure.
9. Maintain product labels and nameplates. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.


CENTRAL MACHINERY

## Assembly Instructions


**Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this document including all text under subheadings therein before set up or use of this product.**

**<u>Note:</u>** Finger tighten hardware until assembly is completed.


1. Attach a Foot to the bottom of each Leg.





2. Attach each Lower Long Brace to two Legs with four Carriage Bolts (4), Washers (5), and Nuts (6).





3. Attach Lower Short Braces to Legs with eight Carriage Bolts (4), Washers (5), and Nuts (6).




4. Attach Upper Short Braces to Legs with eight Carriage Bolts (4), Washers (5), and Nuts (6).




5. Attach Upper Front and Back Braces to Legs with eight Carriage Bolts (4), Washers (5), Nuts (6).




6. Attach Upper Cross Brace to the center of Upper Front and Back Braces with four Carriage Bolts (4), Washers (5), and Nuts (6).

7. Tighten all hardware securely.




8. Place Tool Stand on flat, level, sturdy surface capable of supporting Stand, tool, and all workpieces.

**<u>CAUTION!</u> TO PREVENT INJURY:** Secure tool to stand before use. If tool does not bolt securely to stand, do not use it with this stand.

9. Mount tool (sold separately) to Tool Stand using appropriate hardware (sold separately).

10. When finished, clean, then store the Tool Stand indoors out of children's reach.

CENTRAL MACHINERY

# PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE COMPONENT LIST AND ASSEMBLY DIAGRAM IN THIS DOCUMENT AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.


CENTRAL MACHINERY

## Component List

| Part | Description | Qty |
|---|---|---|
| 1 | Foot | 4 |
| 2 | Leg | 4 |
| 3 | Lower Side Brace | 2 |
| 4 | Carriage Bolt M6 x 1.0-12 | 34 |
| 5 | Washer 5/16 | 34 |
| 6 | Nut 6 x 1.0 | 34 |

| Part | Description | Qty |
|---|---|---|
| 7 | Lower Front/Back Brace | 2 |
| 8 | Upper Side Brace | 2 |
| 9 | Upper Front Brace | 1 |
| 10 | Upper Cross Brace | 1 |
| 11 | Upper Back Brace | 1 |

## Assembly Diagram




CENTRAL MACHINERY


For product assistance, please visit harborfreight.com/customer-service/contact-us

**Record Date Code Here:**

---

**Note:** If product has no Date Code, record month and year of purchase instead.

**Note:** The component list and assembly diagram are shown for reference only. To view all currently available replacement parts, please visit harborfreight.com/parts

Specify UPC 193175569585 when ordering parts.

CENTRAL MACHINERY

## Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

CENTRAL MACHINERY

**26677 Agoura Road • Calabasas, CA 91302 • 1-800-444-3353**