
Parrot Uncle

F6355110V



Parrot Uncle

F6355110V

Installation & Operating Instructions for the
Parrotuncle Owner's Installation, Manual

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

Safety Information

1. To reduce the risk of an electrical blow, electricity on the protective switch or the safety box went out before starting.
2. All wiring must correspond to the NASI/NFPA 70-1999 National Electric Code and local electrical regulations. The electrical installation must be carried out by a qualified and approved electrician.
3. The connection box and support construction must be assembled safely and 35 pounds (15.9 kilos) must be able to transport reliably. Use only output boxes listed with labeling.

   "Accepted for fans with a weight of 35 lbs (15.9 kg) or less."
4. The fan must be installed with a minimum distance of 2.1 m (7 feet) from the posterior edge of the wings to the floor.
5. Do not operate the reverse switch if the fan wings are moving. You have to turn off the fan and stop the wings before reverse the direction of the wing.
6. Do not place objects on the road to wings.
7. To avoid lesions or damage to the fan and other objects, be careful if you work on the fan or clean it.
8. Electrical diagrams only serve as a reference. The lighting rates that are not delivered with the fan must be listed and marked with the valve model that will be installed for use. The switches must be general use switches UL. Take into account the instructions for the appropriate installation included in the lighting rates and the switches.
9. After the electrical connections have been made, the size staircase must be turned up and carefully push to the plug box. The cables must be distributed in such a way that the ground connected driver and the device head are next to the socket.

   All fixing screws must be verified before installation and, if necessary, followed.

WARNING: To reduce the risk of injury, knife supports (also known as flanges) cannot be folded during installation or after installation. Do not put any object on the path of wings.

WARNING: Remove rubber motor attacks at the bottom of the fan before mounting the wings or try the engine.

WARNING: To avoid the risk of a fire or an electrical blow, this fan should not be used with a semiconductor speed controller.

WARNING: To avoid a possible electric shock, turn off the current in the main security box before wiring. If you feel that you do not have enough knowledge or experience in electrical wiring, communicate with a license electrician.

WARNING: Electrical diagrams only serve as a reference. The optional use of a lighting rate must be on the list and marked with this fan for use.

WARNING: To reduce the risk of fires, electrical discharges, or injuries, assemble the device in a socket that with the inscription is accepted for fans with a weight of 35 lbs (15.9 kg) or less. It is marked and use the screws supplied with the plug.

TECHNICAL INFORMATION

SKU	Nominal voltage	Nominal output (motor)	Light
F6355110V	110-120V AC	53W	2*E26 MAX.25W (Not included)

Parrot Uncle

F6355110V

Installation & Operating Instructions for the
Parrotuncle Owner's Installation, Manual

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER



Wood screw(4PCS)



Plastic wire nut(3PCS)



Blade bracket screw(1PCS)



Mounting screw(2PCS)




Washer(2PCS)



Spring washer(2PCS)



Screws for light (1PCS)




Balanced parts package (1PCS)




Blade screw(16PCS)




Blade washer(16PCS)




REMOTE CONTROL(1PCS)



Mounting bracket



Fan-motor assembly




Decorative cover

Biade(5PCS)

Biade bracket (5PCS)





Linht shade

Please check whether above accessories are completed or not? Yes,and install.


Parrot Uncle

F6355110V

Installation & Operating Instructions for the
Parrotuncle Owner's Installation, Manual

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

1




Take the finished F6355110V out of the packing box.

2

INSTALLING THE FAN:
1.Tools Required: Phillips screwdriver, pair of pliers, straight slot screwdriver, adjustable wrench, stepladder,and wire cutters.


INSTALLING THE MOUNTING BRACKET:The ceiling fan must be installed in a location so that the blades are 12"(300mm) spacing from the tip ofthe blade to the nearest objects or walls. When hanging the Fan REMEMBER to turn off the power.
2.Followthe instruction below to hang your fan properly:1.For concrete ceiling, drill two holes in the ceiling and secure the mounting bracket to the ceiling with two 0.32"(8mm) (distance between the two holes should be appropriate)expansion screws, flat washers.nuts provided and tighten with a spanner.




⚠ Note

Check whether it is securely installed.

3.For instaling to outlet box, secure the outlet box directly to the building structure. Use appropriatefasterners and building materials. The outlet box and its support must be able to fully support the movingweight of the fan(at least 100lbs). Use a UL listed metal outlet box. Do not use a plastic outlet box. Figure1& 2 examples to mount the outlet box.




3



Use a Phillips screwdriver toloosen the screw in the directionof the arrow shown in the figureand place the screw for subsequentinstallation.

⊕ Phillips screwdriver

4



Place the left tab (A)of the lower mountingbracket into a left large slot (A) in the uppermounting bracket. Then slide the right tab(B with Oval Hole) of the lower mountingbracket into the right large slot (B) on theupper mounting bracket until all four holesare in alignment.(PS: A tab is for A slot, andB tab is for B slot)

⊕ Phillips screwdriver


Parrot Uncle

F6355110V

Installation & Operating Instructions for the
Parrotuncle Owner's Installation, Manual


WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

5



Re-install the previously removed lower bracketscrews to secure the lower mounting bracketand the upper mounting bracket.


6



Safety rope installation procedure.


⊕ Phillips screwdriver

7



Installation of decorative cover.

8



Installation of blade and blade bracket.

⊕ Phillips screwdriver


Parrot Uncle

F6355110V


Installation & Operating Instructions for the
Parrotuncle Owner's Installation, Manual

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

9




⊕ Phillips screwdriver



Blade assembly installation diagram.


10



⊕ Phillips screwdriver


Lampshade installation diagram.

11



E26 bulb installation diagram.

12



The product installation is complete.

Parrot Uncle

F6355110V

Installation & Operating Instructions for the
Parrotuncle Owner's Installation, Manual

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER


Remote controller

INSTRUCTION OF INSTALLATION AND OPERATION

1. INSTALLING RECEIVER IN CEILING FAN

A.Safety precautions

1. WARNING: HIGH VOLTAGE! Disconnect power by removing fuse or switching off circuit breaker.
2. Do not use with solid state fans.
3. Electrical wire must meet all local and national electrical code requirements.
4. Supply for fan must be 110/120 volt, 60Hz, 3.5A
5. Maximum fan motor amps: 1.0.
6. Maximum light watts: 180 incandescent or ballast and LED.
7. To Reduce the risk of shock, this fan must be installed with a wall switch/control.



(FIG.1)


CAUTION: Ceiling Angle Shall Not Exceed 30 Degrees, For Mounting Controller. Models GA030

B. Installing receiver in fan

1. Remove power from the circuit.
2. Remove ceiling fan canopy from the mounting bracket.
3. Disconnect existing wiring between ceiling fan and Supply in electrical junction box.
4. Make connections as follows, using the wire nuts supplied.

CONNECT TO

Red/Black receiver wire(AC IN L).....Red/Black supply wire
White receiver wire(AC IN N).....White supply wire
White receiver wire(TO MOTOR N)...White fan wire
Black receiver wire(TO MOTOR L)...Black fan wire
Blue receiver wire(FOR LIGHT)...Blue light wire



If other fans or supply wires are different color, have this unit installed by qualified licensed electrician.

a.Push all connected wires up into junction box.

b.Lay the brown antenna wire on top of the receiver,and put the receiver into the mounting bracket.

c.Reinstall the canopy on the mounting bracket.

d.Restore power.

e.Install 3.0 volt battery. (To prevent damage to transmitter, remove the battery if not used for a long time).

f. Store the transmitter away from excessive heat or humidity.

g.This remote control unit is equipped with roll code combinations. In order to prevent possible interference from or to other remote units such as garage door openers, car alarm or security system. If you find that your fan and light kit go on and off without using your remote control, simply change the code combination in your transmitter and receiver.

Parrot Uncle

F6355110V

Installation & Operating Instructions for the
Parrotuncle Owner's Installation, Manual

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

2. OPERATING TRANSMITTER:

Operating the buttons on the panel of the transmitter.

3 key -for fan high speed.


2 key-for fan medium speed.

1 key-for fan low speed.

OFF key-for fan off.

LIGHT key-for light on and off.

2hr , 4hr , 8hr button to set the FAN sleep timer



MODEL:GA030

OPERATION DISTANCE 20 FEET

YOUR REMOTE NOW HAS FULL CONTROL OF THE FAN AND LIGHT.

3.TROUBLE SHOOTING GUIDE


a.Power to receiver?

b.Receiver wired correctly?

c.Fan manual speed control in highest position?

d.Light kit switch turned on?

e.Good battery in the transmitter?



(FIG.1)

If there are two or more ceiling fans installed in the same house, in order to prevent your ceiling fans from being affected by the remote control of the adjacent ceiling fans, first turn the switch in each remote control transmitter to the CODE(UP) position (see the schematic diagram FIG1) Remarks: The standard state of the transmitter is in the down code COM.

(Power-off means you need to use a wall switch to shut down the power of the ceiling fan, if you do not have a wall switch, please power off the whole room from the air circuit-breaker for each room)

After installing the remote control receiver on the ceiling fan

1: Turn on the power of the 1# ceiling fan receiver (the power of the 2# receiver is kept in a power-off state), within 30 seconds after the fan power is turned on, press the LEARN button corresponding to the 1# transmitter, then The receiver will learn the transmitter code. When the transmitter code is learned successfully, the light of the ceiling fans will flash twice, and then it can be used normally.

2: Turn on the power of the 2# ceiling fan receiver (the power of the 1# receiver is kept in a power-off state), within 30 seconds after the fan power is turned on, press the LEARN button corresponding to the 2# transmitter, then The receiver will learn the transmitter code. When the transmitter code is learned successfully, the light of the ceiling fans will flash twice, and then it can be used normally.

And so on, only one ceiling fan is powered on each time the corresponding transmitter learns.

After the 1# and 2# remote control transmitters have been successfully learned, turn on the power of the two ceiling fans. At this time, the 1# transmitter and the 2# transmitter can be used separately for one ceiling fan.

FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.
This device may not cause harmful interference.
This device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital, pursuant to Part 15 or the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may casue harmful interference to radio communications,

However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--- Reorient or relocate the receiving antenna.

--- Increase the separation between the equipment and receiver.

--- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--- Consult the dealer or an experienced radio/ TV technician for help.

WARNING:

Do NOT install this fan with variable speed wall control or wall-mounted dimmer switch. It will permanently damage the fan's remote control and cause the fan's function to fail.



NO Variable speed wall control



NO Dimmer switch

Parrot Uncle

F6355110V

Installation & Operating Instructions for the
Parrotuncle Owner's Installation, Manual

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

⚠WARNING

- **INGESTION HAZARD**: This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Intemal Chemical Burns** in as little as 2 hours.
- **KEEP** new and used batteries **OUT OF REACH OF CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.

Even used batteries may cause severe injury or death.

Call a local poison control center for treatment information.

Compatible battery type is CR2032,3V

Ensure the batteries are installed correctly with regard to polarity (+ and -).

Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries

Non-rechargeable batteries are not to be recharged. Exhausted batteries are to be removed from the product.

Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting,leakage or explosion resulting in chemical burns.

Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product,remove the batteries, and keep them away from children.

⚠WARNING INGESTION HAZARD: This product contains a button cell or coin battery.


Parrot Uncle


F6355110V

Installation & Operating Instructions for the
Parrotuncle Owner's Installation, Manual

WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER

Size of product





WOBBLE

The fan blades have been adjusted in the factory to minimize any wobble.

NOTE:CEILING FANS TEND TO MOVE DURING OPERATION DUE TO THE FACT THAT THEYARE MOUNTED ON A RUBBER

CROMMET, IF THE FAN WAS MOUNTED RIGIDLY TO THECEILING, IT WOULD CAUSE EXCESS VIBRATION. MOVEMENT OF A FEW CENTIMENTERSIS QUITE ACCEPTABLE AND DOES NOT SUGGEST ANY PROBLEMTO REDUCE THE FAN WOBBLE: PLEASE CHECK THAT ALL SCREWS WHICH SECURED THE MOUNTINGBRACKET AND DOWNROD ARE SECURE,BALANCING AWOBBLING CEILING FAN:

1.Check that all blade and blade arm screws are secure.


2.Most fan wobbling problems are caused when blade levels are unequal. Check this level byselecting a point on the ceiling above the tip of one of theblades.Measure this distance.Rotate the fan until the next blade is positioned formeasurement. Repeat for each blade. The distance deviation should be equal within1/8"(0.32cm).

3.If the blade wobble is still noticeable, interchanging twoadjacent (side by side) blades can redistribute the weight.

AND POSSIBLY RESULT IN SMOOTHER OPERATION. WARNING: TO REDUCE THE RISK OF PERSONALINJURY, DO NOT BEND THE BLADE ARM WHILE INSTALLING, BALANCING THE BLADES, ORCLEANING THE FAN. DO NOT INSERT FOREIGN OBJECTS BETWEEN ROTATING FAN BLADES.

NOISE

When it is qulet(especially at night) you may hear occasional small noises. This is normal. Please allow a 24.hour “breaking-in" period, most noises associated with a new fan disappear during the time.
When it is qulet(especlally at night) you may hear occasional small noises. This is normal. Please allow a 24.hour “breaking-in" period, most noises associated with a new fan disappear during the time.



CARE AND CLEANING

1.Periodic cleaning ofyour ceiling fan is the only maintenance reguired, Use a soft brush or lint free cloth toavoid scratching the paint finish, Please make sure to turn oX electricity power before you clean your fan.

2.Do not use water when cleaning your ceiling fan. It could damage the motor or the bladesand create the possibility ofan electrical shock.

3.motor has permanently lubricated ball bearing. no need to oilnote: make sure the power is off at the electrical


Parrot Uncle