EPSON®

Epson iProjection Operation Guide (Windows/Mac)

Contents

Notations Used in This Guide 5

Using the Manual to Search for Information 6

Searching by Keyword 6
Jumping Directly from Bookmarks 6
Printing Only the Pages You Need 6

Introduction to the Epson iProjection Software 7

Epson iProjection Features 8

Connection to Various Devices 8
Four-Panel Display 8
Change Presenters and Projection Position 9
Moderator Function 9
Screen Delivery and Thumbnail Display Function 10
Easy Network Projection Using a USB Flash Drive (Windows Only) 10

Setting Up the Software for the First Time 12

Installing the Software 13

Epson iProjection System Requirements 13
Requirements for Extended Display 13
Epson iProjection Editions 14
Installing the Epson iProjection Software (Windows) 14
Installing the Epson iProjection Software (Mac) 14

Selecting Projector Network Settings 15

Connection Methods for Various Network Environments 15
Recommended Wireless Environment for Multi PC Projection 16
Setting Up a Projector to Connect in Quick Connection Mode 16
Setting Up a Projector when Connecting by Wireless LAN 17
Setting Up a Projector when Connecting by Wired LAN 18

Connecting to the Projector and Projecting Images 19

Connection Methods 20

Connection Methods for Various Meeting Styles 20
Connecting the Projector and a Computer Directly Using Wireless Communication 21
Connecting to the Projector from the Software over a Network System 24

Selecting the Projector Search Method 27

Search Methods 27
Searching for Network Projectors Automatically 27
Searching for Network Projectors by Specifying an IP Address or Projector Name 28
Searching for Network Projectors Using a Profile 28
Profiles for Search 29
Performing a Profile Search 29
Registering a Profile 29
Exporting a Profile 31
Importing a Profile 31
Sharing a Profile over a Network 31

Controlling the Projected Display 33

Screen Types for Projection Control 33
Operating the Projected Display Status 33
Changing the Number of Projected Panels 34
Changing the Presenter 35
Changing the Projection Position 36

Disconnecting 37

Using Additional Functions 38

Searching for Network Projectors Using a Shortcut 39

Creating a Shortcut 39

Connecting to Network Projector Using a USB Flash Drive (Windows Only) 40

Creating a USB key on a USB Flash Drive (Windows Only) 40
Using a USB Key to Connect a Windows Computer 40

Connecting to Multiple Projectors (Mirroring) 42

Outputting Audio from the Projector 43

Projecting Your Screen 44

Changing the Moderator 45

Distributing the Projected Screen 46

Selecting the Participant's Screen to Project Using Thumbnails ... 47

Hiding the Projection Control Screen 48

Prohibiting Participant Operations 49

Controlling the Connection Bandwidth 50

Bandwidth Control Restrictions 51

Solving Problems 52

Solving Network Connection Problems 53

Solutions When You Cannot Connect Using Quick Connection Mode 53
Solutions When You Cannot Connect Projectors Using Advanced Connection Mode (Wireless) 53
Solutions When You Cannot Connect Projectors Using Advanced Connection Mode (Wired) 55

Solving Problems During Projection 56

Solutions When the Screen is Not Projected Properly 56
Solutions When Audio is Not Played Properly 56
Solutions When the Moderator Function Does Not Work 57
Solutions When the Projected Screen is Not Delivered 57

Error Messages List 58

Error Messages When Starting up the Epson iProjection Software 58
Error Messages When Using a USB Key 59
Error Messages When Searching for and Selecting Projectors 60
Error Messages When Projecting 61
Error Messages When Operating a Profile 61
Error Messages When Using the Moderator Function 61
Error Messages When Distributing the Projected Screen 62

Event ID List 63

Screen Summary 64

Select Connection Mode Screen 65

Search Screen 66

Save Screen 68

Set options 69

Set options - User Settings 69
Set options - General settings 70
Set options - Adjust performance 71
Set options - Audio Output 72
Set options - Deliver 73

Toolbar 75

Projection Control Screen 76

Thumbnail Screen 79

Viewer Screen 80

Appendix 81

Updating and Uninstalling the Software 82

Getting the Latest Version of the Software 82
Uninstalling the Epson iProjection Software (Windows) 82
Uninstalling the Epson iProjection Software (Mac) 82

Supported Resolutions 83

Limitations 84

Connection Limitations 84

Notices 85

Copyright Notice 85
About Notations 85
Trademarks 85
Copyright Attribution 85

Notations Used in This Guide

Safety Symbols

The projector and its manuals use graphical symbols and labels to indicate content that tells you how to use the product safely.
Read and carefully follow the instructions that are marked with these symbols and labels to avoid injury to persons or damage to property.

⚠ Warning	This symbol indicates information that, if ignored, could possibly result in personal injury or even death.
⚠ Caution	This symbol indicates information that, if ignored, could possibly result in personal injury or physical damage due to incorrect handling.

General Information Notations

Attention	This label indicates procedures that may result in damage or injury if sufficient care is not taken.
	This label indicates additional information that may be useful to know.
[Button name]	Indicates the name of the buttons on the remote control or the control panel. Example: [Esc] button
Menu/Setting name	Indicates projector menu and setting names. Example: Select the **Image** menu ☛ **Image** > **Advanced**
⏩	This label indicates links to the related pages.
☛	This label indicates the projector's current menu level.

⏩ Related Links


- "Using the Manual to Search for Information" p.6

Using the Manual to Search for Information

The PDF manual allows you to search for information you are looking for by keyword, or jump directly to specific sections using the bookmarks. You can also print only the pages you need. This section explains how to use a PDF manual that has been opened in Adobe Reader X on your computer.


Related Links

- "Searching by Keyword" p.6
- "Jumping Directly from Bookmarks" p.6
- "Printing Only the Pages You Need" p.6



Searching by Keyword

Click **Edit** > **Advanced Search**. Enter the keyword (text) for information you want to find in the search window, and then click **Search**. Hits are displayed as a list. Click one of the displayed hits to jump to that page.



Jumping Directly from Bookmarks

Click a title to jump to that page. Click + or > to view the lower level titles in that section. To return to the previous page, perform the following operation on your keyboard.

- Windows: Hold down **Alt**, and then press ←.
- Mac OS: Hold down the command key, and then press ←.

Printing Only the Pages You Need


You can extract and print only the pages you need. Click **Print** in the **File** menu, and then specify the pages you want to print in **Pages** in **Pages to Print**.

- To specify a series of pages, enter a hyphen between the start page and the end page.

  Example: 20-25

- To specify pages that are not in series, divide the pages with commas.

  Example: 5, 10, 15



Introduction to the Epson iProjection Software

See the information here to learn more about the Epson iProjection software.

Related Links

- "Epson iProjection Features" p.8


The Epson iProjection software is an application that allows you to hold interactive meetings or lessons by projecting images from network projectors. You can use a variety of display options for your environment.

Related Links
- "Connection to Various Devices" p.8
- "Four-Panel Display" p.8
- "Change Presenters and Projection Position" p.9
- "Moderator Function" p.9
- "Screen Delivery and Thumbnail Display Function" p.10
- "Easy Network Projection Using a USB Flash Drive (Windows Only)" p.10

Connection to Various Devices

You can connect up to 50 devices to a projector simultaneously, such as computers, smartphones and tablets using the Epson iProjection software. (Up to four devices can project at one time.)

You can also hold remote meetings over a network by simultaneously projecting the same image on up to four projectors on the network.




Related Links
- "Connecting to Multiple Projectors (Mirroring)" p.42
- "Connection Methods" p.20

Four-Panel Display

You can simultaneously display up to four screens in separate projected panels, which is useful in both business and educational environments.

For example, you can compare and analyze data while simultaneously projecting screens from multiple devices. In an educational environment, you can project lesson material on one part of the screen and student answers on another to enhance the learning experience.



Related Links
- "Changing the Number of Projected Panels" p.34

Change Presenters and Projection Position

Using the Epson iProjection software, you can easily change the screen being projected and the projection position by simply dragging and dropping user names in panels on the projection control screen.

You can share the projector with other users on the same network without having to change cable connections, allowing users to take turns giving presentations.




The projection control screen is available only on the Standard Edition of the software.

Related Links
- "Changing the Presenter" p.35
- "Changing the Projection Position" p.36

Moderator Function

When using the moderator function, only one person plays a role of moderator who can control the projected display. This function is suitable for meetings in which one user is the moderator and the other users are participants, and the moderator must control the projected display.

This can also be useful in a classroom environment where the moderator must control the lesson without interruption.




This function is available only for supported models.

Related Links
- "Changing the Moderator" p.45
- "Connection Methods" p.20

Screen Delivery and Thumbnail Display Function

You can distribute the currently projected screen images to the participant's devices. The participants can then add notes to the received images using drawing software, which the moderator can check as thumbnails. This feature is suitable for environments where the moderator wants to provide questions for the participants to answer, and then select which answers or ideas to project in response.




This function is available only for supported models.

Related Links
- "Distributing the Projected Screen" p.46
- "Selecting the Participant's Screen to Project Using Thumbnails" p.47

Easy Network Projection Using a USB Flash Drive (Windows Only)

You can use a commercially available USB flash drive as a USB key to transfer the projector's network information to a Windows computer. Creating the USB key allows you to quickly project images from the network projector.

When you change the presenter, you can switch the projected screen by inserting the USB key to a new presenter's computer.



- This function is available only for supported models. See your projector *User's Guide* for more details.
- You cannot use the USB key as a projector's wireless LAN module.

Related Links

- "Connecting to Network Projector Using a USB Flash Drive (Windows Only)" p.40

Setting Up the Software for the First Time

Follow these instructions before connecting a computer to the projector over a network.

Related Links

- "Installing the Software" p.13
- "Selecting Projector Network Settings" p.15

Install the Epson iProjection software by downloading it from the Epson Web site.

- If the language selected for the installation differs from the language of the operating system being used, the screens may not display correctly.
- If any earlier version of this software or EasyMP Multi PC Projection is installed on your computer, uninstall it first and then install the Epson iProjection software.

Related Links

- "Epson iProjection System Requirements" p.13
- "Epson iProjection Editions" p.14
- "Installing the Epson iProjection Software (Windows)" p.14
- "Installing the Epson iProjection Software (Mac)" p.14

Epson iProjection System Requirements

Your computer must meet the following system requirements to use the Epson iProjection software.

Requirement	Windows	Windows (Arm)	Mac
Operating system	Windows 10 • Windows 10 Home (32- and 64-bit) • Windows 10 Pro (32- and 64-bit) • Windows 10 Enterprise (32- and 64-bit)	Windows 11 • Windows 11 Home (64-bit) • Windows 11 Pro (64-bit) • Windows 11 Enterprise (64-bit)	macOS • macOS 13 (Ventura) • macOS 14 (Sonoma) • macOS 15 (Sequoia) • macOS 26 (Tahoe)
	Windows 11 • Windows 11 Home (64-bit) • Windows 11 Pro (64-bit) • Windows 11 Enterprise (64-bit)		
CPU	8th Generation Intel Celeron or faster (8th Generation Intel Core i5 or faster recommended)	Snapdragon X or faster (Snapdragon X Plus or faster recommended)	• 8th Generation Intel Core i5 or faster • Apple M1 or later (Apple Silicon)
Memory	4 GB or more (8 GB or more recommended)		
Hard disk space	50 MB or more		
Display	Resolution between 800 × 600 (SVGA) and 1920 × 1200 (WUXGA)		

Related Links

- "Requirements for Extended Display" p.13

Requirements for Extended Display

Using the extended display function of your operating system, you can view a different screen on your computer display than the screen you project from your projector.

To use the extended display function, your computer must meet the following system requirements.

Requirement	Description
Operating system	Windows 10, version 2004 or later
Supported display resolution (for both the computer display and projector)	• 1920 × 1200 • 1920 × 1080 • 1280 × 800 • 1024 × 768

- When using interactive projector features over a network, select a primary and an extended display.
- To use interactive projector features over a network as the extended display, make sure of the following:
  - Use the Windows **Control Panel** > **Tablet PC Settings** to set up the pen and display for projection
  - Select the same resolution for the primary display and the extended display

Epson iProjection Editions

You can choose the software edition to install that suits your role in the projection environment.

- **Standard Edition**

  You can use all functions of the Epson iProjection software.

  You can control the projected image and also function as a moderator.
- **Participant Edition**

  You can connect to the projector only as a participant of the moderator function and cannot control the projected images.

If you want to switch editions, uninstall and reinstall this software.

Installing the Epson iProjection Software (Windows)

Install the Epson iProjection software on your computer.

- You need administrator authority to install the software.
- You need to install Microsoft .NET Framework 4.6.2 before installing the Epson iProjection software.

1. Turn on your computer.
2. Make sure all running applications are closed.
3. Download the software from the Epson Web site.
4. Follow the on-screen instructions to install.

Installing the Epson iProjection Software (Mac)

Install the Epson iProjection software on your computer.

1. Turn on your computer.
2. Make sure all running applications are closed.
3. Download the software from the Epson Web site.
4. Follow the on-screen instructions to install.

Follow these instructions to select a connection method between a computer and the projector, and then set up the projector.

Related Links

- "Connection Methods for Various Network Environments" p.15
- "Recommended Wireless Environment for Multi PC Projection" p.16
- "Setting Up a Projector to Connect in Quick Connection Mode" p.16
- "Setting Up a Projector when Connecting by Wireless LAN" p.17
- "Setting Up a Projector when Connecting by Wired LAN" p.18

Connection Methods for Various Network Environments

You can choose a connection mode to suit your network environment.


Check how the projector is connected to the network system (wireless or wired) and the communication path from the computer to the projector.

Depending on your projector, some connection methods may not be available. See your projector *User's Guide* for more details.


- To connect the projector to the computer directly using wireless communication: Use **Quick Connection Mode**.



- To connect the projector to the computer using a wireless network system: Use **Advanced Connection Mode**.



- To connect the projector to the computer using a wired network system: Use **Advanced Connection Mode**.



Recommended Wireless Environment for Multi PC Projection

When you connect multiple devices to a projector using the Quick connection mode, we recommend limiting the number of devices to six or less to maintain the projection performance. The number of devices that can connect to a projector at the same time differs depending on the wireless communication environment.

When you connect a projector to a wireless LAN and connect multiple devices wirelessly using the Advanced connection mode, note the following recommendations.

- Set up multiple access points so that one of the access points can connect up to 10 or 20 devices. See the access point manual for more information on the maximum number of devices that can be connected.
- When you use multiple access points, assign a different channel to each access point, and use different access points for the projector connection and the computer connection.
- Use a wireless LAN controller, if possible, to enhance the connection stability.
- Use an access point that supports 802.11n.

Contact your network administrator for help in setting up the wireless environment.

If your projector supports a wired LAN connection, we recommend using a wired LAN connection when you connect multiple devices to the projector.

Setting Up a Projector to Connect in Quick Connection Mode

To connect a computer directly to the projector using wireless communication, you need to select network settings on the computer and the projector.

The necessary settings vary depending on your projector. See your projector *User's Guide* for instructions.

1. Select the necessary settings to connect your computer to a wireless LAN. See the documentation supplied with your computer for more details.
2. Install the wireless LAN unit in the projector, if necessary. See your projector *User's Guide* for instructions.
3. Turn on the projector.
4. Press the [Menu] button on the remote control or the control panel, and select the **Network** menu.
5. Turn on wireless LAN support.

6 Select one of these settings to connect the projector to the computer directly using wireless communication. The necessary settings vary depending on your projector.
- Turn on the **Simple AP** setting.
- Select **Quick** for **Connection Mode**.

7 Select other options as necessary for your network. See your projector *User's Guide* for instructions.

8 Select security settings. Check with your network administrator for more information on choosing the correct settings.

9 When you have finished selecting settings, save your settings and exit the menus.

Related Links
- "Connecting the Projector and a Computer Directly Using Wireless Communication" p.21

Setting Up a Projector when Connecting by Wireless LAN

To connect a computer to the projector over a wireless LAN, you need to select network settings on the computer and the projector.

The necessary settings vary depending on your projector. See your projector *User's Guide* for instructions.

1 Contact your network administrator and write down the settings for the access point, such as the SSID and security settings.

2 Connect the computer to the network.

To set up a network connection, if necessary, see the documentation supplied with your computer or network adapter.

3 If the projector does not have a built-in wireless LAN, install the wireless LAN unit on the projector. See your projector *User's Guide* for instructions.

4 Turn on the projector.

5 Press the [Menu] button on the remote control or the control panel, and select the **Network** menu.

6 Turn on wireless LAN support.

7 Select one of these settings to connect the projector to a wireless LAN. The necessary settings vary depending on your projector.
- Turn off the **Simple AP** setting.
- Select **Advanced** for **Connection Mode**.

8 Select other options as necessary for your network. See your projector *User's Guide* for instructions.

9 Select security settings as necessary for your network. Check with your network administrator for more information on choosing the correct settings.

10 When you have finished selecting settings, save your settings and exit the menus.

- If no **Web Control Password** has been set, a screen prompting you to set a password is displayed before you can save settings. Follow the on-screen instructions to set the password.

Related Links

- "Connecting to the Projector from the Software over a Network System" p.24

Setting Up a Projector when Connecting by Wired LAN

To connect a computer to the projector using a wired LAN, you need to select network settings on the computer and the projector.

The necessary settings vary depending on your projector. See your projector *User's Guide* for instructions.

1. Contact your network administrator and check that DHCP is available under the current network environment.

   If DHCP is not available, write down the following values that are available for your projector.
   - IP Address
   - Subnet Mask
   - Gateway Address

2. Connect the computer to the network.

   To set up a network connection, if necessary, see the documentation supplied with your computer or network adapter.

3. Connect a LAN cable to the projector.

4. Turn on the projector.

5. Press the [Menu] button on the remote control or the control panel, and select the **Network** menu.

6. Select these IP settings for your wired LAN as necessary.
   - DHCP is available: Set **DHCP** to **On**.
   - DHCP is not available: Set **DHCP** to **Off** and enter the projector's IP Address, Subnet Mask, and Gateway Address values as necessary.

7. When you have finished selecting settings, save your settings and exit the menus.

- If no **Web Control Password** has been set, a screen prompting you to set a password is displayed before you can save settings. Follow the on-screen instructions to set the password.

Related Links

- "Connecting to the Projector from the Software over a Network System" p.24

Connecting to the Projector and Projecting Images

Follow these instructions to connect the computer and the projector over a network, and to project images from your computer's screen using the projector.

Make sure you have already set up the software and selected a connection mode for the projector.

Related Links

- "Connection Methods" p.20
- "Selecting the Projector Search Method" p.27
- "Controlling the Projected Display" p.33
- "Disconnecting" p.37

You can select a suitable method to connect the computer and the projector over a network depending on your meeting style.

Related Links

- "Connection Methods for Various Meeting Styles" p.20
- "Connecting the Projector and a Computer Directly Using Wireless Communication" p.21
- "Connecting to the Projector from the Software over a Network System" p.24


Connection Methods for Various Meeting Styles

You can choose a connection method to suit the style of your meeting.


Decide how you want to hold your meeting. Depending on the connection method you selected, the connection procedure differs.

Depending on your projector, some connection methods may not be available. See your projector *User's Guide* for more details.

- All users can control the projected display and become presenters. (Holding discussions and interacting with other users in a business environment.)



- Only one user is the moderator and has full control over the meeting using the moderator function. (Holding a class or lesson using the participants' computer screens in an educational environment.)



To start a meeting using the moderator function, one user must connect to the projector as the moderator and the other users must connect to the projector as participants.

Related Links

- "Changing the Moderator" p.45
- "Connecting to the Projector from the Software over a Network System" p.24

Connecting the Projector and a Computer Directly Using Wireless Communication

When your projector is set up as indicated below, you can connect the projector and a computer directly using wireless communication to project the computer's screen.

- The wireless LAN unit is installed in the projector or the projector has built-in wireless LAN modules.
- You select one of these settings to connect the projector to the computer directly using wireless communication. The necessary settings vary depending on your projector.
  - Turn on the **Simple AP** setting.
  - Select **Quick** for **Connection Mode**.

- When you use the Participant Edition of the software, you must connect the projector and a computer over a network system.
- When you connect the projector and a computer directly using wireless communication, the connection between the computer and an access point is disconnected.
- Make sure you turn on your computer's wireless communication function.

1 Press the [LAN] button or [Source Search] button on the remote control to switch the input source to LAN.

You see the network information screen.




2 Start the Epson iProjection software.

- Windows: Select **Start**, **EPSON Projector**, and then select **Epson iProjection**.
- Mac: Double-click **Epson iProjection** from the **Applications** folder.

> You can also create a shortcut and use it to start the Epson iProjection software and to automatically search for saved projectors.

3 Select **Quick Connection Mode**, and then click **OK**.




4 Search for the projector using one of the following methods.

- **Automatic Search**: Searches for the projector automatically.
- **Profile**: Searches for the projector based on a previously saved profile.

The projector search results are displayed.

5 Select the projector you want to connect to from the **Projector List**, and then select one of the following options.

- You want all users to be able to become participants in the moderator function: Make sure **Connect as a Moderator, or disable interrupt connections** is not selected, and then click **Connect**.
- You are the moderator user and you do not want other users to be able to interrupt the moderator presentation: Select **Connect as a Moderator, or disable interrupt connections**, and then click **Connect**.




> - The moderator function is available only for supported models and is available only on the Standard Edition of the software.
> - When one user connects as a moderator, the moderator function turns on.

When the **Projector Keyword** is set to **On** or the **Moderator Password** is set in the projector settings, the keyword entry screen is displayed.


6 Enter the Projector Keyword displayed on a screen, and then press **OK**.

7 When the following dialog box is displayed, enter the passphrase set on the projector, and then click **Connect**.



If you select **Save the passphrase and don't show this dialog box again**, the projector's SSID and passphrase are saved on the computer and this dialog box is not displayed the next time you connect. You do not have to enter the passphrase again.

If the projector's passphrase has not been changed from the default, the following dialog box is displayed. Change the passphrase from the projector's **Network** menu.



When a connection is established, the computer screen is projected and the following toolbar is displayed on the computer screen.



The computer screen for the user who connects first is projected in full screen mode. Users who connect later can project their own screen by clicking the  button on the toolbar or can control the projected display from the projection control screen by clicking the  button on the toolbar.

- When a connection is established, the input source for the projector automatically switches to the LAN source if no other signal is being input. If the input source does not automatically switch to the LAN source, press the [LAN] button or [Source Search] button on the remote control.
- The displayed toolbar varies depending on the connection method and the edition of the software.
- When using the moderator function, only the moderator can control the projected display.

Related Links

- "Setting Up a Projector to Connect in Quick Connection Mode" p.16
- "Disconnecting" p.37
- "Selecting the Projector Search Method" p.27
- "Controlling the Projected Display" p.33
- "Searching for Network Projectors Using a Shortcut" p.39

Connecting to the Projector from the Software over a Network System

When your projector is set up as indicated below, you can connect the projector and a computer over a network by using the Epson iProjection software.

- The wireless LAN unit is installed if a projector does not have built-in wireless LAN modules (wireless networks only).
- You select one of these settings to connect the projector to a wireless LAN. The necessary settings vary depending on your projector.
  - Turn off the **Simple AP** setting.
  - Select **Advanced** for **Connection Mode**.
- A LAN cable is connected to the projector (wired networks only).

Make sure you also connected a computer to the network.

1 Press the [LAN] button or [Source Search] button on the remote control to switch the input source to LAN.

You see the network information screen.




2 Start the Epson iProjection software.

- Windows: Select **Start**, **EPSON Projector**, and then select **Epson iProjection**.
- Mac: Double-click **Epson iProjection** from the **Applications** folder.

You can also create a shortcut and use it to start the Epson iProjection software and to automatically search for saved projectors.

3 Select **Advanced Connection Mode**, and then click **OK**.




4 Search for the projector using one of the following methods.

- **Automatic search**: Searches for the projector automatically.
- **Manual search**: Searches for the projector based on a specified IP address or projector name.
- **Profile**: Searches for the projector based on a previously saved profile.

The projector search results are displayed.

5 Select the projector you want to connect to from the **Projector List**, and then select one of the following options.

- You want all users to be able to become participants in the moderator function: Make sure **Connect as a Moderator, or disable interrupt connections** is not selected, and then click **Connect**.
- You are the moderator user and you do not want other users to be able to interrupt the moderator presentation: Select **Connect as a Moderator, or disable interrupt connections**, and then click **Connect**.



- The moderator function is available only for supported models and is available only on the Standard Edition of the software.
- When one user connects as a moderator, the moderator function turns on.

When the **Projector Keyword** is set to **On** or the **Moderator Password** is set in the projector settings, the keyword entry screen is displayed.

6 Enter the Projector Keyword displayed on a screen, and then press **OK**.

When a connection is established, the computer screen is projected and the following toolbar is displayed on the computer screen.



The computer screen for the user who connects first is projected in full screen mode. Users who connect later can project their own screen by clicking the

 button on the toolbar or can control the projected display from the projection control screen by clicking the  button on the toolbar.

- When a connection is established, the input source for the projector automatically switches to the LAN source if no other signal is being input. If the input source does not automatically switch to the LAN source, press the [LAN] button or [Source Search] button on the remote control.
- The displayed toolbar varies depending on the connection method and the edition of the software.
- When using the moderator function, only the moderator can control the projected display.

Related Links

- "Setting Up a Projector when Connecting by Wireless LAN" p.17
- "Setting Up a Projector when Connecting by Wired LAN" p.18
- "Disconnecting" p.37
- "Selecting the Projector Search Method" p.27
- "Controlling the Projected Display" p.33
- "Searching for Network Projectors Using a Shortcut" p.39

You can select a suitable method to search for a projector depending on the status or location of the projector you want to connect to.

Related Links
- "Search Methods" p.27
- "Searching for Network Projectors Automatically" p.27
- "Searching for Network Projectors by Specifying an IP Address or Projector Name" p.28
- "Searching for Network Projectors Using a Profile" p.28

Search Methods

You can use one of the following methods to search for the projector you want to connect to. Choose the best method depending on your environment.

- Searching for Network Projectors Automatically

  You can automatically search for available projectors on the network.

  Search results differ depending on the connection mode you use.

  - Quick Connection Mode: Displays the SSID for available projectors.
  - Advanced Connection Mode: Displays available projectors on the network. Searches are performed only on the same subnet. Projectors on different subnets are not displayed in the search results.
- Searching for Network Projectors by Specifying an IP Address or Projector Name

  If the projector you want to connect to is not found automatically, you can search for the target projector by specifying the IP address or a projector name. By specifying the IP address, you can also search for the projector at remote locations on a different subnet.
- Searching for Network Projectors Using a Profile


  You can save network projector information as a profile, and then specify the profile to search for the same projector instead of providing projector details each time you search. By creating a group of profiles for each place where a projector is set up and managing them with folders, the target projector can be found quickly.

Related Links
- "Searching for Network Projectors Automatically" p.27
- "Searching for Network Projectors by Specifying an IP Address or Projector Name" p.28
- "Searching for Network Projectors Using a Profile" p.28

Searching for Network Projectors Automatically

You can automatically search for available projectors on the network, and then project images by simply selecting the projector.

Click **Automatic search** on the search screen.



The search results are displayed.

When you click **Refresh**, the latest information is displayed.


If you cannot find any projectors, try one of the other search methods.

Searching for Network Projectors by Specifying an IP Address or Projector Name


If the projector you want to connect to is not found automatically, you can search for the target projector by specifying the IP address or the projector name.

Manual Search is available only in **Advanced Connection Mode**.

1 Click **Manual search** on the search screen.



2 Enter the IP address or the projector name for the projector you want to connect to, and then click **Search**.



The search results are displayed.

Searching for Network Projectors Using a Profile

You can save network projector information as a profile, and then search for the same projector using the profile instead of specifying the projector details each time.

Related Links

- "Profiles for Search" p.29
- "Performing a Profile Search" p.29
- "Registering a Profile" p.29
- "Exporting a Profile" p.31
- "Importing a Profile" p.31
- "Sharing a Profile over a Network" p.31

Profiles for Search


You can save information for a network projector as a profile. A profile is a file containing all of the projector's information, such as the projector name, IP address, and SSID. By using a profile, you can easily search for saved projectors instead of providing projector details.

You can export the registered profile to create a backup, and then import it locally to easily search for projectors on another computer. You can also share the exported profile over a network, allowing other users to easily search for projectors.


Performing a Profile Search

You can specify the profile to search for the saved projector instead of providing projector details each time you search.

1 Click **Profile** on the search screen.



2 Double-click the folder or the projector icon for the profile you want to use from the list.



The search results are displayed.

Related Links

- "Registering a Profile" p.29


Registering a Profile

After searching for a projector, you can save the projector details as a profile using a memorable name that you can search for easily later.

You cannot register a profile under the **Shared Profile** folder on the search screen.


1 While the projectors are displayed on the search screen, perform one of the following operations.

- Register projectors displayed in the **List of Connected Projectors**: Click **Register**.
- Register a specific projector: Right-click the projector you want to register in the **Projector List**, and then click **Add Item to Profile**.
- Register all projectors found by the search: Right-click one of the projectors in the **Projector List**, and then click **Add All to Profile**.



The Save screen is displayed.

2 Enter the **Projector file name**, and select the folder where you want to save the profile, and then click **OK**.



The profile is registered and the projector information is saved in the profile.

- The folder structure can be six folders deep.
- Click **Create New folder** if you want to create a new folder.
- To register a specific projector, you can drag and drop the projector from the **Projector List** to the folder under **Profile**.
- You can drag and drop profiles and folders to change the folder structure.

Exporting a Profile

You can export a profile and share it with other users allowing them to easily search for projectors and join a meeting.

> You cannot export the profiles under the **Shared Profile** folder on the search screen.

1. On the search screen, right-click the folder containing the profile you want to share under **Profile**, and then click **Export**.
   The Save As screen is displayed.
2. Select where you want to save the profile (.mplist), and then click **Save**.

The profile is exported.

Related Links
- "Registering a Profile" p.29
- "Importing a Profile" p.31
- "Sharing a Profile over a Network" p.31

Importing a Profile

You can locally import an exported profile and use it to easily search for projectors and join a meeting.

> - You can also import a profile (.plist) exported using EasyMP Network Projection.
> - You cannot import profiles under the **Shared Profile** folder on the search screen.
> - You cannot import profiles created in a different connection mode.

1. On the search screen, right-click the folder to which you want to import the profile under **Profile**, and then click **Import**.
   The Open screen is displayed.
2. Select the profile (.mplist), and then click **Open**.


The profile is imported locally.

Related Links
- "Exporting a Profile" p.31

Sharing a Profile over a Network

You can share an exported profile with other users over a network so that any changed projector information is easily updated. The shared profile is read and updated automatically when the Epson iProjection software is started.

1. Place the profile (.mplist) in a shared network location such as a server.
2. Click **Set options** on the search screen.
   The Set options screen is displayed.
3. Click the **User Settings** tab.
4. Enter the network location or URL to the shared profile (including the name of the profile) in **Shared Profile Name**.
   - For a file server (Windows only): \\xxxxx\xxxxx.mplist
   - For a web server: http://xxxxx/xxxxx.mplist



5 Click **Apply**.

The shared profile is read and the Set options screen closes.

The shared profile is read only and cannot be edited in the Epson iProjection software.

Related Links

- "Exporting a Profile" p.31

Follow these instructions to use the toolbar and the projection control screen to control the screen being projected.

Related Links
- "Screen Types for Projection Control" p.33
- "Operating the Projected Display Status" p.33
- "Changing the Number of Projected Panels" p.34
- "Changing the Presenter" p.35
- "Changing the Projection Position" p.36

Screen Types for Projection Control


You can choose the type of screen you use to control projected images to suit your situation. You can switch the screen type by clicking the button on the toolbar or the button on the projection control screen.

- The displayed toolbar and the projection control screen vary depending on the connection method and the edition or your role of this software.
- The projection control screen is available only on the Standard Edition of the software.

- Use the toolbar to display a wide image of the projected display and perform operations on the projected image.



- Use the projection control screen to change the number of projected panels, presenters, or the projection position.



Related Links
- "Toolbar" p.75
- "Projection Control Screen" p.76

Operating the Projected Display Status

You can control the projected display while projecting your computer screen by starting, stopping, or pausing the projected image.

Perform one of the following operations on the toolbar or the projection control screen.

- **Show**: Click the button. The computer screen is projected as it is.
- **Stop**: Click the button. The projected image stops. A black screen is projected while stopped.

- **Pause**: Click the button. The projected image pauses. The paused image is projected, even if you make changes on the computer screen.

- These buttons are not available for participants when using the moderator function.
- The moderator can also control the other users' projection using the projection control screen when using the moderator function.

Related Links
- "Projection Control Screen" p.76


Changing the Number of Projected Panels

You can divide the projected display into a maximum of four panels. By changing the number of panels, you can project screens from multiple devices at the same time, or project one computer screen in full screen mode.

- This function is not available for participants when using the moderator function.
- You can also use the button to project your computer screen in full screen mode.

1 Click the button on the toolbar.
The projection control screen is displayed.

2 Click the panel of the user to be projected in the projection area.



The selected panel is framed in blue.

3 Perform one of the following operations to change the number of available panels in the projection area.

- Project one panel in full screen mode: Click the button.
- Split the projected display in two and project the selected panel and the adjacent right or left panel: Click the button.
- Split the projected display into four panels and project them all: Click the button.

The number of panels changes and the background color for panels being projected becomes white.

- You can also change the number of panels by right-clicking in the projection area. Right-click the panel, and then select the number of total panels.
- If there is no user in a white panel, a black screen is projected.
- The background color for panels not being projected is gray.

Related Links

- "Projection Control Screen" p.76


Changing the Presenter

You can change the presenter by dragging and dropping one of the connected user names in the list onto a panel in the projection area.

This function is not available for participants when using the moderator function.

1. Click the button on the toolbar.
   The projection control screen is displayed.

2. Select the user names in the user list, and then drag and drop the user name onto a white panel in the projection area.



- The moderator can check the participant's device screens as thumbnails and select which user to project. Click the button on the toolbar or the projection control screen.
- If you cannot find the user that you want to project in the user list, you can search for them using the user search box.
- You can also right-click a user name in the user list to select the projection position.
- If there is no user in a white panel, a black screen is projected.

The selected user's computer screen is projected.

3 To finish projecting, drag and drop the user name from the projection area to the user list.

> You can also finish the selected user's projection by right-clicking the panel in the projection area, and then clicking **End Projection**.

The background color of the user name in the user list is blue while their screen is projected. The background color of the user name is gray when a user is in the panel but their screen is not being projected.

Related Links
- "Changing the Projection Position" p.36
- "Selecting the Participant's Screen to Project Using Thumbnails" p.47

Changing the Projection Position


You can change the projection position by dragging and dropping the user name from one position to another in the projection area.

> This function is not available for participants when using the moderator function.

1 Click the button on the toolbar.

The projection control screen is displayed.

2 Select the user in the projection area, and then drag and drop the user name into another position.



The projection position is changed.

> When the or button is selected, you can drag and drop the user name in a gray panel to the white panel to switch the image being projected. If you drag and drop the user name in a white panel to the gray panel, the image for that user will not be projected.

Related Links
- "Changing the Number of Projected Panels" p.34

You can disconnect one computer or all devices from the projector when you finish projecting.


1 Perform one of the following operations.

- Disconnect your computer and the projectors: Click the **Leave** button on the toolbar.
  The connection between your computer and the projectors is no longer active.



- When you are the moderator, the **Disconnect All** button is displayed on the toolbar instead of this button.
- You can also disconnect by clicking **Leave** from the **Disconnect** menu on the projection control screen.
- The moderator can disconnect other participants by right-clicking the selected user in the user list, and then clicking **Leave** on the projection control screen when using the moderator function.
- When the moderator leaves the meeting, the moderator function turns off.

- Disconnect all devices from the projectors: Click the button on the toolbar, and then click **Disconnect All** from the **Disconnect** menu on the projection control screen.
  The connection between all devices and projectors participating in the meeting is no longer active.



This function is not available for participants when using the moderator function.

The confirmation screen is displayed.

2 Click **Yes**.

You are returned to the search screen.

Using Additional Functions

Follow these instructions to use the additional Epson iProjection functions that may be useful during a meeting.

Related Links

- "Searching for Network Projectors Using a Shortcut" p.39
- "Connecting to Network Projector Using a USB Flash Drive (Windows Only)" p.40
- "Connecting to Multiple Projectors (Mirroring)" p.42
- "Outputting Audio from the Projector" p.43
- "Projecting Your Screen" p.44
- "Changing the Moderator" p.45
- "Distributing the Projected Screen" p.46
- "Selecting the Participant's Screen to Project Using Thumbnails" p.47
- "Hiding the Projection Control Screen" p.48
- "Prohibiting Participant Operations" p.49
- "Controlling the Connection Bandwidth" p.50

You can save network projector information as a shortcut, and then double-click it to start the Epson iProjection software. This allows you to easily search for the same projectors instead of specifying the projector details each time.

Related Links
- "Creating a Shortcut" p.39

Creating a Shortcut

After searching for a projector, you can save the projector details as a shortcut that you can use later. A shortcut contains all of the projector's information, such as the projector name and IP address. Creating a folder shortcut saves information for multiple projectors contained in the folder.

1. On the search screen, right-click the projector or folder from the **Profile** or **Projector List**, and then click **Create Shortcut**.
   The Save As screen is displayed.

2. Select where you want to save the shortcut (.pme), and then click **Save**.

The shortcut is created and the projector information is saved in the shortcut.

- Double-clicking a shortcut (.pme), you can start the Epson iProjection software in the same mode as you created its shortcut.
- When you use the Participant Edition of the software, use a shortcut file created in **Advanced Connection Mode**.
- You can also select the projector or folder from the **Profile** or **Projector List**, and then drag and drop to the location where you want to create the shortcut.

You can use a commercially available USB flash drive as a USB key to transfer the projector's network information to a Windows computer. Creating the USB key allows you to quickly project images from the network projector.

Related Links
- "Creating a USB key on a USB Flash Drive (Windows Only)" p.40
- "Using a USB Key to Connect a Windows Computer" p.40

Creating a USB key on a USB Flash Drive (Windows Only)

You can create a USB key on a commercially available USB flash drive so you can use it to connect to your projector wirelessly.

When creating a USB key, make sure you use a USB flash drive that meets the following conditions.
- Formatted to FAT
- No security functions

We recommend deleting any files on the drive before creating a USB key.

1. Start **USB Key Setup Tool**.
   Select **Start**, **EPSON Projector**, and then select **USB Key Setup Tool**.
2. Select the application type that starts when you insert the USB key to your computer.
3. Insert an empty USB flash drive directly to your computer's USB port.
4. Follow the on-screen instructions to create the USB key.
   USB key creation begins and the software writes a file to the USB flash drive.

Caution
Do not remove the USB flash drive from the computer during USB key creation. If you remove the drive, the USB key may not be created correctly. If USB key creation fails, create the USB key again.

If there are multiple USB flash drives connected to your computer, follow the on-screen instructions to specify the drive for which you want to create a USB key.

5. Select **Safely Remove Hardware** in the Windows taskbar, and then remove the USB flash drive.

You can now use the USB flash drive as a USB key.

Related Links
- "Epson iProjection Editions" p.14

Using a USB Key to Connect a Windows Computer

After creating the USB key, you can quickly project images from the network projector. If you have previously used the USB key, you can use the network projector by simply connecting the USB key to your computer.

1. Make sure your projector is using one of the following network connections:
   - The wireless LAN module is installed or built into your projector.
   - A wired LAN cable is connected to your projector.
2. Turn on the projector.

3. Press the [LAN] button or [Source Search] button on the remote control to switch the input source to LAN.
   You see the network information screen.

4. Verify that an SSID and IP address are displayed.

5. Insert the USB key into the projector's USB Type A port.

   The location of the USB Type A port varies depending on your projector. See your projector *User's Guide* for more details.

   You see a projected message that the network information update is complete.

6. Remove the USB key.

7. Insert the USB key into a USB port on your computer.

8. Follow the on-screen instructions to install the Epson iProjection software.

   - If the Windows Firewall message is displayed, click **Yes** to disable the firewall.
   - You need administrator authority to install the software.
   - If it is not installed automatically, double-click MPPLaunch.exe in the USB key.


   After a few minutes, your computer image is displayed by the projector.

   If you want to switch the presentation to your computer, click the  button on the toolbar.

9. When you have finished projecting wirelessly, select **Safely Remove Hardware** in the Windows taskbar, and then remove the USB key from your computer.


   - You can share the USB key with other users without disconnecting your computer. To do this, deselect the **Quit application when removing the USB key** checkbox on the **Set options** screen in the Epson iProjection software.
   - You may need to restart your computer to reactivate your wireless LAN connection.

Connecting to multiple projectors and projecting the same image is known as mirroring. You can perform mirroring with up to four projectors.



- Mirroring is available only in **Advanced Connection Mode**.
- For best results, we recommend that you connect the projector to a wired LAN to perform mirroring.

On the search screen, select up to four projectors you want to connect to, and then click **Connect**.




A projector mirroring group is formed and the same image is projected from multiple projectors.

- When you select one projector from a projector mirroring group, all of the projectors in that group are selected.
- When other users are already connected to a projector in a mirroring group, you can only select another projector from the same mirroring group. You cannot select a projector that is not in a mirroring group.

You can output audio from the projector only when one computer is connected to one projector, and you are projecting in full screen mode.

1. Click **Set options** on the search screen.
   The Set options screen is displayed.
2. Click the **Audio Output** tab.
3. Select **Output audio from the projector**, and then click **Apply**.



When you select 256Kbps or 512Kbps as **Use Bandwidth** on the **Adjust performance** tab, you cannot output audio from the projector and cannot select this setting.

The Set options screen closes.

Related Links

- "Projecting Your Screen" p.44
- "Controlling the Connection Bandwidth" p.50

You can project the computer screen in full screen mode without projecting any other users' screens.

1. On the search screen, select the projector you want to connect to, and then click **Connect**.
   The toolbar is displayed.

2. Click the  button.



- You can also use the  button on the projection control screen.
- This button is not available for participants when using the moderator function.

Your computer screen is projected in full screen mode.

Changing the Moderator


While using the moderator function, you can change the moderator when another user needs to control the projected display.

> The moderator function is available only on the Standard Edition of the software.

1. On the search screen, select the projector you want to connect to, select **Connect as a Moderator, or disable interrupt connections**, and then click **Connect**.
   The moderator function turns on and the toolbar is displayed.

2. Click the button on the toolbar.
   The projection control screen is displayed.


3. Click the **Quit as Moderator** button on the moderator's computer.



   The confirmation screen is displayed.

4. Click **Yes**.
   The moderator function turns off.

5. Click the **Become Moderator** button on the projection control screen on a different user's computer.



   The confirmation screen is displayed.

6. Click **Yes**.

The moderator function turns back on and the new moderator can control the projected display.

Related Links

- "Connection Methods for Various Meeting Styles" p.20

The moderator can distribute the currently projected screen images to the participant's devices.

1. Click the button on the toolbar or the projection control screen.

   > You can also deliver a blank screen. Click the button on the toolbar, and then click **Deliver Blank Screen** from the **Tool** menu.

   You see the confirmation screen.

2. Click **Start**.

   The button and the button appear on the computer screen.

3. Click the button.

When the screen distribution succeeds, the moderator sees a completion message and the distributed image automatically appears in the Viewer on the participant's devices.

Related Links


- "Viewer Screen" p.80

Selecting the Participant's Screen to Project Using Thumbnails

The moderator can check the participant's device screens as thumbnails and select which user to project.

1 Click the button on the toolbar or the projection control screen.
The thumbnails screen is displayed.

2 Select up to 12 thumbnails you want to project.



- To update to the latest thumbnails, click the button.
- To clear all selections, click . If you click this again, the previously selected thumbnails are selected again.
- To switch the size and the number of thumbnails displayed on one page, click the or button.

3 Click the button.

> When you select more than 5 thumbnails, the thumbnail selection screen appears. After selecting up to 4 thumbnails, you must click the button again.

The selected thumbnails are projected. Click the button to close the thumbnails screen and return to the toolbar or the projection control screen.

Hiding the Projection Control Screen


You can hide the projection control screen from other users while projecting your computer screen. This allows you to change the necessary settings without projecting the operation. The projected image currently displayed is paused automatically when you switch the toolbar to the projection control screen. Your computer screen is projected again when you return to the toolbar.

> This function is available only for the moderator when using the moderator function.

1. Click **Set options** on the search screen.
   The Set options screen is displayed.

2. Click the **General settings** tab.

3. Select **Freeze projected screen when displaying Projection control screen**, and then click **Apply**.



The Set options screen closes. The operation on the projector control screen will not be projected next time you use it.


The moderator can lock mouse operations on participant's devices so that the participant cannot change the images being projected.

> You cannot lock operations on the extended display.

- Click the  button on the projection control screen to lock the participant's mouse operations. The  button changes to the  button on the projection control screen. The participants see the  icon to indicate that mouse operations are locked.
- Click the  button on the projection control screen to unlock the participant's mouse operations. The  button changes to the  button on the projection control screen. The participants can operate the mouse on their devices.

You can reduce the size of data transferred to the projector to decrease the network load. To do this, you can control the connection bandwidth.

1. Click **Set options** on the search screen.
   Set options screen appears.
2. Click the **Adjust performance** tab.
3. Select **Projection Mode** according to the projection content.
   - **Movies**: Suitable for playing videos smoothly.
   - **Operations**: Suitable for displaying the mouse or software operation on PC smoothly.
4. Select the bandwidth you want to use as the **Use Bandwidth** setting.



When you select a narrower bandwidth, the projected image quality may decline but the network load is reduced.

If you do not need to output audio while controlling bandwidth, make sure you clear the **Output audio from the projector** setting on the **Audio Output** tab. The bandwidth used for audio can then be used for the image transfer to improve the image quality.

Related Links

- "Bandwidth Control Restrictions" p.51

Bandwidth Control Restrictions

Note the following bandwidth limitations.

- When you limit the bandwidth, the image quality may decline due to the compression of the transferred data.
- When you select 256Kbps or 512Kbps as **Use Bandwidth** on the **Adjust performance** tab, you cannot output audio from the projector. If you want to transfer audio, select the bandwidth to 1Mbps or more.
- The bandwidth may momentarily exceed the value you selected because each value in the list is an average value measured within 30 seconds.
- You can limit the bandwidth only of data you send. You cannot limit data that you receive, such as a thumbnail.

Related Links

- "Outputting Audio from the Projector" p.43

Solving Problems

See the following sections to check for solutions to problems you may have using the Epson iProjection software.

Related Links

- "Solving Network Connection Problems" p.53
- "Solving Problems During Projection" p.56
- "Error Messages List" p.58
- "Event ID List" p.63

Try these solutions depending on your network environment.

Related Links
- "Solutions When You Cannot Connect Using Quick Connection Mode" p.53
- "Solutions When You Cannot Connect Projectors Using Advanced Connection Mode (Wireless)" p.53
- "Solutions When You Cannot Connect Projectors Using Advanced Connection Mode (Wired)" p.55

Solutions When You Cannot Connect Using Quick Connection Mode

When you cannot connect the computer and the projector using Quick Connection Mode, try the following solutions.

- Check the status of the external devices used for the network connection or the environment in which the network devices and the projector are located.
  - Connect the specified wireless LAN unit to the projector securely, if necessary. See your projector *User's Guide* for details.
  - Check for any obstacles between the computer and projector, and change their position to improve communication. Sometimes the indoor environment prevents the projector from being found in a search.
  - Set the radio strength for the network devices to the maximum.
- Check the projector's network settings.
  - Select one of these settings to connect the projector to the computer directly using wireless communication. The necessary settings vary depending on your projector.
    - Turn on the **Simple AP** setting.
    - Select **Quick** for **Connection Mode**.
  - Turn on the wireless LAN setting, if necessary.
  - When you enable the security setting, set the same passphrase to the computer and the projector.
  - Close the network settings menu on the projector.
- Check the computer's network settings.
  - Make sure you are using a computer that can connect to a wireless LAN.
  - Enable the wireless LAN setting or AirPort on your computer.
- Check the software settings.
  - Make sure you start the software in the correct connection mode. If you cannot select or change the connection mode, select **Display Connection Mode Selection window on startup** on the **General settings** tab in the Set options screen. The projector displays the select connection mode screen after you restart the software.

Related Links
- "Set options - General settings" p.70

Solutions When You Cannot Connect Projectors Using Advanced Connection Mode (Wireless)

When you cannot connect the computer and the projector using Advanced Connection Mode over a wireless network, try the following solutions. If you cannot resolve the problem, contact your network administrator.

- Check the status of the external devices used for the network connection or the environment in which the network devices and the projector are located.
  - Connect the specified wireless LAN unit to the projector securely, if necessary. See your projector *User's Guide* for details.
  - Check for any obstacles between the access point and the computer or projector, and change their position to improve communication. Sometimes, indoor environments prevent the projector from being found in a search.
  - Make sure that the access point and the computer or projector are not too far apart. Move them closer together and try to connect again.

- Check for interference from other equipment, such as a Bluetooth device or microwave. Move the interfering device farther away or expand your wireless bandwidth.
- Set the radio strength for the network devices to the maximum.
- Set the IP address, the subnet mask, and the gateway address for the access point correctly.
- Make sure the wireless LAN system of the access point supports the projector's wireless LAN system.

- Check the projector's network settings.
  - Select one of these settings to connect the projector to a wireless LAN. The necessary settings vary depending on your projector.
    - Turn off the **Simple AP** setting.
    - Select **Advanced** for **Connection Mode**.
  - Set the computer, the access point, and the projector to the same SSID.
  - Set **DHCP** to **Off**. When **DHCP** is set to **On**, it may take some time to enter LAN standby status if an available DHCP server is not found.
  - Set the IP address, the subnet mask, and the gateway address for the projector correctly.
  - Turn on the wireless LAN setting, if necessary.
  - Set the wireless LAN system to meet the standards supported by the access point.
  - When you enable the security setting, set the same passphrase to the access point, the computer, and the projector.
  - Close the network settings menu on the projector.
- Check the computer's network settings.
  - Make sure you are using a computer that can connect to a wireless LAN.
  - Enable the wireless LAN setting or AirPort on your computer.
  - Connect to the access point to which the projector is connected.
  - Turn off the firewall. If you do not want to turn it off, register the firewall as an exception. Make the necessary settings to open the ports. The ports used by this software are "3620", "3621", and "3629".
- Check the access point settings.
  - Set connection permission at the access point to allow projectors to connect if any functions that block connections, such as MAC Address restrictions and port restrictions, are set to the access point.
- Check the software settings.
  - Select the network adapter you are using from **Switch LAN** on the Set options screen. If the computer has multiple LAN environments, a connection cannot be established unless the network adapter is selected correctly.
  - If you cannot find the projector you want to connect to using **Automatic search**, select **Manual search** to specify the IP address.
  - Make sure you start the software in the correct connection mode. If you cannot select or change the connection mode, select **Display Connection Mode Selection window on startup** on the **General settings** tab in the Set options screen. The projector displays the select connection mode screen after you restart the software.
  - Make sure the projector supports the Epson iProjection version being used. Install the Epson iProjection software by downloading it from the Epson Web site.
  - Install the latest version of the Epson iProjection software on all computers. The maximum number of computer connections and the availability of the moderator function varies depending on the projector model, no matter which version of the Epson iProjection software you are using.
  - When another user is already connected, you can only connect to projectors in the same mirroring group as that selected by the other user. Select a projector from the same mirroring group as the user who is already connected, or select a projector that is in standby status.

Related Links

- "Set options - General settings" p.70

- "Searching for Network Projectors by Specifying an IP Address or Projector Name" p.28

Solutions When You Cannot Connect Projectors Using Advanced Connection Mode (Wired)

When you cannot connect the computer and the projector using Advanced Connection Mode over a wired network, try the following solutions. If you cannot resolve the problem, contact your network administrator.

- Check the status of the external devices used for the network connection or the environment in which the network devices and the projector are located.
  - Connect the network cable securely.

    - Use a commercially available 100BASE-TX or 10BASE-T LAN cable.
    - To prevent malfunctions, use a category 5 or higher shielded LAN cable.

- Check the projector's network settings.
  - Set **DHCP** to **Off**. When **DHCP** is set to **On**, it may take some time to enter LAN standby status if an available DHCP server is not found.
  - Set the IP address, the subnet mask, and the gateway address for the projector correctly.
  - Close the network settings menu on the projector.
- Check the computer's network settings.
  - Enable LAN settings on your computer.

    Windows: Check **Control Panel** > **Hardware and Sound** > **Device Manager**.
  - Turn off the firewall. If you do not want to turn it off, register the firewall as an exception. Make the necessary settings to open the ports. The ports used by this software are "3620", "3621", and "3629".
- Check the software settings.
  - Select the network adapter you are using from **Switch LAN** on the Set options screen. If the computer has multiple LAN environments, a connection cannot be established unless the network adapter is selected correctly.
  - If you cannot find the projector you want to connect to using **Automatic search**, select **Manual search** to specify the IP address.
  - Make sure you start the software in the correct connection mode. If you cannot select or change the connection mode, select **Display Connection Mode Selection window on startup** on the **General settings** tab in the Set options screen. The projector displays the select connection mode screen after you restart the software.
  - Make sure the projector supports the Epson iProjection version being used. Install the Epson iProjection software by downloading it from the Epson Web site.
  - Install the latest version of the Epson iProjection software on all computers. The maximum number of computer connections and the availability of the moderator function varies depending on the projector model, no matter which version of the Epson iProjection software you are using.
  - When another user is already connected, you can only connect to projectors in the same mirroring group as that selected by the other user. Select a projector from the same mirroring group as the user who is already connected, or select a projector that is in standby status.

Related Links

- "Set options - General settings" p.70
- "Searching for Network Projectors by Specifying an IP Address or Projector Name" p.28

Try these solutions depending on your situation.

Related Links
- "Solutions When the Screen is Not Projected Properly" p.56
- "Solutions When Audio is Not Played Properly" p.56
- "Solutions When the Moderator Function Does Not Work" p.57
- "Solutions When the Projected Screen is Not Delivered" p.57

Solutions When the Screen is Not Projected Properly

If the screen is not projected or there are problems with the project images try the following solutions.

- If you are using a Microsoft Office application, stop moving the mouse pointer. If you move the mouse pointer continuously, the screen may not be refreshed quickly.
- The Media Player movie playback screen may not be projected depending on the computer.
- The screen saver preview may not be projected properly depending on the computer.
- Reduce the number of connected devices if the connection speed declines.
- For Mac, when playing back movies, start the Epson iProjection software first before starting playback. If the Epson iProjection software is started during movie playback and the display screen resolution and color numbers are changed, try moving the movie playback window, minimizing it, or resizing it and so on.
- When using a computer that does not meet the software requirements, images and audio for movies may stop.
- When another user is the moderator, you cannot control your projected display. Change the moderator or project the screen without a moderator.
- When duplicating a display using a computer with a 3rd Generation Intel Core i series or earlier CPU, select **Always duplicate these displays** on the **General settings** tab in the **Set options** screen.
- When the projected images are interrupted or freezing, change the **Projection Mode** setting on the **Adjust performance** tab in the **Set options** screen.
  - **Movies**: Suitable for playing videos smoothly.
  - **Operations**: Suitable for displaying the mouse or software operation on PC smoothly.

Related Links
- "Set options - General settings" p.70
- "Set options - Adjust performance" p.71
- "Changing the Moderator" p.45

Solutions When Audio is Not Played Properly

If there is no audio coming from the projector, try the following solutions.

- Allow loading of the audio driver. Restart your computer, open **System Preferences**, select **Security & Privacy**, and then select **Allow** under the **General** tab.
- Audio can only be transferred to one projector. When multiple projectors are connected to one computer, disconnect other projectors and try again.
- Select **Output audio from the projector** on the **Audio Output** tab on the **Set options** screen.
- You can only output the computer's audio from the projector when projecting one computer screen in full screen mode.
- If the bandwidth is limited on the **Adjust performance** tab on the **Set options** screen, try increasing the connection bandwidth.
- If the volume for the computer is set to the minimum while the projector volume is set to the maximum, the noise may be mixed. Turn up the computer's volume and turn down the projector's volume.

Related Links
- "Set options - Audio Output" p.72

Solutions When the Moderator Function Does Not Work

If the moderator function does not work properly, try the following solutions.

- Make sure you use the Standard Edition of the software. If you use the Participant Edition of the software and need the moderator function, reinstall this software as necessary.
- Make sure your projector supports the moderator function. See the *User's Guide* supplied with the projector for more details.
- When another user is the moderator, you cannot control your projected display. Change the moderator.
- Make sure you select **Connect as a Moderator, or disable interrupt connections** when you connect a projector.

Related Links

- "Changing the Moderator" p.45

Solutions When the Projected Screen is Not Delivered

If the screen delivery function does not work properly, try the following solutions.

- Make sure your projector supports the screen delivery function. See the *User's Guide* supplied with the projector for more details.
- Close running projector functions.
- Make sure the image being projected is not protected by copyrights.

Related Links

- "Distributing the Projected Screen" p.46

When an error occurs, an error message is displayed on your computer screen. Check for your message and follow the instructions here to clear the error.

Related Links

- "Error Messages When Starting up the Epson iProjection Software" p.58
- "Error Messages When Using a USB Key" p.59
- "Error Messages When Searching for and Selecting Projectors" p.60
- "Error Messages When Projecting" p.61
- "Error Messages When Operating a Profile" p.61
- "Error Messages When Using the Moderator Function" p.61
- "Error Messages When Distributing the Projected Screen" p.62

Error Messages When Starting up the Epson iProjection Software

Error Messages	Remedy
This application is already running.	Two instances of the Epson iProjection software have been started.
Cannot start this application because other EPSON Projector software (Quick Wireless Connection) is already running.	Close Quick Wireless Connection and then start the Epson iProjection software. To close Quick Wireless Connection, perform **Safely Remove Hardware** from the icon on the task bar to remove the Quick Wireless Connection USB Key from the computer.
Cannot start this application because other EPSON Projector software (USB Display) is already running.	Close USB Display and then start the Epson iProjection software. Do one of the following to close USB Display: • Windows: Disconnect the USB cable from the projector. • Mac: Select **Disconnect** from the **USB Display** icon menu on the menu bar or Dock, and then remove the USB cable.
Cannot start this application because other EPSON Projector software (EasyMP Network Projection) is already running.	Close EasyMP Network Projection and then start the Epson iProjection software.
Cannot start this application because other EPSON Projector software (USB Key Setup Tool) is already running.	Close the USB Key Setup Tool and then start the Epson iProjection software.
Cannot start this application because other EPSON Projector software (Epson Wireless Presentation) is already running.	Close Epson Wireless Presentation and then start the Epson iProjection software.
Cannot start this application because other EPSON Projector software (Epson Wireless Transmitter Settings) is already running.	Close Epson Wireless Transmitter Settings and then start the Epson iProjection software.
Cannot start this application because other EPSON Projector software (Epson Classroom Connect) is already running.	Close Epson Classroom Connect and then start the Epson iProjection software.
Epson iProjection initialization failed.	Restart the Epson iProjection software. If the message is still displayed, uninstall and then reinstall the Epson iProjection software.

Error Messages	Remedy
Cannot open the shortcut file.	The shortcut file may be corrupted. Start the Epson iProjection software, and then try searching for and connecting to the projector again.
Cannot find the projector linked to the shortcut file. Search again.	Check the following items. • Open a shortcut file in the connection mode for which you created the shortcut file. • Open a shortcut file in **Advanced Connection Mode** if you use the **Participant Edition** of the software.
Files are missing or invalid. Failed to start the application. Reinstall/remove the application.	Uninstall and then reinstall the Epson iProjection software.
Network adapter information could not be obtained.	Check the following items. • A network adapter is installed on the computer. • The driver for the network adapter being used is installed on the computer. • The network adapter is enabled. After checking, restart the computer and then restart the Epson iProjection software. If you still cannot connect, check the network settings on the computer and the network settings on the projector.
Cannot start from the shortcut while projecting.	Stop projecting and then start projection from the shortcut. You cannot start projection from the shortcut when you are already projecting using the Epson iProjection software.
Cannot start from the shortcut while the Option screen is displayed. Close the Option screen, and then try opening the shortcut again.	The Set options screen is displayed. Close the Set options screen.
The slide show will not begin until PowerPoint is restarted.	Close PowerPoint, and then start the slide show again.
Cannot be used with the current OS version. Reinstall Epson iProjection.	Reinstall the Epson iProjection software.
Unable to start from the shortcut. A connection has already been established with the projector.	Stop projecting and then start projection from the shortcut. If the USB key is connected, remove the USB key.

Related Links

- "Uninstalling the Epson iProjection Software (Windows)" p.82
- "Uninstalling the Epson iProjection Software (Mac)" p.82
- "Installing the Epson iProjection Software (Windows)" p.14
- "Installing the Epson iProjection Software (Mac)" p.14

Error Messages When Using a USB Key

Error Messages	Remedy
Unable to find connection information. Insert the USB key.	Insert the USB key securely into your computer.
Unable to find connection information. Insert the USB key into the projector.	Insert the USB key securely into the projector to update the projector network information.
Unable to find a projector that can connect with Quick Connection Mode.	Close the Epson iProjection software and then insert the USB key again.
Unable to find a projector that can connect with Advanced Connection Mode.	

Error Messages	Remedy
Unable to use the USB key while the application is running.	
Unable to find a projector that can connect with Participant Edition.	Make sure the projector is connected to the network using the Advanced connection mode, and then update the projector network information saved on the USB key.
Files are missing or invalid. Failed to start the application. Set up the USB key again.	Delete all files on the USB flash drive, and then start the USB Key Setup Tool to create a USB key again.
Unable to set up the USB key. Files are missing or invalid. Reinstall Epson iProjection.	
Unable to set up the USB key. Reinsert the USB memory device and start USB Key Setup Tool again.	
Unable to set up the USB key. Check the amount of free space. Necessary free space: 150 MB	
Administrator authority is required to run USB Key Setup Tool.	Run the USB Key Setup Tool as a user with administrator authority.

Related Links

- "Creating a USB key on a USB Flash Drive (Windows Only)" p.40
- "Using a USB Key to Connect a Windows Computer" p.40

Error Messages When Searching for and Selecting Projectors

Error Messages	Remedy
Cannot join. The maximum number of participants has been exceeded.	The maximum number of devices are already connected to the projector. Disconnect users and projectors that are not projecting screens.
The projector keyword does not match. Please try again.	Check the Projector Keyword displayed on the screen, and enter the Projector Keyword.
Connection failed due to projector keyword mismatch.	
The selected projector is mirroring another projector.	When another user is already connected, you can only connect to the projectors in the same mirroring group as that selected by the other user. Select a projector from the same mirroring group, or select a projector that is in standby status.
One or more projectors are not responding.	You cannot connect to multiple projectors simultaneously. Check the network settings on the computer and the network settings on the projector.
A network error occurred.	Turn on your computer's wireless LAN, and then try searching for the projector again. If you still cannot connect to the projector, check the network settings on the computer and the network settings on the projector.
Connection to the projector failed.	Check if the projector you want to connect to is already connected to EasyMP Network Projection. You cannot connect to a projector that is already connected using EasyMP Network Projection.

Related Links

- "Supported Resolutions" p.83
- "Uninstalling the Epson iProjection Software (Windows)" p.82
- "Uninstalling the Epson iProjection Software (Mac)" p.82
- "Getting the Latest Version of the Software" p.82
- "Installing the Epson iProjection Software (Windows)" p.14
- "Installing the Epson iProjection Software (Mac)" p.14

Error Messages When Projecting

Error Messages	Remedy
The projector has disconnected.	An error may have occurred in the projector. Check the projector's indicator lights.
A network error occurred.	Try connecting again. If you still cannot connect to the projector, check the network settings on the computer and the network settings on the projector.

Error Messages When Operating a Profile

Error Messages	Remedy
Enter max. 32 characters.	The entered text exceeds 32 characters. Shorten the name to 32 characters or less.
Enter a folder name.	No folder name entered. Enter a folder name.
Folders should not be created more than 6 layers deep.	The folder structure is deeper than six folders. Create the new folder higher up in the folder structure.
There is already a folder named XXX in this folder.	A folder with the same name already exists. Enter another folder name.
There is already a file named XXX in this folder.	A projector with the same name already exists. Enter another projector name.
Cannot import. Format not supported by this application.	Check the profile you want to import. You cannot import a profile when projector information has not been registered, or when the profile is corrupt.
Cannot import because the folder structure exceeds six folders.	The folder structure cannot exceed six layers. Import, move, or copy to a folder higher up in the folder structure.
Cannot move because the folder structure exceeds six folders.	
Cannot copy because the folder structure exceeds six folders.	
Failed to open the file.	The profile may be corrupted. Try importing the profile again.
Failed to save the file.	Make sure you have access rights to the folder, and then try again.
Cannot import certain items because the connection modes differ.	Import a profile in the connection mode in which you created a profile.

Related Links

- "Registering a Profile" p.29
- "Importing a Profile" p.31

Error Messages When Using the Moderator Function

Error Messages	Remedy
Cannot switch to moderator.	You cannot become the moderator when another user is the moderator. Ask the current moderator to quit, and then try again.

Error Messages	Remedy
Failed to switch to Moderator Mode	Make sure another user is not the moderator, and then try again.
The moderator function is not available. You have been connected as a participant.	The projector you are connecting to does not support the moderator function. To become the moderator, change to a projector that supports the moderator function.

Related Links

- "Changing the Moderator" p.45

Error Messages When Distributing the Projected Screen

Error Messages	Remedy
The projector is processing. Wait for a while, and then try to deliver again.	Close running projector functions, and then try again.
Cannot deliver the image currently being projected.	Make sure the image being projected is not protected by copyrights.
A network error occurred while delivering. Please try again.	Make sure the moderator can connect to the projector.
Cannot save the received file. Check the amount of free space.	Make sure you have enough free space to save the received images.
Cannot save the received file. Check the access rights to the Save To folder.	Check the location where the received image is saved on the **Deliver** tab in the Set options screen and make sure you have access rights to the folder.
Cannot save the received file. Check the folder settings.	

Related Links

- "Distributing the Projected Screen" p.46

When a connection error occurs, a number indicating the type of error is displayed as follows.

Event ID: 04xx

Check the numbers and then apply the following countermeasures. If you cannot resolve the problem, contact your network administrator, or contact Epson as described in your projector *User's Guide*.

Event ID	Cause	Remedy
0432	Failed to start up the network software.	Restart the projector.
0435		
0434	Network communication is unstable.	Check the network communication status, and reconnect after waiting for a while.
0481		
0482		
0433	Cannot play transferred images.	Restart the network software.
0484	Communication was disconnected from the computer.	
04FE	The network software ended unexpectedly.	Check the status of network communications. Restart the projector.
04FF	A system error occurred in the projector.	Restart the projector.
0891	Cannot find an access point with the same SSID.	Set the computer, the access point, and the projector to the same SSID.
0892	The WPA/WPA2 authentication type does not match.	Check that the wireless LAN security settings are correct.
0893	The WEP/TKIP/AES encryption type does not match.	
0894	Communication was disconnected because the projector connected to an unauthorized access point.	Contact your network administrator for more information.
0898	Failed to acquire DHCP.	Check the DHCP server to see if it is operating correctly and check the LAN cable to see if it is connected correctly. If you are not using DHCP, set **DHCP** to **Off**.
0899	Other communication errors	If restarting the projector or the network software does not solve the problem, contact Epson as described in your projector *User's Guide*.
089A	The EAP authentication type is not the same.	Check that the wireless LAN security settings are correct. Also, check if the certificate is installed correctly.
089B	EAP server authentication failed.	
089C	EAP client authentication failed.	
089D	Key exchange failed.	
0B01	The built-in storage could not be detected correctly.	Perform **Delete All Internal Data**. When the internal storage is deleted correctly, plugin the power cord for the projector and turn it on. If it is not deleted correctly, contact Epson as described in your projector *User's Guide*. Go to **Extended** > **Whiteboard Settings** > **Internal Storage**.
0BFF	An error has occurred in the Whiteboard function.	Restart the projector.

Screen Summary


See these sections for more information about the Epson iProjection screens.

Related Links

- "Select Connection Mode Screen" p.65
- "Search Screen" p.66
- "Save Screen" p.68
- "Set options" p.69
- "Toolbar" p.75
- "Projection Control Screen" p.76
- "Thumbnail Screen" p.79
- "Viewer Screen" p.80

Select Connection Mode Screen

When you start the Epson iProjection software, the select connection mode screen is displayed.




1	Select the connection mode.
2	Select to always connect using the selected connection mode.

Related Links

- "Connection Methods for Various Network Environments" p.15

After selecting the connection mode, the search screen is displayed.



1	User name	Displays the user name displayed in the user list on the projection control screen. You can edit the user name on the **User Settings** tab on the Set options screen.
2	Automatic search	Searches for projectors on the network to which the computer is connected.
3	Manual search (Advanced Connection Mode only)	Searches for projectors on the network by specifying the projector's IP address or projector name.
4	Profile	Searches for projectors on the network by using the projector information saved previously.
5	Profile list	Displays the registered profiles (projector information). When you double-click the profile, the projectors registered in the profile are searched for on the network.
6	Set options	Displays the Set options screen.
7	Connect	Connects to the selected projectors.
8	List of Connected Projectors (Advanced Connection Mode only)	Displays information on the projectors selected from the **Projector List**. Even if the search method is changed, the content of the **List of Connected Projectors** remains the same.
9	Register (Advanced Connection Mode only)	Registers the projectors from the **List of Connected Projectors** to a profile.
10	Connect as a Moderator, or disable interrupt connections.	Connects to the selected projectors as the moderator and you can prevent any other users from interrupting your connection (supported models only). The moderator function is available only on the Standard Edition of the software.
11	Clear list	Clears information displayed in the **Projector List** and the **List of Connected Projectors**.
12	Projector List	Displays a list of the projectors found on the network. You can then select projectors to connect to. The search results for each search method (**Automatic search**, **Manual search**, and **Profile**) are displayed in separate lists.

		• **Status**: See the description of projector status icons in the next table. • **Projector name**: Displays the projector's name. • **SSID** (Quick Connection Mode only): Displays the projector's SSID. • **Signal intensity** (Quick Connection Mode only): Displays the signal intensity when a connection is made in Quick Connection Mode. As the Signal intensity increases, so does the number of lit indicators. • **IP address** (Advanced Connection Mode only): Displays the projector's IP address. • **Comments**: Displays comments for the projector. You can edit the comment by right-clicking the profile, and then clicking **Property**. You can enter up to 32 characters.
⓭	Refresh	Updates information in the **Projector List**.
⓮	Manual search box (Advanced Connection Mode only)	When using **Manual search**, enter the projector's IP address or the projector name. Click the **Search** button to search for the specified projector.


Projector status icons in the **Projector List** are described in the following table.

 Standby	Available. You can connect to the projector.
 Busy	Available. Although other computers are connected to the projector, you can also connect at the same time.
 Mirroring...	Available. You can connect to a group of projectors that are projecting the same image (mirroring).
 Currently in use by another application	Not available. The projector is displaying the network configuration screen or is being used by other projector software.
 Searching	Not available. A **Manual search** or **Profile** search is already being used to search for the projector.
 Not found.	Not available. The specified projector could not be found using **Manual search** or **Profile** search.
 Unsupported Projectors	Not available. The projector is not compatible with the Epson iProjection software.
 Not acquired	Available. Displayed when a projector with security settings enabled is found in Quick Connection Mode.

Related Links

- "Searching for Network Projectors Automatically" p.27
- "Searching for Network Projectors by Specifying an IP Address or Projector Name" p.28
- "Searching for Network Projectors Using a Profile" p.28
- "Searching for Network Projectors Using a Shortcut" p.39

When you search for projectors and save information as a profile on the search screen, the Save screen is displayed.



1	Projector file name	Enter the projector file name.
2	Save in	Select the folder where you want to save the profile.
3	Create New folder	Creates a new folder.
4	OK	Registers the projector information in the profile.

Related Links

- "Registering a Profile" p.29

When you click **Set options** on the Epson iProjection search screen, the Set options screen is displayed.


- You can also access Set options from the **Tool** menu on the projection control screen. When you access Set options from the projection control screen, the **User Settings** tab is not displayed.
- The available settings vary depending on the edition of the software.

Related Links

- "Set options - User Settings" p.69
- "Set options - General settings" p.70
- "Set options - Adjust performance" p.71
- "Set options - Audio Output" p.72
- "Set options - Deliver" p.73

Set options - User Settings

When you click the **User Settings** tab on the Set options screen, the following screen is displayed.



User name	Enter the user name displayed in the user list on the projection control screen. You can enter up to 32 characters. This setting is synchronized with the setting on the search screen.
Shared Profile Name (Advanced Connection Mode only)	Enter the network location or URL of the shared profile (including the name of the profile) as shown below. • For a file server (Windows only): \ \xxxxx\xxxxx.mplist • For a web server: http://xxxxx/xxxxx.mplist
Delete (Advanced Connection Mode only)	Deletes the input history for **Manual search**.


Usage Survey	Select to allow Epson to acquire application usage information.
Projector Operation Log Information	Select to allow Epson to acquire projector operation log information.
Reset	Resets all adjustment values for **Set options** to their default settings, except for **Switch LAN** on the **General settings** tab.

Related Links

- "Search Screen" p.66
- "Projection Control Screen" p.76
- "Searching for Network Projectors Automatically" p.27
- "Sharing a Profile over a Network" p.31

Set options - General settings

When you click the **General settings** tab on the Set options screen, the following screen is displayed.



Display in high resolution when dividing the projected screen in two or four	Available only for projectors with a resolution of WUXGA (1920 × 1200) or Full HD (1920 × 1080). Select to display all divided screens in high resolution. Clear this setting if displaying the image takes too long or is interrupted.
Display Connection Mode Selection window on startup	Select to display the Select Connection Mode screen each time the software starts. Clear this checkbox once you have settled on a regular startup method.


Freeze projected screen when displaying Projection control screen	Available only for the moderator when using the moderator function. Select to hide the operations on the projection control screen from other users while projecting your computer screen.
Use Interactive Pen	Select to use the interactive function over a network (supported models only). You do not need to connect a computer to the projector with a USB cable. You can use the following devices at the same time. • Windows: Two Easy Interactive Pens and six touch points • Mac: One mouse
Quit application when removing the USB key	Select to disconnect the computer when you remove the USB key from your computer. Deselect this checkbox if you want to share the USB key with other users without disconnecting your computer.
Always duplicate these displays	Select to duplicate a display using a computer with a 3rd Generation Intel Core i series or earlier CPU.
Switch LAN	Windows only Use this setting if you need to switch the network adapter used to perform a search when a computer has multiple adapters. By default, all of the network adapters are used to perform a search.
Wireless LAN passphrase setting files (Quick Connection Mode only)	In Quick Connection Mode, SSIDs and passphrases are stored on the computer when connecting to a projector with security settings enabled. You can edit and delete the stored information. Edit: Displays the wireless network management screen for the computer. Delete all: Deletes all the SSIDs and passphrases stored on the computer.
Reset	Resets all adjustment values for **Set options** to their default settings, except for **Switch LAN** on the **General settings** tab.

Related Links

- "Changing the Number of Projected Panels" p.34
- "Hiding the Projection Control Screen" p.48


Set options - Adjust performance

When you click the **Adjust performance** tab on the Set options screen, the following screen is displayed.



Use Bandwidth	Controls the bandwidth for the data transfer. When you select a narrower bandwidth, the projected image quality may decline but the network load is reduced.
Projection Mode	Select an appropriate projection mode according to the projected content. • **Movies**: Suitable for playing videos smoothly. • **Operations**: Suitable for displaying the mouse or software operation on PC smoothly.
Copyright	Display Open-Source Software License Information
Version	Windows only Displays the Epson iProjection version information.
Reset	Resets all adjustment values for **Set options** to their default settings, except for **Switch LAN** on the **General settings** tab.

Related Links
- "Controlling the Connection Bandwidth" p.50



Set options - Audio Output


When you click the **Audio Output** tab on the Set options screen, the following screen is displayed.

Output audio from the projector	Select to output the computer's audio from the projector. Clear to output audio from the computer. • You can only output the computer's audio from the projector when projecting one computer screen in full screen mode. • When you select **256Kbps** or **512Kbps** as **Use Bandwidth** on the **Adjust performance** tab, you cannot output audio from the projector and cannot select this setting.
Reset	Resets all adjustment values for **Set options** to their default settings, except for **Switch LAN** on the **General settings** tab.

Related Links
- "Outputting Audio from the Projector" p.43
- "Controlling the Connection Bandwidth" p.50

Set options - Deliver

When you click the **Deliver** tab on the Set options screen, the following screen is displayed.



Display received images in the Viewer	Select to open the received image in the Viewer bundled with the Epson iProjection software.
Save Location Folder	Displays the folder where the received image file is saved. Saved images are stored in the following folders. • **Windows** <startup_drive>:\users\<user_name>\Documents\Epson iProjection • **Mac** <startup_drive>:\Users\<user_name>\Pictures\Epson iProjection

Open Save Location Folder	Opens the folder where the received image file is saved.
Allow Moderator Monitoring	Select to allow the moderator to view the computer screen as a thumbnail.
Reset	Resets all adjustment values for **Set options** to their default settings, except for **Switch LAN** on the **General settings** tab.

Related Links

- "Distributing the Projected Screen" p.46

After the Epson iProjection software starts and a connection is made with the projector, the toolbar is displayed on the computer screen. You can use this toolbar to control the projected image and to disconnect the network connection.




The items displayed on the toolbar vary depending on the connection method and the edition or your role of the software.

Show	Releases **Stop** or **Pause** and projects the computer screen as it is.
Stop	Stops projection while connected to the projector. A black screen is projected while stopped.
Pause	Pauses the computer screen currently displayed. The projected display does not change, even if you make changes on the computer screen.
Deliver Projected Screen	Distributes the currently projected screen images to the participant's devices.
Display Thumbnails	Displays thumbnails of the participant's device screens for the moderator to check.
Display Received Image	Displays received images in the Viewer.
Project My Screen	Projects your computer screen in full screen mode.
Leave	Disconnects the connection between your computer and the projectors.
Disconnect All	Disconnects the connection between all devices and projectors participating in the meeting.
Switch to Projection control screen	Switches to the projection control screen.
Projector Information	Displays projector network information. The **Projector Keyword** is the keyword you entered when you connected to the projector. ----: The projector keyword is not set. **Unknown**: The projector keyword is not acquired because the connection is established without entering the projector keyword such as reading QR code and inserting the USB key.

Related Links

- "Projection Control Screen" p.76
- "Operating the Projected Display Status" p.33
- "Projecting Your Screen" p.44
- "Disconnecting" p.37

When you click the button on the toolbar, the projection control screen is displayed.



- The projection control screen is available only on Standard Edition of the software.
- The items displayed on the projection control screen vary depending on your role of the software and projector being used.

1	File menu	Click to select **Exit** to close the software.
	Tool menu	Click to select the following items. • **Deny User Operations**: Locks the participant's mouse operations. You cannot lock operations on the extended display. • **Allow User Operations**: Unlocks the participant's mouse operations. • **Deliver Blank Screen**: Distributes a blank screen to the participant's devices so that participants can draw freely. • **Display Received Image**: Displays received images in the Viewer. • **Set options**: Displays the Set options screen.
	Disconnect menu	Click to select **Leave** or **Disconnect All**.
	Help menu	Click to select **Version information**.
2	Number of connections	Displays the number of users connected to the projector.
3	User information	Displays your name and status. Displayed in blue when your computer screen is being projected. Displayed in gray when you are in the projection area but not projecting.
4	User search box	Enter the user name you want to search for, and then click the button. The search results are displayed in the user list. Click the button to return to the original user list.

⑤	User list	Displays the user names for the computers connected to the projectors. You can connect up to 50 devices to a projector simultaneously, such as computers, smartphones and tablets using the Epson iProjection software. When you drag and drop a user name to a white panel in the projection area, the computer screen is projected. The background for users that are currently being projected is blue and users that are in the projection area but not currently projecting is gray. Even if a user left the session, their name remains in the user list and their text color is gray. The default setting for the user name is the log in user name. You can change the user name on the **User Settings** tab on the Set options screen, or the search screen.
⑥	 Deliver Projected Screen	Distributes the currently projected screen images to the participant's devices.
⑦	Connected Projector Name	Displays the name of the projector you are currently connected to. When you click the projector name, the projector control web page is displayed. You can control projector operations on your computer screen in the same way as using the remote control. See your projector *User's Guide* for more details.
⑧	 Projector Information	Displays projector network information. The **Projector Keyword** is the keyword you entered when you connected to the projector. ----: The projector keyword is not set. **Unknown**: The projector keyword is not acquired because the connection is established without entering the projector keyword such as reading QR code and inserting the USB key.


⑨	 Display Thumbnails	Displays thumbnails of the participant's device screens for the moderator to check.
⑩	Quit as Moderator/ Become Moderator	Click the **Quit as Moderator** button to stop being the moderator, or the **Become Moderator** button to become the moderator. The displayed button varies depending on the connection method.
⑪	Moderator	Displays the moderator name when there is a moderator.
⑫	Projection area	When the background color for a panel is white, the computer screen for the user in that panel is projected. If there is no user in the white panel, a black screen is projected. By dragging and dropping the user name, you can change the screen being projected and the position at which the computer screen is projected.
⑬	Target panel	Move the target panel framed in blue by clicking on one of the panels in the projection area. You can project the computer screen where the target panel is positioned when you click one of the change projection buttons.
⑭	Screen control buttons	Indicates the following status of the projector. •  **Show**: Releases **Stop** or **Pause** and projects the computer screen as it is. •  **Stop**: Stops projection while connected to the projector. A black screen is projected while stopped. •  **Pause**: Pauses the computer screen currently displayed. The projected display does not change, even if you make changes on the computer screen.
⑮	 Deny/Allow User Operations	Locks or unlocks the participant's mouse operations. You cannot lock operations on the extended display.

⑯	 Switch to Toolbar	Switches to the toolbar.
⑰	Change projection buttons	Changes the number of panels available for projecting computer screens. •  **One Screen**: Projects the screen from one device in full screen mode without dividing the projected display. •  **Two Screens**: Projects the screens from up to two devices at the same time by dividing the projected display in two. •  **Four Screens**: Projects the screens from up to four devices at the same time by dividing the projected display in four.
⑱	 Project My Screen	Projects your computer screen in full screen mode.

Related Links

- "Search Screen" p.66
- "Set options - User Settings" p.69
- "Toolbar" p.75
- "Disconnecting" p.37
- "Projecting Your Screen" p.44
- "Changing the Moderator" p.45
- "Hiding the Projection Control Screen" p.48
- "Distributing the Projected Screen" p.46
- "Prohibiting Participant Operations" p.49
- "Controlling the Projected Display" p.33

When you click the button on a toolbar or a projection control screen, the following screen is displayed.



1	Thumbnail	Displays a participant's device screen. The thumbnail being projected is surrounded by a blue frame.
2	Thumbnail check box	Select the thumbnail that you want to project. You can select up to 12 thumbnails.
3	User name	Displays the user name of each thumbnail. You can display up to 32 characters.
4	Close	Closes the thumbnail screen.
5	Project	Projects the thumbnail you selected. When you select more than 5 thumbnails, the thumbnail selection screen appears. After selecting up to 4 thumbnails, you must click the button again.
6	Project My Screen	Projects the screen from your computer in full screen mode without projecting any other users' screens.
7	Next	Displays next page.
8	Page list	Switches to the page you want to view.
9	Previous	Displays previous page.
10	Display Small Thumbnails	Reduces the size of each thumbnail so you can view more thumbnails on the screen.
11	Display Large Thumbnails	Increases the size of each thumbnail so you can view more details on each one.
12	Clear All	Displays the number of selected thumbnails. Deselect the check box to clear all the selections. If you select the check box again, the previously selected thumbnails are selected again.
13	Refresh	Refreshes the thumbnails.

The viewer screen appears when you perform one of the following operations.

- When you receive the distributed image data.
- When you select **Display Received Image** from the Tool menu on the projection control screen.
- When you click the  button on the toolbar.



1	Next data	Displays next data.
2	Previous data	Displays previous data.

Appendix

See these sections to learn more about the Epson iProjection software.

Related Links

- "Updating and Uninstalling the Software" p.82
- "Supported Resolutions" p.83
- "Limitations" p.84
- "Notices" p.85

Follow these instructions to update or uninstall the Epson iProjection software.

Related Links
- "Getting the Latest Version of the Software" p.82
- "Uninstalling the Epson iProjection Software (Windows)" p.82
- "Uninstalling the Epson iProjection Software (Mac)" p.82

Getting the Latest Version of the Software

Updates to this software and this guide may be available for your product. To check for updates, visit support.epson.com and select your product.

Uninstalling the Epson iProjection Software (Windows)

Follow the instructions below to uninstall the Epson iProjection software.

You need administrator authority to uninstall the software.

1. Turn on your computer.
2. Make sure all running applications are closed.
3. Press the key on the keyboard to display all apps.
4. Right-click (press and hold) **Epson iProjection Ver.X.XX**, and then select **Uninstall**.
5. Follow the on-screen instructions.

Uninstalling the Epson iProjection Software (Mac)

For Mac, follow the instructions below to uninstall the Epson iProjection software.

1. Turn on your computer.
2. Make sure all running applications are closed.
3. Open the **Applications** folder.
4. Open the **Epson iProjection** - **Tools** folder, and then double-click **Epson iProjection Uninstaller.app**.
5. Follow the on-screen instructions.

Supported Resolutions

The following computer screen resolutions can be projected. You cannot connect to a computer with a resolution greater than WUXGA.

- SVGA(600 × 800)
- XGA(768 × 1024)
- SXGA(960 × 1280)
- SXGA(1024 × 1280)
- SXGA+(1050 × 1400)
- WXGA(768 × 1280)
- WXGA(800 × 1280)
- WXGA+(900 × 1440)
- UXGA(1200 × 1600)
- Full HD(1080 × 1920)
- WUXGA(1200 × 1920)

When using a computer screen with a unique aspect ratio, the resolution is increased or decreased depending on the resolution of the computer and the projector to avoid impairing image quality.

Depending on the resolution, the vertical or horizontal margins may be projected in black.

Check these sections for restrictions applied when projecting computer images while using the Epson iProjection software.

Related Links
- "Connection Limitations" p.84

Connection Limitations

Note the following limitations when using the Epson iProjection software.

- You can connect up to four projectors to one computer and project simultaneously. (Multi-screen is not supported.)
- You can connect up to 50 devices to a projector simultaneously, such as computers, smartphones and tablets using the Epson iProjection software.
- Audio can only be transferred when connected to one projector and projecting one computer screen in full screen mode. If multiple projectors are connected or if the projected display is divided, audio cannot be transferred during projection.
- If the transmission speed of the wireless LAN is low, the network may disconnect unexpectedly.
- Applications that use part of DirectX functions may not be displayed correctly (Windows only).
- You cannot project full-screen MS-DOS prompts (Windows only).
- There are times when the image on the computer screen and the image projected by the projector may not match exactly.
- Movies are not played as smoothly as they are on a computer.
- When you enable the **Use Interactive Pen** setting on the **General settings** tab on the **Set options** and see black bands on the computer screen, the position of the interactive pen may be misaligned.

Check these sections for important notices about your software.

Related Links

- "Copyright Notice" p.85
- "About Notations" p.85
- "Trademarks" p.85
- "Copyright Attribution" p.85

Copyright Notice

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. No patent liability is assumed with respect to the use of the information contained herein. Neither is any liability assumed for damages resulting from the use of the information contained herein.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable against any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

The contents of this guide may be changed or updated without further notice.

Illustrations in this guide and the actual projector may differ.

About Notations

- Microsoft ® Windows® 10 operating system
- Microsoft ® Windows® 11 operating system

In this guide, the operating systems above are referred to as "Windows 10" and "Windows 11". Furthermore, the collective term "Windows" is used to refer to them all.

- macOS 13 (Ventura)
- macOS 14 (Sonoma)
- macOS 15 (Sequoia)
- macOS 26 (Tahoe)

In this guide, the collective term "Mac" is used to refer to all of the operating systems above.

Trademarks

Epson is a registered trademark of Seiko Epson Corporation.

XGA is a trademark or registered trademark of International Business Machines Corporation.

Mac and macOS are registered trademarks of Apple Inc.

Microsoft and Windows are trademarks of the Microsoft group of companies.

Other product names used herein are also for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

Sofware Copyright: This product uses free sofware as well as sofware to which this company holds the rights.

Copyright Attribution

This information is subject to change without notice.

© 2025 Epson America, Inc., 11/25

CPD-63686