工艺:70g书纸+四色,双面印刷,扇形折X6再对折
料号:98-01-2224F　摊开尺寸:780X350mm,拆成形后尺寸:130X175mm

ARTISTE

ADH300

No need to return to store
Get code of Whatsapp / Wechat
(You can scan with camera or others app)

USER GUIDE

1)Headphone Receiver

1.Volume Up and Down Control
2. Signal lost LED indicator
3.Power LED
4.ON/OFF Control
5.Power LED indicator

2)Accessories

10.RCA-3.5mm cable
11.AAA x 2 pcs batteries for Headphone (2 pieces)
Headset x headphone
12.Optical cable
13.RCA - Female 3. 5mm cable

AUTO OFF:
Headset will turn off automatically if there is no input of audio signal for more than 30 minutes, need to restart the headset and play sound again.

Note: Rechargeable batteries have durable life. If you need to replace them, the batteries are on the right some.If. You just press the latch down lightly, don't need much strength.Then insert 2 pcs batteries into the battery compartment, pay attention to the polarity requirement. Make sure the batteries are placed at the right polarity.
Never attempt to charge other types of batteries or non-rechargeable batteries.

4. CONNECTION AND USE

4.1 Following Hookup A
You need:

1.Headset　2. Transmitter　3. RCA-Female 3.5mm cable　4.RCA 2.5mm cable

Using 3.5mm/RCA audio out

You need to use after hookup:

Headset
Headset
1.Plug
Plug in headset jack
2.Sound
Connect headset to transmitter with 3.5mm/RCA audio cable
3.Power light on
Turn on headset and transmitter, Power light will be lit up

If no sound,please check the TV setting refer to **"5.TV SETTING"**
Note:
1.Please remember to turn the volume down before put them on, since the default volume is high
2.If you still can not receive audio on the headphone,connect the transmitter to your Cable Box/Satellite Box RCA audio out rather than your television.

4.2 Following Hookup C
Using Optical audio out(must purchase3.5*4 separately)
You need:

1.Headset　2. Transmitter　3. RCA-Female 3.5mm cable　4.RCA 2.5mm cable

5.RCA-3.5mm adapter　6.Optical cable　7.Optical adapter　8.AC/DC power for the adapter

Package Weak ? Include the optical adapter

5. TV SETTING

Note: Either TVs are similar to the settings, Or contact your TV manufacturer for more details.

SONY TV:

Headphones or speakers
Headphones
Press The Home button on remote
Options
Select
Sound
Select
Audio Output
Headphones Audio Out　Audio Out　TV Speakers　Audio System
Headphones 3.5 mm output
Sound in dolby(r) dig.　TV and headphones (see details)　Headphones (see details)

Whether has sound at the upper time
Options
Select
Sound
Select
Speakers

1. COMPONENT PART LIST

A)Transmitter

1.Power/Audio Signal Charging indicator
2.Charging pins
3.Audio IN Socket
4.DC IN Socket

2. CHARGING

1.For your convenience, rechargeable batteries have been inserted in the Headset. Please charge it for 7 hours before first use.
2.Turn OFF the headset by pressing and holding the power button about 2 seconds. Charge the transmitter, the red LED light start to flash, indicating charging.
3.**Retract the headphone band** to contact with charging pin correctly when charging.
4.Place the headphone on the charging cradle. Green LED will turn on when it is charging correctly. Green LED will turn off after fully charged.

Please retract the headphone band to contact charging pins correctly when charging

Headset charging cradle

Power
Charge

Charging
Fully charged

3. CHECK YOUR DEVICE' S OUTPUT PORTS

	RCA (3.5mm)	Headset (3.5mm)	Headset (3.5mm)	Headset (3.5mm)
Jack Options				
Battery Compartment	✓	✓	✗	✗
Please see Hookup	Hookup A	Hookup B	Hookup C	N/A

PHONE TEST

Before connect the transmitter to TV, it is **better** to connect to a phone via 3.5mm cable to test the item. Connect the transmitter to your phone via 3.5mm cable, then turn on the headset and transmitter, turn on it, the LED light shows **red**. Play phone music, turn on the headphone, LED light on the left turns to **green**, indicating the headset receives the signal. If the headset works successfully, you will hear sound. (Refer **Point 6.1** for detail)

4.3 Following Hookup B
You need:

1.Headset　2. Transmitter　3.Headset 3.5mm cable　4. RCA-female 3.5mm cable

Using RCA audio out (Red/White pairs) Optional **AUDIO OUT**

You need to use after hookup:

Headset
Headset
1.Plug
Plug in headset jack
2.Sound
Connect headset to transmitter with 3.5mm/RCA audio cable
3.Power light on
Turn on headset and transmitter, Power light will be lit up

If no sound,please check the TV setting refer to **"5.TV SETTING"**
Note:
1.Please remember to turn the volume down before put them on, since the default volume is high
2.If you still can not receive audio on the headphones while at the same time having audio from the television speakers,connect the transmitter to your Cable Box/Satellite Box RCA audio out rather than your television.

You need to use after hookup:

Headset
Headset
1.Plug
Plug in headset jack
2.Sound
Connect headset to transmitter with 3.5mm/RCA audio cable
3.Power light on
Turn on headset and transmitter, Power light will be lit up

Headset
Headset
1.Plug
Plug in headset jack
2.Sound
Connect headset to transmitter with 3.5mm/RCA audio cable
3.Power light on
Turn on headset and transmitter, Power light will be lit up

SAMSUNG TV:

Menu
Select
Sound
Select
Sound Setting
Select
Sound Output
Select
Headphone
Select
Sound Output
Select
Headphone
Select
Sound Output
Select
Headphone