MONSTER PRINTER SLUG

BRAND: Monster
CATEGORY: Audio
PRODUCT NAME: Monster Party Flux
FILE NAME: MBL1-1004 Manual
ITEM NUMBER: MBL1-1004

PRINT 4C
2 Sided - Accordion Fold

PRESS WORK: TRIM TO SIZE, SCORE, FOLD & GLUE WHEN SPECIFIED

SCALE: 100%

ASSEMBLED PACKAGE DIMENSIONS (in Inches)

WIDTH: 3"
HEIGHT: 3.74"
DEPTH: N/A

DIELINE OVERALL DIMENSIONS (in Millimeters)
WIDTH: 450mm
HEIGHT: 95mm

PRESS SPEC COLOR REFERENCES

- DIELINE
- CLEAR WINDOW 0.3mm
- GLOSS UV SPOT
- EMBOSSING (RELIEF)
- DEBOSSING (SUNKEN)
- FOLDING LINE
- PRODUCT PLACEMENT
- FOILING
- GLUE FOLD
- Ø20mm SECURITY STICKERS PLACEMENT
- BLISTER OR INNER TRAY PLACEMENT
- CLOTH LIFT TAG

PACKAGING MATERIALS, THICKNESS & SIZE

SUBSTRATE TYPE: 400 gsm Giftbox
WINDOW:
INNER TRAY
MAGNET:
VELCRO:
SECURITY STICKERS: Ø20mm
HANG TAB:
FOAM:
CORRUGATED BOARD:
PLASTIC BAG:
MANUAL: 128gsm

ADDITIONAL PANTONE COLORS (NOT CMYK)

SOLID COLOR NAME:

NEON COLOR NAME:
METALLIC COLORS:
VENDOR'S FOIL NAME/NUMBER:

PACKAGING TYPES

FOLDING CARTON: Print 4/0
FOLDING CARTON WITH DOOR PANEL:
RIGIT GIFT BOX:
CLAMSHELL:
SLIDING/SLIPCASE:
TRAPPED BLISTER CARD
BLISTER CARD:
OTHER:

FILE SAVED AS:
.ai = FULLY EDITABLE
-OUT.ai = OUTLINED
.pdf = Acrobat
.jpg = Flat image
.png = DIGITAL (transparent background)

APPROVAL CHECKLIST:

PRIMARY DESIGNER: **Phil A**
DATE: **6/26**

SECONDARY DESIGNER:
DATE:

APPROVED BY:
DATE:

AUTHORIZATION SIGNATURES:

MONSTER

PARTY FLUX

BLUETOOTH® PARTY SPEAKER WITH LED LIGHTING

QUICK START GUIDE

SCAN QR CODE TO EXTEND YOUR PRODUCT'S WARRANTY

MBL1-1004-BLK

v1.0 0626

SAFETY AND CARE INSTRUCTIONS

Read all the instructions before using the product and then store them for future reference. Failure to follow these safety instructions could lead to fire, electrical shock, personal injury, property damage, or damage to the product.

- This product contains a non-replaceable rechargeable lithium-ion battery. When discarding, follow your local and state guidelines.
- Do not expose to rain, moisture, or other liquid. Do not use near water such as swimming pools, bathtubs, or sinks, if it becomes wet, immediately unplug the product from a power source. Do not handle the unit, USB cord or wall charger with wet hands.
- Do not charge, or use, the product if it has been submerged in water, or if water has gotten inside the product.
- Do not expose to heat sources, the sun, or leave it in a hot vehicle. Do not dispose of product in an active fire.
- Do not expose the product to extremely high or low temperatures. Use this product in a location with a temperature of 32°F - 95°F. Prolonged exposure to extreme heat or cold reduces battery longevity. Exposure to fire or temperatures above 170°F could cause serious damage and explosion.
- Do not disassemble, there are no serviceable parts inside. Do not drop. Do not use product if damaged or modified or if you see any bulging, swelling, leakage or other abnormality.
- Never insert objects other than the specified cables into the product. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not modify or try to use it for a non-intended purpose. Overload outputs above rating may result in a risk of fire or injury.
- Do not place anywhere where the product would become crushed or punctured.
- Charge using the correct wall adapter and make sure that the adapter is inserted all the way into the electrical outlet. Disconnect the speaker once the product is fully charged.
- This product is not a toy. Keep out of reach of children or those that require supervision.
- Do not use abrasive cleaning solvents to clean the unit.
- Store in a cool, dry location in the original package.

Note: Lithium-ion batteries will self-discharge over time, and it is normal for battery performance to decline after several years of usage. To ensure battery life, do not store the product in an uncharged state for a length of time. If left in a discharged state for too long a lithium-ion battery will no longer have the ability to be recharged.

INTRODUCTION

Thank you for choosing Monster's Bluetooth Party Speaker with LED Lighting. Features powerful room-filling sound, vibrant color-changing lights, and multiple ways to play. Bring the energy wherever you go, from pumping playlists to late-night karaoke sessions; it is built to keep the music loud, clear, and nonstop. Stream wirelessly via Bluetooth®, plug in a mic, or connect your guitar and take center stage—an all-in-one party system. True Wireless Stereo (TWS) technology allows you to pair two speakers together for a bigger sound and a fully immersive experience with synchronized audio and lighting that takes the vibe to the next level!

SPECIFICATIONS

- Bluetooth version: 5.3
- Bluetooth Range: Up to 30ft
- FM Frequency Range: 88.1-108.0
- TWS Technology
- Speaker Wattage: 60W (Peak: 200W)
- Dual 8" Woofers
- 1.5" Tweeter
- Input Voltage: DC 5V/1.5A
- Media Files Supported: MP3
- Battery: 5,400mAh Lithium-ion
- Available Input Ports:
  - USB-A Media (64GB Max. not included)
  - MicroSD Card (64GB Max. not included)
  - 2 Microphone Ports (microphones not included)
  - Guitar Port (guitar and cord not included)
  - 3.5mm Auxiliary Line-in (cable not included)

WHAT'S INCLUDED

- Bluetooth Party Speaker with LED Lighting
- USB-A to USB-C Charging Cable
- DC 5V2A USB-A Power Adapter
- User Manual

AT A GLANCE

1. USB-A Flash Drive Port
2. MicroSD Card Port
3. Aux Port
4. Microphone Ports
5. Guitar Port
6. BT and Battery LED Indicator
7. USB-C Charging Port
8. Power Switch
9. Treble Dial
10. Bass Dial
11. Microphone Echo Dial
12. Guitar Volume Dial
13. Microphone Volume Dial
14. Speaker Volume Dial
15. Mode Button
16. EQ Button
17. LED Light Button
18. Vocal Mute Button
19. TWS Button
20. Rewind Button
21. Play/Pause Button
22. Forward Button

KEY FUNCTIONS GUIDE

Power Switch: Press the Power switch to power on or off. Once turned on, the LED display will show "HI" followed by "BATT" (Battery), and the numerical battery level up to 100 (fully charged).

Mode (M): Individual single-presses switches modes between Microsd, USB Flash Drive, Bluetooth, FM, and AUX function. The LED display will show "TF" for MicroSD (TF) card, a "U" will show for USB Flash Drive, followed by your track's number, "BT" will show for Bluetooth, "Lod" followed by station number will show for FM radio, and "Line" will show for Auxiliary/Line-in cord input.

TWS ( ): Requires 2 speakers of the same model. Power on both speakers. Ensure both are in Bluetooth mode. Single-press TWS button on either speaker. Once activated, the LED display will show "ON," and a prompting tone will sound. Shortly after, a second prompting tone will sound to indicate successful connection.

Single-press TWS button on either speaker once more. The LED display will show "OFF" and a prompting tone will sound, indicating TWS technology is deactivated.

Volume Dial Knob: Turn to decrease or increase volume of speaker. Once adjusted, the LED display will show the volume of the speaker as "VO-00." Volume ranges from (00) to (30).

MIC Vol Dial Knob: Turn to increase or decrease microphone volume. Once adjusted, the LED display will show "VO-00." Microphone volume ranges from (00) to (30).

Vocal Mute: Single-press for a suppressed or an unsuppressed vocals effect of songs during karaoke sing-alongs. Once activated/deactivated, the LED display will show "ON" or "OFF."

Note: Effectiveness of this mode varies depending on the production mixing of the audio playing.

M. Echo Dial Knob: Turn to increase or decrease the microphones' echo effect. Once adjusted, the LED display will show "EE-00." Echo ranges from (00) to (16).

Bass Dial Knob: Turn to increase or decrease bass. Once adjusted, the LED display will show "B – 0." Bass ranges from (–6) to (6).

Treble Dial Knob: Turn to increase or decrease treble. Once adjusted, the LED display will show "T – 0." Treble ranges from (–6) to (6).

Equalizer (EQ): Individual single-presses cycles through preset EQ modes: Wall, Rock, Jazz, Classic, and Normal. Abbreviations of the EQ modes will show on the LED display as you cycle through.

GT. VOL Dial Knob: Turn to increase or decrease guitar volume.

LED Light ( ): Individual single-presses cycles through various lighting modes. The LED display will show the numerical lighting spaces as "L-1." Lighting options range from (1) to (8), and "OFF" will show on the LED display, if the lighting option is turned off.

In Bluetooth Mode

Play/Pause Button ▶||
- Long-press to disconnect/reconnect.
- Single-press to play/pause audio.

Back Button |◀◀
- Single-press to go back to previous track.

Forward Button ▶▶|
- Single-press to skip to next track.

In USB Flash Drive Mode:

Play/Pause Button ▶||
- Single-press to play/pause audio.

Back Button |◀◀
- Single-press to go back a track.
- Press and hold to rewind within a track.

Forward Button ▶▶|
- Single-press to skip to next track.
- Press and hold to fast-forward within a track.

In FM Mode

Play/Pause Button ▶||
- Single-press to mute/unmute station.
- Press and hold to enter/exit fast station search.

Back Button |◀◀
- Single-press to go back a station.
- Press and hold to fast search stations manually.

Forward Button ▶▶|
- Single-press to skip to next station.
- Press and hold to fast search stations manually.

Note: When pressing the Play/Pause button to pause FM station audio or BT audio, "PAUS" will show on the LED display.

CHARGE YOUR DEVICE

- Before operating your speaker, always ensure it is fully charged for optimal performance.
- Utilize the included USB-A to USB-C charging cable and power adapter to charge the speaker.
- Plug the power adapter into a standard wall outlet.
  Note: The speaker cannot be used while charging.
- When operating the speaker and the battery becomes low, there will be a prompting sound.
- Charging and pairing status will be indicated by the LED indicator, see chart below.
- Remaining battery level is shown on the LED display at power on. To check the level you can switch the speaker off and back on once more.

OPERATION

- The speaker comes with rolling wheels for ease of movement and placement. Ensure that the speaker is placed on stable ground while in use or charging.
- Power on/off your speaker by pressing the Power switch.
- Once your speaker powers on, the LED display will show "BATT" followed by the numerical battery level and will automatically go into Bluetooth pairing mode.
- Pairing mode will be indicated by a blinking "BT" on the LED display and a blinking blue light under the Bluetooth icon on the keys interface.
- Once the speaker is paired to your smartphone or Bluetooth-enabled device, "BT" will stop blinking on the LED display and the blue light under the Bluetooth icon will be solid.

LED INDICATOR BEHAVIOR

Blue Flashing	Bluetooth pairing mode
Solid Blue	Bluetooth paired
Red Solid	Charging
Off (while plugged in)	Charging complete, disconnect from power

CONNECT YOUR DEVICE

For the best audio quality, adjust the volume of your smartphone to below 50% before connecting to your speaker. Once connected, adjust the volume of your speaker to your desired level or gradually increase the volume of your smartphone.

Note: Depending on your smartphone's manufacture, you may need to adjust the volume using your smartphone to reach desired audio levels.

PAIRING WITH BLUETOOTH

1. Make sure your speaker is fully charged, and your smartphone's Bluetooth is enabled, Turn on the speaker by pressing the Power switch.
2. Once you turn on the speaker, it will automatically go into pairing mode and will be ready to pair to your smartphone, or any Bluetooth-enabled device.
3. Open the Bluetooth settings on your smartphone and select "Monster MBL1-1004" from the list of available new devices.
4. The speaker will automatically connect to your smartphone via Bluetooth, and the blinking blue light indicator will become steady. If you are unable to connect the speaker to your smartphone, try the following:
   - Ensure the speaker and your smartphone are turned on, and both are fully charged.
   - Make sure your smartphone's Bluetooth setting is switched on.
   - Restart your smartphone.
5. To disconnect, reconnect, or revert the speaker back to pairing mode press and hold the Play/Pause (▶||) button.

TWS PAIRING

To link the speaker with a second speaker (sold separately) for a True Wireless Stereo experience, both speakers must be of the same model.

- Power on both speakers.
- Single-press the TWS ( ) button on either speaker, The LED display will show "ON" and there will be a prompting sound indicating the speaker entered the TWS search.
- Once both speakers connect, you will hear a second prompting sound indicating a successful connection.
- To disconnect TWS, single-press the TWS ( ) button on either speaker once more. The LED display will show "OFF" and there will be a prompting sound indicating the TWS connection between both speakers is disconnected.

Note: Only one of the two speakers can be paired with a Bluetooth-enabled device. If both speakers are already paired to separate Bluetooth-enabled devices, the TWS pairing will fail, Ensure the second speaker is not paired to a Bluetooth-enabled device by long-pressing the Play/Pause ( ) button.

ACCESSING FM RADIO

To Access FM Radio, locate the Mode (M) button. Individual single-presses of the Mode (M) button cycles through media options until you reach the FM mode.

- Press and hold the Play/Pause ( ) to enter automatic fast station (88.1–108.0) search.
- Press and hold the Play/Pause ( ) once more to stay on one station.
- Single-press the Play/Pause ( ) button to mute/unmute channels.
- Single-press the Forward or Back button ( ) to cycle the channels manually.
- Press and hold the Forward ( ) or Back button ( ) to fast search channels manually.

To go back to Bluetooth or any other modes, single-press the Mode (M) button.

MEDIA OPTIONS AND AVAILABLE PORTS

You can listen to music, perform, and karaoke through your speaker using the following methods:

- **Bluetooth**: Connect your smartphone or Bluetooth-enabled device wirelessly to the speaker.
- **USB Flash Drive or MicroSD Card**: Insert a USB flash drive or MicroSD card (64GB max. sold separately) loaded with media into the speaker.
- Use an **AUX cable** (sold separately) to connect the speaker to an external AUX input for direct playback without the need for Bluetooth connectivity.

Note: When the AUX cable is inserted, it will override Bluetooth connectivity. Single-press the Mode button to cycle back to Bluetooth connectivity if needed.

- Plug your guitar cord into the GT port and start playing, turn the GT. Vol dial to increase or decrease the guitar's volume.
- For karaoke parties, plug up to two microphones into the MC 1, and MC 2 ports.

Note: The speaker also supports connecting 2 additional wireless U-segment microphones (sold separately). Refer to the U-segment microphones manufacturer's user manual for usage, maintenance, troubleshooting or any other directions.

CARE AND MAINTENANCE

- Recommended to at least fully charge once every 30 days to avoid battery idleness.
- Store in a cool, dry location in the original package.

TROUBLESHOOTING

Q1: My speaker is not connecting to my Bluetooth device.

A1: Ensure the speaker is fully charged before use.

A2: Ensure Bluetooth is enabled on your device, and the speaker is in pairing mode for a successful pairing.

A3: Ensure your Bluetooth-enabled device is within range of the speaker at the time of pairing for a successful operation.

Q2: My speaker is not synchronizing with my second speaker for TWS.

A1: Ensure that the second speaker is of the same model.

A2: Ensure the speakers are in close-proximity and connected to a Bluetooth device for audio.

A3: Refer to "TWS Pairing" and follow the pairing steps once more, allow up to 60 seconds for completing the syncing process.

Q3: How can I get to FM Radio?

A: Single-press the (M) Mode button on the speaker's interface to shuffle through audio modes until you reach FM radio function.

FCC STATEMENT

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct interference by one or more of the following measures: • Reorient or relocate the receiving antenna • Increase the separation between the equipment and receiver • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected • Consult the dealer or an experienced radio/ TV technician for help.

FCC RADIATION EXPOSURE STATEMENT This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC RADIATION EXPOSURE STATEMENT This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

MONSTER

The illustrated products and specifications may differ slightly from those supplied.
The M Monster logo and M Slice logo are trademarks or registered trademarks of Monster, Inc. or affiliated entities. The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Jem Accessories is under license. All other brand names are trademarks of their respective owners, Neither Jem Accessories, Inc. nor Monster, Inc. is affiliated with the respective owners of their trademarks, Licensed and Manufactured by Jem Accessories, Inc. Edison, NJ 08817.

WARRANTY

Jem Accessories, Inc. Limited Warranty Policy for Monster Products Last Updated: March 27, 2020

This limited warranty contains important information about your rights and obligations, as well as limitations and exclusions that may apply to you.

1. WHAT THIS LIMITED WARRANTY COVERS; PERIOD OF COVERAGE. Jem Accessories, Inc. ("Jem Accessories"), 32 Brunswick Ave, Edison, New Jersey, USA, warrants to the owner of the enclosed Monster branded product contained in this box ("Product") will be free from defects in materials and workmanship for a period of one year. Notwithstanding the foregoing, the Warranty Period for a factory refurbished Product is one (1) year, even if installed by a professional. If the Product fails to conform to this Limited Warranty during the Warranty Period, Jem Accessories will, at its sole discretion, either (a) repair or replace any defective Product or component; with proof of purchase using original documentation. Repair or replacement may be made with a new or refurbished product or components, at Jem Accessories's sole discretion. If the Product or a component repaired within it is no longer available, Jem Accessories may, at Jem Accessories's sole discretion, replace the Product with a similar product of similar function. This is your sole and exclusive remedy for breach of this Limited Warranty. Any Product that has either been repaired or replaced under this Limited Warranty will be covered by the terms of this Limited Warranty for the longer of (a) ninety (90) days from the date of delivery of the repaired Product or replacement Product, or (b) the remaining Warranty Period. This Limited Warranty is not transferable from the original purchaser to subsequent owners.

2. TOTAL SATISFACTION RETURN POLICY If you are the original purchaser of the Product and you are not satisfied with this Product for any reason, you may return it in its original condition to the retailer in compliance with the retailer's return policy.

3. WARRANTY CONDITIONS; HOW TO GET SERVICE IF YOU WANT TO CLAIM UNDER THIS LIMITED WARRANTY Before making a claim under this Limited Warranty, the owner of the Product must (a) visit monsterlifeinnovence.com/support during the Warranty Period to provide notice of your warranty claim and describe the alleged failure, and (b) comply with Jem Accessories (or its authorized distributor's) return shipping instructions. Jem Accessories will have no warranty obligations with respect to a returned Product if it determines, at its reasonable discretion after examination of the returned Product, that the Product is an Ineligible Product (defined below).

4. WHAT THIS LIMITED WARRANTY DOES NOT COVER This Limited Warranty does not cover the following (collectively "Ineligible Products"): (i) Products marked as "sample" or "Not for Sale", or sold "AS IS"; (ii) Products that have been subject to: (a) modifications, alterations, tampering, or improper maintenance or repairs; (b) handling, storage, installation, testing, or use not in accordance with any quick start guide, manual or other instructions provided by Jem Accessories; (c) abuse or misuse of the Product; (d) breakdowns, fluctuations, or interruptions in electric power or the telecommunications network; or (e) Acts of God, including but not limited to lightning, flood, tornado, earthquake, or hurricane; or (iii) any non-Jem Accessories branded hardware products, even if packaged or sold with Jem Accessories hardware. This Limited Warranty does not cover consumable parts, including batteries, unless damage is due to defects in materials or workmanship of the Product, or software (even if packaged or sold with the product). Jem Accessories recommends that you use only authorized service providers for maintenance or repair. Unauthorized use of the Product or software can impair the Product's performance and may invalidate this Limited Warranty.

5. DISCLAIMER OF WARRANTIES Except as stated above in this Limited Warranty, and to the maximum extent permitted by applicable law, Jem Accessories disclaims all express, implied, and statutory warranties and conditions with respect to the product, including the implied warranties of merchantability and fitness for a particular purpose. To the maximum extent permitted by applicable law, Jem Accessories also limits the duration of any applicable implied warranties or conditions to the duration of this limited warranty.

6. LIMITATION OF DAMAGES In addition to the above warranty disclaimers, in no event will Jem Accessories be liable for any consequential, incidental, exemplary, or special damages, including any damages for lost data or lost profits, arising from or relating to this limited warranty or the product, and Jem Accessories's total cumulative liability arising from or related to this limited warranty or the product will not exceed the amount actually paid for the product by the original purchaser.

7. LIMITATION OF LIABILITY The Jem Accessories online services at monsterlifeinnovence.com ("services") provide you information ("product information") regarding your Jem Accessories products or other peripherals connected to your products ("product peripherals"). The type of product peripherals that may be connected to your product may change from time to time. Without limiting the generality of the disclaimers above, all product information is provided for your convenience, "as is", and "as available". Jem Accessories does not represent, warrant, or guarantee that product information will be available, accurate, or reliable or that product information or use of the services or product will provide safety in your home. You use all product information, the services, and the product at your own discretion and risk. You will be solely responsible for (and Jem Accessories disclaims) any and all loss, liability, or damages, including to your wiring, fixtures, electricity, home, product, product peripherals, computer, mobile device, and all other items and parts in your home, resulting from your use of the product information, services, or product. Product information provided by the services is not intended as a substitute for direct means of obtaining the information. For example, a notification provided through the service is not intended as a substitute for audible and visible indications in the home and on the product, nor for a third party monitoring service that monitors alarm state.

8. YOUR RIGHTS AND THIS LIMITED WARRANTY This Limited Warranty gives you specific legal rights. You may also have other legal rights that vary by state, province, or jurisdiction. Likewise, some of the limitations in this Limited Warranty may not apply in certain states, provinces or jurisdictions. The terms of this Limited Warranty will apply to the extent permitted by applicable law. For a full description of your legal rights you should refer to the laws applicable in your jurisdiction and you may wish to contact a relevant consumer advisory service. If you need to start a warranty claim for your Monster Smart device, please reach out to Customer Support by emailing customerservice@monsterlifeinnovence.com or calling our support number 866-246-2008. Please allow 7-10 business days to process warranty claims. Customers located outside of U.S. will be responsible for all shipping costs.

2ND YEAR EXTENDED WARRANTY

Register your Monster product to extend your warranty as listed above for one additional year. Scan the QR code on the cover of this manual to register your product, or visit https://monsterlifeinnovence.com/limited-warranty/