01 基本参数 BASIC PARAMETERS

基本信息

电　　压：4.2V

连接方式：USB/2.4G/蓝牙

背　　光：RGB

按键类型：薄膜键盘

电　　流：≤275mA

U S B 线：1.5M

灯光效果：14种灯效模式

键盘尺寸：45.1*14.7*4.3CM

兼容性

按键兼容：支持26键无冲

系统兼容：支持 Win2000/WinXP/WinME/Vista/Win7/Win8/Win10/MAC 等系统

系统切换

FN + A 切换为WIN系统 | FN + S 切换为MAC系统

02 模式切换 MODE SWITCHING

蓝牙模式：

Fn+1：短按进入蓝牙BT1通道，长按两秒进入BT1的配对模式

Fn+2：短按进入蓝牙BT2通道，长按两秒进入BT2的配对模式

Fn+3：短按进入蓝牙BT3通道，长按两秒进入BT3的配对模式

2.4G模式：

Fn+4：短按进入2.4G模式，长按两秒进入2.4G配对模式

03 快捷键介绍 SHORTCUT KEY INTRODUCTION

快捷键	WIN	快捷键	MAC
FN+F1	屏幕亮度-	F1	屏幕亮度-
FN+F2	屏幕亮度+	F2	屏幕亮度+
FN+F3	转换窗口	F3	多任务控制窗
FN+F4	麦克风	F4	启动台
FN+F5	多媒体	F5	呼出siri
FN+F6	上一曲	F6	剪屏
FN+F7	下一曲	F7	前一首歌曲/倒退
FN+F8	播放/暂停	F8	播放/暂停
FN+F9	停止	F9	后一首歌曲/快进
FN+F10	静音	F10	静音
FN+F11	音量-	F11	音量-
FN+F12	音量+	F12	音量+
FN+ BackSpace	开/关背光		
FN+ ESC	长按3S恢复背光出厂设置		
FN+ Insert	切换灯光效果		
FN+ PGUP	背光亮度 +		
FN+ PGDN	背光亮度 -		
FN+ -_	背光速度 -		
FN+ +=	背光速度 +		
FN+ W	A/S/W/D键和方向键功能互换		
FN+ WIN	Win功能锁定/解锁		

FURYCUBE
REVOLUTION & INNOVATION

JS108 PRO

Membrane Keyboard

Membrane Keyboard Manual

01 BASIC PARAMETERS BASIC PARAMETERS

Basic Information

Voltage：4.2V

Connection：USB/2.4G/Bluetooth

Backlight：RGB

Keyboard Type：Membrane

Current：≤275mA

USB Cable：1.5M

Lighting Effects：14 lighting modes

Dimensions (L x W x H)：45.1 × 14.7 × 4.3 cm

Compatibility

Key Rollover: 26-Key Rollover (26KRO)

Windows: Win2000 / WinXP / Vista / Win7 / Win8 / Win10 / Win11

Mac: Supported

Other Systems: Supported

System Switching

FN + A Windows System | FN + S Mac System

02 MODE SWITCHING MODE SWITCHING

Bluetooth mode:

Fn+1 Press once: Switch to Bluetooth 1 ; Press and hold: Enter Bluetooth 1 pairing mode

Fn+2 Press once: Switch to Bluetooth 2 ; Press and hold: Enter Bluetooth 2 pairing mode

Fn+3 Press once: Switch to Bluetooth 3 ; Press and hold: Enter Bluetooth 3 pairing mode

2.4G Wireless mode:

Fn+4 Press once: Switch to 2.4G mode ; Press and hold: Enter 2.4G pairing mode

03 SHORTCUT KEY INTRODUCTION SHORTCUT KEY

Shortcut Key	WIN	Shortcut Key	MAC
FN+F1	Screen Brightness -	F1	Screen Brightness -
FN+F2	Screen Brightness +	F2	Screen Brightness +
FN+F3	Switch Windows	F3	Mission Control
FN+F4	Microphone	F4	Launchpad
FN+F5	Multimedia	F5	Launch Siri
FN+F6	Previous Track	F6	Screenshot
FN+F7	Next Track	F7	Previous Track / Rewind
FN+F8	Play/Pause	F8	Play/Pause
FN+F9	Stop	F9	Next Track / Fast Forward
FN+F10	Mute	F10	Mute
FN+F11	Volume -	F11	Volume -
FN+F12	Volume +	F12	Volume +
FN+ BackSpace	Backlight On / Off		
FN+ ESC	Restore Default Backlight Settings (Hold 3 sec)		
FN+ Insert	Change Lighting Effect		
FN+ PGUP	Backlight Brightness +		
FN+ PGDN	Backlight Brightness -		
FN+ -_	Backlight Speed -		
FN+ +=	Backlight Speed +		
FN+ W	Swap WASD and Arrow Key Functions		
FN+ WIN	Lock/Unlock Win		

Are there any problems with our products?

Please contact us and we will reply as soon as possible to ensure that all your needs can be solved

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.