



ATTENTION: Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.

**2007–1999 Sierra/Silverado/Escalade, 2007–1997 Suburban/Yukon/
Tahoe, 2007–05 Yukon Denali, 2007–04 Colorado/Canyon,
2007–02 Avalanche/Sierra Denali, 2007–01 Yukon XL,
2000–1997 K2500/K3500, 1999–97 K1500**

The following information is to help in the installation of your Dorman 4X4 component. You will need the following parts:

Chemicals: Permatex #14 with PTFE (or equivalent)

Tools: Pick or small wire brush

STEP 1: Using a pick or small wire brush, remove the old thread sealant from the axle tube. Failure to do so may cause thread damage to your new part.

Step 2: Apply a minimal amount of Permatex #14 with PTFE (or equivalent) to the threads of 600-101.

Disclaimer:

Even though every attempt is made to ensure this information is complete and accurate, it is impossible to account for all possible circumstances or situations. Please consult with a qualified auto technician before attempting to perform any work you are not qualified to do. Automobiles can be hazardous to work on; be sure to take all necessary safety precautions. Failure to do so may result in property damage or personal injury. Certain motor vehicle standards and performance requirements may apply to your motor vehicle (such as Federal Motor Vehicle Safety Standards by the National Highway Traffic Safety Administration). Be sure that your work is performed in accordance with such standards and that you do not disable any motor vehicle safety feature.