



# Water Pump Kit

## Assembly Instructions

**Model:**  
CKPUMPKIT



### Compatible with:

#### Handwash Station

PWS25MN  
PWS25WH

#### Kitchenette

C48ELPUMP  
C48ELGLASSPUMP

**BEFORE USE, PLEASE READ AND FOLLOW ALL SAFETY RULES AND OPERATING INSTRUCTIONS**

<b>Model:</b>	<b>Serial Number:</b>
---------------	-----------------------








**Felix Storch, Inc.**  
An ISO 9001:2015 registered company  
770 Garrison Avenue  
Bronx, NY 10474  
[www.summitappliance.com](http://www.summitappliance.com)









## **Table of Contet**

List of Pump Kit Components	<b>2 - 3</b>
Installing the Pump Kit to the Handwash Station	<b>4</b>
Installing the Pump Kit to the Kitchenette	<b>5</b>
Final Assembly	<b>6</b>

## List of Pump Kit Components

Component	Image	Quantity
Bottled Water Dispenser Pump System, 20ft 110V AC US Plug Water Dispensing Pump		1
5 Gallon Freshwater Container		1
6 Gallon Waste Container		1
3/8 in. Brass Water Cut-off Valve		1
1/4" Acetal Copolymer Compression Sleeve		1
20 in. Length Braided Stainless Steel Faucet Connector		2
1-1/2-in Flexible Plastic Drainage Pipe		1

<p>1/2 in. x 520 in. White Teflon Tape</p>		<p><b>1</b></p>
<p>Mounting Template (18x12) For models: C48ELPUMP &amp; C48ELGLASSPUMP</p>		<p><b>1</b></p>
<p>10-32 x 1 1/4" Phillips Head Truss Screw Stainless Steel</p>		<p><b>4</b></p>
<p>10-32 Nylon Lock Nut Stainless Steel</p>		<p><b>4</b></p>
<p>10 x 5/8" Fender Washer Stainless Steel</p>		<p><b>4</b></p>
<p>Sink Basket Strainer</p>		<p><b>1</b></p>

To order replacement parts, visit our website: [summitapplianceparts.com](http://summitapplianceparts.com)



## Installing the Pump Kit to the Handwash Station

Applicable for Models: PWS25MN & PWS25WH

**Important:** It is recommended that the pump kit be installed by a qualified professional or licensed plumber experienced in plumbing installations.

- 1) Open the handwash station cabinet.
- 2) To install the faucet, set the gasket on top of the pre-drilled holes of the sink.
- 3) Insert the water faucet through the gasket and secure the faucet to the pump line with the provided nuts on the underside of the sink.
- 4) Secure the pump to the interior wall of the cabinet, using the four provided screws, washers, and nuts. Be sure the screw heads are on the outside of the cabinet. Ensure nothing sits directly on the floor, keeping any cords or wires dry.
- 5) To connect the pump to the valve, place the valve nut over the water line.
- 6) The plastic sleeve has a wider and narrower side. Place the plastic sleeve onto the water line through the wider side.
- 7) Insert the metal flange into the end of the water line as far as it will go.
- 8) Wrap the threading of the valve, then secure the water line to the cut off valve. Tighten the nut as much as you can.
- 9) Now that the water intake line is attached, wrap the other two threads of the cut-off valve in Teflon tape, then connect the small ends of the two faucet connector lines to the cut off valve.
- 10) Wrap the threads of the faucet underneath the sink, then attach the wider ends of the connector lines to the faucet.
- 11) Set the freshwater jug in the rear right-hand corner. Uncap the freshwater jug and insert the water pull into the freshwater jug. Be careful, as some water may overflow when the device is first inserted.
- 12) Apply plumber's putty (not supplied) to top flange of strainer basket. Insert strainer basket into sink drain. Place rubber gasket and tighten with nut. Attach the drainage pipe to the underside of the sink drain, then set the end into the waste water jug.
- 13) Open the water cut-off valve.

**NOTE:** If mounting the pump is not possible for your set-up, the pump can be placed on the floor of the cabinet. It is recommended to place it, so the **ON/OFF switch is accessible.**

**NOTE:** The pump has two tubes, a thinner tube which runs to the metal water cut-off valve and a thicker water pull tube, which pulls water from the freshwater jug.

**Tip:** Place pump on rubber feet to reduce noise.

## Installing the Pump Kit to the Kitchenette

Applicable for Models: C48ELPUMP & C48ELGLASSPUMP

**Important:** It is recommended that the pump kit be installed by a qualified professional or licensed plumber experienced in plumbing installations.

- 1) Open the cabinet of your combo kitchen. Move the wire shelf to the floor of the cabinet. This is to ensure nothing sits directly on the floor, keeping any cords or wires dry.
- 2) To install the faucet, set the gasket on top of the pre-drilled holes of the combo kitchen.
- 3) Insert the water faucet through the gasket and secure the faucet with the provided nuts on the underside of the sink.
- 4) The pump will be secured to the inner wall of the combo kitchen, using four machine screws and nuts.
- 5) Place the provided template on the left side of the combo kitchen, in the top-right corner. It should align to the front edge and along the bottom edge of the stainless-steel top.
- 6) Using a 1/4" drill bit, drill the four template holes.
- 7) Secure the pump to the interior wall of the cabinet, using the four provided screws, washers, and nuts. Be sure the screw heads are on the outside of the cabinet.
- 8) The pump has two tubes, a thinner tube which runs to the metal water cut-off valve and a thicker water pull tube, which pulls water from your freshwater jug.
- 9) To connect the pump to the valve, place the valve nut over the water line.
- 10) The plastic sleeve has a wider and narrower side. Place the plastic sleeve onto the water line through the wider side.
- 11) Insert the metal flange into the end of the water line as far as it will go.
- 12) Wrap the threading of the valve, then secure the water line to the cut off valve. Tighten the nut as much as you can.
- 13) Now that the water intake line is attached, wrap the other two threads of the cut-off valve in Teflon tape, then connect the small ends of the two faucet connector lines to the cut off valve.
- 14) Wrap the threads of the faucet underneath the sink, then attach the wider ends of the connector lines to the faucet.
- 15) Set the freshwater jug in the rear right-hand corner. Uncap the freshwater jug and insert the water pull into the freshwater jug. Be careful, as some water may overflow when the device is first inserted.
- 16) Attach the drainage pipe to the underside of the sink drain, then set the end into the wastewater jug.
- 17) Open the water cut-off valve.

**NOTE:** If mounting the pump is not possible for your set-up, the pump can be placed on the floor of the cabinet. It is recommended to place it, so the **ON/OFF switch is accessible.**

**Tip:** Place pump on rubber feet to reduce noise.

## Final Assembly



If you need further assistance, contact Summit Tech. Support, or visit [www.summitappliance.com/handwash-station](http://www.summitappliance.com/handwash-station) to see a video of the installation.



**Felix Storch, Inc.**  
An ISO 9001:2015 registered company  
770 Garrison Avenue  
Bronx, NY 10474  
[www.summitappliance.com](http://www.summitappliance.com)