



SNOW PLOW CUSTOM MOUNT KIT GUIDE

FULL MOUNT KIT GUIDE | V.250829

MAKE	MODEL	2WD	4WD	YEAR	KIT NUMBER	FITS	DOES NOT FIT	OTHER NOTES	
FORD	Ranger	X	X	83-92	81100				SCB
FORD	Ranger	X	X	93-97	81110				SCB
FORD	Ranger	X	X	98-10	81122	EDGE		MAY HAVE TO REMOVE BUMPER SKIRT	SCB
FORD	Ranger	X	X	11-17	81123				SCB
FORD	Ranger - Bronco		X	18-24	81128*				ECB
FORD	Bronco II	X	X	83-90	81100				SCB
FORD	Explorer		X	91-94	81110				SCB
FORD	Explorer		X	95-96	81115				SCB
FORD	Explorer		X	97-01	81122			MAY HAVE TO REMOVE BUMPER SKIRT	SCB
FORD	Explorer		X	02-06	81125	4DR	2DR SPORT TRAC		SCB
FORD	Explorer 2dr Sport		X	01-03	81122		4DR	MAY HAVE TO REMOVE BUMPER SKIRT	SCB
FORD	Explorer 4dr Sport	X	X	01-06	81122			MAY HAVE TO REMOVE BUMPER SKIRT	SCB
FORD	Explorer 4dr Sport	X	X	07-10	81127				SCB
FORD	Mountaineer		X	97-01	81122			MAY HAVE TO REMOVE BUMPER SKIRT	SCB
FORD	Mountaineer		X	02	81125				SCB
FORD	Escape		X	02-05	81135			ATTACHES TO TOW HOOK MOUNT PLATES	CFW
FORD	Escape		X	06-12	81235				CFW
FORD	Van	X		86-97	81305				CMK
FORD	Aviator		X	03-05	81125				SCB
FORD	F150 - F250	X	X	72-79	81501	F100 / F150 RANGER/F250	SUPERCAB F250 HD (HD 81516)		SCB
FORD	F150	X	X	80-91	81503	EXPLORER			SCB
FORD	F150	X	X	92-96	81510				SCB
FORD	F150	X		97-04	81511	4DR CREW CAB / HERITAGE	LIGHTNING / HARLEY DAVIDSON	DS RAIL LARGER THAN PS	SCB
FORD	F150		X	97-04	81512	4DR CREW CAB / HERITAGE	STX / NEW BODY STYLE		SCB
FORD	F150	X	X	04-14	81521	NEW BODY STYLE	HERITAGE	MAY HAVE TO REMOVE SECOND AIR DAM	SCB
FORD	F150	X	X	15 - 25	81522			NEED TO REMOVE AUTO AIRDAM AND TRIM PLASTIC FLAP	SCB
FORD	Lincoln Mark LT	X	X	06	81521				SCB
FORD	F250		X	97-99	81512	NEW BODY STYLE	STANDARD OR SUPER DUTY		SCB

IMPORTANT: SNOWBEAR® BY MARLON® CUSTOM MOUNT KITS ARE SUBJECT TO CHANGE IN ORDER TO ACCOMMODATE NEWER MAKES AND MODELS OF VEHICLES. SNOWBEAR® BY MARLON® MOUNT KITS ARE COMPATIBLE WITH DK2® BY MARLON® SNOWPLOWS. IF YOU HAVE ANY QUESTIONS, PLEASE CALL US TOLL-FREE AT 1-888-277-6960





SNOW PLOW CUSTOM MOUNT KIT GUIDE

FULL MOUNT KIT GUIDE | V.250829

MAKE	MODEL	2WD	4WD	YEAR	KIT NUMBER	FITS	DOES NOT FIT	OTHER NOTES	
FORD	F250 HD SD		X	80-91	81516				CMK
FORD	F250 HD SD		X	92-98	81517				CMK
FORD	F250 HD SD		X	99-03	81518	ALSO FITS F350	**DOES NOT FIT WITH LEAF SPRINGS		SCB
FORD	F250 HD SD	X	X	04-07	81519*	LEAF SPRINGS		REQUIRES EXTENDED CROSS BAR	ECB
FORD	F250-F350	X	X	08-25	81520			NEED TO REMOVE LOWER PLASTIC AIR DAM	SCB
FORD	F250 - F350	X	X	11-18	81530	MODIFIED - LIFTED TRUCKS			SCB
FORD	Bronco	X	X	78-79	81501	XLT / CUSTOM			SCB
FORD	Bronco	X	X	80-91	81503	EDDIE BAUER			SCB
FORD	Bronco	X	X	92-96	81510	NITE			SCB
FORD	Expedition / Navigator	X		97-02	81511			DS RAIL LARGER THAN PS	SCB
FORD	Expedition / Navigator		X	97-02	81512				SCB
FORD	Expedition / Navigator	X	X	03-14	81521				SCB
FORD	Expedition / Navigator	X	X	15 - 25	81522*				ECB
FORD	Excursion		X	00-04	81518				SCB
MAZDA	B-Series		X	86-93	87610				CFW
MAZDA	B-Series	X	X	94-97	81110				SCB
MAZDA	B-Series	X	X	98-10	81122			MAY HAVE TO REMOVE LOWER SKIRT BRACKET	SCB
MAZDA	Navajo		X	91-94	81110				SCB
MAZDA	Tribute		X	02-05	81135			ATTACHES TO TOW HOOK MOUNT PLATES	CFW
MAZDA	Tribute		X	06-12	81235				CFW
GM	S-10 / S-15 / Sonoma / S-Jimmy / S-Blazer	X		82-04	82602				SCB
GM	S-10 / S-15 / Sonoma / S-Jimmy / S-Blazer		X	82-04	82610	2001 TRAILBLAZER	2002 TRAILBLAZER		SCB
GM	Colorado / Canyon	X	X	04-06	82612		EXTREME		SCB
GM	Colorado / Canyon Off Road		X	07-14	82625			CRASH BAR MAY INTERFERRE ON 82615	SCB
GM	Colorado / Canyon Off Road		X	14-22	82630	lifted vehicle	stock height vehicle	MAY NEED TO REMOVE OR MODIFY BUMPER SKIRT	SCB

IMPORTANT: SNOWBEAR® BY MARLON® CUSTOM MOUNT KITS ARE SUBJECT TO CHANGE IN ORDER TO ACCOMMODATE NEWER MAKES AND MODELS OF VEHICLES. SNOWBEAR® BY MARLON® MOUNT KITS ARE COMPATIBLE WITH DK2® BY MARLON® SNOWPLOWS. IF YOU HAVE ANY QUESTIONS, PLEASE CALL US TOLL-FREE AT 1-888-277-6960



SNOW PLOW CUSTOM MOUNT KIT GUIDE

FULL MOUNT KIT GUIDE | V.250829

MAKE	MODEL	2WD	4WD	YEAR	KIT NUMBER	FITS	DOES NOT FIT	OTHER NOTES	
GM	Colorado / Canyon Off Road		X	14-22	82631	STOCK HEIGHT VEHICLE		MAY NEED TO REMOVE OR MODIFY BUMPER SKIRT	SCB
GM	Colorado / Canyon Off Road		X	23-25	82635				SCB
GM	Jimmy/Blazer		X	05	82610		TRAILBLAZER		SCB
GM	Trailblazer		X	02-12	82611		BLAZER	MAY HAVE TO REMOVE PLASTIC BUMPER SKIRT	SCB
GM	Envoy		X	98-01	82610				SCB
GM	Envoy		X	02-09	82611			MAY HAVE TO REMOVE PLASTIC BUMPER SKIRT	SCB
GM	Bravada		X	91-01	82610				SCB
GM	Bravada		X	02-04	82611				SCB
GM	H3 HUMMER		X	05-10	82613				SCB
GM	Tracker / Sunrunner / Asuna		X	99-04	88625				CFW
GM	Tracker / Sunrunner / Asuna		X	91-98	88620	4DR	2DR		CCB
GM	Tracker / Sunrunner / Asuna		X	89-98	88611	2DR	4DR		SCB
GM	1500		X	73-80	83001				SCB
GM	1500		X	81-87	83003				SCB
GM	1500	X	X	88-98	83005				SCB
GM	1500	X	X	99-00	83005	CLASSIC BODY STYLE	NEW BODY STYLE		SCB
GM	Silverado / Sierra 1500	X	X	99-00	83007	NEW BODY STYLE	CLASSIC BODY STYLE		SCB
GM	Silverado / Sierra 1500	X	X	01-02	83007	6 BOLT HUB	1500HD / C3 / DENALI / QUAD STEER		SCB
GM	Silverado / Sierra 1500	X	X	03-04	83009				SCB
GM	Silverado / Sierra 1500	X	X	05-07	83013	Z-71		HAVE TO REMOVE PLASTIC BUMPER SKIRT	SCB
GM	Silverado / Sierra 1500	X	X	08-18	83012	NEW STYLE	OLD STYLE	HAVE TO REMOVE PLASTIC BUMPER SKIRT	SCB
GM	Silverado / Sierra 1500	X	X	18-25	83019			HAVE TO REMOVE PLASTIC BUMPER SKIRT	SCB
GM	1500HD	X	X	01-04	83008		1500		SCB
GM	1500HD	X	X	05-06	83011		1500		SCB
GM	2500		X	73-80	83001				SCB
GM	2500		X	81-87	83003				SCB

IMPORTANT: SNOWBEAR® BY MARLON® CUSTOM MOUNT KITS ARE SUBJECT TO CHANGE IN ORDER TO ACCOMMODATE NEWER MAKES AND MODELS OF VEHICLES. SNOWBEAR® BY MARLON® MOUNT KITS ARE COMPATIBLE WITH DK2® BY MARLON® SNOWPLOWS. IF YOU HAVE ANY QUESTIONS, PLEASE CALL US TOLL-FREE AT 1-888-277-6960



SNOW PLOW CUSTOM MOUNT KIT GUIDE

FULL MOUNT KIT GUIDE | V.250829

MAKE	MODEL	2WD	4WD	YEAR	KIT NUMBER	FITS	DOES NOT FIT	OTHER NOTES	
GM	2500	X	X	88-98	83005				SCB
GM	2500	X	X	99-00	83005	CLASSIC BODY STYLE	NEW BODY STYLE		SCB
GM	Silverado / Sierra 2500	X	X	99-00	83008	NEW BODY STYLE	CLASSIC BODY STYLE		SCB
GM	Silverado / Sierra 2500	X	X	01-04	83008	8 BOLT HUB			SCB
GM	Silverado / Sierra 2500	X	X	05-06	83011	8 BOLT HUB			SCB
GM	Silverado / Sierra 2500	X	X	07-12	83014			CONFIRM FLAT OR CURVED FRAME	SCB
GM	Silverado / Sierra 2500 (curved frame)	X	X	12 - 15	83015				SCB
GM	Silverado / Sierra 2500	X	X	15-18	83016*			REQUIRES EXTENDED CROSSBAR	ECB
GM	Silverado / Sierra 2500	X	X	19-25	83017				SCB
GM	2500HD	X	X	01-04	83008	8 BOLT HUB			SCB
GM	2500HD	X	X	05-06	83011	8 BOLT HUB			SCB
GM	Jimmy/Blazer/Suburban		X	73-80	83001				SCB
GM	Jimmy/Blazer/Suburban		X	81-91	83003				SCB
GM	Blazer	X	X	92-94	83005			95 AND NEWER - S BLAZER	SCB
GM	Tahoe	X	X	95-98	83005				SCB
GM	Suburban / Yukon	X	X	92-98	83005				SCB
GM	Suburban / Yukon / Tahoe 1500	X	X	99-00	83005	CLASSIC BODY STYLE	NEW BODY STYLE		SCB
GM	Suburban / Yukon / Tahoe 1500	X	X	99-05	83007	NEW BODY STYLE	CLASSIC BODY STYLE	MAY HAVE TO REMOVE PLASTIC BUMPER SKIRT	SCB
GM	Suburban / Yukon / Tahoe 1500	X	X	05-07	83013			NEED PICTURE OF DRIVERS SIDE FRAME	SCB
GM	Suburban / Yukon / Tahoe 1500	X	X	07-18	83012			MAY HAVE TO REMOVE PLASTIC BUMPER SKIRT	SCB
GM	Suburban / Yukon / Tahoe 1500	X	X	19-25	83019			MAY HAVE TO REMOVE PLASTIC BUMPER SKIRT	SCB
GM	Avalanche 1500	X	X	01-04	83009		AVALANCHE 2500	HAVE TO REMOVE PLASTIC BUMPER SKIRT	SCB
GM	Avalanche 1500	X	X	05-07	83013		AVALANCHE 2500	HAVE TO REMOVE PLASTIC BUMPER SKIRT	SCB

IMPORTANT: SNOWBEAR® BY MARLON® CUSTOM MOUNT KITS ARE SUBJECT TO CHANGE IN ORDER TO ACCOMMODATE NEWER MAKES AND MODELS OF VEHICLES. SNOWBEAR® BY MARLON® MOUNT KITS ARE COMPATIBLE WITH DK2® BY MARLON® SNOWPLOWS. IF YOU HAVE ANY QUESTIONS, PLEASE CALL US TOLL-FREE AT 1-888-277-6960



SNOW PLOW CUSTOM MOUNT KIT GUIDE

FULL MOUNT KIT GUIDE | V.250829

MAKE	MODEL	2WD	4WD	YEAR	KIT NUMBER	FITS	DOES NOT FIT	OTHER NOTES	
GM	Avalanche 1500	X	X	08-18	83012	WITH FRAME SHOES		MAY HAVE TO REMOVE PLASTIC BUMPER SKIRT	SCB
GM	Avalanche 2500	X	X	02-04	83008				SCB
GM	Avalanche 2500	X	X	05-11	83011				SCB
GM	Avalanche 2500	X	X	12-16	83015				SCB
GM	Suburban / Yukon 2500	X	X	99-00	83005	CLASSIC BODY STYLE	NEW BODY STYLE		SCB
GM	Suburban / Yukon 2500	X	X	99-00	83008	NEW BODY STYLE	CLASSIC BODY STYLE		SCB
GM	Suburban / Yukon 2500	X	X	01-04	83008		YUKON DENALI		SCB
GM	Suburban / Yukon 2500	X	X	05-11	83011		YUKON DENALI		SCB
GM	Suburban / Yukon 2500	X	X	12-14	83015				SCB
GM	Suburban / Yukon 2500	X	X	15-18	83016*			REQUIRES EXTENDED CROSSBAR	ECB
GM	Suburban / Yukon 2500	X	X	19-25	83017				SCB
GM	Denali / Escalade	X	X	99-00	83005	CLASSIC BODY STYLE	NEW BODY STYLE		SCB
GM	Denali / Escalade	X	X	01-04	83008 or 83009	NEW BODY STYLE	CLASSIC BODY STYLE	NEED FRAME PHOTO TO CONFIRM	SCB
GM	Denali / Escalade	X	X	05-11	83011				SCB
GM	Denali / Escalade	X	X	12-14	83015				SCB
GM	Denali / Escalade	X	X	15-18	83016*			REQUIRES EXTENDED CROSSBAR	ECB
GM	Denali / Escalade	X	X	19-25	83017				SCB
DODGE	Dodge Dakota	X	X	87-96	84125				SCB
DODGE	Dodge Dakota	X	X	97-99	84130	4DR CLUB CAB			SCB
DODGE	Dodge Dakota		X	00-04	84134	4DR CLUB CAB			SCB
DODGE	Dodge Dakota	X	X	05-11	84135				SCB
DODGE	Dodge Durango	X	X	98-99	84130				SCB
DODGE	Dodge Durango		X	00-03	84134				SCB
DODGE	Dodge Durango	X	X	04-11	84135				SCB
DODGE	Dodge Durango	X	X	11-18	84106*				ECB
DODGE	Dodge Power Wagon		X	75-80	84303	W100 / W250			SCB
DODGE	Dodge Power Ram		X	81-93	84303	W100 / W250			SCB
DODGE	Dodge Power Wagon		X	05-10	84312				SCB

IMPORTANT: SNOWBEAR® BY MARLON® CUSTOM MOUNT KITS ARE SUBJECT TO CHANGE IN ORDER TO ACCOMMODATE NEWER MAKES AND MODELS OF VEHICLES. SNOWBEAR® BY MARLON® MOUNT KITS ARE COMPATIBLE WITH DK2® BY MARLON® SNOWPLOWS. IF YOU HAVE ANY QUESTIONS, PLEASE CALL US TOLL-FREE AT 1-888-277-6960





SNOW PLOW CUSTOM MOUNT KIT GUIDE

FULL MOUNT KIT GUIDE | V.250829

MAKE	MODEL	2WD	4WD	YEAR	KIT NUMBER	FITS	DOES NOT FIT	OTHER NOTES	
DODGE	Dodge Power Wagon		X	11 - 18	84317				SCB
DODGE	Dodge Ram 1500	X	X	94-01	84309			NEED TO REMOVE TOW HOOKS	SCB
DODGE	Dodge Ram 1500	X	X	02-05	84311	OFF-ROAD COMP	SRT-10		SCB
DODGE	Dodge Ram 1500	X	X	06-08	84313		MEGA CAB 1500		SCB
DODGE	Dodge Ram 1500		X	09-24	84315	2019 CLASSIC	2019 REBBEL - LARAMIE - LONG HORN	MUST REMOVE LOWER PLASTIC BUMPER DEFLECTOR/auto dam	SCB
DODGE	Dodge Ram 1500		X	19-24	84314*	REBBEL - models with steel belly pan	models without steel belly pan/bumper	REQUIRES EXTENDED CROSSBAR	ECB
DODGE	Dodge Ram 1500		X	19-24	84318	REBBEL - LARAMIE - LONG HORN	2019 CLASSIC - ECO-DIESEL	MUST REMOVE LOWER PLASTIC BUMPER DEFLECTOR/auto dam	SCB
DODGE	Dodge Ram 1500		X	19-24	84328*	REBBEL - LARAMIE - LONG HORN - ECO-DIESEL	2019 CLASSIC	MUST REMOVE LOWER PLASTIC BUMPER DEFLECTOR/auto dam	ECB
DODGE	Dodge Ram 2500	X	X	94-02	84309				SCB
DODGE	Dodge Ram 2500	X	X	03-10	84312	MEGA CAB			SCB
DODGE	Dodge Ram 2500-3500		X	11 - 18	84317			MUST REMOVE DROP TUBES ON BOTTOM OF FRAME	SCB
DODGE	Dodge Ram 2500-3500		X	19-24	84319			MUST REMOVE DROP TUBES ON BOTTOM OF FRAME	SCB
DODGE	Ramcharger		X	74-93	84303	AW100 / AW150 / PROSPECTOR			SCB
DODGE	Raider / Montero		X	87-90	87103				SCB
DODGE	Montero		X	83-91	87103				SCB
JEEP	Jeep Cherokee	X	X	84-02	84105				SCB
JEEP	Jeep Cherokee Wagoneer	X	X	79-83	84100		COIL SPRINGS		SCB
JEEP	Jeep CJ-5 / CJ-7		X	72-86	84110				SCB
JEEP	Jeep Comanche Pickup	X	X	86-92	84105				SCB
JEEP	Jeep Commander	X	X	06-10	84104			REMOVE TOW HOOKS	SCB
JEEP	Jeep Grand Cherokee	X	X	93-98	84102				SCB
JEEP	Jeep Grand Cherokee	X	X	99-04	84103*			REMOVE OR MODIFY BUSH GUARD - EX CROSS BAR	ECB
JEEP	Jeep Grand Cherokee	X	X	05-10	84104			REMOVE TOW HOOKS	SCB

IMPORTANT: SNOWBEAR® BY MARLON® CUSTOM MOUNT KITS ARE SUBJECT TO CHANGE IN ORDER TO ACCOMMODATE NEWER MAKES AND MODELS OF VEHICLES. SNOWBEAR® BY MARLON® MOUNT KITS ARE COMPATIBLE WITH DK2® BY MARLON® SNOWPLOWS. IF YOU HAVE ANY QUESTIONS, PLEASE CALL US TOLL-FREE AT 1-888-277-6960





SNOW PLOW CUSTOM MOUNT KIT GUIDE

FULL MOUNT KIT GUIDE | V.250829

MAKE	MODEL	2WD	4WD	YEAR	KIT NUMBER	FITS	DOES NOT FIT	OTHER NOTES	
JEEP	Jeep Grand Cherokee		X	11 - 18	84106			NOTCH OR REMOVE PLASTIC DEFLECTOR PLATE	SCB
JEEP	Jeep Grand Wagoneer	X	X	84-91	84100		COIL SPRINGS		SCB
JEEP	Jeep Compass		X	07-12	84200			FITS PATRIOT - NEED TO CUT PLASTIC UNDER BUMPER	CMK
JEEP	Jeep Grand Wagoneer	X	X	93	84102				SCB
JEEP	Jeep J10 / J20 Honcho / Laredo	X	X	79-87	84100				SCB
JEEP	Jeep Liberty		X	02-07	84121		CRD DIESEL	MAY HAVE TO REMOVE LOWER PLASTIC BUMPER SHIELD	SCB
JEEP	Jeep Scrambler / CJ-8 Pickup		X	81-85	84110				SCB
JEEP	Jeep Wagoneer	X	X	84-90	84105				SCB
JEEP	Jeep Wrangler		X	07-08	84119			MAY HAVE TO REMOVE AIR DAM	SCB
JEEP	Jeep Wrangler / Rubicon / Sahara		X	09-18	84219			NOTCH OR REMOVE PLASTIC DEFLECTOR PLATE	SCB
JEEP	Jeep Wrangler / Rubicon / Sahara / Truck		X	18-24	84220			NOTCH OR REMOVE PLASTIC DEFLECTOR PLATE	SCB
JEEP	Jeep Wrangler / TJ		X	97-06	84117	UNLIMITED			SCB
JEEP	Jeep Wrangler / YJ		X	86-96	84115				SCB
NISSAN	Pickup		X	83-86	86605	1986 WITH 4 HEAD LIGHTS	1986 WITH 2 HEAD LIGHTS		CFW
NISSAN	Pickup		X	86-97	86610	1986 WITH 2 HEAD LIGHTS	1986 WITH 4 HEAD LIGHTS		CFW
NISSAN	Frontier Pickup	X	X	98-04	86620	4DR / DESERT RUNNER 2WD			SCB
NISSAN	Frontier Pickup	X	X	05-20	86621			CUT HOLE IN PS BOTTOM BUMPER PLASTIC	SCB
NISSAN	Xterra		X	99-04	86620			BUSH GUARD MAY HAVE TO BE REMOVED	SCB
NISSAN	Xterra	X	X	05-14	86621			CUT HOLE IN PS BOTTOM BUMPER PLASTIC	SCB
NISSAN	Xtrail		X	05-09	86700			REMOVE TOW HOOKS	CFW
NISSAN	Pathfinder		X	86-95	86610				CFW
NISSAN	Pathfinder		X	96-04	86615			BUSH GUARD MAY HAVE TO BE REMOVED	SCB
NISSAN	Pathfinder	X	X	05-20	86621			CUT HOLE IN PS BOTTOM BUMPER PLASTIC	SCB

IMPORTANT: SNOWBEAR® BY MARLON® CUSTOM MOUNT KITS ARE SUBJECT TO CHANGE IN ORDER TO ACCOMMODATE NEWER MAKES AND MODELS OF VEHICLES. SNOWBEAR® BY MARLON® MOUNT KITS ARE COMPATIBLE WITH DK2® BY MARLON® SNOWPLOWS. IF YOU HAVE ANY QUESTIONS, PLEASE CALL US TOLL-FREE AT 1-888-277-6960





SNOW PLOW CUSTOM MOUNT KIT GUIDE

FULL MOUNT KIT GUIDE | V.250829

MAKE	MODEL	2WD	4WD	YEAR	KIT NUMBER	FITS	DOES NOT FIT	OTHER NOTES	
NISSAN	Infinity QX4		X	97-03	86615			BUSH GUARD MAY HAVE TO BE REMOVED	SCB
NISSAN	Titan		X	04-16	86625				SCB
NISSAN	Titan HD		X	19-24	86626				SCB
NISSAN	Titan HD		X	17-18	86635				SCB
NISSAN	Armada		X	04-16	86625			BUSH GUARD MAY HAVE TO BE REMOVED	SCB
TOYOTA	Pickup		X	80-84	85100				CFW
TOYOTA	Pickup	X		89-95	85005				CCB
TOYOTA	Pickup		X	85-95	85105		TACOMA		SCB
TOYOTA	Rav-4		X	94-06	85200				CFW
TOYOTA	Rav-4		X	07-12	85201				CFW
TOYOTA	Lexis RX300-Highlander		X	99-04	85010				CFW
TOYOTA	Tacoma		X	95-97	85115				SCB
TOYOTA	Tacoma		X	98-04	85120	PRERUNNER 2WD			SCB
TOYOTA	Tacoma		X	05-23	85123		X-RUNNER	07-08 REMOVE TOW HOOK	SCB
TOYOTA	Tacoma			24-25	85125				SCB
TOYOTA	T-100		X	93-98	85110				SCB
TOYOTA	4 Runner		X	86-95	85105				SCB
TOYOTA	4 Runner		X	96-02	85120				SCB
TOYOTA	4 Runner		X	03-13	85122				SCB
TOYOTA	FJ Cruiser	X	X	07-12	85122				SCB
TOYOTA	Tundra	X	X	99-06	85111			MAY HAVE TO REMOVE PLASTIC GUARD	SCB
TOYOTA	Tundra	X	X	07-21	85113		CREWMAX CAB	85114 FITS AS WELL	SCB
TOYOTA	Sequoia		X	00-05	85111			SUV	SCB
TOYOTA	Sequoia		X	06-21	85113			85114 FITS AS WELL	SCB
ISUZU	Pickup		X	88-95	86106				SCB
ISUZU	Hombra		X	96-00	82610				SCB
ISUZU	Amigo		X	90-95	86106				SCB
ISUZU	Trooper		X	88-91	86105				SCB

IMPORTANT: SNOWBEAR® BY MARLON® CUSTOM MOUNT KITS ARE SUBJECT TO CHANGE IN ORDER TO ACCOMMODATE NEWER MAKES AND MODELS OF VEHICLES. SNOWBEAR® BY MARLON® MOUNT KITS ARE COMPATIBLE WITH DK2® BY MARLON® SNOWPLOWS. IF YOU HAVE ANY QUESTIONS, PLEASE CALL US TOLL-FREE AT 1-888-277-6960



SNOW PLOW CUSTOM MOUNT KIT GUIDE

FULL MOUNT KIT GUIDE | V.250829

MAKE	MODEL	2WD	4WD	YEAR	KIT NUMBER	FITS	DOES NOT FIT	OTHER NOTES	
ISUZU	Trooper		X	92-97	86106				SCB
ISUZU	Trooper		X	98-05	86108				SCB
ISUZU	Rodeo		X	92-97	86106				SCB
ISUZU	Rodeo		X	98-04	86109			REMOVE OR MODIFY BUSH GUARD	SCB
SUZUKI	Sidekick		X	89-98	88611	2DR	4DR		SCB
SUZUKI	Sidekick		X	91-98	88615	4DR SPORT	4DR		CCB
SUZUKI	Sidekick		X	96-98	88620	4DR	2DR OR 4DR SPORT		CCB
SUZUKI	Sidekick		X	99-04	88625				CFW
SUZUKI	Samurai		X	80-95	88605				CFW
SUZUKI	Vitara		X	99-04	88625				CFW
LANDROVER	Discovery		X	89-99	89010		SERIES II		SCB
HONDA	Acura SLX		X	96-97	86106				SCB
HONDA	Acura SLX		X	98-99	86108				SCB
HONDA	Passport		X	92-97	86106				SCB
HONDA	Passport		X	98-02	86109			REMOVE OR MODIFY BUSH GUARD	SCB
HONDA	Ridgeline		X	05-16	86110			MAY HAVE TO ENLARGE THE ACCESS POINTS IN PLASTIC BELLY PAN	CFW

IMPORTANT: SNOWBEAR® BY MARLON® CUSTOM MOUNT KITS ARE SUBJECT TO CHANGE IN ORDER TO ACCOMMODATE NEWER MAKES AND MODELS OF VEHICLES. SNOWBEAR® BY MARLON® MOUNT KITS ARE COMPATIBLE WITH DK2® BY MARLON® SNOWPLOWS. IF YOU HAVE ANY QUESTIONS, PLEASE CALL US TOLL-FREE AT 1-888-277-6960