

## Quick Reference Guide: IW026 Wireless Earbuds    FCC ID:2BU8M-BKCQ002

**Product Specifications** | **Model Number** | IW026 | | **Pairing Name** | IW026 | | **Earbud Battery** | 30mAh (approx. 1.5 hours to charge) | | **Case Battery** | 200mAh (approx. 1.5 hours to charge) | | **Power Input / Output** | Input: DC 5V/200mA | Output: DC 5V/20mA\*2 |

---

### Touch Controls & Operation

Your earbuds are controlled using the multi-function button on either the left or right earbud:

- **Power On:** Remove earbuds from the case, OR press the button for **3 seconds**.
- **Power Off:** Place earbuds back into the case, OR long-press the button for **5 seconds**.
- **Play / Pause:** Click the button **once**.
- **Volume Up / Down:** Click the button **twice** (double-click).
- **Skip / Previous Track:** Click the button **three times**.
- **Answer / Hang Up Call:** Click the button **once** during an incoming or active call.
- **Reject Call:** Long-press the button for **2 seconds** during an incoming call.

### Pairing Instructions:

1. Remove the earbuds from the case (or press the buttons for 3 seconds) to automatically enter pairing mode.
  2. Open the Bluetooth/Wireless settings on your device.
  3. Select "IW026" from the list of available devices to pair. *(Note: After the first successful pairing, the earbuds will automatically reconnect to your device when turned on.)*
- 

### Charging Guide

#### Charging the Earbuds:

- Fully charge the earbuds before the first use.
- Place the earbuds into the charging case; they will begin charging automatically.
- A **red indicator light** on the earbuds means they are charging.
- The red light will turn off when fully charged.
- *Note: Inside the case, blue indicator lights will also turn off once the earbuds are fully charged.*

#### Charging the Case:

- Fully charge the charging case before the first use.
- Plug a Type-C cable into the case and connect it to a USB power source.
- The battery indicator lights on the case will light up during charging.

- When fully charged, all four indicator lights will remain solid on. As the case battery drains through use, these lights will turn off one by one.

---

## Safety & Compliance Notices

- **Environment:** Keep away from children, open flames, and extreme temperatures (heat, cold, humidity), as this will negatively impact performance.
- **Care:** Do not tamper with or disassemble the earbuds.
- **FCC Compliance:** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- **Warning:** (1) Using earbuds at high to moderate volumes for extended periods of time will result in permanent hearing damage. It is advised you keep volume levels moderate to low at times for your safety. (2) Do not use while driving a car, cycling, operating machinery, or performing other activities that require hearing surrounding sounds. (3) Do not use earbuds in thunderstorms, the earbuds may not work properly in the condition, and increase the risk of bringing hit by lightning. (4) Do not use any corrosive cleaner / oil to clean the earbuds. (5) If the earbuds come in contact with liquid, please wipe it off immediately. (6) If submersed in water, do not turn the earbuds on until completely dried. (7) Please use the original charging cable provided by the earbuds manufacturer for charging and choose the right adapter.

- FCC Statement:
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - (1) This device may not cause harmful interference, and
  - (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - —Reorient or relocate the receiving antenna.
  - —Increase the separation between the equipment and receiver.
  - —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - —Consult the dealer or an experienced radio/TV technician for help.
- Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.