

VAC N BLO VNB SERIES



ALL MODELS ARE: *Sturdy All Steel; 4.0 HP Twin Fan; 10.8 Amps; 1,170 Watts; 12' Cord w/ Halo End Cap to wrap cord. 2 Speed or Variable Speed; Shoulder Strap, 2-20 Extension Wands, Upholstery Nozzle, Crevice Tool,*

Different models and what they come with:

VNB4AFBR (112-112730): Dual Power Unit with dual mounted legs and cord storage wrap, wall/table mounting bracket, 2 x 6 Ft. Flexible Hose, Deluxe 4 Piece Micro Detailing Attachments, Blower Nozzle, Inflator Adaptor, Upholstery Nozzle & Dust Brush.

VNB-83BA (112-112273): Upholstery Nozzle, Crevice Tool, 2 - Extension Wands, Blower Nozzle, Dust Brush, Micro Tool Kit, Inflator Adaptor, Shoulder Strap

VNB-94BD (112-112327): 1 x 6 Ft. Flexible; Blower Nozzle, Combo Swivel Floor Brush, Dust Brush, Micro Tool Kits, Inflator Adaptor, Upholstery Nozzle & 4 Wheel Dolly. **(Model shown.)**

VNB-73B (112-045014): Dual Power Unit, 3-foot Flexible Hose, Inflator Adaptor & Upholstery Nozzle.

INSTRUCTIONS (Instructions are general for all VNB Models. Some of the information below may not pertain to your specific model. Check list above for parts and accessories that go with your machine):

VACUUM:

- Depress buttons on hose coupling; insert into vacuum front-end cap.
- To reach those inaccessible areas, connect the Extension Wands to the hose. Eliminate bending to clean low areas and stretching to reach the high areas.
- Start the vacuum by pushing the On/Off Switch.
- The Combo Floor/Rug Tool: Attach to the steel chrome extension wands to clean carpeting. Depress pedal for bare floors or carpeting. The swivel action permits proper contact with all surfaces.
- Floor & Wall Brush: Used with extension wands for cleaning walls, hardwood, tile, cement or linoleum surfaces.
- Crevice Tool: Cleans those hard to reach, tight spots.
- Dust Brush: The long, soft bristles gently loosen dust furniture, blinds, moldings, windowsills, etc.
- Crevice Tool: Allows you to clean those hard-to-reach places.
- Pik-All Nozzle: Cleans stairs, upholstery, draperies, and more.

BLOWER:

To use as a blower, release clamps and remove front end cap and cloth bag, but leave foam filter in place. Attached hose to exhaust end.

TO INFLATE INFLATABLES

To use as an inflator, release clamps and remove front end cap, cloth bag and foam filter. Attached coupling and hose to exhaust end.

Inflator Adaptor: When inflating air mattresses, boats, rafts, insert hose coupling into exhaust. Inflator adapters are sold separately.

ADDITIONAL PARTS FOR PURCHASE (the below items are available for purchase on our website www.MetroVac.com; use the provided product # in the search):

- Foam Filter – MVC-56F
- Disposable Paper Bags – DV-5PBRP
- Disposable Bags with Adaptor Tube – DV-5PBA
- Cloth Dust Bag (4 ½") - MVC-65
- Dusting Brush – MVC-206BBB
- Rubber Blower Nozzle – MVC-196AB
- Air Concentrator – MVC-196AA
- Mini Attachment Kit – MVC-212-SK
- 6" Handheld Turbine Driven Rotating Brush – MVC-200B
- 10 ½" Turbine Driven Revolving Brush – MVC-200C
- 9" Swivel Brush – MVC-190B
- Combo Carpet Nozzle / Floor Brush – MVC – 200A
- Crevice Tool – MVC-188
- Shoulder Strap – MVC-49C
- Roll – A – Round 4 Wheel Dolly – 4WD
- Roll – A – Round 4 Wheel Dolly w/ Swivel Wheels – 4WDSW
- 3 – Piece Handle – MVC-47
- Carbon Brushes ABC-3
- 25 Ft. Cord – MVC-289A
- Front End Cap w/ Riveted Buttons – MVC-57BL
- Single Speed Switch – MVC-74
- Plastic Tube Adapter – MVC-55
- Halo Cord Holder – MVC-83
- 18/3 Cord – MVC-285
- 4.0 HP Twin Fan Motor – MVC-157D
- Extension – MVC-194
- Combo Swivel Floor Brush w/ Large Rear Wheels – MVC-200E
- Inflator Adapter – MVC-211C-AS
- 3/16" Inflator Adapter – MVC-211D-AS
- "Pik - All" Utility Nozzle – MVC-185A
- AirForce Mounting Bracket – AFBR-1 (**Only for use with VNB4AFBR**)
- Hoses:
 - 6' Standard Flexible Hose – MVC-202A
 - Deluxe 6.5' HeavyDuty Flexible Hose – AFTM-211
 - 3' Flexible Hose – MVC-178A

Filtration includes paper disposable bag, permanent cloth bag, foam filter. To protect your motor, and for maximum efficiency and log life, dispose of the used paper bag. Frequently check the permanent cloth bag for dust/dirt buildup and caking. Shake out the permanent cloth bag frequently. Check and replace the foam filter and filter 3 to 4 times a year.

CAUTION: If your machine has suction but does not clean when the hose is attached, remove the hose from the suction end and place it on the blower end. Blow out the hose, it may be clogged.

Replacing / Cleaning Filter (Filter MVC-56F):

1. Take out the filter and replace it with new or shake out.
 - a. You can rinse the filter and reuse, BUT IT MUST BE COMPLETELY DRY BEFORE PUTTING BACK INTO THE MACHINE.

- b. Replace it with a new filter after 3 rinses.
2. Put filter back into the baffle.
3. Screw baffle endcap back onto the machine.

Replacing carbon brushes (ABC-3: see additional parts list above; should be changed after about 500 hours of use):

1. Remove front endcap.
2. Find wire going to carbon brush and use flathead screwdriver to loosen tab.
3. Use Phillips screwdriver to remove carbon brush mounting bracket.
4. Install tab into new carbon brush and replace mounting bracket.

Air Force Mounting Bracket Instructions (bracket sold separately: AFBR-1 – ONLY THE VNB4AFBR CAN BE MOUNTED):
PLEASE FOLLOW THE DIRECTIONS CAREFULLY TO MOUNT THE BRACKET PROPERLY.

TO MOUNT ON WALL

1. Place Air Force Mounting Bracket on the wall where desired with open portion of bracket in upright position.
2. With bracket as template, mark 4 holes where indicated.
3. With a Phillips head screwdriver or “punch” create holes in sheetrock.
4. Attach bracket with 4 self-tapping wood screws and mollies (supplied).
5. After the mounting plate has been secured and tightened, place blower on mounting plate and slide dryer until legs lock into place.
6. When the dryer is locked into place screw into threaded hole on side of the bracket to avoid movement of the dryer as a result of vibration.



IT IS VERY IMPORTANT TO MAKE SURE THAT THE MOUNTING BRACKET IS SECURE AND CAN HANDLE THE WEIGHT AND PULLING THAT MIGHT OCCUR DURING THE NORMAL USAGE OF THIS PRODUCT. METRO WILL NOT BE RESPONSIBLE FOR DRYERS THAT ARE DAMAGED AS A RESULT OF IMPROPER BRACKET MOUNTING.

WARRANTY:

This machine carries a Five Year Limited* Warranty on the unit and the motor.
There is a One Year Limited* Warranty on Parts, Switches, and Cords.

*MetroVac will repair any defective or malfunctioning product at no charge, or replace it (if it is deemed unrepairable), during the warranty period, with the following exceptions:

- Mechanical alterations made to the machine will void the warranty.
- The warranty does not cover physical damage made to the machine, improper electrical connections, or water damage.
- Warranty does not cover carbon brushes, carbon brush wear, filters, or general maintenance.

- Removal of the date stamp code from the machine will void the warranty.

*Customer is responsible for shipping charges to and from our facility.

***Even if the product is beyond the warranty period, we suggest you send the unit back to our factory for expert repairs and maintenance at reasonable rates. Please click the following link to access our Repairs and Maintenance form
<https://metrovac.com/pages/warranty-and-repair-request> ***

Warranty benefits are only available on MetroVac products that are purchased from MetroVac or authorized MetroVac dealers. The manufacturer's warranty is not transferable when sold by unauthorized retailers. MetroVac does not participate in Amazon's extended warranties.

WARNING: To reduce the risk of fire, electric shock, or injury Do not leave appliance when plugged in. Unplug from outlet when not in use and before servicing.

- Do not allow it to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use it with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into the openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
- Do not use without dustbag and/or filters in place.
- Turn off controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids such as gasoline or use in areas where they may be present.
- To avoid electric shock, do not use it on wet surfaces, do not expose to rain; store indoors.
- To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit into an outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.
- For a grounded appliance: "Connect to a properly grounded outlet only. See Grounding Instructions."

MetroVac / Metropolitan Vacuum Cleaner Co.

5 Raritan Road, Oakland, NJ 07436

800-822-1602 / 201-405-2225

www.MetroVac.com