

BUTTONS

LOS ANGELES

A woman with red hair tied in a bun is shown in profile, wearing a black earbud. A digital glitch effect is applied to the right side of her face, creating multiple overlapping, semi-transparent images of her features. The background is a plain, light gray.

**PURE SOUND,
IMMERSIVE EXPERIENCE**





● SILVER

● GOLD

● PINK

● CREAM




DESIGN
MEETS
PERFORMANCE






CALL TO ACTIVATE
COMMAND WITH EASE


PACKAGE CONTENTS



BUTTONS CLIP PRO
OPEN-EAR EARPHONES
(2 PIECES)



BUTTONS CLIP PRO
DEDICATED PORTABLE
CHARGING CASE



PRODUCT MANUAL &
WARRANTY CARD



USB CHARGING CABLE



STORAGE POUCH



EAR CAP

Important Notice: Do not use the Product if any parts are missing or damaged. For troubleshooting articles, videos, and product repair or replacement information, please visit the BUTTONS official website at www.buttonsair.com. Contact our customer service at service@buttonsair.com (Global).

DOWNLOAD THE OFFICIAL BUTTONS EARPHONES APP

1. Scan the QR code below with your smartphone camera to download the BUTTONS APP, and follow the on-screen instructions to complete installation.




2. Alternatively, users can search for the APP in their phone's app store and follow the installation prompts.

Note: For the best app experience, your device should meet these minimum requirements:

Android platform	iOS platform
Operating system: Android 9.0 or later; SoC: Qualcomm Snapdragon 660 equivalent or better; RAM: 4 GB or more;	Operating system: iOS 15.0 or later; SoC: A12 or better; RAM: 3 GB or more;

3. After installation, you can use it according to the interface prompts of the APP software, or click the ≡ button in the upper right corner of the default page (Figure A) to quickly access the APP user guide.




4. About BUTTONS APP Features: Once you've downloaded and installed the BUTTONS APP and paired your phone with BUTTONS CLIP PRO earphones via Bluetooth, the APP will automatically bind with the earphones. The APP allows you to monitor battery levels, function status, and other basic information for better device management. After registering and logging in as a new user, you'll unlock additional features including, including EQ sound effects selection, smart AI interaction, AI translation, and more exciting features waiting for you to explore (learn more about these features through the instructions button after installing the APP).

POWER ON & POWER OFF


ON

Earphones automatically power on when the charging case lid is opened;

Note: When using for the first time, please remove the insulating protective film on the metal contacts of the left and right earphones to ensure normal charging.



①




②

OFF


Earphones power off when placed in the charging case and the lid is closed to begin charging.

Note: When returning earphones to the case, ensure the speaker portion faces the outer sides of the case.





①

②



BLUETOOTH PAIRING



Enable Bluetooth on your phone, find "BUTTONS CLIP PRO" in the Bluetooth device list and tap to connect.


When prompted to "Authorize Bluetooth pairing request", tap "Pair". Voice prompt "Connected" indicates successful pairing. Voice prompt "Disconnected" indicates connection loss.

After initial pairing, the earphones will automatically connect when the case is opened.

CHARGING INSRUCTIONS

Charging the Case:

Charging: LED breathes/pulses **Fully Charged:** LED stay solid **Charging Error:** Red LED flashes quickly for 5s, then turns off



Charging the Earphones:

Place earphones in the charging case - a white light flash indicates proper contact with charging pins.
Close the lid to begin charging automatically.

Low Battery: Voice prompt "Battery Low"

Charging Status: After placing earphones in case and closing lid, breathing LED indicates charging


Fully Charged: LED indicator turns off

Note: These light indicators apply only when charging the case separately. When opening the case lid: Green LED indicates low case battery, charging needed; Red LED indicates critically low case battery, charge immediately.

Please use a standard 5V-1A charger. Using chargers outside these specifications may damage the device.

- Needs Charging
- Battery Depleted
- Charging Error
- ⦿ Currently Charging
- Fully Charged
- LED Off

BUTTONS AND LED INDICATOR GUIDE



-  Battery check  <3s
-  Pairing mode  ≥3s
-  Factory reset  ≥8s

BATTERY LEVEL DISPLAY

-  >40%
-  15% – 40%
-  5% – 15%

CHARGING STATUS

-  Charging
-  Fully charged
-  Charging error


-  White light solid
-  White light flashing
-  Green light solid
-  Red light solid
-  Red light flashing
-  Light off

PROPER WEARING INSTRUCTIONS

This is an open-ear design that doesn't require insertion into the ear canal.

The earphones are reversible and automatically detect wearing orientation.


Please refer to the diagram on the right for product area names.



BUTTONS CLIP PRO EAR CAP INSTALLATION GUIDE


① IDENTIFY ORIENTATION

A1 at the top right
(dot facing upward)
A2 on the bottom left,
A3 on the bottom right




② ALIGN AND INSERT

Align A3 with the top of the earbud.
Then wrap A2 downward around the earbud
and gently rotate to secure into place.




④ INSTALLATION COMPLETE

To remove, gently lift the ear cap
and detach it outward from the
earbud.



③ ADJUST FIT

Ensure the ear cap fits snugly and remains
securely in place without shifting.



Note:

- Avoid excessive pulling during installation to prevent damage to the ear cap. make sure the ear cap is fully fitted to ensure stability and optimal audio performance.
- If the ear cap becomes dirty, rinse gently with clean water and allow it to air dry before reuse.

WEARING DETECTION AND SLEEP MODE

Wearing Detection:



During music playback, removing one or both earphones automatically pauses music. Playback resumes automatically when earphones are worn again.
During phone calls, removing both earphones automatically switches audio to phone speaker. Audio returns to earphones when either or both earphones are worn again.

Note: Tap controls are disabled when earphones are detected as not being worn.
For double and triple taps, use your index fingertip to tap the cover.
First-time users may need practice to master the operation.
Taps that are too hard/soft or too fast/slow may fail to trigger the controls.

Sleep Mode:

Entering Sleep Mode: Earphones automatically enter sleep mode after a period when: unable to pair with Bluetooth device; removed from ears and not in use; out of Bluetooth range.

Exiting Sleep Mode: Place earphones back in charging case, open and close the lid once, then remove them to exit sleep mode.




EARPHONE CONTROLS



MUSIC



CALLS



VOICE



X2: DOUBLE TAP X3: TRIPLE TAP

SAFETY GUIDELINES

Input: DC 5V=500mA

Output: DC 5V=280mA

Bluetooth Operating Frequency & Transmission Power: 2402MHz-2480MHz, < 11dBm

Declaration: Contains safety information.

Declaration: Contains a lithium-ion battery. The battery must be properly recycled or disposed of.

Warning: To avoid hearing damage, do not listen at high volume for extended periods.

Warning: Device contains magnets.

Warning: Choking hazard. This product contains small parts.

Warning: The symbol indicates that this product must not be disposed of with household waste. It should be taken to an appropriate collection facility for recycling. Proper disposal and recycling help protect natural resources, human health, and the environment. For more information on disposal and recycling, please contact your local authorities or the retailer where you purchased this product.

Compliance and Warranty:

EU Compliance Declaration

Beijing Techao Weijia Electronic Science & Technology Co., Ltd. hereby declares that this radio equipment complies with the EU Directive 2014/53/EU. The full text of the EU compliance declaration can be found at www.buttonssair.com

Package Contents:

BUTTONS CLIP PRO earphones x2 BUTTONS CLIP PRO portable charging case x1 USB Type-A to Type-C charging cable x1

Product manual x1 Storage pouch x1 Ear Cap x4



Made for

 iPhone | iPad

Product Name: BUTTONS CLIP PRO

Product Type: Ear-Clip True Wireless Bluetooth Earbuds

Product Model: CLIPBTN20

Charging Voltage/Current: 5V=1A

FCC ID: 2A83I-CLIPBTN20

Made in China

Manufacturer: Beijing Techao Weijia Electronic Science & Technology Co., Ltd.

Address: Room 2107, 2nd Floor, Building 8, No. 1 Courtyard, Shuangqiao Middle Road, Chaoyang District, Beijing

Control	Tapping
Speaker	Φ12mm dual magnetic horn
Frequency response range	20-20KHz
Impedance	16Ohm
Call microphone	2mic+VPU
Radio frequency communication range	15m
Waterproofing grade	IP54
Earphones battery	45mAh*2
Charging case battery	480mAh
Bluetooth version	5.4
Weight	Approx. 6.6g (per earbud) / 97.4g (2 earbuds + charging case)
Warranty period	1 year

(1) FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Cleaning Instructions for Black Leather:

This product is made with high-quality leather. To ensure it stays in excellent condition and maintains its aesthetic appeal over time, please follow these cleaning guidelines:

Never use cleaning agents that contain alcohol, bleach, or other harsh chemicals. Such substances can cause the leather to fade, crack, or become damaged, which would affect the product's overall feel and longevity.

We recommend using a clean, soft cloth to gently wipe the surface, effectively removing dust and stains, and keeping the leather looking fresh and polished.



COMPATIBLE WITH

iPhone 17e, iPhone 17 Pro Max, iPhone 17 Pro, iPhone Air, iPhone 17, iPhone 16e, iPhone 16 ProMax, iPhone 16 Pro, iPhone 16 Plus, iPhone 16, iPhone 15 Pro Max, iPhone 15 Pro, iPhone 15Plus, iPhone 15, iPhone 14 Pro Max, iPhone 14 Pro, iPhone 14 Plus, iPhone 14, iPhone SE (3rd generation), iPhone 13 Pro Max, iPhone 13 Pro, iPhone 13, iPhone 13 mini, iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini, iPad Air 13-inch (M4), iPad Air 11-inch (M4), iPad Pro 13-inch (M5), iPad Pro 11-inch (M5), iPad Air 13-inch (M3), iPad Air 11-inch (M3), iPad (A16), iPad mini (A17 Pro), iPad Pro 13-inch (M4), iPad Pro 11-inch (M4), iPad Air 13-inch (M2), iPad Air 11-inch (M2), iPad Pro 12.9-inch (6th generation), iPad Pro 11-inch (4th generation), iPad (10th generation), iPad Air (5th generation), iPad (9th generation), iPad mini (6th generation), iPad Pro 12.9-inch (5th generation), iPad Pro 11-inch (3rd generation), iPad (8th generation), iPad Air (4th generation), iPad Pro 11-inch (2nd generation), iPad Pro 12.9-inch (4th generation)

Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Apple, Apple TV, Apple Watch, iPad, iPad Air, iPad Pro, iPhone, Lightning, and tvOS are trademarks of Apple Inc., registered in the U.S. and other countries and regions.

Apple, Apple TV, Apple Watch, iPad, iPad Air, iPad Pro, iPhone, Lightning, and tvOS are trademarks of Apple Inc., registered in the U.S. and other countries and regions. The trademark "iPhone" is used in Japan with a license from Aiphone K.K.

ABOUT THE WARRANTY

BUTTONS Limited Warranty

Important Notice: By using your BUTTONS earphones (the "Product"), you agree to the terms of this BUTTONS Limited Warranty (the "Warranty"). If you do not agree to these terms, please refrain from using the Product and return it within the return period specified in BUTTONS' return policy.

Who is Covered by this Warranty?

This limited warranty is available only to end users (the "End Users") who have purchased the Product from BUTTONS-authorized dealers in their respective region or country.

Limited Warranty:

Subject to the terms and conditions of this warranty, BUTTONS offers a one (1) year warranty period starting from the date of the original retail purchase by the End User (the "Warranty Period"). This warranty ensures that the Product will be free from material defects in design, materials, and workmanship under normal and customary consumer use, and in accordance with any BUTTONS-written guidelines, specifications, or instructions (including environmental and storage requirements). Any non-conforming products must be reported to BUTTONS, accompanied by documentation and supporting information reasonably required by BUTTONS to verify, diagnose, and correct the non-conformity.

Warranty Conditions and Exclusions:

This warranty is valid only if: (i) the original receipt from a BUTTONS-authorized dealer, showing the purchase date and serial number, is submitted along with the Product for repair or replacement; (ii) the warranty seals and serial numbers on the Product have not been tampered with, removed, or defaced; and (iii) the Product has not been modified, altered, damaged, misused, or neglected by the End User or any other party in any way.

This warranty does not cover: (a) Consumable parts, such as batteries, that are designed to wear out over time, unless the failure is due to a defect in materials or workmanship; (b) Cosmetic damage, including but not limited to scratches, dents, and broken plastic on ports, as well as normal wear and tear resulting from ordinary aging of the device; (c) Damage caused by using the Product with third-party devices or products not provided or recommended by BUTTONS.

ABOUT THE WARRANTY

Warranty Service Instructions

If, after appropriate inspection, BUTTONS determines that the Product does not conform to this warranty during the Warranty Period, BUTTONS or its authorized service provider will, at its sole discretion, repair or replace the Product in accordance with these terms.

This warranty provision represents the End User's sole and exclusive remedy for any warranty claims regarding the Product and constitutes BUTTONS' entire liability and obligation under the warranty.

If BUTTONS or its authorized service provider repairs or replaces the Product (the repaired or replaced product hereinafter referred to as the "Replacement"), the Replacement will be covered by the warranty for the remainder of the original Warranty Period or for ninety (90) days from the date of repair or replacement, whichever is longer. Repairs or replacements may involve the use of functionally equivalent reconditioned, previously installed, or refurbished parts or components. All replaced parts or components will become the property of BUTTONS.

All warranty returns must be processed through the original sales channel, designated distributor, platform, offline store, or customer service representative, who will assist with forwarding the product to the specified after-sales service center.


Before initiating a warranty return, users must provide BUTTONS or its authorized service provider with the following information:

1. Original purchase receipt, packaging, and accessories
2. Product model, color, and size
3. Serial number
4. Contact information (name and phone number)


The product must be returned with shipping costs prepaid. Any related returns will be sent back at the End User's expense. If BUTTONS determines that the returned product does not meet the warranty terms outlined herein, the End User will also be responsible for the costs incurred by BUTTONS in returning the product to the End User.

This warranty, apart from the aforementioned contents, also covers any other statutory rights and remedies that the End User may have under applicable laws, specifically for products sold to End Users located outside mainland China. To obtain information about any applicable statutory rights or warranty services in such cases, please first contact the dealer from whom the product was purchased or the distributor that provided the product.


包装内包含以下物件



BUTTONS CLIP PRO
耳夹式耳机 (2只)



BUTTONS CLIP PRO
耳机专属便携式充电舱



产品手册及保修卡



USB充电线



包装布袋



耳机帽

注意：如果产品的任何部分缺失或损坏，请勿使用。请访问BUTTONS官网www.buttonssair.com，了解故障排除文章、视频以及产品维修或更换信息。或联系客服邮箱地址service@buttonssair.com(Global)，中国大陆地区用户，也可在工作时间拨打官方售后电话：400-600-8802 (CN)。

下载BUTTONS耳机官方应用软件

1.使用您的智能手机摄像头扫描右方二维码下载BUTTONS APP，并按照手机页面提示完成安装。




2.通常，用户也可尝试从各手机品牌的应用市场搜索该APP,并尝试按照手机页面提示完成下载安装。

注意: 为了更好体验这款APP，您的手机软硬件系统需满足以下要求:

安卓平台	iOS平台
操作系统：Android9.0或更新版本； SOC：Qualcomm Snapdragon 660相当或更高性能； RAM：4GB或更大容量；	操作系统：iOS15或更新版本； SOC：A12 或更高性能； RAM：3GB或更大容量；

3.安装后可按照APP软件的界面提示使用，或可点击默认页面（图A）左上角的  按钮，点击“使用帮助快速”查阅APP使用指南。



4.关于BUTTONS APP功能简介如果您完成了BUTTONS APP的下载和安装，并让手机与BUTTONS CLIP PRO耳机通过蓝牙设备列表正确配对后，打开BUTTONS APP会自动绑定耳机。配合该APP您可以查看耳机电量、功能状态等基础信息，方便您更好地管理耳机设备。


如果您按BUTTONS APP的页面提示完成新用户注册和登陆，您将可以使用APP的更多功能，包括EQ音效选择、智能AI互动、AI翻译更多精彩内容 and 科技功能等您探索(安装APP后通过说明按钮，您可学习更多功能的使用方法)。

开机&关机


ON

耳机在充电盒中，
打开充电盒盖，耳机自动开机。

注：首次使用时，请移除左右耳机金属触点上的
绝缘保护膜，以确保正常充电。



①




②


OFF

耳机放入充电盒中，合上充电盒盖子，耳机断连并开始充电。


注：放回充电盒时，保持带有扬声器的部分，朝向充电盒左右外侧。




①



②



配对连接



打开手机蓝牙开关，在蓝牙设备列表中找到“BUTTONS CLIP PRO”并点击连接。


系统弹出“授权蓝牙配对请求”对话框，点击“配对”按钮，耳机语音提示“Connected”，表明耳机连接成功。蓝牙连接断开时，耳机语音提示“Disconnected”。

第一次连接成功后，下一次打开充电盒盖，将会自动开始蓝牙连接。

充电

给充电盒充电

正在充电:充电盒LED指示灯呼吸闪烁 **充电完成:**充电盒LED指示灯长亮 **充电故障:**充电盒LED指示灯红色快闪5s后熄灭



给耳机充电

将耳机放入充电盒中，白灯会闪烁一下，表示金属触点接触正常，合上盖子自动为耳机充电。

耳机低电:语音提示:“Battery Low”

充电状态:打开充电盒，放入耳机，合上充电盒盖子，充电盒LED指示灯呼吸闪，

表示耳机处在充电状态


充电完成:充电盒LED指示灯熄灭

注:上述灯光指示仅适用于单独为充电盒充电时使用;当打开充电盒盖,如LED指示灯显示绿色,则表明充电盒电量低,需要对设备进行充电。当打开充电盒盖,如LED指示灯亮红色,则表明充电盒电量将耗尽,请马上对设备充电。

请使用正规5V-1A充电器为本机充电,超出规格充电器会造成设备损坏。

- 需要充电
- 电量耗尽
- 充电故障
- ⦿ 正在充电
- 充电完成
- 指示灯熄灭

按键及指示灯说明



电量



配对模式



恢复出厂设置

 <3s

 ≥3s

 ≥8s

电量显示

-  >40%
-  15% - 40%
-  5% - 15%

充电显示

-  正在充电
-  充电完成
-  充电故障

 白灯常亮

 白灯闪烁

 绿灯常亮

 红灯常亮

 红灯闪烁


 指示灯熄灭

正确佩戴耳机

本产品为开放式耳机，无需塞入耳道。耳机不区分左右，可根据佩戴情况自动识别。请根据右图所示了解产品区域名称。

扬声器在前，耳后夹在后，轻掰开C桥，将耳机夹在耳朵上。


可上下调整耳机至舒适位置，完成佩戴。



BUTTONS CLIP PRO耳帽安装示意


① 识别方向

A1右上（圆点朝上）
A2左下、A3右下




② 对齐并套入

把A3对准音筒上方，
再将A2向下包住耳机，
轻轻旋转按入。




③ 调整贴合

确保耳套都贴合牢固、不松动。



④ 安装完成

如需拆卸，轻轻掀起，
再向外取下耳帽。



注意：·安装时请避免用力拉扯，以免损坏耳帽。请确认耳帽已完全贴合，避免影响佩戴稳定性与声音效果。
·如耳帽沾有污渍，请用清水轻轻冲洗并自然晾干后再使用。

佩戴检测和休眠模式

佩戴检测

音乐播放过程中，取下一只或两只耳机同时取下后，音乐自动暂停，耳机再次放入耳中后，音乐自动恢复播放。

手机通话过程中，取下两只耳机后，自动切换成手机听筒。

佩戴任意一只或两只耳机后，自动切回耳机端。

注：当检测到耳机未佩戴时，耳机将不支持敲击操作。

双击或三连击操作时，建议您使用食指指尖敲击C桥，

首次使用时您需要一些练习以熟练操作，

敲击力度过大/过小及速度过快/过慢都可能导致耳机敲击操作无法成功触发。



休眠模式：

进入休眠：

耳机如出现无法与蓝牙设备配对、或从耳中取下不用、再或脱离蓝牙范围等情况超过一定时间，则自动进入休眠模式；

退出休眠：

将耳机放回充电盒，开合盖一次，再次取出，耳机退出休眠模式。



耳机操作



音乐



通话



语音



语音指令



X2：连击两次 X3：连击三次



安全指南

输入Input: DC 5V=500mA

输出Output: DC 5V=280mA

蓝牙工作频率&发射功率: 2402MHz-2480MHz, < 11dBm

声明: 内有安全信息说明

声明: 内含锂离子电池。电池必须妥善回收或处理。

警告: 为避免听力损伤, 请勿长时间以高音量收听。

警告: 设备内含有磁铁

警告: 窒息危险, 本产品含有小零件。

警告: 带有此符号表示不得将本产品作为生活垃圾丢弃, 应将其运送到适当的收集设施进行回收。正确的处置和回收利用有助于保护自然资源、人类健康和环境。有关本产品的处置和回收等更多信息, 请与您当地的有关部门联系, 或与您购买此产品的零售商联系。

合规性和保证

欧盟符合性声明

北京特潮未加电子科技有限公司特此声明, 本无线电发射设备符合欧盟指令2014/53/EU。

你可以在互联网上的www.buttonsair.com找到欧盟符合性声明的全文。

内含物:

BUTTONS CLIP PRO耳机x2 BUTTONS CLIP PRO耳机便携充电盒x1

USB Type-A到Type-C充电线x1 产品手册x1 收纳袋x1 耳帽x4

清洁注意事项:

本产品部分采用高品质皮革材质, 为确保其长久保持良好状态与美观, 清洁时请务必留意:

严禁使用含有酒精、漂白剂等刺激性成分的清洁剂, 此类清洁剂可能会对皮革造成褪色、干裂或材质损伤, 影响产品的整体质感与使用寿命。

建议您使用干净、柔软的布料, 轻轻擦拭即可有效去除表面灰尘与污渍, 使皮革始终光洁如新。

产品名称: BUTTONS CLIP PRO

产品类型: 夹耳式真无线蓝牙耳机

产品型号: CLIPBTN20

充电电压/电流: 5V=1A

FCC ID: 2A831-CLIPBTN20

中国制造

制造商: 北京特潮未加电子科技有限公司

地址: 北京市朝阳区双桥中路1号院8幢二层2107



固 220-J11976



操控	敲击
扬声器	Φ12mm双磁喇叭
频响范围	20~20KHz
阻抗	16Ohm
通话Mic	2mic+VPU
射频通信范围	15m
防水等级	IP54
耳机电池	45mAh*2
充电盒电池	480mAh
蓝牙版本	5.4
重量	约6.6g(每只耳机)97.4g(2只耳机+充电盒)
质保时间	1年

保修说明

BUTTONS 有限保修

重要声明:通过使用您的 BUTTONS 耳机(简称“产品”),您同意接受本 BUTTONS有限保修条款(简称“保修”)的约束。如果您不同意此份保修条款,请不要使用该产品,并在 BUTTONS 的退货政策中所规定的退货期限内将其退还。

谁会受到本保修的保障?

只有在最终用户所在地区或国家由 BUTTONS 授权经销商处购买本产品的最终用户(称“最终用户”)才有资格享受本有限保修。

有限保修:

根据本保修的条款及条件, BUTTONS提供— (1) 年的保修期,从最终用户最初零售购买之日起— (1) 年(简称“保修期”),该产品是在正常和惯常的消费者使用条件下,以及任何BUTTONS 书面指南、规定或说明(包括如环境和存储要求)下,无设计、材料和工艺之重大缺陷的情况下运行。任何不合格品会以表格和 BUTTONS 合理要求的辅助信息报告给 BUTTONS,使其能够验证、诊断和修正不合格品。

保修条件及除外责任:

只有在下述情况下,本保修才有效: (i) 将 BUTTONS授权经销商向原始最终用户开出的原始收据,上注有购买日期和序列号,连同本产品一起提交以进行修理或更换; (ii) 本产品表面上的密封签或序列号均未被篡改、移除或污损;以及 (iii) 本产品未被最终用户或使用者或任何其他人以任何方式修改、变更、破坏、滥用或疏忽。本保修不适用于(a)消耗性零件,如随时间推移而耗损的电池设计,除非由于材料或工艺上的缺陷而引起的故障; (b)外观损坏,包括但不限于刮痕、凹痕及端口塑料损坏,以及由于设备正常老化而导致的正常磨损或断裂;以及(c)将本产品与 BUTTONS 未提供或推荐的任何第三方设备或产品一起使用。



保修说明

如果BUTTONS在适当检查后自行决定认为该产品在保修期内未能符合本保修的要求，BUTTONS或其授权服务提供商将由BUTTONS决定，根据此规定条件修理或更换产品。

对于BUTTONS任何有关本产品的保修，本条款规定最终用户唯一和专门的补救措施，以及BUTTONS的唯一责任和专有赔偿责任。

如果BUTTONS或其授权服务提供商修理或更换本产品(这种修理或更换的产品，简称“更换品”),则更换品应在原保修期的剩余时间，或从修理或更换之日起的九十 (90) 天享有保修，以较长者为准。修理或更换可能涉及到使用功能相同之旧的、或先前安装或翻修的部件或零件。被更换的零件或部件会变成BUTTONS的财产。


所有保修退货必须邮递到公司指定售后地址(地址：中国北京市朝阳区新源南路8号启皓大厦西塔11层，电话(86-400-600-8802) 保修退货前，用户应向BUTTONS或授权服务提供商提供如下信息：

- 1、原始购买收据、包装及附件
- 2、型号、颜色和尺寸
- 3、序列号
- 4、您的联络信息(姓名和电话号码)


本产品必须以运费预付的方式退回。相关的退货会在最终用户的支出下退回其原始地。如果BUTTONS确定最终用户退回的产品不符合本文所述的保修条款，则最终用户还要承担BUTTONS将产品运回给最终用户的费用。

本保修除上述内容之外还有最终用户根据适用法律可能拥有的其他法定权利和补救措施，这是针对产品销售给位于中国大陆以外的最终用户。如要取得此类情况下的任何适用法定权利或相关保修信息或服务，请先联系您购买本产品的经销商或提供本产品的发行商。


包裝內包含以下物件



BUTTONS CLIP PRO
耳夾式耳機 (2隻)



BUTTONS CLIP PRO耳機專屬
便攜式充電艙



產品手冊及保修卡



USB充電線



包裝布袋



耳機帽

注意：如果產品的任何部分缺失或損壞，請勿使用。請訪問BUTTONS官網www.buttonssair.com，瞭解故障排除文章、視頻以及產品維修或更換資訊。或聯絡客服郵箱地址service@buttonssair.com(Global)。

下載BUTTONS APP耳機官方應用程式

TC

1.使用您的智能電話攝像頭掃描下方二維碼下載BUTTONS APP，並按照手機頁面提示完成安裝。



2.通常，用戶也可嘗試從各手機品牌的應用市場搜索該APP，並嘗試按照手機頁面提示完成下載安裝。
注意：為了更好體驗這款APP，您的手機硬件系統需滿足以下要求：

安卓平臺	iOS平臺
操作系統: Android9.0或更新版本; SOC: Qualcomm Snapdragon 660相當或更高性能; RAM: 4GB或更大容量;	操作系統: iOS15或更新版本; SOC: A12或更高性能; RAM: 3GB 或更大容量;

3.安裝後可按照APP軟件的界面提示使用，或可點擊默認頁面(圖A)右上角的 ≡ 按鈕，快速查閱APP使用指南。



4.關於BUTTONS APP功能簡介如果您完成了BUTTONS APP的下載和安裝，並讓手機與BUTTONS CLIP PRO耳機通過藍牙設備列表正確配對後，打開BUTTONS APP會自動綁定耳機。配合該APP您可以查看耳機電量，功能狀態等基礎信息方便您很好地管理耳機設備。


如果您按BUTTONS APP的頁面提示完成新用戶註冊和登錄，您將可以使用APP的更多功能，包括EQ音效選擇、智能AI互動、AI翻譯等更多精彩內容和科技功能等您探索(安裝APP後通過說明按鈕，學習更多功能的使用方法)。

開機&關機


ON

耳機在充電盒中，打開充電盒蓋，耳機自動開機；

注：首次使用時，請移除左右耳機金屬觸點上的絕緣保護膜，以確保正常充電。



①




②


OFF

耳機放入充電盒中，合上充電盒蓋子並開始充電。


請注意，放回充電盒時，保持帶有揚聲器的部分，朝向充電盒左右外側。



①




②



配對連接

TC



打開手機藍牙開關, 在藍牙設置列表中找到
“BUTTONS CLIP PRO” 並點擊連接

系統彈出“授權藍牙配對請求”對話框, 點擊“配對”按鈕, 耳機語音提示“Connected”, 表明耳機連接成功。

藍牙連接斷開時, 耳機語音提示“Disconnected”。
第一次連接成功後, 下一次打開充電盒蓋, 將會自動開始藍牙連接。


充電

為充電盒充電：

正在充電：充電盒LED指示燈呼吸閃爍

充電完成：充電盒LED指示燈常亮

充電故障：充電盒LED指示燈紅色快閃5s後熄滅



為耳機充電

將耳機放入充電盒中，白燈會閃爍一下，表示金屬觸點接觸正常，合上蓋子自動為耳機充電。

耳機低電：語音提示：“Battery Low”

充電狀態：打開充電盒，放入耳機，合上充電盒蓋子，充電盒 LED 指示燈呼吸閃，表示耳機處在充電狀態

充電完成：充電盒 LED 指示燈熄滅


注：上述燈光指示僅適用於單獨為充電盒充電時使用；當打開充電盒蓋，如LED指示燈顯示綠色，則表明充電盒電量低，需要對設備進行充電。當打開充電盒蓋，如LED指示燈亮紅色，則表明充電盒電量將耗盡，請馬上對設備充電。

請使用正規5V-1A充電器為本機充電，超出規格充電器會造成設備損壞。

- 需要充電
- 電量耗盡
- 充電故障
- ◐ 正在充電
- 充電完成
- 指示燈熄滅

按鍵及指示燈說明

TC



電量

 <3s



配對模式

 ≥3s



恢復出廠設置

 ≥8s

電量顯示

-  >40%
-  15% - 40%
-  5% - 15%

充電顯示

-  正在充電
-  充電完成
-  充電故障



-  白燈常亮
-  白燈閃爍
-  綠燈常亮

-  紅燈常亮
-  紅燈閃爍
-  指示燈熄滅

正確佩戴耳機

本產品為開放式耳機，無需塞入耳道。耳機不區分左右，可根據佩戴情況自動識別。請根據右圖所示瞭解產品區域名稱。


揚聲器在前，耳後夾在後，輕掰開C橋，將耳機夾在耳朵上。
可上下調整耳機至舒適位置，完成佩戴。



BUTTONS CLIP PRO耳帽安裝示意


① 識別方向

A1右上（圓點朝上）
A2左下、A3右下




② 對齊并套入

把A3對準音筒上方，再將A2向下包住耳機，輕輕旋轉按入。




③ 調整貼合

確保耳套都貼合牢固、不鬆動。



④ 安裝完成

如需拆卸，輕輕掀起，再向外取下耳帽。



注意：
·安裝時請避免用力拉扯，以免損壞耳帽。請確認耳帽已完全貼合，避免影響佩戴穩定性與聲音效果。
·如耳帽沾有污漬，請用清水輕輕沖洗并自然晾乾后再使用。

佩戴檢測和休眠模式

佩戴檢測

音樂播放過程中，取下一隻或兩隻耳機同時取下後，音樂自動暫停，耳機再次放入耳中後，音樂自動恢復播放。

手機通話過程中，取下兩隻耳機後，自動切換成耳機聽筒。佩戴任意一隻或兩隻耳機後，自動切回耳機端。



注：當檢測到耳機未佩戴時，耳機將不支持敲擊操作。

雙擊或三連擊操作時，建議您使用食指指尖敲擊面蓋，首次使用時您需要一些練習以熟練操作，敲擊力度過大 / 過小及速度過快 / 過慢都可能導致耳機敲擊操作無法成功觸發。

休眠模式：

進入休眠：耳機如出現無法與藍牙設備配對、或從耳中取下不用、再或脫離藍牙範圍等情況超過一定時間，則自動進入休眠模式；

退出休眠：將耳機放回充電盒，開合蓋一次，再次取出，耳機退出休眠模式。



耳機操作



音樂



通話



語音



語音指令



語音喚醒

HALI

呼喚

"HALI HALI"

X2：連擊兩次 X3：連擊三次

安全指南

輸入Input: DC 5V=500mA

輸出Output: DC 5V=280mA

藍牙工作頻率&發射功率: 2402MHz-2480MHz, < 11dBm

聲明: 內有安全資訊說明

聲明: 內含鋰離子電池。電池必須妥善回收或處理。

警告: 為避免聽力損傷，請勿長時間以高音量收聽。

警告: 設備內含有磁鐵

警告: 窒息危險，本產品含有小零件。

警告: 帶有此符號表示不得將本產品作為生活垃圾丟棄，應將其運送到適當的收集設施進行回收。正確的處置和回收利用有助於保護自然資源、人類健康和環境。有關本產品的處置和回收等更多資訊，請與您當地的有關部門聯繫或與您購買此產品的零售商聯繫。



內含物:

BUTTONS CLIP PRO耳機x2 BUTTONS CLIP PRO耳機便攜充電盒x1

USB Type-A到Type-C充電線x1 產品手冊x1 收納袋x1 耳帽x4

安全說明:

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前述合法通信，指依電信管理法規定作業之無線電通信。

低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

Made for

iPhone | iPad

清潔注意事項:

本產品部分採用高品質皮革材質，為確保其長久保持良好狀態與美觀，清潔時請務必留意：

嚴禁使用含有酒精、漂白劑等刺激性成分的清潔劑，此類清潔劑可能會對皮革造成褪色、乾裂或材質損傷，影響產品的整體質感與使用壽命。

建議您使用乾淨、柔軟的布料，輕輕擦拭即可有效去除表面灰塵與污漬，使皮革始終光潔如新。

產品名: BUTTONS CLIP PRO

產品類型: 夾耳式真無線藍牙耳機

產品型號: CLIPBTN20

充電電壓/電流: 5V=1A

FCC ID: 2A83I-CLIPBTN20

中國製造

製造商: 北京特潮末加電子科技有限公司

地址: 北京市朝陽區雙橋中路1號院8幢二層2107

操控	觸控
揚聲器	Φ12mm雙磁喇叭
頻響範圍	20-20K Hz
阻抗	160hm
通話Mic	2mic+VPU
射頻通訊範圍	15m
防水等級	IP54
耳機電池	45mAh*2
充電盒電池	480mAh
藍牙版本	5.4
重量	約 6.6g (每隻耳機) / 97.4g (2 隻耳機 + 充電盒)
質保時間	1年

符合電子資訊產品污染控制管理辦法之有害物質或元素標示表

部件名稱 (Name of the Parts)	產品中有有害物質或元素的名稱和含量					
	鉛(Pb)	汞(Hg)	鎘(Cd)	六價鉻(Cr(VI))	多溴聯苯 (PBB)	多溴二苯醚(PBDE)
電路板組件 (PWB assembly)	×	○	○	○	○	○
塑膠部件 (Plastic parts)	○	○	○	○	○	○
金屬部件 (Metallic parts)	○	○	○	○	○	○
皮革部件 (Leather parts)	○	○	○	○	○	○
喇叭部件 (Speaker driver)	○	○	○	○	○	○
內部線材 (Internal wire)	○	○	○	○	○	○
其他部件 (Others)	○	○	○	○	○	○

本表格依SJ/T 11364之規定編製

○：表示該有害物質在該部件所有均質材料中的含量均在GB/T 26572規定的限量要求以下。

×

表示該有害物質至少在該部件的某一均質材料中的含量超出GB/T 26572規定的限量要求；

表中標有“X”的所有部件都符合歐盟RoHS指令。



220-J11976

保修說明

BUTTONS 有限保修

重要聲明：通過使用您的 BUTTONS 耳機（簡稱“產品”），您同意接受本 BUTTONS 有限保修條款（簡稱“保修”）的約束。如果您不同意此份保修條款，請不要使用該產品，並在 BUTTONS 的退貨政策中所規定的退貨期限內將其退還。

誰會受到本保修的保障？

只有在最終用戶所在地區或國家由 BUTTONS 授權經銷商處購買本產品的最終用戶（稱“最終用戶”）才有資格享受本有限保修。

有限保修：

根據本保修的條款及條件，BUTTONS 提供一 (1) 年的保修期，從最終用戶最初零售購買之日起一 (1) 年（簡稱“保修期”），該產品是在正常和慣常的消費者使用條件下，以及任何 BUTTONS 書面指南、規定或說明（包括如環境和存儲要求）下，無設計、材料和工藝之重大缺陷的情況下運行。任何不合格品會以表格和 BUTTONS 合理要求的輔助信息報告 BUTTONS，使其能够驗證、診斷和修正不合格品。

保修條件及除外責任：

只有在下述情況下，本保修才有效：(i) 將 BUTTONS 授權經銷商向原始最終用戶開出的原始收據，上注有購買日期和序列號，連同本產品一起提交以進行修理或更換；(ii) 本產品表面上的密封籤或序列號均未被篡改、移除或污損；以及 (iii) 本產品未被最終用戶或使用者或任何其他人以任何方式修改、變更、破壞、濫用或疏忽。

本保修不適用於 (a) 消耗性零件，如隨時間推移而耗損的電池設計，除非由於材料或工藝上的缺陷而引起的故障；(b) 外觀損壞，包括但不限於刮痕、凹痕及端口塑料損壞，以及由於設備正常老化而導致的正常磨損或斷裂；以及 (c) 將本產品與 BUTTONS 未提供或推薦的任何第三方設備或產品一起使用。

保修說明

TC

如果 BUTTONS 在適當檢查後自行決定認為該產品在保修期內未能符合本保修的要求，BUTTONS 或其授權服務提供商將由 BUTTONS 決定，根據此規定條件修理或更換產品。

對於 BUTTONS 任何有關本產品的保修，本條款規定最終用戶唯一和專門的補救措施，以及 BUTTONS 的唯一責任和專有賠償責任。

如果 BUTTONS 或其授權服務提供商修理或更換本產品（這種修理或更換的產品，簡稱“更換品”），則更換品应在原保修期的剩餘時間，或从修理或更換之日起的九十（90）天享有保修，以較長者為準。修理或更換可能涉及到使用功能相同之舊的、或先前安裝或翻修的部件或零件。被更換的零件或部件會變成 BUTTONS 的財產。

所有保修退貨必須郵遞到公司指定售後地址（地址：中國北京市朝陽區新源南路 8 號啟皓大廈西塔 11 層，電話 86-400-600-8802）。

保修退貨前，用戶應向 BUTTONS 或授權服務提供商提供如下訊息：

- 1、原始購買收據、包裝及附件
- 2、型號、顏色和尺寸
- 3、序列號
- 4、您的聯繫方式（姓名和電話號碼）

本產品必須以運費預付的方式退回。相關的退貨會在最終用戶的支出下退回其原始地。如果 BUTTONS 確定最終用戶退回的產品不符合本文所述的保修條款，則最終用戶還要承擔 BUTTONS 將產品運回給最終用戶的費用。

本保修除上述內容之外還有最終用戶根據適用法律可能擁有的其他法定權利和補救措施，這是針對產品銷售給位於中國大陸以外的最終用戶。如要取得此類情況下的任何適用法定權利或相關保修信息或服務，請先聯繫您購買本產品的經銷商或提供本產品的發行商。