




产品说明书



K1683P2双协议固态硬盘

前言

感谢您购买MAIWO（麦沃）产品，为了您能够更好的使用本产品，请您在正式使用本产品前，仔细阅读使用本手册所提及的操作要点及注意事项。

MAIWO（麦沃）为深圳市凯祥源科技有限公司注册商标。

声明事项

深圳市凯祥源科技有限公司只对产品本身存在的问题负有保修和维修责任，对于用户操作所引起的数据资料删改或丢失，不负任何责任，也不对因此造成的其它间接损失负责。鉴于数据资料的价值不可估量，正式操作本产品之前，重要资料请自行备份。


注意事项

如果您使用的是新的硬盘，需要将硬盘初始化并格式化后才能正常出盘。具体参考新硬盘初始化、分区与格式化教程。

产品参数

产品名称：

MAIWO K1683P2固态硬盘




产品名称	MAIWO K1683P2固态硬盘
支持硬盘	30/42/60/80MM, M-key, B&M-key M.2
盘位	单盘位
内部接口	M.2 SATA协议或NVMe协议均支持
传输接口	USB3.1, Type-C
材质	铝合金+塑胶
功能	数据传输
产品尺寸	141x31.5x9.5 MM
操作系统	Windows/Mac OS/Linux, 带OTG功能安卓系统
指示灯	通电蓝色灯长亮，硬盘读写数据闪烁

①

操作指南

一、产品安装：

- 1.1. 硬盘侧面（有USB3.1接口处）取出硬盘PCBA板。
- 1.2. 然后把硅胶塞塞入硬盘对应孔位。
- 1.3. 再将NGFF(M.2)SSD或M.2 NVMe协议固态硬盘倾斜45°插入PCBA板NGFF(M.2)接口，调整硅胶塞固定硬盘。
- 1.4. 装上铝壳和塑胶盖，螺丝锁定。




②

操作指南

二、产品安装：

2.1. 将安装好的固态硬盘（可选择USB3.1或Type-C口），连接电脑端。




注：如果是旧硬盘，那么在“计算机”里可以发现新增的硬盘，并可以正常读写。如果是新硬盘，需要先进行初始化、分区和格式化后，才能使用。

③

操作指南

三、新存储卡初始化流程：

3.1. 新硬盘初始化：鼠标右键点击“计算机”，查看“管理-磁盘管理”发现新磁盘，将其初始化；




注：新硬盘初始化有MBR和GPT两种格式选择，如果您的硬盘小于或等于2T，请选择MBR格式，大于2T请选择GPT格式。

④

操作指南

四、存储卡分区流程：

4.1. 分区格式化：新硬盘初始化后将会变成“磁盘1”，用鼠标右键点击“磁盘1”，然后点击“新建简单卷”进行分区，根据提示操作，可选择所需要分区的大小，并勾选格式化选项，可以依次建立多个分区，直到完成。



⑤

关于保修

- A、本产品执行国家三包政策：如有质量问题，7天包退，15天包换，1年保修。起始时间以客户收到产品的日期起计算。
- B、电源线、USB线等配件不在保修范围内，如损坏有微更换。
- C、天灾造成损坏不在保修范围内，可以提供有偿维修服务。
- D、消费者使用不当，造成产品故障，可以提供有偿维修服务。


如果您在操作过程中遇到问题，请拨打我们的客服热线4000-666-205，我们的技术人员将为您提供技术支持。

保 修 卡			
产品品牌	MAIWO	型 号	K1683P2
购买日期		保修期限	
用户姓名		联系电话	
客户地址			
技术支持		4000-666-205	
客服热线			
销 售 商			
厂家地址			

⑥



User Manual




K1683P2 MAIWO M.2 SSD Enclosure

Feature

Description:

MAIWO K1683P2 M.2 SSD Enclosure




Model:	K1683P2
Name:	Dual head USB M.2 SATA SSD Enclosure
Interface:	USB-A/USB-C to M.2
Support SSD type:	M-key, B&M-key M.2
Support SSD size:	2230, 2242, 2260, 2280
Rating:	5V via USB
USB speed:	10Gbps up to
Material:	Aluminum alloy+plastic
Dimension:	141x31.5x9.5 MM
Compatibility:	Windows/Mac OS/Linux


Quick Installation Guide

1. Installation:

- 1.1. Pull the PCBA board out of the aluminum case from USB-A port.
- 1.2. Put the silicone gel into the corresponding hole on the PCBA board (according to the SSD length).



- 1.3. Obliquely insert the M.2 SSD to the M.2 slot, adjust the silicone gel to fasten the SSD.
- 1.4. Slide the PCBA back into the case, put the plastic cover on, fix it by 2 screws.




①

Quick Installation Guide

1. Installation:

- 1.5. Connect USB cable with housing and PC.




Remark: for partitioned SSD, it will be recognized as "New Volume" after connect with USB cable, it can be read and write directly; for new SSD, you must do initialization and partition before recognize after connect with PC.

②

Quick Installation Guide

2. New hard disk format:

- 2.1. View "computer - Manage - disk management" to find the new disk.




③

Quick Installation Guide

2. New hard disk format:

- 2.2. Right click the "Disk 1", then click "New Simple Volume".




④

Quick Installation Guide

3. Hard disk partition:

- 3.1. According to the instruction, choose the size of partition, then click "Next" to finish.




⑤

Quick Installation Guide

3. Hard disk partition:

- 3.2. Then you can find the new hard disk in the "Computer", it's ready to be use.



⑥