


骨传导蓝牙耳机



使用指南及保修说明
Operating instructions and Wananty description

示意图



产品清单

- 1: 耳机 x1 2: 充电线 x1 3: 说明书(含保修卡) x1

使用说明

蓝牙配对
首次使用，耳机正常开机后，会进入蓝牙配对状态，此时手机蓝牙设置里可搜索到“X13”，点击连接成功后指示灯灭灯，播放音乐，蓝灯会5秒闪烁一次。

更换配对设备及回连
断开当前配对设备蓝牙，耳机指示灯红蓝交替闪烁，其他设备即可搜索到“X13”，点击连接“X13”骨传导耳机支持自动回连配对设备，正常开机后会自动回连最后一次连接的设备，请确保前端（如手机蓝牙）正常开启。

充电
正常蓝牙连接状态下，手机会显示耳机电量，如电量显示红色，即表示需要充电，插入充电线充电即可。2小时左右即可充满。充电状态下指示灯为红灯常亮，充满电则蓝灯常亮。

注意 请使用输出5V1A及以内的充电器。

! 本产品的可充电电池必须妥善处理后，以便回收利用。请不要将电池放入火中，以免引起爆炸。

开关机

功能	操作	指示灯
开机	长按“”3秒	蓝灯亮1秒
关机	长按“”5秒	红灯亮1秒

操作说明

功能	耳机状态	操作
增加音量	播放音乐	单击“+”
减少音量		单击“-”
下一曲		长按“+”1秒
上一曲		长按“-”1秒
暂停播放		暂停播放
恢复播放	单击“⏻”	
接听电话	来电时	
挂断电话		长按“⏻”1秒
拒接电话		
音量控制	通话中	单击“+”/“-”

指示灯说明

搜索配对	红灯灯交替闪烁
正在充电	红灯常亮
充满电量	蓝灯常亮
蓝牙音乐播放	蓝灯5秒闪一次

AI智能语音控制

(手机需支持语音唤醒功能)

功能	耳机状态	操作
语音控制	蓝牙已连接	双击“”

说明：在蓝牙连接状态中，双击“”，听到提示音后，就可以语音操控手机，节约操作手机的时间，快捷又智能。
例如您可以直接操控耳机问：
现在几点钟.....今天天气.....
导航去深圳世界之窗.....打电话给某某.....
打开网易云音乐.....播放刘德华的冰雪.....下一曲.....音量降低.....
打开美团.....打开喜马拉雅.....打开微信.....播放戏曲.....

智能运动，轻松好玩

故障及排除

无法开机
确定耳机是否充满电量，按键是否误操作，同时充电激活。
无法蓝牙连接
耳机指示灯是否处于红蓝交替闪烁阶段，如耳机处于蓝灯呼吸状，表示耳机与其他设备已经连接，需要断开当前连接设备。

无法回连
确定前端（如手机蓝牙）是否正常开启。

耳机音量较小
手机是否需加大音量，需要手机增加或减小音量。确认佩戴方式是否正确。

产品参数

型号：X3Pro	版本：6.0
重量：24g	充电：≈2h
通话：-42dB	播放：≈6h&60%音量
距离：蓝牙10米	输入：5V/150mA
容量：200mAh	防水：IPX5
协议：A2DP, AVRCP, HFP	

注意事项

- 保养与清洁：**
- 耳机不能泡水，不然耳机会短路烧坏。
 - 如何长时间不使用，请至少一个月充满一次电。
 - 请不要私自拆装产品上任何部件，如发现产品有缺陷请立即停止使用，并联系销售方售后处理。
 - 每次运动后将耳机擦拭干净，特别是充电口位置，要及时处理干净，防止汗水，盐水腐蚀充电口，影响产品寿命。
 - 产品远离火源、热源、冷冻源、化学品、严禁暴力撞击拆装挤压产品。
 - 请使用输出5V1A及以内的充电器。



产品保修卡

该卡为产品保修凭证，请妥善保管

产品名称：	产品型号：
购买日期：	客户名称：
联系方式：	

产品维修记录


日期	不良现象	方案

Bone conduction Bluetooth headphones



Instructions for usage and warranty
Operating instructions and Warranty description

Schematic diagram



Parts list

- 1: Headphone x1 2: Charging cable x1 3: Instruction manual x1

Instruction

Bluetooth Paring
When used for the first time, after the headset is turned on normally, it will enter the Bluetooth pairing state. At this time, "X13" can be searched in the Bluetooth settings of the mobile phone. After clicking the connection button, the indicator light will turn off, and the music will start playing. The blue light will flash once every 5 second.

Change paired devices and reconnect
Disconnect the Bluetooth of the currently paired device, the headset indicator light flashes red and blue alternately, other devices can search for "X13", Click connect . For connected devices, please ensure that the front end (such as mobile phone Bluetooth) is turned on normally.

Charging
Normal connection, the phone will display the earphone battery, such as the battery display red, that is, the meter show the need to charge, plug in the charging line to charge. about 2 hours to fill, charging status indicator is red light, full charge often blue light .

Note Please use a USB power adapter with an output of 5V less than 1A.

! The rechargeable battery of this product must be properly disposed of for recycling. Please do not place the battery in a fire to avoid explosion.

Power On/Off

Function	Operation	Indicator light
Power On	Press ‘’ for 3s	The blue light on for 1s
Power Off	Press ‘’ for 5s	The red light on for 1s

Operating instruction

Function	Earphone status	Operation
Increase volume	Play music	Click '  '
Reduce volume		Click '  '
Next song		Press '  ' for 1s
Previous song		Press '  ' for 1s
Pause		Click '  '
Resume	Pause	
Answer the call		Phone calls in
Hang up		
Decline the call		
Volume control	Calling	Click '  ' / '  '

Indicator

Search for a match	Red and blue lights flash alternately
Charging	Normally on red light
Finished charging	Normally on blue light
Bluetooth music player	Blue light flashes once every 5 sec.

AI intelligent voice control

(Phone needs to support voice wake-up function)

Function	Earphone status	Operation
Voice control	Bluetooth is connected	Double click ‘’

Note: In the Bluetooth connection status, Double click ‘’ . After hearing the prompt, you can voice control the phone, saving time to operate the phone, fast and smart.
For example: You can directly control the earphone and ask:
What time is it now.....Today's weather.....
Navigate to Taipei 101.....Call someone

Smart exercise, easy and full of fun

Troubleshooting

Unable to boot
Determine whether the headset is fully charged, whether the button is misoperated, and then charge and activate.

Unable to connect to Bluetooth
Whether the headphone indicator is in the alternately flashing stage of red and blue, such as the headphone is in the breathing state of blue light, Indicates that the headset has been connected to other devices and needs to disconnect the current connected device.

Can't back to even
Make sure the front end (e.g., Bluetooth) is open properly.

Headphone volume is low
Whether the phone increases the volume, the phone needs to increase or decrease the volume. Wearing a way Whether it is right.

Product parameter

Model: X3Pro	Version: 6.0
weight: 24g	Battery: 200mAh
Input: 5V/150mA	Charging time: ≈2h
Call parameters: -42dB	
Waterproof grade: IPX5	
Distance: Bluetooth 10 meter	
Operating time : ≈6h@60% Volume	
Profile: A2DP, AVRCP, HFP	

Care and cleaning

- The product cannot be soaked in water, otherwise it will short-circuit and burn out.
- If not used for a long time, please fully charge it at least once a month.
- Do not disassemble any part of the product without permission. If you find that the earphone is defective, please stop using it.
- Keep the product away from fire, heat, freezing, and chemicals. Do not immerse the earphone in water, and do not wipe it with chemicals such as aromatherapy water.
- Store in a cool, dry place. Do not expose the product to direct sunlight for a long time.
- Please use a USB power adapter with an output of 5V less than 1A.



Product warranty card

This card is a product warranty certificate, please keep it properly

Product name:	Product model:
Purchase date:	Clients name:
Contact:	

Product maintenance records

Date	Bad phenomenon	Solution



70mm

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.