



2X

stronger suction

User Guide

INTRODUCTION & FEATURES

The ionvac Power Max is here to help you keep your home and car mess-free! This handheld, cordless vacuum cleaner boasts a powerful suction that picks up dust, debris, and dirt from the smallest crevices on any surface. It includes a crevice nozzle specifically designed to help you clean all those hard-to-reach corners, as well as an upholstery nozzle to vacuum your sofa and other sensitive surfaces. Lightweight and compact, battery-powered, and featuring USB-C charging for maximum convenience, the ionvac Power Max is designed to make cleaning a breeze!


FEATURES

- Powered by a powerful rechargeable battery.
- Storage tray for easy organization.
- Lightweight and ultraportable, perfect for cleaning your home and car.
- A crevice nozzle with an attached dust brush, to clean all those hard-to-reach corners.
- An upholstery nozzle for your sofa and sensitive surfaces.

PACKAGE CONTENTS

ionvac Power Max
Storage tray
USB-C charging cable
Crevice nozzle with a dust brush
Upholstery nozzle
User guide

ionvac Power Max CORDLESS VACUUM



HOW TO CHARGE THE BATTERY

1. Plug one end of the USB-C cable into the vacuum and the other end into a USB power source.
2. The indicator lights will flash while charging and turn solid when finished.
3. When the vacuum has finished charging, disconnect the USB-C cable.

NOTE: It is normal for the ionvac's battery casing to heat up while charging. To retain the full capacity of the ionvac's rechargeable battery, be sure to fully charge it every two to three months if not in use.

HOW TO USE THE VACUUM CLEANER

Make sure the vacuum cleaner is fully charged before use.

1. Press the POWER button to turn the vacuum ON.
2. Press the POWER button a second time to switch to HIGH mode.
3. Press the POWER button again to turn the vacuum OFF.

ATTACHING AND REMOVING NOZZLES

- To attach a nozzle, insert it into the suction opening.
- To remove a nozzle, simply pull it out of the suction opening.
- Use the crevice nozzle to reach all corners and angles that cannot be reached with the suction opening.
- The upholstery nozzle is suitable for use on sensitive surfaces.

CLEANING DIRECTIONS

A. To Clean the Attachment nozzles

1. Remove any hairs or threads from the brush and wipe it with a slightly damp cloth.

B. To Clean the Dust collector

1. Make sure the vacuum cleaner is OFF and disconnected from the power source.
2. Hold the vacuum cleaner with the dustbin over a garbage can.
3. Press the dustbin release button and remove the suction inlet.
4. To clean, wipe the dust collector using a damp cloth.

C. To Clean the filter

1. Press the dustbin removal button.
2. Remove the dustbin.
3. Pull out the filter.
4. Clear the dust from the dustbin and wipe with a damp cloth.
5. Reinsert filter into the dustbin and reconnect dustbin to the vacuum.

NOTE: Filter should be replaced every 3 months.

SPECIFICATIONS

Input	5V/2A
Power	75W
Battery	2800mAh
Suction power	5kPa
Charging time	3-4 hours
Usage time	Up to 30 minutes
Dustbin Capacity	Approx. 150ml
Size	16.1 x 2.6 x 2.7 inches
Weight	0.95 lbs.

Never vacuum up the following:

- Glowing ash, cigarette butts, matchsticks, etc.
- Toxic substances (acid, asbestos, etc.).
- Water or any other liquids.
- Sharp objects (e.g. glass, nails, etc.)
- Plaster, cement, dust from drilling, construction waste, makeup, etc.

SAFETY INSTRUCTIONS

Please read the safety instructions carefully before using this product. Keep this manual for future reference.

- This product is not intended for cleaning large areas or for extended use.
- The product is intended for domestic use only and not for commercial purposes.
- This product is not a toy. It is not intended for use by children under 12 years of age.
- Do not immerse the vacuum or its charging cable in water or other liquids.
- Do not touch with wet hands.
- Do not insert objects into the suction opening of the vacuum.
- The vacuum cleaner should only be used when fully assembled and with the filter inserted.
- Never use the vacuum cleaner on humans or pets. Keep hair and items of clothing such as shoelaces and scarves away from the suction opening.

CUSTOMER SUPPORT

If you have any other questions or issues with using the ionvac Power Max, please contact Technical Support at support@tzumi.com or 1-855-GO-TZUMI.



ionvac Power Max. Distributed by tzumi Inc. NY, NY, 10016 ©Copyright 2022 tzumi Inc. All Rights Reserved. Made in China. All other trademarks and trade names are the property of their respective owners. All pictures shown are for illustration purposes only. The actual product may vary due to product enhancement. Subject to change without prior notice.