


2.4G遥控越野车使用说明

1. 认识你的遥控器



2. 遥控器安装电池及对频



遥控器对频说明：
打开遥控器电源开关，此时指示灯闪烁，打开遥控车电源开关，遥控器指示灯常亮，遥控车与遥控器对频完成。

遥控器使用2x1.5V "AA" 电池（电池不包含）

4. 使用遥控器行驶




1. 前进/后退
将左控制杆向上推/向后拉，遥控车前进/后退。



2. 左转/右转
将右控制杆向左推/向右推，遥控车左转/右转。



3. 音乐
按下遥控器音乐按键，遥控车开始播放音乐，再次按下切换音乐。




4. 自动演示
按下遥控器自动演示按键，遥控车开始自动演示。




5. 灯光开关
按下遥控器灯光开关按键，控制遥控车灯光开启/闪烁/常亮/关闭。

*请在操作前仔细阅读说明书并妥善保管以便日后参考。

3. 遥控车电池安装说明



遥控车（内含电池）



注意：
长时间不用请把电池取出

USB充电使用事项


1. 电池组第一次使用必须先充好电，以确保电量充足，如长期不使用则会自动放电，如充电过度则会缩短电池寿命。
2. 使用者应定期检查电线、插头、外壳及相关部件，若发生损坏必须停止使用，直至修复完好。
3. 玩具不能连接到不受推荐使用的电源上，充电条件：将USB智能充电线接上原厂电池。
4. 建议使用合适的适配器进行充电，不能使用快速充电器进行充电。
5. 请使用正确适配器进行充电，输入：100-240V~50/60Hz 0.2A；输出：5.0V --- 500mA 0.5-1.5A。
6. 充电说明：充电电池接上智能USB充电线，智能USB充电线可通过接入带有USB插口的电源介质，对电池进行充电，如：台式电脑、笔记本电脑、移动电源、USB电源插座或通过USB转接插头接入电源充电。
7. 长时间不使用遥控车，请将遥控车电池与遥控器电池取出。
8. 充电时，USB指示灯灯光常亮，充电完成后指示灯灯光熄灭。

2.4G Remote Control Off-Road Car User Manual

1. Know your remote control




2. Installing batteries and pairing the controller




Pairing Instructions:
Turn on the remote control. At this time, the light will flash. Turn on the RC car. The remote light will stay on, indicating that the pairing is complete.

The remote uses 2x1.5V "AA" batteries (batteries not included)

4. Driving with the remote control



1. Forward/Backward
Push the left joystick up/pull it back to move the car forward/backward.



2. Turn left/Turn right
Push the right joystick to the left/right to make the RC car turn left/right.



3. Music
Press the music button on the remote to play music. Press it again to switch to the next song.




4. Auto demo
Press the auto demo button on the remote to start the auto demo.




5. Light switch
Press the light switch button on the remote to control the lights of the RC car to turn on/flash/stay on/turn off.

*Please read the manual carefully before operation and keep it for future reference.

3. The Installation of the RC car battery



RC car (battery included)



Note:
Remove the battery if you do not use it for a long time.

Attention for Charging via USB

1. Battery should be fully charged for the first time using. The battery will still self-discharge when not in use. If not in use for a long time, please ensure that the battery has about half of the power to prevent over discharge damage. Overcharging can shorten battery life.
2. Please regularly check the cord, plug, casing and other accessories and stop using before being repaired if any damages are found.
3. Do not connect the toys with the power that is not recommended. Charging conditions: Connect the USB smart charging cable with the original battery.
4. Please use appropriate adapter instead of fast charger for charging.
5. Please use the right adapter for charging. Input: 100-240V~50/60Hz 0.2A; output: 5.0V --- 500mA 0.5-1.5A.
6. Charging notes: To charge the battery, please connect the battery with smart USB charging cable, which has access to power media with USB interface, such as: desktop, laptop, mobile power, USB socket. Alternatively, you can use a USB adapter to connect with the power for charging.
7. Please remove the battery for the remote control truck and the remote controller if they are not expected to use for a long period of time.
8. When charging, the USB light is steady on. When fully charged, the light goes off.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.