


**PHILIPS**

***NORELCO***

Shaver

i9000

Prestige Ultra





## **Initial setup**

**6**

Configuración inicial



## **Important to know**

**8**

Aspectos importantes a saber



## **Charging your shaver**

**9**

Cargar su afeitadora

## **Shaving modes**

**10**

Selección de modos

## **Light guidance**

**14**

Guía de luz



## **Dry shaving**

**18**

Afeitado seco



## **Wet shaving**

**19**

Afeitado húmedo



## **Head shaving**

**20**

Cabezal de afeitado



## **Changing click-on attachments**

**21**

Cambiar los accesorios de ajuste de clic



## **Precision trimmer**

**22**

Cortadora de precisión



## 5+1 Precision Beard Styler

23

Recortadora de barba con precisión 5+1



## Nose and ear trimmer

25

Cortador de vello de nariz y oreja



## Deep Clean 3-in-1 Face Massager

26

Masajeador facial 3 en 1 de limpieza profunda



## Body Groomer

28

Rasuradora corporal



## Trimming body hair (3mm)

29

Recorte de vello corporal (3 mm)



## Shaving body hair

30

Afeitado de vello corpo



## Thorough cleaning

32

Limpieza a fondo



## Installing Cleaning cartridge

34

Instalar el cartucho de limpieza



## **How to clean with cleaning station** **35**

Cómo limpiar con la estación de limpieza



## **Cleaning cartridge replacement** **36**

Reemplazar el cartucho de limpieza



## **Blade replacement (SH91)** **37**


Reemplazar la cuchilla (SH91)



## **Replacing the Body Groomer cutting unit** **38**

Reemplazo de la unidad de corte de la rasuradora corporal





# Accessories included

Accesorios incluidos



|           | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
|-----------|---|---|---|---|---|---|---|---|---|----|----|
| XP9400/89 |   | ✓ |   |   |   |   | ✓ |   |   |    |    |
| XP9401/83 | ✓ |   | ✓ |   |   |   |   |   | ✓ |    |    |
| XP9401/92 |   | ✓ |   |   |   |   | ✓ |   |   |    | ✓  |
| XP9402/86 |   |   |   |   |   |   |   |   | ✓ | ✓  | ✓  |
| XP9403/88 |   |   | ✓ | ✓ |   |   |   |   | ✓ | ✓  | ✓  |
| XP9405/84 |   | ✓ |   |   |   |   |   |   | ✓ | ✓  |    |
| XP9405/99 | ✓ |   | ✓ |   |   |   | ✓ |   |   | ✓  |    |
| XP9406/93 |   | ✓ |   |   | ✓ |   | ✓ | ✓ |   |    | ✓  |
| XP9407/94 |   | ✓ |   | ✓ | ✓ |   |   | ✓ | ✓ | ✓  | ✓  |



GET STARTED

Cómo empezar




[www.philips.com/MyShaveri9000PrestigeUltra](http://www.philips.com/MyShaveri9000PrestigeUltra)



Initial setup



Configuración inicial





## Important to know





Aspectos importantes a saber





# Charging your shaver

Cargar su afeitadora



## Shaving modes

During your shave you can select your preferred shaving mode. Each mode has its own characteristics.

|                                                                                                |                                                                         |
|------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|
| <br>Sensitive | For a shave that is softer on the skin.                                 |
| <br>Regular   | A great all-rounder for daily shaving.                                  |
| <br>Intense   | Higher power for heavy beards.                                          |
| <br>Foam     | Optimized for shaving with foam or gel.                                 |
| <br>Custom  | Shave your way with customized settings. (Only configurable in the app) |



## Modos de afeitado

Mientras se afeita, puede elegir su modo de afeitado preferido. Cada modo tiene sus propias características.

|                                                                                                |                                                                                               |
|------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|
| <br>Sensitive | Para un afeitado más gentil con su piel.                                                      |
| <br>Regular   | Ideal para el afeitado diario.                                                                |
| <br>Intense   | Mayor potencia para barbas gruesas.                                                           |
| <br>Foam     | Optimizado para afeitarse con espuma o gel.                                                   |
| <br>Custom  | Aféitese a su manera con configuraciones personalizadas. (Solo configurable en la aplicación) |



## Selecting modes

You can toggle between modes by pressing the mode button when the shaver is switched on. Your last selected mode will be stored for your next shave.



## Selección de modos

Cuando la afeitadora está encendida, puede cambiar el modo presionando el botón de modo. El último modo seleccionado se guardará para su próximo afeitado.



## Light guidance

The light ring on your shaver can assist you in improving your shaving performance.

The light ring at the top of your shaver can provide you:

### *Pressure feedback*

Providing guidance in applying the right amount of pressure



Too little pressure



Perfect pressure



Too much pressure

### *Motion feedback*

Providing guidance in making the right rotational motions.



## Guía de luz

El anillo de luz en su afeitadora puede ayudarlo a mejorar su rendimiento al afeitarse.

El anillo de luz en la parte superior de su afeitadora puede proporcionarle:

### *Retroalimentación de presión*

Le ofrece orientación para aplicar la cantidad correcta de presión



Muy poca presión



Presión ideal



Demasiada presión

### *Retroalimentación de movimiento*

Le ofrece orientación para realizar los movimientos de rotación correctos.



## Combined feedback

Providing guidance both applying the right pressure and making the right rotational motions.



Wrong motions:  
Purple light ring



Too much  
pressure: Orange  
light ring

## *Retroalimentación combinada*

Le ofrece orientación tanto para aplicar la cantidad de presión ideal como para realizar los movimientos de rotación correctos.



Movimientos incorrectos:  
Anillo de luz púrpura








Demasiada presión: Anillo de luz naranja



# Dry shaving



Afeitado seco





## Wet shaving







Afeitado húmedo





# Head shaving


Cabezal de afeitado





## Changing click-on attachments





Cambiar los accesorios de ajuste de clic





# Precision trimmer







Cortadora de precisión





# 5+1 Precision Beard Styler

Recortadora de barba con precisión 5+1












# Nose and ear trimmer








Cortador de vello de nariz y oreja






# Deep Clean 3-in-1 Face Massager

Masajeador facial 3 en 1 de limpieza profunda









# Body Groomer

Rasuradora corporal






[www.philips.com/support](http://www.philips.com/support)



## Trimming body hair (3mm)




Recorte de vello corporal (3 mm)









## Shaving body hair

Afeitado de vello corporal







# Thorough cleaning

Limpeza a fundo



Deep  
clean



1



2



3



4



5





6



7












## Installing cleaning cartridge


Instalar el cartucho de limpieza





## How to clean with cleaning station









Cómo limpiar con la estación de limpieza





# Cleaning cartridge replacement

Reemplazar el cartucho de limpieza





## Blade replacement (SH91)

Reemplazar la cuchilla (SH91)



1



2



3



4



5



6




SH93

7



8






## Replacing the Body Groomer cutting unit

Reemplazo de la unidad de corte de la rasuradora corporal



1



2




3



TT2000

4








Manufactured for:  
Philips Personal Health  
a division of Philips North America LLC  
P.O. Box 10313, Stamford, CT 06904



This symbol on the product's nameplate  
means it is listed by  
Underwriters' Laboratories, Inc.

3000.129.4700.6



Introduction

Congratulations on your purchase and welcome to Philips Norelco!

To fully benefit from the support that Philips Norelco offers, register your product at: **www.norelco.com/register**.

The full model number (e.g. XX0000/00) is located on the bottom of the packaging, your receipt or order confirmation.

IMPORTANT SAFETY INSTRUCTIONS

When using an electric product, basic precautions should always be followed, including the following:

**Read all instructions before using this product.**

DANGER

To reduce the risk of electric shock:

- To charge the product, only use a USB power source on a certified product with output rating 5 V, ≥ 1 A. For safe charging in a moist environment (e.g. in a bathroom), only use an IPX4 (splash-proof) power source. A suitable power source (e.g. Philips HQ87) is available via [www.philips.com/support](http://www.philips.com/support). If you need support finding the correct USB power source, contact Philips support at 1-800-243-3050. Using a non-certified USB power source may cause hazards or serious injuries.
- Keep the USB cable, the USB power source and the charging stand dry (Fig. 1).
- Do not reach for a corded product that has fallen into water. Unplug immediately from the power outlet.
- Do not place or store the product or charging stand where it can fall or be pulled into a tub or sink. Do not place or drop the product or charging stand into water or other liquid.
- This product is waterproof (Fig. 2). It is suitable for use in the bath or shower and for cleaning under the tap. For safety reasons, the product can therefore only be used without cord.
- This product does not work while it is connected to the power outlet. Except when charging, always unplug this product from the power outlet.
- Remove USB power source from power outlet and product before cleaning.

WARNING

To reduce the risk of burns, fire, electric shock, or injury to persons:

- This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety. Children should be supervised to ensure that they do not play with the product.
- Use this product only for its intended household use as described in this manual. Misuse can lead to hazards or serious injuries. Do not use attachments not recommended by Philips North America LLC. Accessories supplied may vary for different products.
- This product is only intended for shaving facial hair and scalp hair. Scalp hair must be shorter than 1.5 mm.
- Do not use the product on damaged skin or skin affected by disease or severe skin irritation without consulting your doctor.
- Do not use brush attachments if you take steroid-based medication.
- Some skin irritation is normal during initial use, but decreases as your skin gets used to hair removal.
- Never operate this product if it has a damaged USB power source, if it is not

- working properly, after it has been dropped or damaged, or after the product or the USB power source has been dropped into water. For assistance call 1-800-243-3050.
- Keep the USB cable and the USB power source away from heated surfaces.
- Never drop or insert any object into any opening.
- Do not use the USB power source in or near a power outlet that contains an electric air freshener to prevent damage to the USB power source.
- Do not charge or plug in product or charging stand outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Always check shaving heads (guards and cutters) before using the product. Do not use the product if cutters or guards are damaged, as injury may occur.
- Always attach the USB cable to the USB power source and the product or charging stand first, then attach the USB power source to the power outlet. To disconnect, set all controls to 'off' position. Then remove the USB power source from the power outlet.
- Plug USB power source directly into power outlet. Do not use an extension cord.
- Unplug USB power source before plugging in or unplugging the product.
- Be careful when handling your smartphone near water and in moist environments.
- The radio waves of Bluetooth-enabled products may impair the operation of pacemakers and other medical devices. Consult your physician for advice and keep the product at least 8 inches (20 cm) away.
- The batteries used in this product may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 100 °C (212 °F) or incinerate.
- Only use original Philips accessories or consumables.
- Charge, use and store the product at a temperature between 50 °F / 10 °C and 95 °F / 35 °C.
- Keep product and batteries away from fire and do not expose them to direct sunlight or high temperatures.
- If the product becomes abnormally hot or smelly, changes color or if charging takes longer than usual, stop using and charging the product and contact Philips.
- Do not place products and their batteries in microwave ovens or on induction cookers.
- Do not open, modify, pierce, damage or dismantle the product or battery to prevent batteries from heating up or releasing toxic or hazardous substances. Do not short-circuit, overcharge or reverse charge batteries.
- If batteries are damaged or leaking, avoid contact with the skin or eyes. If this occurs, immediately rinse well with water and seek medical care.
- When you handle batteries, make sure that your hands, the product and the batteries are dry.
- To avoid accidental short-circuiting of batteries after removal, do not let battery terminals come into contact with metal objects (e.g. coins, hairpins, rings). Do not wrap batteries in aluminum foil. Tape battery terminals or put batteries in a plastic bag before you discard them.

Philips Norelco Quick Clean Pod Cartridge fluid

- Do not take internally.
- Avoid contact with the eyes. In case of eye contact, thoroughly flush with cold water. If irritation persists, get medical attention.
- Keep out of reach of children.



- The frequency band in which the appliance operates is 2.4 GHz.
- This appliance is equipped with Bluetooth class 2.
- The maximum radio frequency power radiated in the frequency band in which the appliance operates is less than 20 dBm

- This device complies with the FCC RF exposure limits and has been evaluated in compliance with portable exposure condition.
- Changes or modifications not expressly approved by Philips could void the users' authority to operate the equipment.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.

SAVE THESE INSTRUCTIONS.

Accessories

Replacement parts and accessories may be purchased at a store near you or on our website [www.philips.com/store](http://www.philips.com/store).

The following accessories and spare parts are available:

- SH91 Philips Norelco replacement shaving heads
- CC12 Philips Norelco Quick Clean Pod Cartridge 2-pack

Assistance

For assistance, visit our website: **www.philips.com/support** or call toll free 1-800-243-3050.

Disposal

- This product contains a rechargeable lithium-ion battery which must be disposed of properly.
- Contact your local town or city officials for battery disposal information. You can also call 1-800-822-8837 or visit: **www.call2recycle.org** for battery drop-off locations (Fig. 3).
- For assistance, visit our website **www.philips.com/support** or call 1-800-243-3050 toll free.
- Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. For recycling information, please contact your local waste management facilities or visit: **www.recycle.philips.com**.

Full Two-Year Warranty

Philips North America LLC warrants this new product (except shaving heads) against defects in materials or workmanship for a period of two years from the date of purchase, and agrees to repair or replace any defective product without charge.

**IMPORTANT:** This warranty does not cover damage resulting from accident, misuse or abuse, lack of reasonable care, the affixing of any attachment not provided with the product or loss of parts or subjecting the product to any but the specified voltage or batteries.\*

**NO RESPONSIBILITY IS ASSUMED FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

In order to obtain warranty service, simply go to **www.philips.com/support**. It is suggested that for your protection you return shipments of product by insured mail, insurance prepaid. Damage occurring during shipment is not covered by this warranty.







Manufactured for:  
Philips Personal Health  
a division of Philips North America LLC  
P.O. Box 10313, Stamford, CT 06904

**LISTED**  
This symbol on the product's nameplate means it is listed by Underwriters' Laboratories, Inc.

© 2025 Philips North America LLC.  
All rights reserved.  
3000.144.4778.3 (04/29/2025)



NOTE: No other warranty, written or oral, is authorized by Philips North America LLC.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion and limitations may not apply to you.

\*Read enclosed instructions carefully.

45-DAY MONEY-BACK GUARANTEE

If you are not fully satisfied with your product send the product back and we'll refund you the full purchase price.

**The product must be shipped prepaid by insured mail, insurance prepaid, have the original sales receipt, indicating purchase price and date of purchase.**

**We cannot be responsible for lost mail.**

**The product must be postmarked no later than 45 days after the date of purchase. Philips reserves the right to verify the purchase price of the product and limit refunds not to exceed suggested retail price.**

**To obtain the money-back guarantee service, please go to www.PhilipsMoneyBack.com and follow the simple 3-step process.**

Delivery of refund check will occur 6–8 weeks after receipt of returned product.

Trademarks

Apple, the Apple logo, iPad, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android is a trademark of Google Inc. Google Play and the Google Play logo are trademarks of Google Inc.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Koninklijke Philips N.V. is under license.

