

Kinglucky

QUICK START GUIDE

X50 Sleep Speaker



Please read the instructions before use.

Package Contents



Speaker




Charging Cable



User Manual

Product Diagram



Basic Operations

-  **Power On:** Press and hold the Power Button for 2 seconds.
Power Off: Press and hold the Power Button for 5 seconds. The indicator flashes blue three times.

Switch Mode

-  Press the Power Button twice to switch between **Bluetooth mode** and **Sleep mode**.
 In Bluetooth mode, the device can connect to external devices for playback. In Sleep mode, you can select built-in sounds.

Music Controls

-  **Play / Pause:** Press the Power Button once.
 **Volume Down:** Press the Left Button once.
 **Volume Up:** Press the Right Button once.
 **Previous Track:** Press the Left Button twice.
 **Next Track:** Press the Right Button twice.


Hands-free Calls

-  **Answer / End Call:** Press the Power Button once.
Reject Call: Press and hold the Power Button for 2 seconds.

Timer Settings

-  **Set Timer:** Press and hold the Timer Button for 2 seconds to cycle through 30, 60, and 90 minutes. Press the Timer Button again after 90 minutes is selected to turn off the timer; the indicator will turn off.

Bluetooth Pairing



- Fully charge the speaker before first use.
- Press and hold the Power button for 2 seconds to turn on the speaker.
- The speaker enters Bluetooth mode by default after turning on.
(If it is in another mode, Press the Power Button twice to switch to Bluetooth mode.)
- Turn on Bluetooth on your phone.
- Select "X50" from the device list to connect.
- You will hear a prompt tone when the connection is successful.

Charging LED Indicator Status

- Charging: Red light flashes
- Fully charged: Blue light stays on
- Low battery: Red light flashes once every 5 seconds

Troubleshooting

Problem	Solution
Cannot turn on	Fully charge the speaker, then press and hold the Power button for 2 seconds.
No sound	Make sure the speaker is on. Press the Power button once to check if the audio is paused. Increase both phone and speaker volume.
Bluetooth cannot connect	Make sure the speaker is in Bluetooth mode. Restart Bluetooth on your phone, select "X50", or remove "X50" and pair again.
Cannot find sleep sounds	Press the Power Button twice to switch to Sleep mode.
Battery life is shorter than expected	Please fully charge before use. Battery life may vary depending on volume, mode, and battery condition. High volume may shorten playback time.
Speaker turns off automatically	Check if the timer is on. The speaker turns off after the selected timer ends.
Sound is too low/unclear	Thick or soft pillows may affect sound. Increase both phone and speaker volume, or move the speaker closer to your ear.
Sound is too loud or your partner can hear it	Lower the volume or place the speaker closer to your ear and farther from your partner's side.